

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta cuptor 950W 230V 550x63mm #415378

Fara TVA: 415,97 Lei

Pret cu TVA: 495,00Lei

Rezistenta cuptor 950W 230V 550x63mm #415378

Putere: 950W

Tensiune: 230V

Lungime: 550mm

Latime: 63mm

Lungime flansa: 90mm

Latime flansa: 25mm

Diametru tub: 8,5mm

Lungime conexiune: 64mm

Circuite de incalzire: 1

Diametru gauri: 6mm

Conexiune: faston tata 6.3mm

Montare: flansa rectangulara

Aplicatie: rezistenta racire in aer

Compatibil cu:

LF 3355508

ASCASO

ALPENINOX

ELECTROLUX PROFESSIONAL

WHIRLPOOL - INDESIT

ZANUSSI

Potrivit pentru:

ZANUSSI Kitchen electric HC/E400 (200003), HC/E800 (200004), HCF/E800 (200005), HC/E410 (200040), HC/E810 (200041), HCF/E810 (200042), ZC/E400 (210003), ZC/E800 (210004), ZCF/E800 (210005), ZC/E410 (210040), ZC/E810 (210041), ZCF/E810 (210042), AC/E400 (220003), AC/E800 (220004), ACF/E800 (220005), OCF/E800 (220062), ECF/E800 (230005)

ZANUSSI Kitchen gas HCF/GE810 (200036), ZCF/GE810 (210036), ACF/GE810 (220036), ECF/G-E810 (230036)

ZANUSSI Neutral counter HFS/E800 (205002), ZFS/E800 (215002), AFS/E800 (225002)

ZANUSSI Pot stove electric HC/E400 (230003), HC/E800 (230004)

Electrolux gas range + electric oven 200036 301-07122003

Electrolux gas range + electric oven 210036 301-31012005

Electrolux gas range + electric oven 220036 301-01032004



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Electrolux gas range + electric oven 230036 527-

Electrolux range 200003 301-07122003

Electrolux range 200004 301-07122003

Electrolux range 200005 301-07122003

Electrolux range 200040 301-07122003

Electrolux range 200041 301-07122003

Electrolux range 200042 301-07122003

Electrolux range 210003 301-31012005

Electrolux range 210004 301-31012005

Electrolux range 210005 301-31012005

Electrolux range 210040

Electrolux range 210041

Electrolux range 210042

Electrolux range 220003 301-07122003

Electrolux range 220004 301-07122003

Electrolux range 220005 301-07122003

Electrolux range 220062 510-13031998

Electrolux range 230003 9109-527

Electrolux range 230004 9109-527

Electrolux range 230005 9109-309

Electrolux base oven 205002 301-07122003

Electrolux base oven 215002 301-20122004

Electrolux base oven 225002 301-20072003

