



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Regulator energie 230V 13A EGO 50.55021.100 #380027

Fara TVA: 84,03 Lei

Pret cu TVA: 100,00Lei

Regulator energie 230V 13A EGO 50.55021.100 #380027

Tensiune: 230V

Capacitate de comutare: 13A

Directie de rotatie: dreapta

Lungime ax: 23mm

Diametru ax: Ø6x4.6mm

Activitate: circuit dublu

Compatibil cu:

LF 3350035

ALPENINOX

AMICA WRONKY

ANGELO PO

ARDO

ARISTON

BEKO

BOMPANI

BRANDT

COOKMAX

DE DIETRICH

EBERHARDT

ELECTROLUX

ELECTROLUX PROFESSIONAL

GICO

GIGA

GORENJE

HAKA

HOTPOINT

ILVE

KÜPPERSBUSCH

MODULAR

PALUX

RIEBER

SMEG



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

TECNOINOX

UNIVERSAL PARTS

VESTEL

WHIRLPOOL - INDESIT

ZANUSSI

EGO 5055021100

EPMS 155294

EPMS 705001

EPMS 705006

EPMS 705017

EPMS BO317571

Potrivit pentru:

ANGELO PO Fry top 0G0PEVTR

ANGELO PO Glass-ceramic plate electric 190VTR

ANGELO PO Kitchen glass-ceramics 0N0VTR, 1N0VTR

ANGELO PO Pasta cooker 0N1CP1GH, 1N1CP2GH

ANGELO PO Pot stove glass-ceramics 04WVT3RV, 090VTR, 1G0PEVTR, 6042520, 6042530, 6043590, 6VTR2

ARISTON Convection oven FC97P.1-E AN (T), FC97P.1-E IX (T), FC98P.1 IX, FD77P IX, FD960P.2-E BK (T), FD960P.2-E WH (T), 28368 (FD97P CH), 28370 (FD97P GC), 28369 (FD97P SL), 28352 (FD98P.1 ICE), 28353 (FD98P.1 MR), FO97P.1-E AN (T), FO97P.1-E IX (T), FO97P.1-E WH (T), FO98P.1 IX, FO98P.1 IX DIGITAL, H10.1IX, H101.1IX, H60.1(ALU), H60.1IX, H60VP.1IX, H60VP.1IX-Y, H61.1(BK), H61.1(WH), H61.1IX, H622.1IX, H62C.1IX, H66.1IX, H66V.1IX, H87V.1(ALU), H87V.1IX, H87VP.1(ALU), H87VP.1IX, H89V.1IX, H89VP.1IX, 26976 (HB20AC(WH)), 26977 (HB22AC(IX)), 26978 (HB22AC(WH)), 29829 (HB22AC.1(WH)), 29123 (HB22AC.1IX), 26507 (HB50ER(ALU)), 26506 (HB50ER(IX)), 29126 (HB50ER.2(ALU)), 29127 (HB50ER.2IX), 26987 (HB52AC(BK)), 26986 (HB52AC(WH)), 29121 (HB52AC.1(BK)), 29122 (HB52AC.1(WH)), 26985 (HB52C(IX)), 29120 (HB52C.2IX), 26996 (HB56C(BK)), 26994 (HB56C(IX)), 26995 (HB56C(WH)), 29119 (HB56C.2IX), 29118 (HB86C.2IX), 27438 (HB86CIX), 22224 (HD50(BK)), 24020 (HD50(ICE)), 22225 (HD50(MR)), 24021 (HD50IX), 28394 (HD870C(ICE)), 28395 (HD870C(MR)), 28396 (HD870C(SL)), 29104 (HD870C.2(ICE)), 29105 (HD870C.2(MR)), 29106 (HD870C.2(SL)), 18194 (HD87C(BK)), 22226 (HD87C(MR)), 18191 (HD87C(WH)), 18194 (HD87C(WH)), 13552 (HM27M), 13553 (HM27M), 05479 (HM27V), 05480 (HM27V), 05481 (HM27V), 22222 (HM55R(BK)), 22221 (HM55R(WH)), 22223 (HM55R(IX)), 16567 (HM87V), 16568 (HM87V), 16569 (HM87V), 26509 (HO10(ALU)), 26510 (HO10(BM)), 26508 (HO10(IX)), 29115 (HO10.2IX), 26512 (HO50(ALU)), 26513 (HO50(BM)), 26511 (HO50(IX)), 29111 (HO50.2(ALU)), 29112 (HO50.2(BM)), 29113 (HO50.2IX), HO50.2TIX, 26997 (HO87EC(IX)), HO87EC.2-EIX, HO87EC.2IX, 26515 (HO87EF(ALU)), 26516 (HO87EF(BM)), 26514 (HO87EF(IX)), 29108 (HO87EF.1(ALU)), 29109 (HO87EF.1(BM)), HO87EF.1-E(ALU), HO87EF.1-E(BM), HO87EF.1-EIX, HO87EF.1IX, HO87EF.2-ETDIX, HO97P.1-E IX (T), HO97P.1-EIX, HR10.1IX, HR50.2IX, HR50.2TIX, HR86T.1IX, HR87.1IX, HR87.1TIX, HR87P.1IX

ARISTON Kitchen glass-ceramics C3V10M.3(W)F, C3V10MW-F, C3V8P(W)U, C3V8P(X)U, C3V8P.2(W)U,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

C3V8P.2(X)U, 26051 (C3V9P(W)U), C3V9P.2(W)U, C3VM6(W)F, C3VM6(X)F, C6V9P(W)U, C6V9P.3(W)U, C6V9PW-SK230, C6V9PW-SK400, C6V9PX-SK230, C6V9PX-SK400, C6VP1(W)SK230, C6VP1(X)SK230, CE6VP5(W)GR, CE6VP5(X)GR

ARISTON Pot stove gas 29500 (PH723RQOGH), PH723RQOGHAUS, PH741RQOGH, PH741RQOGHAUS, PH741RQOGHCN, PH741RQOGHU

ARISTON Pot stove glass-ceramics KBM6002DHCL, KBM6004 IX, KBM6011DH IX, KBM6014D IX, KBT6003I BI, KBT6003I IX, KBT6004I BI, KBT6004I IX, KBT6011DH IX, KBT6013T BI, KBT6013T IX, KBT6013T-C IX, KBT6114ID BI, KBT6114ID IX, KBT6114ID-C IX, KBT6412I BI, KBT6412I IX, KBT6412I-C IX, KBT8134DO IX, KOT7424IO BI

BRANDT Kitchen glass-ceramics K2551-1 (K2551), KNA84W1N1 (KNA84W1N), KNA85W1N1 (KNA85W1N), KNW95W1N1 (KNW95W1N), KV268WE11 (KV268WE1), KV269WE11 (KV269WE1), KV373WE11 (KV373WE1), KV373XE11 (KV373XE1), KV374WE11 (KV374WE1), KV374WE12 (KV374WE1), KV374XE11 (KV374XE1), KV374XE12 (KV374XE1), KV571WN11 (KV571WN1), KV571WN12 (KV571WN1), KV571XN11 (KV571XN1), KV571XN12 (KV571XN1), KV600WN11 (KV600WN1), KVE255-1 (KVE255), KVE255-2 (KVE255), KVP3000-1 (KVP3000), KVP3000-2 (KVP3000), KVP3000B-1 (KVP3000B)

BRANDT Kitchen induction 920012014 (4CF-400VX)

DE DIETRICH Pot stove induction 7DT0905 (DTV304BE1), DTV304BE12 (DTV304BE1), 7DT0946 (DTV703B), 7DT0949 (DTV703W), 7DT0948 (DTV703X)

GIGA Kitchen glass-ceramics SK4VFCE

GIGA Pot stove glass-ceramics SKCV40E, SKCV80E

HOTPOINT Electric oven electric HH831ERJIX-HA

HOTPOINT Kitchen glass-ceramics C3BM6(W)F-HA, C3BM6(X)F-HA, C3VM5(W)UA-HA, CE6VP5(W)GR-HA, CE6VP5(X)GR-HA, CE6VP5XGRHAS, H5VMH6AXPL, H6V9CA1WFR, H6VMC6A.B(X)FR, H6VMH6A.BXGR

HOTPOINT Pot stove gas PH741RQOGH-HA

HOTPOINT Pot stove glass-ceramics 7HKRM641DXRUHA, 7HKRM641DXRU-HA, CEM645DX, CRM641DC, CRM641DX, E6011, E6011X, E6014, E6014X, KBM6014DIX-HA, KRM641DX

KÜPPERSBUSCH Kitchen glass-ceramics LEH500, LEH503, LEH505, LEH700, LEH703, LEH705, SEH300, TEH300

RIEBER Pot stove electric VARITHEK CK 3,4

SMEG Electric oven S104X-5, S106X-5, S106X-6, S108X-5, S108X-6, SC041MFX, SC0468X-8, SC0485X-8, SC04MFX, SC0578X-8, SC061MFX, SC061X-8, SC06MFX, SC081MFX, SC081X-8, SC08MFX, SC63MFX, SC64MFX, SC73MFX, SC74MFX, SE108EB-1, SE108NE-1, SE108X-1, SE108X-5, SE286X, SE286X-5, SE62MFX-5, SE63MFX-5, SE72MFX-5, SE73MFX-5

SMEG Kitchen electric A1C, A1C.1, A1CA, A1CA.1, CBE66MF, CE66MFA, CE66MFA1, CE66MFX, CE66MFX1, CE6CMX, CE92CMX, CE9CMX, CE9CMXA, CIE66MDK3, CIE66MF, SUK60CMFA, SUK60CMFX, UK60CMFA, UK60CMFA1, UK60CMFX, UK60CMFX1

SMEG Pot stove PDX12RUSB

SMEG Pot stove electric P652, P752, P764AO, P764PO, P775AO, P775PO, P864A, P864A-9, P864P, P864P-9, P875A, P875P, PDX30B, PDX30C, SA661X1, SE641X, SE661X, SE661X1

TECNOINOX Kitchen electric PFC70E0, PFC70E60, PFC70E7, PFC70V7, PFC8E7, PFC8E9, PFC8V7, PFC8VE9

TECNOINOX Pot stove electric PCC35E0, PCC35E1, PCC35E60, PCC35E61, PCC35E7, PCC4E7, PCC4E9,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

PCC4FE7, PCC4FE9, PCC70E0, PCC70E60, PCC70E7, PCC8E7, PCC8E9, PCC8FE7, PCC8FE9, PCCM8FE7, PCCM8FE9

WHIRLPOOL - INDESIT Convection oven EHM304CN, 24040 (HGM10K(IX)), F024040 (HGM10K(IX)), F030157 (HGM300K.C(BR)), F030156 (HGM300K.C(WH)), F030155 (HGM300K.CIX), F030162 (HGM30K.C(BR)), F030161 (HGM30K.C(WH)), F030160 (HGM30K.CIX), 12762 (HGMVEDEL), F012762 (HGMVEDEL), F068272 (HI50EK.AIX), F036797 (HI50EK.B(WH)), F036798 (HI50EK.BIX), F058894 (HI53EK.BIXGR), F036799 (HI56EK.BIX), F038108 (HI56EK.BIXGR), F081390 (HIM 20K.A(BK)-2), F074485 (HIM506EK.AIX), F078293 (HIM506EK.AIX-2), F074486 (HIM506EK.AWH), F078298 (HIM506EK.AWH2), F078287 (HIM50EK.AIX2), F074487 (HIM531EK.AIX), F078301 (HIM531EK.AIX-2), F074488 (HIM537EKAIX), F060836 (IH51K.AIX), F078304 (IH51K.AIX2), F060837 (IH63K.AIX)

WHIRLPOOL - INDESIT Electric oven 853524501020 (AKG245AVWP), 853524501030 (AKG245WHWP), 853542901000 (AKG429/IX), 853543222010 (AKG432/01/IX), 853543222030 (AKG432/03/IX), 853543222000 (AKG432/IX), 857746901500 (AKP469IX), 857746901501 (AKP469IX), 857746901502 (AKP469IX), 857746901503 (AKP469IX), 857746901504 (AKP469IX), 857746922000 (AKP469IX)

WHIRLPOOL - INDESIT

Kitchen gas 857637032020 (ACM3702N), 857639832000 (ACM398N), 851236601000 AGB366WP), 851236701000 (AGB367WP), 851250301000 (AGB503WP), 851258801000 (AGB588WP), AXMT6532IX

WHIRLPOOL - INDESIT Kitchen glass-ceramics ACMT5531IX, ACMT5531WH, F088232 (I5VM6HAWBG), F084285 (I6VMH2ABXGR), F060903 (K6C7(IX)-SK), F057876 (K6C7(W)-NO), F033973 (K6C7(W)-SK), F033974 (K6C7(X)-SK), F073925 (KN3C76A(W)BG), F081172 (KN3C76AWBGS), F073913 (KN6C72A(X)-GR), F081167 (KN6C72AXGRS)

WHIRLPOOL - INDESIT

Pot stove 857746619000 (AKP466), 857746622000 (AKP466AV), 857746622020 AKP466NB), 857746619000 (AKP466WH)

WHIRLPOOL - INDESIT Pot stove glass-ceramics F074068 (VRM641MDC), F074067 (VRM641MDIX)

ZANUSSI Fry top KT/E1 (200226), KT/E2 (200227), QT/E1 (210226), WT/E1 (220226), WT/E2 (220227)

ZANUSSI Kitchen A9IREH400N (393170), A9IRED200N (393214)

ZANUSSI Kitchen electric MIF/E700 (161062), MIF/E700D (161070), MIF/E710 (161074), MIF/E710D (161077), RIF/E2 (168152), RIV/E2 (168153), XIF/E2 (168552), XIV/E2 (168553), JIF/E2 (168752), JIV/E2 (168753), MIF/E2 (168952), MIV/E2 (168953), XMIF/E710 (174042), CIF/E710 (174102), PIF/E2 (178025), PIV/E2 (178026), PIF/E2E5 (178033), OIF/E2 (178325), TIF/E2E5 (178633), Z7IREH40E0 (372026)

ZANUSSI Pot stove electric MI/E350 (161060), MI/E700 (161061), MI/E350D (161068), MI/E700D (161069), MI/E360 (161072), MI/E710 (161073), MI/E360D (161075), MI/E710D (161076), RI/E1 (168150), RI/E2 (168151), XI/E1 (168550), XI/E2 (168551), JI/E1 (168750), JI/E2 (168751), MI/E1 (168950), MI/E2 (168951), XMI/E360 (174040), XMI/E710 (174041), CI/E710 (174101), PI/E1 (178023), PI/E2 (178024), PI/E1E5 (178031), PI/E2E5 (178032), OI/E1 (178323), OI/E2 (178324), TI/E1 (178623), TI/E2 (178624), TIF/E2 (178625), TIV/E2 (178626), TI/E1E5 (178631), TI/E2E5 (178632), HI/E400 (200038), HI/E800 (200039), KI/E1 (200119), KI/E2 (200120), KI/E2E5 (200125), ZI/E400 (210038), ZI/E800 (210039), QI/E1 (210119), QI/E2 (210120), QI/E2E5 (210125), QT/E2 (210227), AI/E400 (220038), AI/E800 (220039), WI/E1 (220119), WI/E2 (220120), WI/E2E5 (220125), E7IRED2000 (371024), E7IREH4000 (371025), E7IREH40E0 (371026), E7IRED200N (371133), E7IREH400N

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(371134), Z7IRED2000 (372024), Z7IREH4000 (372025), Z7IRED200N (372133), Z7IREH400N (372134),  
A7IRED2000 (373024), A7IREH4000 (373025), A7IRED200N (373133), A7IREH400N (373134), E9IRED2000  
(391044), E9IREH4000 (391045), E9IREH400N (391170), Z9IRED2000 (392044), Z9IREH4000 (392045),  
Z9IREH400N (392170), A9IRED2000 (393044), A9IREH4000 (393045)  
ZANUSSI Pot stove gas HI/G400 (200047), HI/G800 (200048), HI/G400N (200056), HI/G800N (200057)

