

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta 6000W 230V ø 47,5mm 370x32x36mm #415068

Fara TVA: 208,12 Lei

Pret cu TVA: 247,66Lei

Rezistenta 6000W 230V ø 47,5mm 370x32x36mm #415068

power 6000W

voltage 230V

mounting diameter 47,5mm

heating circuits 3

length 370mm

width 32mm

height 36mm

diameter thermostat sleeves 7mm

length thermostat sleeves 165mm

position thermostat sleeve eccentric, non clinging

tube diameter 8,5mm

hole distance 62mm

hole diameter 8mm

connection male faston 6.3mm

mounting 3 hole flange

application immersion heater

Compatibil :

Electrolux, Zanussi

Electrolux dishwasher 503000 9110-04022002

Electrolux dishwasher 503001 9110-04072005

Electrolux dishwasher 503002 9110-04022002

Electrolux dishwasher 503003 9110-04022002

Electrolux dishwasher 503004 9110-04072005

Electrolux dishwasher 503005 9110-

Electrolux dishwasher 503006 9110-04022002

Electrolux dishwasher 503008 445-04022002

Electrolux dishwasher 503009 9110-04022002

Electrolux dishwasher 503010 244-04072005

Electrolux dishwasher 503011 244-19032001

Electrolux dishwasher 503012 445-04072005

Electrolux dishwasher 503015 527-19032001

Electrolux dishwasher 503016 527-29012001



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Electrolux dishwasher 503017 527-29012001
Electrolux dishwasher 504000 242-942
Electrolux dishwasher 504001 242-942
Electrolux dishwasher 504002 242-942
Electrolux dishwasher 504003 242-942
Electrolux dishwasher 504005 242-942
Electrolux dishwasher 504006 242-942
Electrolux dishwasher 504007 242-942
Electrolux dishwasher 504008 242-942
Electrolux dishwasher 504009 242-942
Electrolux dishwasher 504010 242-942
Electrolux dishwasher 504014 509-942
Electrolux dishwasher 504015 509-942
Electrolux dishwasher 504016 711-22101999
Electrolux dishwasher 504017 711-31032000
Electrolux dishwasher 504028 242-942
Electrolux dishwasher 504029 242-942
Electrolux dishwasher 504053 509-942
Electrolux dishwasher 504061 509-942
Electrolux dishwasher 504065 509-942
Electrolux dishwasher 504080 509-942
Electrolux dishwasher 505000 245-11112002
Electrolux dishwasher 505001 245-11112002
Electrolux dishwasher 505002 245-06021998
Electrolux dishwasher 505003 245-04022002
Electrolux dishwasher 505004 245-04022002
Electrolux dishwasher 505005 245-13111997
Electrolux dishwasher 505007 245-11112002
Electrolux dishwasher 505008 245-06021998
Electrolux dishwasher 505009 519-11112002
Electrolux dishwasher 505012 313-19032001
Electrolux dishwasher 505014 313-11112002
Electrolux dishwasher 505015 313-06021998
Electrolux dishwasher 505016 313-19032001
Electrolux dishwasher 505018 545-01032000
Electrolux dishwasher 505020 545-11112002
Electrolux dishwasher 505021 545-11112002
Electrolux dishwasher 505037 545-11112002
Electrolux dishwasher 698015 9110-04072005



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Electrolux dishwasher 698020 242-942
Electrolux dishwasher 698021 242-942
Electrolux dishwasher 698025 245-11112002
Electrolux dishwasher 727015 9110-04022002
Electrolux dishwasher 727020 242-942
Electrolux dishwasher 727021 242-942
Electrolux dishwasher 727025 245-04022002
Electrolux dishwasher 777310 9110-27122000
Electrolux dishwasher 777430 245-27122000

