



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Termostat reglabil 30-110°C EGO 55.13226.030 #375871

Fara TVA: 336,13 Lei

Pret cu TVA: 399,99Lei

Termostat reglabil 30-110°C EGO 55.13226.030 #375871

temperature max. 110°C

operating temperature range 30-110°C

number of poles 1 pole

function 1CO

switching capacity 16A

probe diameter 6mm

probe length 113mm

capillary pipe length 2930mm

capillary pipe length insulated - mm

gland nut M9x1

shaft diameter 6x4.6mm

shaft length 23mm

shaft position upper

rotation angle 270°

height 40mm

width 35mm

depth 30mm

Compatibil :

Alpeninox 0E5032, 0K7035

EGO 5513226030

Electrolux 0E5032, 0K7035

Therma

Viscount 932292-04

Zanussi 0E5032, 0K7035

Electrolux conveyor dishwasher 510116 118-01032004

Electrolux conveyor dishwasher 510117 118-01032004

Electrolux conveyor dishwasher 510118 118-01032004

Electrolux conveyor dishwasher 510119 118-01032004

Electrolux conveyor dishwasher 510300 118-01032004

Electrolux conveyor dishwasher 510301 118-01032004

Electrolux conveyor dishwasher 510302 118-01032004

Electrolux conveyor dishwasher 510303 118-01032004



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Electrolux conveyor dishwasher 510305 118-01032004
Electrolux conveyor dishwasher 510306 118-01032004
Electrolux conveyor dishwasher 510307 118-01032004
Electrolux conveyor dishwasher 510308 118-01032004
Electrolux conveyor dishwasher 510310 118-01032004
Electrolux conveyor dishwasher 510311 118-01032004
Electrolux conveyor dishwasher 510312 118-01032004
Electrolux conveyor dishwasher 510313 118-01032004
Electrolux conveyor dishwasher 510320 118-01032004
Electrolux conveyor dishwasher 510321 118-01032004
Electrolux conveyor dishwasher 510322 118-01032004
Electrolux conveyor dishwasher 510323 118-01032004
Electrolux conveyor dishwasher 510325 118-01032004
Electrolux conveyor dishwasher 510326 118-01032004
Electrolux conveyor dishwasher 510327 118-01032004
Electrolux conveyor dishwasher 510328 118-01032004
Electrolux conveyor dishwasher 510330 118-01032004
Electrolux conveyor dishwasher 510331 118-01032004
Electrolux conveyor dishwasher 510332 118-01032004
Electrolux conveyor dishwasher 510333 118-01032004
Electrolux conveyor dishwasher 511060
Electrolux conveyor dishwasher 511061
Electrolux conveyor dishwasher 511062
Electrolux conveyor dishwasher 511063
Electrolux conveyor dishwasher 511300 118-27022004
Electrolux conveyor dishwasher 511301 118-27022004
Electrolux conveyor dishwasher 511302 118-27022004
Electrolux conveyor dishwasher 511303 118-27022004
Electrolux conveyor dishwasher 511305 118-27022004
Electrolux conveyor dishwasher 511306 118-27022004
Electrolux conveyor dishwasher 511307 118-27022004
Electrolux conveyor dishwasher 511308 118-27022004
Electrolux conveyor dishwasher 511310 118-27022004
Electrolux conveyor dishwasher 511311 118-27022004
Electrolux conveyor dishwasher 511312 118-27022004
Electrolux conveyor dishwasher 511313 118-27022004
Electrolux conveyor dishwasher 511320 118-27022004
Electrolux conveyor dishwasher 511321 118-27022004
Electrolux conveyor dishwasher 511322 118-27022004

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Electrolux conveyor dishwasher 511323 118-27022004

Electrolux conveyor dishwasher 511325 101-27022004

Electrolux conveyor dishwasher 511327 118-27022004

Electrolux conveyor dishwasher 511330 118-27022004

Electrolux conveyor dishwasher 511332 118-27022004

Electrolux conveyor dishwasher 511340 118-27022004

Electrolux conveyor dishwasher 511341 118-27022004

Electrolux conveyor dishwasher 511342 118-27022004

Electrolux conveyor dishwasher 511343 118-27022004

Electrolux conveyor dishwasher 511345 118-27022004

Electrolux conveyor dishwasher 511347 118-27022004

Electrolux conveyor dishwasher 511350 118-27022004

Electrolux conveyor dishwasher 511352 118-27022004

 E-GO