

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Comutator (selector) 0-1 EGO 49.21015.300 #3057027

Fara TVA: 96,64 Lei

Pret cu TVA: 115,00Lei

Comutator (selector) 0-1 EGO 49.21015.300 #3057027

contact capacity 16A 250V - max 150°C

D-shaped pin \varnothing 6x4.6 mm

rear hole for thermostat

Poles: 2

Positions: 2

Use: Normal

Connections: Screw

Contact Capacity (Phase): 10A-380V 15A-250V

Compatibil cu:

5060904057 AMBACH

5060940570 AMBACH

22050400 BERTO'S

300176 BONNET

RTCU900110 COLGED

COOKMAX

537000400 DESCO

RTCU900110 DEXION

214421 EBERHARDT

EGO 4921015300, 49.21015.300

EGO 4921015733, 49.21015.733

RTCU900110 ELETTOBAR

806117 EMMEPI

C00217 EMMEPI

EPMS

Y16200 GIGA

300176 HOBART

RTCU900110 HOBART

483286009351 INDESIT

C00497228 INDESIT

182825 KÜPPERSBUSCH

183232 KÜPPERSBUSCH

MA1037313200 LAINOX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

537000400 LOTUS

1037035700 MARENO

1037313200 MARENO

MA1037035700 MARENO

MA1037313200 MARENO

RTCU900110 MBM

DE0197 MORICE

1037313200 SILKO

0109057 SILKO

0101380 SILKO

300176 THIRODE

483286009351 WHIRLPOOL

C00497228 WHIRLPOOL

AMBACH Bain-marie electric BU-35, BU-70, BUC-35, BUC-70, BUC-70-L, BUC-70-R, BUE-40, BUE-70, EBM-40, EBM-80, EBMC-40, EBMC-80, EBMC-80-I, EBMC-80-L, EBMC-80-R

AMBACH Boiling pan electric BPG-50, EKM-50

AMBACH Bratt pan electric EKB-120, EKB-150, EKH-90, EKM-90, EUB-40, EUB-45, EUB-60, EUB-60-ECO

AMBACH Bratt pan gas GKB-120, GKB-150, TPE-80, TPG-80

AMBACH Kitchen electric EKE-70, EPS-40, EPS-80, EPSE-80, GKE-70, GPSE-80, SIE-105, SIEC-105

AMBACH Oven under cooktop electric EHE-80, ERE-70

AMBACH Pot stove electric CHE-80, EH-80, EK-40, EK-70, ERE-105, EREC-105, GRE-105, GRE-70

AMBACH Pot stove gas GHE-120, GHE-80

BERTO'S Fryer electric E10-10MB6, E10B4

DESCO Fryer electric FRE63, FRE66

DEXION Bain-marie electric LX9EBM4T

DEXION Fryer electric ME046-03-004

DEXION Kitchen electric LX9E4F, LX9E4FQ, ME099-05-010, ME139-05-010, ME139-05-020

DEXION Kitchen gas LX9G4SFE

DEXION Oven under cooktop electric LX9EF09

EMMEPI Kitchen electric 704EF, 704EFN, 704EFVN, 904EF, 906EFB, E704EFN, E704FEN, E706FEB-8, E706FEBN, E706FEB-P35, E706FEB-P37, E706FEB-P38, E904FE, E906EFB, ET72FEN

EMMEPI Kitchen gas E704FE-8, E704FE-P22, E704FE-P23, E704FE-P25, E706FE-8, E706FE-P33, E706FE-P35, E706FE-P37, E706FE-P38, E906FEB, E908FE

EMMEPI Kitchen induction ET7FEN

EMMEPI Pot stove gas E704FE, E706FE, E706FEB

GIGA Bratt pan electric CBRE, CBREIN

GIGA Fryer electric CF1E4, CF2E4, CF2E6, CF4E, CF6E, CFE15, CFE15D, FC1E4, IF1E4, IF2E6, IF4E, IF6E, KFE1, KFE15, KFE15D, KFE2, KFE20, KFE20D, KFE4, KFE8, OPFE1, OPFE15, OPFE15D, OPFE2, OPFE20, OPFE20D, SKF1E, SKF2E, SKF2E4, SKF4E, SKF6E, TF1E, TF2E4, TF4E, TF6E

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

GIGA Fryer gas KFG4, KFG8, TF2E

GIGA Kitchen electric M74FPFXE, M74PFXE, M74PQFXE, M76PFXE

GIGA Kitchen gas M74FFXE, M74FMPFXE, M76FFXE, M76FMPFXE, M76FPFXE

HOBART Bain-marie electric BTESBM

HOBART Convection oven electric BBEO

HOBART Fryer electric HEF472VT, HEF47T, HEF77T

HOBART Kitchen electric BME4QO, BME4RO, BME6QO, BME6RO

HOBART Kitchen gas BMG4BOE, BMG6BOE

KÜPPERSBUSCH Boiling pan electric NED080, NED150, NED250, NED300, NEK040, NEK060, NEK080, NEK100, NEK150, NEM100, NER500, NES040, NES060, NES080, NES100, NES150

KÜPPERSBUSCH Fry top electric NEB630

KÜPPERSBUSCH Fryer electric FEF040, NEF176

LOTUS Bain-marie electric BM-10EM, BM-4EM, BM-6EM, BM-8EM, BS-4EMX

LOTUS Chaffing dish electric BS-4EM

LOTUS Electric oven FORNO S70 GN2-1 ELETTRICO STATICO CARCASSA, FORNO S70 GN3-1 ELETTRICO STATICO CARCASSA, FORNO S90 GN2-1 ELETTRICO STATICO CARCASSA

LOTUS Fryer F25-94G

LOTUS Fryer electric FE-10, FE-2-10, FE-2-8, FE-8, FEC-4, FEM-2-6, FEM-6, FME-10, FME-15, FME-2-10, FME-2-15, FMPE-20, FMPE-25, FMPE-30, FP-6ET, FPE-20, FPE-25, FQ-4EM, FQ-4ET, FQ-6EM, FQ-6ET

LOTUS Fryer gas F18-94G, F2-18-98G, F2-25-98G, F45-78G

LOTUS Pasta cooker electric CP-94ET, CP-94ETX, CP-98ET, CP-98ETX, CPB-98ET

MARENO Bain-marie electric B64E, B66E, OBSEI-40M

MARENO Bratt pan electric BR7-8EF, BR7-8EI, BR9-12EFM, BR9-12EIM, BR9-8EF, BR9-8EFM, BR9-8EI, BR9-8EIM, BR9S-8EF, BR9S-8EI

MARENO Bratt pan gas BR9-12GFM, BR9-12GIM, BR9-8GF, BR9-8GFM, BR9-8GI, BR9-8GIM

MARENO Fry top electric FT12-9ELC, FT12-9EM, FT12C-9EL, FT12C-9ELC, FT12C-9EM, FT12C-9EMC, PM12-9E

MARENO Fryer electric FQE-40, FQE-40D, FQE-40DSP, FQE-60, FQE-60D, FQE-60DSP, NF11C4E10, NF11C9E10, NF74E10T, NF74E10TK, NF74E10TKW, NF74E10TW, NF76E10T, NF76E10TK, NF76E10TKW, NF76E10TW

MARENO Neutral counter warm SDVC15, SDVC15S

MARENO Potato heater SP7-4E

MARENO Potato heater electric BSEI-40M, NSP74E, NSP94E, SP64E, SP9-4E

MARENO Self service counter SDPC08, SDPC12, SDPC12S, SDPC15, SDPC15S, SDVC08, SDVC08S, SDVC12, SDVC12S, SNA12, SNA16, SNA20, SNA708, SNA712, SNA715, SNAC12, SNAC16, SNAC20, SNAC712, SNAC715, SNG08, SNG12, SNG16, SNG20, SPAC12, SPAC16, SPAC20, SPAC712, SPAC715, SPCG08, SPCG12, SPCG16, SPCG20, SPCG708, SPCG712, SPCG715, SVAC16, SVAC20, SVAC712, SVAC715, SVCG08, SVCG12, SVCG16, SVCG20, SVCG708, SVCG712, SVCG715

MARENO Solid top range electric NCT94E, NCT98E, NCT98E2, NCT9FE8E, NCT9FE8E2

MARENO Warm table AR-712PA, AR-712PP, AR-712PS, AR-713PA, AR-713PP, AR-713PS, AR-714PA, AR-714PP, AR-714PS, AR-715PA, AR-715PP, AR-715PS, AR-716PA, AR-716PP, AR-716PS, AR-717PA, AR-717PP, AR-717PS,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

AR-719PA, AR-719PP, AR-719PS, AR-720PA, AR-720PP, AR-720PS

MBM Bain-marie electric EBM408, EBM45, EBM498T, EBM49T, EBM777, EBMA498, EBMA777

MBM Bratt pan electric EBR8, EBRVC98, EBRVI8, EBRVI98, EMT477, EMT777

MBM Fry top electric AQE477, AQE777, ECFT46, ECFT66, EFT90L, EFT90LR, EFT90R, MG7AQE477

MBM Fryer electric EF408, EF46, EF477, EF4772V, EF4772VT, EF477T, EF498, EF777, EF777T, EF908, EF998, EF998T, MG7EF477, MG7EF4772V, MG7EF4772VT, MG7EF477T, MG7EF777T

MBM Fryer gas GF408N, GF411, GF908N, GF911

MBM Kitchen electric E4AR, E4F, E4F9, E4F9Q, E6AR, E6FA, E6FA9, E6FA9Q, E6FAR, E6FM8

MBM Kitchen gas G2SF6, G2SF6G, G4SFE, G4SFE9, G6SFEA, G6SFEA9, G6SFMG8, G8SF2E

MBM Oven under cooktop electric EF09, EFB09, GT2SFERA

MBM Pot stove gas G3SF6, G3SF6G

SILKO Bain-marie electric CME1021, CME1022, CME9020, CME9021, CME9022

SILKO Bain-marie gas ME82GPS

SILKO Boiling pan electric CPE90100, CPE90100A, CPE90150, CPE90150A, PE8AI10, PE8AI15, PE8NI10, PE8NI15

SILKO

Bratt pan electric

SE84CRA, SE84IRA, SE86CRA, SE86IRA, SE94CRM, SE94IRM, SE96CRA, SE96IRA

SILKO Kitchen gas CCG10652, CCG10653, CCG10852, CCG90653-1, CCG90663-1

SILKO Neutral counter warm EAR612PA, EAR612PP, EAR612PS, EAR613PA, EAR613PP, EAR613PS, EAR614PA, EAR614PP, EAR614PS, EAR615PA, EAR615PP, EAR615PS, EAR616PA, EAR616PP, EAR616PS, EAR617PA, EAR617PP, EAR617PS, EAR618PA, EAR618PP, EAR618PS, EAR619PA, EAR619PP, EAR619PS, EAR620PA, EAR620PP, EAR620PS, EAR712PA, EAR712PP, EAR712PS, EAR713PA, EAR713PP, EAR713PS, EAR714PA, EAR714PP, EAR714PS, EAR715PA, EAR715PP, EAR715PS, EAR716PA, EAR716PP, EAR716PS, EAR717PA, EAR717PP, EAR717PS, EAR718PA, EAR718PP, EAR718PS, EAR719PA, EAR719PP, EAR719PS, EAR720PA, EAR720PP, EAR720PS

SILKO Oven under cooktop electric CCG70653, CCG70663

SILKO Oven under cooktop gas CCG90653

SILKO Pot stove gas CCG90663, CTT70653, CTT70653L

WHIRLPOOL Kitchen gas ADN602



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

