

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Motoreductor rotisor universal ax 5x5mm 4W #D240074

Fara TVA: 42,02 Lei

Pret cu TVA: 50,00Lei

Motoreductor rotisor universal ax 5x5mm 4W #D240074

pin cu conexiune pătrată 5x5 mm - 4 Watt

Compatibil cu:

ARISTON C00082359

ARISTON 482000027537

BITRON

CANDY 42807664

EPMS 568001

EPMS 568008

EPMS M082359

44002394 HOOVER

HOTPOINT C00082359

HOTPOINT 482000027537

INDESIT C00082359

INDESIT 482000027537

ROSIERES 42807664

WHIRLPOOL 482000027537

ARISTON Convection oven electric CISFB21.2(WH), CISFB21.2IX, CISFBG(WH), CISFBGIX, CISFRG0(AN), DB62IX MK2, F1012.1IX, F73C.2IXAUS, F76C.2(BK), F76C.2(WH), F76C.2IX, F97C.2(BK), F97C.2(WH), F97C.2IX, F99C.1IX, F99C.1IXAUS, 26973 (FB20AC(WH)), 25505 (FB21(BK)), 25504 (FB21(WH)), 29082 (FB21.2BK), 29083 (FB21.2IX), 29084 (FB21.2WH), 25502 (FB21A(BK)), 26634 (FB21A(BR)), 25501 (FB21A(WH)), 29085 (FB21A.2(BK)), 29086 (FB21A.2(IX)), 29019 (FB21A.2(WH)), FB21A.2IXAG, 25503 (FB21AIX), 25506 (FB21IX), 26974 (FB22AC(IX)), 26975 (FB22AC(WH)), 29610 (FB22AC.1(WH)), 29072 (FB22AC.1IX), 26214 (FB26(BK)), 26155 (FB26(WH)), 29080 (FB26.2(BK)), 29081 (FB26.2(WH)), 26154 (FB26C(BK)), 26164 (FB26C(WH)), 29070 (FB26C.2(BK)), 29071 (FB26C.2(WH)), 27435 (FB61CIXAG), 25967 (FB86P BK), 25966 (FB86P IX), 25968 (FB86P WH), 30075 (FB970C.2(BK)), 30074 (FB970C.2(WH)), FB970C.2-E(BK), FB970C.2-E(WH), FB970C.2-EIX, 30076 (FB970C.2IX), 26215 (FB97C(BK)), 26158 (FB97C(IX)), 26159 (FB97C(WH)), 29062 (FB97C.2(BK)), 29063 (FB97C.2(IX)), 29064 (FB97C.2(WH)), FB97C.2-E(BK), FB97C.2-E(WH), FB97C.2-EIX, FB99C.1IX, FBCF04(BK), FBCF04(WH), 25508 (FBG(BK)), 25509 (FBG(IX)), 25507 (FBG(WH)), FC101P.1IX, 27425 (FC62CIXAG), 25971 (FC97 P (AN)), 25972 (FC97 P (IX)), FC97P.1-E(AN), FC97P.1-EIX, 26363 (FC98P IX), 28351 (FC98P.1IX), 31280 (FC98P.1IX), FCF05(BK), FCF05(WH), FD771P BK, 24616 (FD771P ICE), 24615 (FD771P MR), 21954 (FD771P WH), 24617 (FD771PIX), 25839 (FD772PBK), 25840 (FD772PWH), 24619 (FD781P ICE), 24618 (FD781P MR), 21955 (FD781PBK), 21956 (FD781PWH), FD960P.2-E(BK), FD960P.2-E(WH), FD961P.1-E(BK), FD961P.1-E(WH),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

FD961P1E(BK), FD96P.2-E(BK), FD96P.2-E(WH), 29090 (FD97C.1(BK)), 29091 (FD97C.1(ICE)), 29092 (FD97C.1(WH)), FD97C.1-E(BK), FD97C.1-E(ICE), FD97C.1-E(WH), 28046 (FD97CBK), 28045 (FD97CICE), 28047 (FD97CWH), FD97P.1-E(ICE), FD97P.2-E(AZ), FD97P.2-E(CH), FD97P.2-E(GC), FD97P.2-E(MR), FD97P.2-E(SL), 31270 (FD98P.1(ICE)), FD98P.1(MR), FD99C.1(BK), FD99C.1(ICE), FD99C.1(WH), FD99P.1(BK), FD99P.1(WH), FH1039PIX, FH103IX, FH52(WH), FH52IX, FH939IX, FH99IX, FHG(BK), FHG(WH), FHGIX, FHGIXAG, FHSBGIX, 26157 (FO97C(ALU)), 26165 (FO97C(AN)), F026216 (FO97C(IX)), 26217 (FO97C(WH)), 29045 (FO97C.1(ALU)), FO97C.1-EIX, 29046 (FO97C.1IX), FO97CIX-AG, 25969 (FO97P (AN)), FO97P (IX), FO97P.1-E(AN), FO97P.1-E(WH), FO97P.1-EIX, 26362 (FO98P IX), 28349 (FO98P.1IX), 31261 (FO98P.1IX), 31262 (FO98PIX AUS.1), FQ1012C.1(ICE), FQ101C.1(ICE), FQ101P.1(ICE), FQ101P.1(ICE)F, FQ76C.2(BK), FQ76C.2(WH), FQ962C.2(ICE), FQ99C.1(BK), FQ99C.1(ICE), FQ99C.1(WH), FQ99P.1(BK)F, FQ99P.1(ICE)F, FQ99P.1(WH)F, FQA99P.1BK, FQA99P.1WH, FR64AN-AG, 25511 (FRG(AN)), 25510 (FRG(BR)), FRG0(AN), FRG0(BR), 26156 (FT95C(AN)), 26455 (FT95C(OW)), 29035 (FT95C.1(AN)), 29036 (FT95C.1(OW)), FT95VC.1(AN), FT95VC.1(OW), FT95VC.1IX, FX34.2XAL, FZ1001P.1IXNE, FZ100P.1(AN), FZ100P.1IX, FZ1011P.1IXAUS, FZ1011P.1IXAUS-G, FZ1012C.1IX, FZ1012P.1GIX60HZ, FZ1012P.1IXF, FZ101P.1IX, FZ101P.1IX60HZ, FZ101P.1IXF, FZ1021P.1IXNE, FZ1022C.1IX, FZ1022P.1IXF, FZ102P.1(AN)F, FZ102P.1IX, FZ102P.1IXF, FZ1031P.1IXAUS-G, FZ1032C.1IX, FZ1032GP.1IXF, FZ1032P.1GIX60HZ, FZ103P.1GIX, FZ932C.2IX, FZ962C.2IX, FZ96C.1IX, FZ970C.1IX, FZ97C.1(WH), 31577 (FZ97P.1(AN)), 33994 (FZ97P.1(WH)), 31576 (FZ97P.1IX), 39515 (FZ990C.1IX), FZ990C.1IXAG, FZ99C.1(AN), FZ99C.1(WH), FZ99P.1(AN)F, FZ99P.1(WH)F, FZ99P.1GIXF, FZ99P.1IXF, FZGIX, FZGIXAG, H101.1IX, 26976 (HB20AC(WH)), 26977 (HB22AC(IX)), 26978 (HB22AC(WH)), 29829 (HB22AC.1(WH)), 29123 (HB22AC.1IX), HO97P.1-EIX, OS 89 C IX, OS 89 IX, OS99DCIX60HZ, OS99DPPIX, 26979 (PB20AC(WH)), 26999 (PB21AIX), 26981 (PB22AC(WH)), 29102 (PB22AC.1(IX)), 29103 (PB22AC.1(WH)), 26980 (PB22ACIX), XF695.2, XF995.3 60HZ

ARISTON Kitchen gas A5GG1FXEX, 26056 (C302MWR), C303E.3(W)F, 26057 (C303EWF), 27109 (C310EWSKD), C312SP4(X)U, C312SP6(X)U, C3150EC-SKD, C3150EW-SKD, C315EC-SKD, 26668 (C315EWSKD), 27112 (C320ECSKD), 27111 (C320EWSKD), C325EW-EX, 27106 (C340GWEX), C340GW-SKD, 29476 (C345E(X)U), C345E.2(X)U, 26044 (C345GWF), 26586 (C345GWP), 27137 (C345GXEX), 26585 (C345GXP), C346GT(W)F, C346GT(X)F, C347G(B)R, C347GW-I, C347GW-P, 26055 (C347GWR), 26673 (C347GXI), C347GX-P, C347P.2(W)I, C347P.2(X)I, 26674 (C347PWI), 26675 (C347PXI), 29477 (C348PT(W)U), 29478 (C348PT(X)U), C348PT.2(W)U, C348PT.2(X)U, C348PV(X)U, C348PV.2(X)U, C349P.2(W)U, 26050 (C349PV(X)U), C349PV.2(X)U, 26054 (C349PWR), 26048 (C349PWU), 26049 (C349PXU), C34SG1(W)R, C34SG1(X)EX, C34SG1(X)R, C34SG3(W)R, C34SG3(X)R, C34SM5(W)R, C34SM5(X)R, C34SN1(W)R, C34SP4(W)U, C34SP4(X)U, C35G1(W)F, C35G1(X)F, C35SP6(W)R, C35SP6(W)U, C35SP6(X)R, C35SP6(X)U, C60N1(W)EX, C612SP6(X)U, C61N1(B)CKD, C61N1(W)CKD, C61N1(X)CKD, C61P6(W)F, C61SP6(X)T, C64SG1(W)EX, C64SG3(B)R, C64SG3(W)R, C64SG3(X)R, 30183 (C65G1(W)F), 30186 (C65P6XF), C65SP6(W)U, C66SP6(A)U, CE60N1(W)EX, CE60N1(X)EX, CE6IFA(W)F, CE6IFAXF, CE6VP6(W)EU, CG64G(B)EX, CG64G(W)EX, CG64G1(B)EX, CG64G1(W)F, CG64SG1(W)EX, CG64SG1(X)EX, CG64SG3(W)R, CG64SG3(X)R, 28237 (CP647GT), 28827 (CP6480MT.2(X)F), 28238 (CP648MT), 29238 (CP648MT.2), CP648MT.2B, CP649FT.2, CP649FTDK, 28247 (CP649MD), CP649MD(X)AUS, 29237 (CP649MD.2), 29253 (CP649MD.2(X)NL), 28239 (CP649MT), 29239 (CP649MT.2), CP65S F8, CP65SF8(FR), CP65SF8DK, 28240 (CP757GT), CP757GT(IT), 28241 (CP758MT), 29240 (CP758MT.2),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CP759FT, CP770SG1AG, CX61FA(W)F, CX61P6(W)F, CX61SN1(X)EX, CX65E9XF, CX65FA(W)F, CX65FAXF, CX65SF9XU, CX66SP6(A)U

ARISTON Kitchen glass-ceramics C3V10M.3(W)F, C3V10MW-F, C3V7M(B)R, C3V7M(X)R, C3V7M.3(W)R, C3V7MW-R, C3V8P(W)U, C3V8P(X)U, C3V8P.2(W)U, C3V8P.2(X)U, 27642 (C3V9EWF), 26051 (C3V9P(W)U), C3V9P.2(W)U, 26053 (C3V9PWR), C3VM5(W)R, C3VM5(X)R, C3VM6(W)F, C3VM6(X)F, C3VP6(W)R, C3VP6(X)R, C6VP6(A)U, C6VP6(X)T, CE6VP6(A)U

CANDY Electric oven 33700835 (FST247-1N), 33700837 (FST247-1W), 33700836 (FST247-1X), 33701288 (FST249-6N), 33701287 (FST249-6W), 33701103 (FST249W), 33701100 (FST249X), 33701091 (FXP695-1X), 33700518 (R100-3GH), 36059103 (R100-3GH), 33700289 (R100TF), 33700519 (R100TF)

CANDY Kitchen 33001336 (CCG500TW-1), 33001337 (CCG5111SW-1), 33001340 (CCG6203BX), 33001192 (CCG6203NW), 33001303 (CCG6203W), 33001242 (CCG9100SX), 33001196 (CCG9101FEX), 33001197 (CCG9101FX), 33001180 (CCG9101SX), 33001202 (CCG9102SX), 33001363 (CCG9105FEB), 33001364 (CCG9105FEW), 33001365 (CCG9105FEX), 33001181 (CCM9101SX), 33001203 (CCM9202SX), 33001178 (CCV6525W), 33001179 (CCV6525X), 33000697 (CGG5612SBS), 33000971 (CGG5621STHW), 33000970 (CGG5622STHS), 33001081 (CGG6521HW), 33001082 (CGG6521HX), 33001358 (CGG6521WCKD), 33001359 (CGG6521XCKD), 33000632 (CGG66TBT), 33001186 (CMM6041B), 33001188 (CMM6041BL), 33001187 (CMM6041S), 33001185 (CMM6041W), 33000935 (CMM662SKHTM), 33001104 (CMM662SKHTM-1), 33001084 (CVM6524PX)

HOTPOINT Convection oven electric SC98PAX, SC98PX(T), SD97EI, SD97EK, SD97EW, SD97I, SD97K, SD97PC, SD97PEH, SD97PEI, SD97PI, SD97W, SD98PAI, SD98PI, ST98PAX, ST98PX

HOTPOINT Electric oven electric 7OOS997DCIXRU-HA, 7OOS997DPIXRU-HA, FT95VC.1ANHAS, OS992DPIX-HA, OS997DPIX-HA, OS99DPIX-HA

HOTPOINT Kitchen electric CE6IE9.1XFHA, CE6IFA.1XF-HA, CE6IFA.2(W)F-HA, CE6IFA.2XF-HA, CE6IFAWFHA

HOTPOINT Kitchen gas C312SP4(X)U-HA, C34SG1(W)R-HA, C34SG1(W)UA-HA, C34SG1(X)R-HA, C34SG17(W)RU-HA, C34SG17(X)RU-HA, C34SG3(W)R-HA, C34SG3(W)R-HAS, C34SG3(W)UA-HA, C34SG3(X)R-HA, C34SG37(W)RU-HA, C34SG37XRU-HA, C34SG3XRHAS, C34SM5(W)R-HA, C34SM5(X)R-HA, C34SM57(W)RU-HA, C34SM57(X)RU-HA, C34SN1(W)R-HA, C34SN17(W)RU-HA, C35G1(W)F-HA, C35G1(X)F-HA, C35SG1(W)F-HA, C35SG1(X)F-HA, C35SG1XFHAS, C35SP6(W)R-HA, C35SP6(W)UA-HA, C35SP6(X)R-HA, C35SP6(X)UA-HA, C35SP6(X)U-HA, C35SP6L(X)U-HA, C35SP6WRHAS, C35SP6WUAHAS, C35SP6XRHAS, C35SP6XUAHAS, C35SP6XUHAS, CG64SG1(W)F-HA, CG64SG1(W)UA-HA, CG64SG3(W)R-HA, CG64SG3(X)R-HA, CG64SG37(W)RU-HA, CG64SG37(X)RU-HA, CG65SG1XUA-HA, CG65SG5XUAHA, CI65SE9(W)R-HA, CI65SE9(X)R-HA, CI65SE97(W)RU-HA, CI65SE97(X)RU-HA, CI6IFA(A)R-HA, CI6VE9(W)R-HA, CI6VE97(W)RU-HA, CI6VE97XRUA, CJ34SG5(X)R-HA, CJ34SG57(X)RU-HA, CJ65SG1(W)R-HA, CJ65SG17(W)RU-HA, CM5GS11WRFH, CM5GS16(W)RFH, CM5GS16(X)RFH, CP 65S FA DK-HA, CP 77 SG1-HA, CP 77 SP2-HA, CP 87 SEA-HA, CP 87 SG1-HA, CP 97 SE2-HA, CP 97 SEA-HA, CP 97 SG1-HA, CP 98 SEA-HA, CP 98 SP1 F-HA, CP 98 SP6 F-HA, CP 98 SP6 NL-HA, CP65SE9(C)-HA, CP65SG1-HA, CP65SP2L-HA, CP66SP6(X)NL-HA, CPDO 902 X I-HA, CX61SFA(W)F-HA, CX61SFAXF-HA, CX61SP6(W)F-HA, CX65SE9(W)F-HA, CX65SE9XF-HA, CX65SF9XU-HA, CX65SFA(W)F-HA, CX65SFAXF-HA, CX65SP2 XB-HA, H5G65AECWUA, H5G66AFXUA, H5GG1FWRU, H5GG1FXRU, H5GG5EWUA, H5GG5FCXUA, H5GG5FWRU, H5GG5FXRU, H5GG5FXUA, H5MMC1AGXFR, H5TGC1GWFR,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

H5TGC1GXFR, H5TMH6AFWPL, H5TMH6AFXPL, HM5GS13WRU

HOTPOINT Kitchen glass-ceramics C3BM6(W)F-HA, C3BM6(X)F-HA, C3VM5(W)R-HA, C3VM5(W)UA-HA, C3VM5(X)R-HA, C3VM57(W)RU-HA, C3VM57(X)RU-HA, C3VP6(W)R-HA, C3VP6(X)R-HA, C3VP6WRHAS, C3VP6XRHAS, CE6VP6(W)EU-HA, CI3VP6(X)R-HA, CI3VP67(X)RU-HA, CP 9VP6 DE-HA, H5V56WRU, H5V56XRU, H5VMC6AXRU, H5VMH6AXEA, H5VMH6AXPL

INDESIT Convection oven electric F067940 (7OIF737K.AIXRU), F069607 (7OIF997K.A(AN)RU), F067941 (7OIF997K.AIXRU), 28969 (FE10.B(IX)NL), F028969 (FE10.B(IX)NL), 28950 (FE20.B(BR)IB), F028950 (FE20.B(BR)IB), 28952 (FE20.B(IX)IB), F028952 (FE20.B(IX)IB), 28951 (FE20.B(WH)IB), F028951 (FE20.B(WH)IB), 28953 (FE21.B(BR)IB), F028953 (FE21.B(BR)IB), 28955 (FE21.B(IX)IB), F028955 (FE21.B(IX)IB), 28954 (FE21.B(WH)IB), F028954 (FE21.B(WH)IB), F027340 (FG10KKB.1), 27341 (FG10KWH.1), F027341 (FG10KWH.1), F068935 (FI23KC.ABK), F068938 (FI23KC.AIX), F068937 (FI23KC.AWH), F056742 (FI23KC.B(BK)), 03567430001 (FI23KC.B(WH)), F056743 (FI23KC.B(WH)), 28960 (HGK2.B(BR)IB), F028960 (HGK2.B(BR)IB), 28962 (HGK2.B(IX)IB), F028962 (HGK2.B(IX)IB), 28961 (HGK2.B(WH)IB), F028961 (HGK2.B(WH)IB), F028966 (HPE2.B(WH)IB), F028967 (HPE2.BIXIB), F058752 (IF737K.AIX), F066523 (IF738K.AIX), F058754 (IF997K.A(AN)), F058755 (IF997K.AIX), F061087 (IF997K.AIXNE)

INDESIT Kitchen electric F085434 (I5E52EWKZ), F085310 (I5E6AEWFR), F085917 (I5ESH1EWUA), F085438 (I5ESH2AEWKZ), F085305 (I5M5C1GWFR), F025274 (K300EW-R), F027056 (K300EW-SK), F027768 (K300EW-SV), F029531 (K300M.B(W)-EU), F026354 (K300MW-EU), F029438 (K30E.C(W)-F), F025629 (K30EW-B), F025272 (K30EW-F), F026351 (K322ESW-EU), F026353 (K323MSW-EU), F029433 (K330E.C(W)-R), F025273 (K330EW-R), F026656 (K332EW-EXCKD), F024168 (K336PSW-U), F029436 (K340E.C(W)-O), F029437 (K340E.C(X)-O), F034261 (K3E1(W)-FR), F035283 (K3E11(W)-R), F067629 (K3E117(W)-RU), F041032 (K3E5(W)-FR), F035999 (K3E51(W)-EU), F067630 (K3E517(W)-RU), F081078 (K3E51WEUS), F030873 (K6E11(W)-F), F041034 (K6E51(W)-FR), F033971 (K6E52(W)-GR), F042380 (K6E55(W)-GR), F073404 (KN1M117S(W)-RU), F073930 (KN1M11S(W)-BA), F081177 (KN1M11SWBAS), F074146 (KN3E11AWEU), F081197 (KN3E11AWEUS), F073453 (KN3E517(W)-RU), F073927 (KN3E62A(W)-BG), F081174 (KN3E62AWBGS), F081096 (KN3E6AWFRS), F073274 (KN6E61A(W)-FR), F084882 (MVI5V05XRU)

INDESIT Kitchen gas F088257 (I5G51GWUA), F085912 (I5G52GWUA), F085532 (I5GG0GWUA), F085437 (I5GG10EWKZ), F085530 (I5GG10FXUA), F085433 (I5GG10GXKZ), F085534 (I5GG10GXUA), F085533 (I5GG1G.2WUA), F085214 (I5GG1G.KXEX), F085215 (I5GG1GXEX), F085531 (I5GG1GXUA), F085306 (I5GGC1G.1XFR), F088443 (I5GGC1GSFR), F085300 (I5GGC1GWFR), F085301 (I5GGC1GXFR), F085536 (I5GMH6AGXUA), F085518 (I5GS1GWNL), F096843 (I5GS1GW-NL), F085516 (I5GS1GXNL), F096842 (I5GS1GXNL), F085222 (I5MG1GXEX), F085304 (I5MMC2AGWFR), F085689 (I5NSH1AEWU), F085686 (I5TMH6AGWU), F085403 (I5TMH6AGXU), F085312 (IW5GGC1GWFR), F026317 (K 342 V(W)-O), F025288 (K132ESW-R), 27279 (K1402GWEX), F027279 (K1402GWEX), F025287 (K142GSX-R), F036002 (K1G2(W)-EX), F035294 (K1G21(W)-R), F035295 (K1G21(X)-R), F067622 (K1G217S(W)-RU), F067623 (K1G217S(X)-RU), F035297 (K1G21S(W)-R), F035983 (K1G21S(X)-HU), F035298 (K1G21S(X)-R), F035299 (K1M11S(W)-R), F025284 (K244GW-R), F025285 (K245GW-R), F025286 (K246GSW-R), F029473 (K300E.B(W)-SK), F029474 (K300E.B(W)-SV), F029434 (K300E.C(W)-R), F027139 (K3200EWEX-SKD), F027104 (K3300EW-EX), 27102 (K3402GWEX), F027102 (K3402GWEX), F027103 (K3403GX-EX), F026315 (K340EW-O), F026316 (K340EX-O),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

F026312 (K342ESW-EU), F027091 (K342GSW-B), F025631 (K342GSW-I), F025279 (K342GSW-R), F025632 (K342GSX-I), F025278 (K342GW-R), F025277 (K342GX-R), F029398 (K342MS.B(W)-I), F029399 (K342MS.B(X)-I), F025636 (K342MSW-I), F025280 (K342MSW-R), F026313 (K342MSX-EU), F025637 (K342MSX-I), F024928 (K343EW-U), F026830 (K343GSW-R), F030279 (K343M.B(W)-U), F030278 (K343M.B(X)-U), F030277 (K343M.B(XW)-U), F028539 (K343MW-U), F026445 (K3444GXW-P), F026311 (K344GSX-EU), F025268 (K344GW-F), F030285 (K345E.B(X)-U), F024829 (K345EX-U), F026446 (K345GSX-P), F024821 (K345GSX-U), F024925 (K345GSXW-U), F027783 (K345GW-F), F024926 (K345GW-U), F027782 (K346GX-F), F029486 (K346M(W)-U), F030283 (K346M.B(W)-U), F030272 (K346P.B(W)-U), F030273 (K346PS.B(W)-U), F030271 (K346PS.B(X)-U), F024931 (K346PSW-U), F024167 (K346PSX-U), F024831 (K346PW-U), F035278 (K3G11(W)-O), F035277 (K3G11(X)-O), F067249 (K3G11S(W)-O), F067250 (K3G11S(X)-O), F034422 (K3G12(X)-U), F067222 (K3G12S(X)-U), F034256 (K3G21(W)-CF), F036005 (K3G21(W)-EX), F035284 (K3G21(W)-R), F035285 (K3G21(X)-R), F034257 (K3G210(W)-FR), F036006 (K3G210(X)-EX), F034258 (K3G210(X)-FR), F067426 (K3G210S(W)-FR), F067635 (K3G217S(X)-RU), F071540 (K3G21S(B)-UA), F067428 (K3G21S(W)-CF), F035286 (K3G21S(W)-R), F033645 (K3G21S(W)-U), F035268 (K3G21S(X)-P), F035287 (K3G21S(X)-R), F033636 (K3G21S(X)-U), F035288 (K3G52S(W)-R), F033653 (K3G55(W)-U), F033654 (K3G55(X)-U), F033655 (K3G55(XW)-U), F047164 (K3G55.A(W)-U), F047162 (K3G55.A(X)-U), F047163 (K3G55.A(XW)-U), F071541 (K3G55S(B)-UA), F067241 (K3G55S.A(W)-U), F067242 (K3G55S.A(X)-U), F067243 (K3G55S.A(XW)-U), F033649 (K3G56(W)-U), F047161 (K3G56.A(W)-U), F067244 (K3G56S.A(W)-U), F053215 (K3G66(W)-U), F053216 (K3G66(X)-U), F067245 (K3G66S(W)-U), F067246 (K3G66S(X)-U), F033647 (K3G76(W)-U), F033646 (K3G76S(W)-U), F033648 (K3G76S(X)-U), F036007 (K3M11(W)-EX), F035289 (K3M11(W)-R), F034260 (K3M51(W)-FR), F054343 (K3M51(X)-FR), F067433 (K3M51S(W)-FR), F067434 (K3M51S(X)-FR), F049274 (K3M56(W)-FR), F035290 (K3N11S(W)-R), F036000 (K3N55S(W)-EU), F053217 (K3T76S(W)-U), F053219 (K3T76S(X)-U), F030886 (K6G2(W)-F), F031986 (K6G21(W)-CF), F033673 (K6G21(W)-EX), F067436 (K6G21S(W)-CF), F030895 (K6G21S(W)-R), F033806 (K6G21S(WX)-P), F033804 (K6G21S(X)-P), F030898 (K6G21S(X)-R), F033156 (K6G25S(W)-U), F067437 (K6G25(W)-F), F030853 (K6G52S(X)-R), F033677 (K6G72(W)-EX), F033159 (K6G76S(A)-U), F030871 (K6M1(W)-F), F030869 (K6M11(W)-EX), F067446 (K6M1S(W)-F), F039680 (K6T21(X)-EX), F033672 (K6T21S(X)-EX), F078053 (KN1G21(W)-EX), F078054 (KN1G21(X)-EX), F073401 (KN1G217S(W)-RU), F073402 (KN1G217SX-RU), F073400 (KN1G217X-RU), F074071 (KN1G21S(X)-HU), F074143 (KN1G21SW-UA), F074144 (KN1G21SX-UA), F074137 (KN1G21WUA), F074138 (KN1G21X-UA), F073805 (KN3G11S(W)-NL), F081152 (KN3G11S(W)-NLS), F081153 (KN3G11S(X)-NLS), F073806 (KN3G11SX-NL), F078327 (KN3G2(W)-UA), F073262 (KN3G210S(W)-FR), F073263 (KN3G210S(X)-FR), F078331 (KN3G210S(X)-UA), F081098 (KN3G210SWFRS), F081099 (KN3G210SXFRS), F081250 (KN3G210SXUAS), F073596 (KN3G210X-EX), F076200 (KN3G212S(W)-FR), F076201 (KN3G212S(X)-FR), F081232 (KN3G212SWFRS), F081233 (KN3G212SXFRS), F073459 (KN3G217(W)-RU), F073463 (KN3G217S(W)-RU), F073464 (KN3G217SX-RU), F073461 (KN3G217X-RU), F073920 (KN3G21S(W)RO), F078330 (KN3G21S(W)-UA), F073921 (KN3G21S(X)-RO), F074153 (KN3G21SX-EU), F081199 (KN3G21SXEU), F074148 (KN3G21W-UA), F073592 (KN3G2W-EX), F073466 (KN3G527S(W)-RU), F074154 (KN3G52SW-UA), F074085 (KN3G76SA(X)), F074155 (KN3G76SAX-EU), F081201 (KN3G76SAXEU), F078335 (KN3G76SAXUA), F081253 (KN3G76SAXUAS), F073467 (KN3M117(W)-RU), F073620 (KN3M21(W)-EX), F073621 (KN3M21X-EX), F073268

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(KN3M51S(W)-FR), F081102 (KN3M51SWFRS), F073269 (KN3M51SX-FR), F081103 (KN3M51SXFRS), 76944 (KN3M522SWFR), F076944 (KN3M522SWFR), F081247 (KN3M522SWFRS), F076203 (KN3M522SX-FR), F073468 (KN3N117S(W)-RU), F073928 (KN3N11SA(W)-BG), F081175 (KN3N11SAWBGS), F074157 (KN3N11SW-EU), F081202 (KN3N11SWEUS), F082421 (KN3N61SAWBG), F073929 (KN3N65SA(W)-BG), F081176 (KN3N65SAWBGS), F082420 (KN3N65SAXBG), F081243 (KN3T760SA(W)-US), F076843 (KN3T760SAWU), F073875 (KN3T76SAX-U), F073601 (KN6G21(W)-EX), F073436 (KN6G217S(W)-RU), F073438 (KN6G217S(X)-RU), F073275 (KN6G21S(W)-FR), F073922 (KN6G21S(W)-R), F073923 (KN6G21S(X)-RO), F073796 (KN6G21SWX-P), F073279 (KN6G2SW-FR), F073441 (KN6G527S(X)-RU), F073594 (KN6M21SXEX), F073593 (KN6M21W-EX), F073602 (KN6T21SX-EX), F058362 (KP6T21S(X)-I), F053226 (KP6T21S(X)-IT), F079697 (MVKGS11(W)RF), F079698 (MVKGS11XRF)

INDESIT Kitchen glass-ceramics F085513 (I5V7H6AXEU), F085309 (I5VM1AXFR), F085317 (I5VMC1AWFR), F086209 (I5VSH1AXFR), F085313 (IW5VMC1AXFR), 27542 (K343MXEU), F027542 (K343MXEU), 26828 (K35CEXF), F026828 (K35CEXF), F029435 (K3C0E.C(W)-R), F026418 (K3C0EW-R), F028647 (K3C10MW-F), F062261 (K3C11(W)-AUS), F034262 (K3C11(W)-FR), F035281 (K3C11(W)-R), F062262 (K3C11(X)-AUS), F054339 (K3C11(X)-FR), F067626 (K3C117(W)-RU), F029443 (K3C15M.C(W)-F), F041031 (K3C51(W)-FR), F054340 (K3C51(X)-FR), F081079 (K3C51WFRS), F096832 (K3C51WFRS), F049272 (K3C55(W)-FR), F035282 (K3C55(X)-R), F067627 (K3C557(X)-RU), F036374 (K3C76(W)-BG), F036373 (K3C76(X)-BG), F067628 (K3C767(X)-RU), F029403 (K3C8P.B(W)-D), F030274 (K3C8P.B(W)-U), F029404 (K3C8P.B(X)-D), F027496 (K3C8PW-D), F026417 (K3C8PW-U), F027497 (K3C8PX-D), 27058 (K3C8PXSK), F027058 (K3C8PXSK), F026407 (K3C8PX-U), F026827 (K3CEW-F), F030875 (K6C11(W)-R), F042381 (K6C51(W)-GR), F030863 (K6C51(W)-R), F059003 (K6C51(X)-EX), F068982 (K6C517(W)-RU), F042382 (K6C56(X)-GR), F073253 (KN3C11(W)-FR), F081091 (KN3C11(W)-FRS), F073254 (KN3C51(W)-FR), F073255 (KN3C51(X)-FR), F081092 (KN3C51WFRS), F081093 (KN3C51XFRS), F073256 (KN3C55(W)-FR), F073448 (KN3C557X-RU), F081094 (KN3C55WFRS), F081160 (KN3C62A(W)US), F073860 (KN3C62AW-U), F074074 (KN3C65A(X)CZ), F081188 (KN3C65AWCZS), F081185 (KN3C65AXCZS), F073450 (KN3C767AX-RU), F073925 (KN3C76A(W)BG), F073258 (KN3C76A(W)-FR), F081172 (KN3C76AWBGS), F081095 (KN3C76AWFRS), F073926 (KN3C76AX-EU), F081173 (KN3C76AXEUS), F073259 (KN3E6A(W)-FR), F073431 (KN6C117(W)-RU), F073433 (KN6C517(W)-RU), F073813 (KN6C61A(W)-NL), F073812 (KN6C61A(X)-NL), F073281 (KN6M1SA(W)-FR), F037665 (KP 9681 MS (X)-DE), F079703 (MVK5V75(X)RF)

ROSIERES Electric oven 33700074 (FE6083/2PN), 33701683 (RF697ZIN), 33701182 (RFA 55FIN), 33700918 (RFA22IN-1), 33700919 (RFA22PN-1), 33700920 (RFA22RB-1), 33700914 (RFA54VIN-1), 33700915 (RFA54VNX-1), 33700916 (RFA54VPN-1), 33700917 (RFA54VRB-1), 33701723 (RFAZ6570IN), 33701724 (RFAZ6570PNI), 33701725 (RFAZ6570RBI), 33701726 (RFAZ7670IN), 33701727 (RFAZ7673IN-EWIFI), 33701728 (RFAZ7673PN-EWIFI), 33701729 (RFAZ7673RB-EWIFI), 33701730 (RFAZ8573IN), 33701731 (RFAZ8673IN), 33701718 (RFCR93IN), 33701719 (RFCR93PN), 33701720 (RFCR93RB), 33700340 (RFD7659MIN), 33701568 (RFS5993IN), 33701567 (RFS5993PN), 33701566 (RFS5993RB), 33701562 (RFS6871IN), 33701574 (RFT4550AV), 33701576 (RFT4550BAV), 33701682 (RFZ6970IN), 33701721 (RFZ7970IN-E WIFI), 33701684 (RFZ7972IN-E WIFI)

ROSIERES Kitchen 33000189 (RCG6020RB), 33000036 (RCG621RB), 33000634 (RCM5931RB), 33001008

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(RCM6972IN-1), 33001011 (RCM6972RB-1)

ROSIERES Kitchen electric 33000958 (RCV5471PN), 33000694 (RCV5471RB), 33001044 (RCV6474RB-1)

ROSIERES Kitchen gas 33000633 (RCG5921RB), 33000868 (RCG5921RB CH), 33000962 (RCG6911RB),  
33001013 (RCG6920MA-1), 33001016 (RCG6920RB-1), 33001017 (RCG6921RB-1)

WHIRLPOOL Kitchen glass-ceramics ACMT5531IX, ACMT5531WH

