

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Contactor AEG LS07 7A 230V 3Kw #3351208

Fara TVA: 257,98 Lei

Pret cu TVA: 307,00Lei

Contactor AEG LS07 7A 230V 3Kw #3351208

Bobina: 230V 50/60Hz

3 contacte normal deschise

1 contact auxiliar normal deschis

Compatibil cu:

AEG LS07F10-50

DANUBE SAVW080100

FAGOR Z213007000

FAGOR 12024011

GEV 380236

LAMBER 0300059

WINTERHALTER 3104068

FAGOR Bain-marie electric BME700, BME-705, BME7-05, BME-710, BME7-10, BME9-05, BME9-05PLUS, BME9-10, BME9-10PLUS

FAGOR Bain-marie gas BMG-710, BMG7-10, BMG9-05, BMG9-10

FAGOR Bratt pan electric CMF6-05

FAGOR Chaffing dish CCF-10, CCF-10CI, CCF-20, CCF-20CI, CCF-40, CCF-40CI

FAGOR Convection oven HG9-00, HG9-15

FAGOR Convection oven electric ACE-061, ACE-101, ACE-102, ACE-201, ACE-202, AE-061, AE-061W, AE-101, AE-101W, AE-102, AE-102W, AE-201, AE-202, APE-061, APE-061W, APE-101, APE-101W, APE-102, APE-102W, APE-201, APE-202, COE-061, COE-101, COE-102, COE-201, COE-202, VE-101, VE-102, VE-201, VE-202, VPE-061, VPE-102, VPE-201, VPE-202

FAGOR Convection oven gas ACG-061, ACG-101, ACG-102, ACG-201, ACG-202, AG-061, AG-101, AG-102, AG-201, AG-202, APG-061, APG-101, APG-102, APG-201, APG-202, COG-061, COG-101, COG-102, COG-201, COG-202, HE9-00, HG9-15OP, VG-101, VG-102, VG-201, VG-202, VPG-101, VPG-102, VPG-201, VPG-202

FAGOR Dishwasher AD-120, AD-120B, AD-120BBTDDUK, AD-120C, AD-120CW, AD-120HY, AD-125, AD-125HRS, AD-15, AD-15D, AD-20CUK, AD-21, AD-21B, AD-21BDD, AD-21C, AD-21D, AD-21DD, AD-21W, AD-45BBT, AD-48HY, AD-48W, AD-505, AD-64, AD-64B, AD-64BBT, AD-64BDD, AD-64BTDD, AD-64C, AD-64CW, AD-64D, AD-64DD, AD-64HY, AD-72, AD-72W, AD-90, AD-90BA, AD-90BBT, AD-90BDD, AD-90DD, ADE-120, ADE-120B, CO-112, CO-142W, CO-172, CO-350, CO-352, CO-400, CO-402, CO-402W, CO-500, CO-501, CO-502, CO-502W, COP-173, COP-174, COP-174W, COP-503, COP-504, COP-504W, ECO-200H, ECO-6000, FI-100AR, FI-100BBTUK, FI-120AR-DD, FI-120B, FI-120C, FI-120HY, FI-200H, FI-30, FI-30AR, FI-30AR-DD, FI-30B, FI-30BBTUK, FI-30UK, FI-48, FI-48B, FI-48BBTUK, FI-48C, FI-48D, FI-48HY, FI-48W, FI-50, FI-60DD, FI-64, FI-64B, FI-64BBT, FI-64C,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FI-64D, FI-64HY, FI-64W, FI-72, FI-72AR, FI-72W, FI-E-100, GA-40, LVC, LVC-21C, LVR, MF-48, MF-64
FAGOR Dishwasher conveyor type ECO-2700, ECO-4000, FI-2700, FI-4000, FI-6000
FAGOR Dishwasher hood type ECO-120, FI-100, FI-100B, FI-120, FI-120-CLINIC, FI-120W, FI-80, FI-80W, MF-120
FAGOR Dishwasher pull-through ECO-160, ECO-200, ECO-280, ECO-370, ECO-460, ECO-550, FI-160, FI-200,
FI-200W, FI-280, FI-370, FI-460, FI-550
FAGOR Electric oven VE-061, VPE-101
FAGOR Fry top electric FTE6-05, FTE6-10, FTE-705, FTE-710, FTE9-05, FTE9-05PLUS, FTE9-10, FTE9-10PLUS,
FTE-C6-05, FTE-C6-10, FTE-C9-05, FTE-C9-10, FTG-705, FTG-705V, FTG-710, FTG-710V
FAGOR Fry top gas FTE7-05, FTE7-10, FTG700, FTG7-05, FTG7-05V, FTG7-10, FTG7-10V, FTG9-00, FTG9-05,
FTG9-10
FAGOR Fryer electric FE6-05, FE6-05TE, FE6-10, FE6-10TE, FTE-700, FTE9-00
FAGOR Fryer gas FG6-05, FG6-10
FAGOR Glasswasher/Cupwasher LVC-12, LVC-15, LVC-15D, LVC-21, LVC-21B, LVC-21D, LVC-21W, LVR-10,
MF-21
FAGOR Kitchen electric CE6-20, CE6-40, CE6-41, CE7-20, CE-740, CE7-40, CE-741, CE7-41, CE9-00, CE9-20,
CE9-40, CE9-41, CGE9-41AD
FAGOR Kitchen gas CG-700, CG7-20, CG7-40, CG7-41, CG7-60, CG7-61, CG9-20AD, CG9-20PLUS, CG9-40AD,
CG9-40PLUS, CG9-41, CG9-41AD, CG9-41PLUS, CG9-60, CG9-60AD, CG9-60PLUS, CG9-61, CG9-61AD,
CG9-61OP, CG9-61PLUS, CG9-82, CG9-82AD, CG9-82PLUS, CGE6-41, CGE741 (CGE-741), CGE7-41, CGE9-41,
CGE9-41PLUS, CGE9-61OP
FAGOR Kitchen induction CE7-20Q, CE7-40Q, CE7-41Q, CE9-20AD, CE9-20PLUS, CE9-40AD, CE9-40PLUS,
CE9-41AD, CE9-41PLUS
FAGOR Oven under cooktop electric HE9-10, HE9-20
FAGOR Oven under cooktop gas HG9-10, HG9-20
FAGOR Pasta cooker electric CPE6-05
FAGOR Pot stove electric CE-720
FAGOR Pot stove gas CG9-10, CG9-11, CG9-20, CG9-40
FAGOR Solid top range gas CGE9-11
FAGOR Washing machine LA-10, LA-10M, LA-13, LA-13M, LA-18, LA-18M, LA-25, LA-25M, LA-25MP, LA-25MPPS,
LB-25M, LN-11, LN-14, LN-18, LN-25, LN-35, LN-60, LR-10, LR-10M, LR-11, LR-13, LR-13M, LR-18, LR-18M,
LR-25, LR-25M
LAMBER Dishwasher 01F, 01F DEP, 045F, 045F ADD, 045F DEP, 045F EK, 045F EK ADD, 050F, 050F ADD, 050F
EK, 050F EK ADD, 075F, 075F DEP, 50F EK ADD, DSP4, F85, F85 DEP, F92, F92 DEP, GS6, GS800, GS900, LS415
LAMBER Dishwasher hood type 015-24L, A240, DSP 5, DSP5, L18, L20, L21, L25
LAMBER Glasswasher/Cupwasher GS4, GS4 EK, GS45 EK, GS5, GS5 EK, S200, S240, S260, S260 ADD, S280,
S280 ADD, S400 EK, S400 EK ADD, S460 ADD, S460 EK, S460 EK ADD, S480 EK, S480 EK ADD, S510, S510
ADD, S510 EK, S510 EK ADD, SL4, SUPER QS, SUPER QS ADD
LAMBER Pan/utensilwashing machines P700
LAMBER Vegetable washing machine LV84

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

WINTERHALTER Dishwasher GKTS 2600, GR 1231, GS 27 B, GS 4

WINTERHALTER Glasswasher/Cupwasher GS 23, GS 25, GS 27, GS 28

WINTERHALTER Pan/utensilwashing machines GR 1210, GR 1220, GR 1221, GR 1230, GR 1320, GR 1321, GR 62

