



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Contactor SIEMENS 3RT2016-1AP01 9A 400V #3351049

Fara TVA: 112,97 Lei

Pret cu TVA: 134,43Lei

Contactor SIEMENS 3RT2016-1AP01 9A 400V #3351049

9A 400V 4Kw - coil 230V 50/60Hz

3 normally open contacts

1 normally open auxiliary contact

Compatibil cu:

AMIKA 73350

AMIKA 80350

BARTSCHER 0229037

BERTO'S 10001

BONNET 2001923H

07070001CB

COLGED 73350

COLGED 80350

COLGED 229037

COOKMAX

COVEN EMCN1H25

DEXION 73350

DEXION 80350

DEXION 229037

ELETTROBAR 73350

ELETTROBAR 80350

ELETTROBAR 229037

EUROWASH 73350

EUROWASH 80350

FOINOX 10001

GEV 380389

GEV 381387

HOBART E229037

HOBART 80350

HOBART 229037

MAIDAID MH102375

MARENO MACM187300

MARENO MACM187301



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MARENO 21453199

MARENO CM187300

MBM 73350

MBM 80350

MBM 229037

MODULINE A34100880

MODULINE 34100880

MORETTI 74550230

PEGO CON10161AP01

PEGO CON20161AP01

REPAGAS 1430006

SIEMENS SIE3RT20161AP01

THIRODE 2001923H

WOLK 73350

WOLK 80350

AMIKADishwasher hood type80X, 8XL

AMIKADishwasher pull-through101XL

BERTO'SConvection oven gasFC200GB

BERTO'SElectric ovenMM10EB

CB Rotisserie electric E-12P, E-8P, P7-5 E

COLGED Dishwasher GL56, GL56S, GL56SPS, GS55, GS55CRP, GS56, GS57, GS60, ISYTECH38-10 D, ISYTECH38-11 D, ISYTECH38-11 GD, ISYTECH38-12 D, ISYTECH38-13 D, ISYTECH38-13 GD, NEOTECH800CRP, NEOTECH800DP, NEOTECH803N, NEOTECH900, PROTECH28-10, PROTECH710, STEELTECH370, STEELTECH38-00, STEELTECH38-00D, STEELTECH38-01D, STEELTECH38-02, STEELTECH38-03D, TOPTECH38-21D, TOPTECH38-23D, TOPTECH38-23DCOP, TOPTECH38-23TDE, TOPTECH38-23TDEGMBH, TOPTECH39-22D, TOPTECH39-23D, TOPTECH39-23DCOP, TOPTECH500, TOPTECH500CRP, TOPTECH920

COLGED Dishwasher conveyor type NEOTECH1010PLUS

COLGED Dishwasher hood type BETA270, C600, GL270, GL270HP, GL71, GL72, GL72CRP, GL74, GL740, GL74A, GL74CRP, GL81, GL82, GLA, ISYTECH28-00, ISYTECH28-00 I, ISYTECH28-00 ID, ISYTECH28-01 G, ISYTECH28-02 G, ISYTECH28-02 GNRG, ISYTECH28-02 GT, ISYTECH28-02 GTNRG, ISYTECH38-13 DNRG, NEO800N, NEO803L, NEO803N, NEOTECH28-05, NEOTECH28-05 DP, NEOTECH28-05 I, NEOTECH28-05 ID, NEOTECH28-06, NEOTECH28-06DP, NEOTECH28-06ID, NEOTECH800, PRO811L, PRO811R, PRO811RCLS, PRO831L, PRO831N, PRO831NCLS, PROTECH20-10I NRG, PROTECH28-10DP, PROTECH28-10I NRG, PROTECH28-10IT NRG, PROTECH28-10T, PROTECH28-16, PROTECH28-16I, PROTECH28-16I NRG, PROTECH28-16T, PROTECH810, PROTECH811, PROTECH811GCLS, PROTECH811ID, PROTECH811R, PROTECH811S, PROTECH811SID, PROTECH811TR-2, SILVER71, SILVER72, STARTECH805, STEEL70, STEEL7-3, STEELTECH18-00, STEELTECH380BK, STEELTECH381, STEELTECH383G, STEELTECH7-3, TOPTECH28-20, TOPTECH28-20GT, TOPTECH28-20NRG, TOPTECH28-20TNRG, TOPTECH28-26, TOPTECH28-26G, TOPTECH28-26GNRG, TOPTECH28-26NRG, TOPTECH28-26T, TOPTECH28-26TG, TOPTECH 28-26TNRG, TOPTECH38-20D,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

TOPTECH38-21DE, TOPTECH38-22D, TOPTECH38-22TD, TOPTECH38-23DE NRG, TOPTECH39-20D, TOPTECH39-21D, TOPTECH39-22TD, TOPTECH39-23, TOPTECH39-23D NRG, TOPTECH39-23GDTDE, TOPTECH39-23TD, TOPTECH740, TOPTECHCTT2820

COLGED Dishwasher pull-through GL80, GL84, ISYTECH31-11.1, ISYTECH31-11.2, ISYTECH31-11G.1, NEOTECH1010, PROTECH1113, PROTECH1117, PROTECH1122, STEEL9-3, TOPTECH31-21.1, TOPTECH31-21.2, TOPTECH31-22.1, TOPTECH31-22.1G, TOPTECH31-22.2, TOPTECH31-22.2G, TOPTECH31-22.3, TOPTECH31-22.3G

COLGED Glasswasher/Cupwasher STEELTECH340H

COLGED Pan/utensilwashing machines LP101, LP105, LP201, LP301, LP60, LP92, NEOTECH901, NEOTECH902, TOPTECH921, TOPTECH922, TOPTECH923, TOPTECH924

COVEN Electric oven TEC 10MX, TEC 10NMX, TEC 6MX

DEXION Dishwasher LP058-00-010MPD, LP058-06-CRP, LP061-00-000H, LP800-00-092

DEXION Dishwasher hood type D600LK, LP100-06-000, LP101-98-00, LP102-98-00, LP103-06-000, LP103-98-00, LP801-00-000

DEXION Dishwasher pull-through LT080-03-000

ELETTROBAR Dishwasher NIAGARA2152, NIAGARA271, NIAGARA291, RIVER282TDE, RIVER294, RIVER295, RIVER295P, RIVER296, RIVER296P, RIVER297, RIVER50, RIVER50CRP, RIVER50D, RIVER53T, RIVER54, RIVER54CRP, RIVER54D, RIVER54PS, RIVER54WRCCRP, RIVER61, RIVER61CRP, RIVER70, RIVER71

ELETTROBAR Dishwasher conveyor type NIAGARA441-2

ELETTROBAR Dishwasher hood type C600, E78, FAST170, FAST180, FAST181, FAST60, FAST73, FAST80, FAST80D, gl74th (GL74), GL740, GL74A, GL74CA, GL74CABT, GL74CNS, GL74CRP, GL74FIERA, GL74NS, NIAGARA281, NIAGARA281-2, NIAGARA281C, NIAGARA281CDD, NIAGARA281DD, NIAGARA281HP, NIAGARA283, NIAGARA283-2 FURNOTEL, NIAGARA283L-2, NIAGARA381, NIAGARA381D, NIAGARA381DP, NIAGARA381HPD, NIAGARA381I, NIAGARA381ID, NIAGARA381L, NIAGARA381L DP, NIAGARA381LI, NIAGARA82CDE, OCEAN380, OCEAN380DD, OCEAN81D, OCEAN81DE, PLUVIA280, RIVER281CRP, RIVER282, RIVER282-2, RIVER282CRP, RIVER282LS-2TDE, RIVER285 NRG, RIVER382 RESTOREX, RIVER382L, RIVER382L NRG, RIVER382L-2, RIVER382LR, RIVER382NRG, RIVER382TDE, RIVER482, RIVER80, RIVER81, RIVER81CRP, RIVER82, RIVER82CRP, RIVER83CDE, RIVER93CDE, RIVERE78, RIVERE80

ELETTROBAR Dishwasher pull-through FAST200, FAST93, NIAGARA2150, NIAGARA2154, NIAGARA2156, NIAGARA411-1, NIAGARA411-2, NIAGARA412-2, RIVER150, RIVER152, RIVER154, RIVER414-2, RIVERMULTI413-1, RIVERMULTI413-2, RIVERMULTI414-2, SEVEN E, SEVEN L

ELETTROBAR Glasswasher/Cupwasher NIAGARA92CDE, NIAGARA92D, RIVER48

ELETTROBAR Glasswasher/Cupwasher hood type NIAGARA82D

ELETTROBAR Pan/utensilwashing machines LP00, LP092, LP101, LP105, LP201, LP301, LP60, LP800, LP92, NIAGARA292, NIAGARA293, RIVER298, U132, U132E, U60E, U61E, U61HE, U70, U70E

EUROWASH Dishwasher EW3103, EW3104, EW3105

EUROWASH Dishwasher hood type 383, 481, 481D, 723, GL713, GL72

EUROWASH Dishwasher pull-through 3509, 3512, 3516, 4512

FOINOX Blast chiller BC100, BC100 1MV, BC100 2MV, BC100 3MV

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FOINOX Convection oven electric Blu Pastry M, Blu Pastry Vip, FC 100 EEP, FC 100 EM, FC 100 ETD, FC 200 EEP, FC 200 EM, FC 200 ETD, FC 201 EEP, FC 201 EM, FC 201 ETD, FC 401 EEP, FC 401 EM, FC 401 ETD, FC 60 EEP, FC 60 EM, FC 60 ETD, FC06E, FC06EA, FC06EDG, FC06EEA, FC06SE, FC06SEA, FC06SEDG, FC12E, FC-12E, FC12EA, FC-12EA EDG, FC12EDG, FC12SE, FC-12SE, FC12SEA, FC-12SEA SEDG, FC12SEDG, FC20E, FC-20E, FC20EA, FC-20EA EDG, FC20EDG, FC50EM, FM 06EB, FM 100 EEP-ED, FM 100 EM, FM 10E, FM 10EB, FM 200 EEP-ED, FM 200 EM, FM 201 CEEPA, FM 201 EEP-ED, FM 201 EM, FM 20EB, FM 401 EEP-ED, FM 401 EM, FM 60 ED, FM 60 EEP, FM 60 EM, FM06EB, FM100ETD, FM200ETD, FM201ETD, FM401ETD, FM60ETD, MIDI005 EEP ED, MIDI005 EM, MM06EA, MM06EAP, MM06EB, MM100 ED, MM100 EEP, MM100 EM, MM100 ETD, MM10EA, MM10EAP, MM10EB, MM200 ED, MM200 EEP, MM200 EM, MM200 ETD, MM201 ED, MM201 EEP, MM201 EM, MM201 ETD, MM20EA, MM20EAP, MM20EB, MM23 EB, MM23 ED, MM23 EEP, MM23 EM, MM23EA, MM23EB, MM401 ED, MM401 EEP, MM401 EM, MM401 ETD, MM60 ED, MM60 EEP ED, MM60 EM, MM60 ETD

FOINOX Convection oven gas FC 100 GEP, FC 100 GM, FC 200 GEP, FC 200 GM, FC 200 GTD, FC 201 GEP, FC 201 GM, FC 401 GEP, FC 401 GM, FC 60 GEP, FC 60 GM, FC05G, FC05GU, FC06 GA GDG, FC06G, FC-06G, FC06GA, FC06GDG, FC100GTD, FC12G, FC12GA, FC-12GA GDG, FC12GDG, FC201CGTD, FC201GTD, FC20G, FC20GA, FC20GA GDG, FC20GDG, FC401GTD, FC60GTD, FM 06GB, FM 06GDG, FM 100 GEP GD, FM 100 GM, FM 10GB, FM 10GDG, FM 200 GEP GD, FM 200 GM, FM 201 GEP-GD, FM 201 GM, FM 20G, FM 20GB, FM 20GDG, FM 401 GEP GD, FM 401 GM, FM 60 GEP, FM 60 GM, FM100GTD, FM200GTD, FM201GTD, FM401GTD, FM60GTD, MM06GA, MM06GAP, MM06GB, MM100 GD, MM100 GEP, MM100 GM, MM100 GTD, MM10GA, MM10GAP, MM10GB, MM200 GD, MM200 GEP, MM200 GM, MM200 GTD, MM201 GD, MM201 GEP, MM201 GM, MM201 GTD, MM20GA, MM20GAP, MM20GB, MM401 GD, MM401 GEP, MM401 GM, MM401 GTD, MM60 GD, MM60 GEP, MM60 GM, MM60 GTD

FOINOX Electric oven FM 100 EEPE, FM 200 EEPE

FOINOX Gas oven FM 200 GEPE, LC06SEM1

FOINOX Pastry oven electric FDE10-155EP, FDE10-155M, FDE10-155TD, FDE55EP, FDE55TD, FP 05E, FP 05EA EDG, FP 100 EEP, FP 100 EM, FP 100 ETD, FP 10E, FP 160 CEM1, FP 40 EEP, FP 40 EM, FP 50 EEP, FP 50 EM, FP 80 EEP, FP 80 EM, FP10EA, FP10EDG, FP160EEP

FOINOX Pastry oven gas FDG10-155EP, FDG10-155M, FDG10-155TD, FDG55EP, FDG55M, FDG55TD, FP 100 GEP, FP 100 GM, FP 100 GTD, FP 10G, FP 50 GEP, FP05G, FP05GA GDG, FP10GA GDG

HOBART Dishwasher hood type ECOMAX 600, ECOMAX 651, ECOMAX 683, GL71, GL72, GL74, H65, H66, H67

MARENO Boiling pan electric NPD98E10, NPD98E15, NPI76E5, NPI78E8, NPI96E5, NPI98E10, NPI98E15, PD9-8E10, PD9-8E15, PD9S-8E10, PI7-6E5, PI9-6E5

MARENO Bratt pan electric NBR7-8EF, NBR7-8EI

MARENO Fry top electric FT12-9ELC, FT12-9EM, FT7-4EL, FT7-4ER, FT7-6EL, FT7-6ELC, FT7-6EM, FT7-6EMC, FT7-8EL, FT7-8ELC, FT7-8EM, FT7-8EMC, FT9-4EL, FT9-4ELC, FT9-4ER, FT9-6EL, FT9-6ELC, FT9-6EM, FT9-6EMC, FT9-8EL, FT9-8ELC, FT9-8EM, FT9-8EMC, PM12-9E

MARENO Fryer electric F12C-4E12, F64ER, F64ERP, F66ERP, FQE-40, FQE-40D, FQE-40DSP, FQE-41, FQE-41L, FQE-41L2, FQE-41R, FQE-41RL, FQE-60, FQE-60D, FQE-60DSP, FQE-61, FQE-61L, FQE-61L2, FQE-61R, FQE-61RL, NF74E10T, NF74E10TK, NF74E10TKW, NF74E10TW, NF74E15, NF76E10, NF76E10T, NF76E10TK, NF76E10TKW, NF76E10TW, NF78E15, NF94E10, NF94E15, NF94E22, NF94E222, NF94E222K, NF94E22K,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

NF96E10, NF98E15, NF98E22, NF98E222, NF98E222K, NF98E22K, NFT74E10, OFQE-41, OFQE-61

MARENO Fryer gas F66ER

MARENO Grill electric NG74EP, NG78EP

MARENO Pasta cooker electric NPC74E, NPC76E, NPC78E, NPC94E, NPC96E, NPC98E, PC12C-4E, PC12C-9E, PC64E, PC66E, PC7-4E, PC7-6E, PC7-8E, PC9-4E, PC9-6E, PC9-8E, PC9S-6E, PC9S-8E

MARENO Salamander electric SME-62M, SME-63M, SME-70M

MARENO Self service counter refrigerated SER15A, SER18A

MBM Dishwasher LF56, LF60, LFD50, LFD60, LFDX50, LOD155, LS521

MBM Dishwasher hood type LK100, LK100EM, LK110, LK130, LK600, LK605, LK611, LK611G, LK620, LK621, LK622, LK622I, LK625, LKD130, LKDX110

MBM Dishwasher pull-through LT81, LTD101, LTD131, LTD171, LTD209, LTD216, LTD220

MBM Pan/utensilwashing machines L065, L080, L080H, LOD102, LOD202, LOD302, LOD304, LOD305, LOD402, LOD502, LOD65, LOD80, LOD80H, LOD93, LP00, LP092, LP101, LP105, LP155, LP201, LP301, LP800, LP92, PL93

MODULINE Convection oven electric RB101E, RB101S, RC101M, RC153E, RC153M, RC162M, RM112M, RM156E, RMC20M, RP101E, RRO081E, RRO101E, RRT112E, RRT153M

MORETTI Convection oven electric BAKY 5M, BAKY 5TE, BAKY 5TM, F40E, F50E, F60E, F60E PLUS, F60E RATIO, F60L PLUS, F60L UM PLUS, F80 UM PLUS, F80E, F80E PLUS, F80E RATIO, F80L PLUS

MORETTI Pizza oven electric AHB, AHC, AHK, AMALFI B, AMALFI C, AMALFI K, iB 5TE, iB 5TM, iD 105.105, iD 105.105 MD, iD 105.65, iD 105.65 MD, iD 60.60, iD 60.60 MD, iD 65.105, iD 65.105 MD, iD 72.72, MHB, MHC, MHK, P120E B, P120E C, P120E K, P60E B, P60E C, P60E K, P80E B, P80E C, P80E K, PD 105.105, PD 105.65, PD 60.60, PD 65.105, PIZZY MD 105.105, PIZZY MD 105.65, PIZZY MD 65.105, PM 105.105, PM 105.65, PM 60.60, PM 65.105, RHB, RHC, RHK, S100C, SC100K, SC120C, SC120K, T75E, T97E

MORETTI Pizza oven gas T64E, T75G, T97G, TT98E

SILANOS Dishwasher n50 (N50), N700, N90

SILANOS Dishwasher hood type N1000, N1300

WOLK Dishwasher conveyor type WKR10, WKR120, WKR13, WKR140, WKR160, WKR17, WKR190, WKR22, WKR26, WKR320

WOLK Dishwasher hood type 1200, WKH500, WKH500E, WKH500EP, WKH500P, WKHH50DDP

WOLK Glasswasher/Cupwasher WKH50, WKH50CD, WKH50P

