

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Bicon (inel etansare) pentru teava ø12mm #3020082

Fara TVA: 6,72 Lei

Pret cu TVA: 8,00Lei

Bicon (inel etansare) pentru teava ø12mm #3020082

ø ext. 14 mm - h 6 mm

for model PEL 22-24-25

Compatibil cu:

ALPENINOX 054979

ALPENINOX 050682

ALPENINOX 027478

ALPENINOX 004374

AMBACH 5050503001

ANGELO PO 36Q0030

ANGELO PO 36Q0200

ANGELO PO 36Q1590

ATA K22012

BARON 6A016300

BARON BN6A016300

CAPIC G701026

COLGED RTCU900014

COOKMAX

DESCO 533017900

DEXION RTCU900014

DIHR 10200182

EBERHARDT 212664

ELECTROLUX PROFESSIONAL 054979

ELECTROLUX PROFESSIONAL 050682

ELECTROLUX PROFESSIONAL 027478

ELECTROLUX PROFESSIONAL 004374

ELETTROBAR RTCU900014

EMMEPI 807907

EMMEPI 8C0412

EPMS 1510515

FAGOR U055043000

FAGOR 12008501



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

GEV 101248
GEV 504008
GIORIK 7070025
HOBART RTCU900014
KROMO 10200182
LAINOX MA417810
0200182LAMBER
LASA 2410300
LASA 3205
LOTUS 533017900
LUXIA 10200182
MACH 80001071
MACH 502009100
MARENO 417810
MARENO MA673300
MARENO MA417810
MARENO 673300
MBM RTCU900014
METOS 10200182
METOS 6A016300
METOS BN6A016300
MODULAR 673.006.00
MODULAR 67300600
OLIS 6A016300
OLIS BN6A016300
PALUX
PALUX 959715
PEL 0906
8ROSINOX RX9481097
SAGI 36Q0030
SAGI 36Q0200
SAGI 36Q1590
SILKO 417810
SILKO MA417810
SILKO 0100842
SIT 0.957.007
TECNOINOX RCK7070025
ZANUSSI 7021050682
ZANUSSI 7021027478



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI 80500881

ZANUSSI Z027478

ZANUSSI Z054979

ZANUSSI 0780027478

ZANUSSI 054979

ZANUSSI 0780050682

ZANUSSI 0780054979

ZANUSSI 077000727855

ZANUSSI 050682

ZANUSSI 0515860200

ZANUSSI 0215170716

ZANUSSI 027478

AMBACH Kitchen electric GKE-70, GPSE-80, SIE-105, SIEC-105

AMBACH Kitchen gas GH-45-G, GH-80, GKG-70, GPSG-80, SIG-105, SIGC-105

AMBACH Lava rock grill gas GLG-40-CP, GLG-70, GLG-80, GLG-90, GLG-90-BF

AMBACH Pasta cooker gas CPG-40, GPK-40, GUK-45

AMBACH Pot stove gas GH-120, GH-40, GH-45, GH-45-H, GH-45-H-G, GH-90, GH-90-G, GH-90-H, GH-90-H-G, GH-90IV-D, GHE-120, GHE-80, GHG-120, GHG-80, SI-105

AMBACH Solid top range gas GK-70, GP-45, GP-90-D, GPS-80

ANGELO PO Boiling pan electric 1A1PI2EA, 1D1PI2E, 1D1PI2EA

ANGELO PO Boiling pan gas 1A1PD1G, 1A1PD2G, 1A1PI1G, 1A1PI1GA, 1A1PI2V, 1A1PI2VA, 1D1PD1G, 1D1PD2G, 1D1PI1G, 1D1PI1GA

ANGELO PO Boiling pan steam 1D1PI2V, 1D1PI2VA

ANGELO PO Bratt pan 291BR2G

ANGELO PO Bratt pan electric 1A1BR1E, 1A1BR2E, 1A1BR2EA, 1D1BR1E, 1D1BR2E, 1D1BR2EA, 2A1BR1E, 2A1BR2E, 2D1BR1E, 2D1BR2E, 2D1BR2EA

ANGELO PO Bratt pan gas 191BR1G, 191BR1GA, 191BR2GA, 1A1BR1G, 1A1BR1GA, 1A1BR2G, 1A1BR2GA, 1D1BR1G, 1D1BR1GA, 1D1BR2G, 1D1BR2GA, 1G1BR1G, 1N1BR2G, 1N1BR2GA, 1N1BR3G, 1N1BR3GA, 291BR1G, 291BR1GA, 291BR2GA, 2A1BR1G, 2A1BR1GA, 2A1BR2EA, 2A1BR2G, 2A1BR2GA, 2D1BR1G, 2D1BR1GA, 2D1BR2G, 2D1BR2GA, 2N1BR2G, 2N1BR2GA, 2N1BR3G, 2N1BR3GA

ANGELO PO Convection oven gas FC101, FC241G, FC61, FCV101, FCV101DM, FCV101DS, FCV141, FCV141DM, FCV141DS, FCV241G, FCV241GDM, FCV241GDS, FCV61, FCV61DM, FCV61DS

ANGELO PO Convection oven steam FCV101 CSA, FCV101DM CSA, FCV101DS CSA, FCV141 CSA, FCV141DM CSA, FCV141DS CSA, FCV241G CSA, FCV241GDM CSA, FCV241GDS CSA, FCV401DM CSA, FCV61 CSA, FCV61DM CSA, FCV61DS CSA

ANGELO PO Fry top electric 0G0FT7G, 1G0FT7G

ANGELO PO Fry top gas 090FT1G, 090FT2G, 090FT4G, 090FT5G, 090FT7G, 0G0FT1G VERS 03-2008, 0G0FT2G VERS 03-2008, 0G0FT4G VERS 03-2008, 0G0FT5G VERS 03-2008, 0N0FT4G, 0N0FT5G, 0N0FT7G, 190FT15G,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

190FT1G, 190FT2G, 190FT3G, 190FT42G, 190FT4G, 190FT6G, 190FT72G, 190FT7G, 1A0FT1G, 1A0FT2G, 1A0FT3G, 1A0FT4G, 1A0FT6G, 1D0FT1G, 1D0FT2G, 1D0FT3G, 1D0FT4G, 1D0FT6G, 1G0FT1G VERS 03-2008, 1G0FT2G VERS 03-2008, 1G0FT3G VERS 03-2008, 1G0FT4G VERS 03-2008, 1G0FT6G VERS 03-2008, 1N0FT2G, 1N0FT4G, 1N0FT6G, 1N0FT7G, 2N0FT1G, 2N0FT7G, 6040560, 6042490, 6042500, 6043200

ANGELO PO Fryer electric 091FR1I, 091FR1IA, 091FR1ID, 191FR2I, 191FR2ID

ANGELO PO Fryer gas 091FR1G, 091FR1GD, 091FR1I VERS 03-2012, 091FR1ID VERS 05-2012, 091FR3G, 091FR3GD, 091FR7G, 091FR7G VERS 05-2012, 091FR7GD, 091FR7GS, 091FR7GX, 0A1FR1G VERS 2004, 0A1FR1GD VERS 2004, 0A1FR3G, 0A1FR3GD, 0B1FR1G, 0B1FR1GD, 0D1FR1G, 0D1FR1G VERS 2004, 0D1FR1GD, 0D1FR1GD VERS 2004, 0D1FR3G, 0D1FR3GD, 0G1FR3G, 0G1FR3GD, 0N1FR1G, 0N1FR1GD, 0N1FR1I, 0N1FR1IA, 0N1FR1ID, 0N1FR3G, 0N1FR3GD, 0N1FR7I, 0N1FR7IA, 0N1FR7ID, 0N1FR7IX, 191FR2G, 191FR2GD, 191FR2I VERS 03-2012, 191FR2ID VERS 09-2012, 191FR4G, 191FR4GD, 1A1FR2G, 1A1FR2G VERS 2004, 1A1FR2GD, 1A1FR2GD VERS 2004, 1A1FR4G, 1A1FR4GD, 1D1FR2G, 1D1FR2G VERS 2004, 1D1FR2GD, 1D1FR2GD VERS 2004, 1D1FR4G, 1D1FR4GD, 1G1FR4G, 1G1FR4GD, 1N1FR2G, 1N1FR2GD, 1N1FR2I, 1N1FR2ID, 1N1FR4G, 1N1FR4GD

ANGELO PO Grill gas 090GRG, 2N0GRG

ANGELO PO Kitchen induction 1N1FAW

ANGELO PO Lava rock grill 190GRG

ANGELO PO Pasta cooker 0B1CP1G

ANGELO PO Pasta cooker electric 0A1CP1E, 0D1CP1E

ANGELO PO Pasta cooker gas 0A1CP1G, 0D1CP1G, 0N1CP1GH, 10CP1GA, 10CP1IA, 10NCP1IA, 12CP1GA, 12CP1IA, 18CP2GA, 18CP2IA, 1A1CP1G, 1A1CP2G, 1D1CP1G, 1D1CP2G, 1N1CP2GH

ANGELO PO Pot stove electric 1A1PI2E

ANGELO PO Pot stove gas 0A1FR1G, 0A1FR1GD

BARON Fryer gas 7FRI-G415, 7FRI-G610, 7FRI-G815

BARON Kitchen gas 7PCF-G120, 7PCF-G121, 7PCF-G160, 7PCF-G161, 7PCF-G800, 7PCF-G811, 7PCF-GE120, 7PCF-GE121, 7PCF-GE160, 7PCF-GE161, 7PCF-GE411, 7PCF-GE800, 7PCFL-G120, 7PC-G120, 7PC-G121, 7PC-G160, 7PC-G161, 7PC-G400, 7PC-G411, 7PC-G800, 7PC-G811, 7PCV-G120, 7PCV-G121, 7PCV-G160, 7PCV-G161, 7PCV-G400, 7PCV-G411, 7PCV-G800, 7PCV-G811

CAPIC Electric oven W290251, W292966, W293061, W383061

CAPIC Grill gas W340912

CAPIC Pot stove electric W382966

CAPIC Pot stove gas W290211, W290215, W290225, W290235, W290245, W290255, W290511, W290515, W296513, W296523, W296533, W296543, W380111, W380112, W380121, W380122, W380131, W380132, W380141, W380142, W380151, W380152, W380161, W380162, W380211, W380221, W380231, W380241, W380251, W380261, W380511, W380521, W380531, W380541, W382511, W382551, W382552, W382561, W382562, W382611, W382651, W382652, W382661, W382662, W386513, W386523, W386533, W386543

CAPIC Solid top range gas W290111, W290112, W290115, W290116, W290121, W290122, W290125, W290135, W290136, W290141, W290142, W290411, W290413, W290415, W380411, W380413, W380421, W380423, W380431, W380433, W380441, W380443, W380451, W380461



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

DESCO Fryer gas FRG63, FRG66

DEXION Bain-marie gas LX9GBM4T

DEXION Fry top gas LX9GFT4, LX9GFT9, MG099-05-203, MG099-15-203

DEXION Fryer gas LX9GC4SC, LX9GC4TSC, LX9GC9SC

DEXION Grill gas LX9GPL4P, LX9GPL9P

DEXION Kitchen electric ME099-05-010, ME139-05-010

DEXION Kitchen gas LX9G4SF, LX9G4SFE, LX9G6SFA, LX9GTF, LX9GTF2D, MG099-04-000, MG099-05-010, MG139-04-012, MG139-05-010, MG139-25-010

DEXION Lava rock grill gas MG099-05-308

DEXION Pasta cooker gas MG099-04-318, MG099-05-305, MG459-04-317, MG459-05-305

DEXION Pot stove gas LX9GT2DS, LX9GT2SS, LXGT9, MG099-03-200, MG099-05-200, MG139-05-200, MG459-05-200

DIHR Dishwasher 19ER (LP3 ELETTRONICA)

DIHR Dishwasher conveyor type 77 (CX), 77 (FX)

DIHR Dishwasher pull-through 34 (AX151), 34 (AX151HS), 34HS (AX151HS), 22 (AX160), 23 (AX210), 24 (AX250), 25 (AX300), 25 (AX300LC), 26 (AX380), 26 (AX380LC), 26 (AX400), 27 (AX440), 27 (AX440LC), 28 (AX540), 28 (AX540LC), 71 (BX230), 71G (BX230), 71G (BX230 CON SISTEMA GIRACESTE), 39 (BX280), 72 (BX300), 87 (TX1500), 85 (UX220)

DIHR Pan/utensilwashing machines 18U (LP2), 18ER (LP2 ELETTRONICA), 19U (LP3), 35U (LP4/800), 35ER (LP4/800 ELETTRONICA)

EMMEPI Pasta cooker electric ECP92EB, ECP94EB

FAGOR Bratt pan gas PL-105, PL-105C, PL-105L, PL-110, PL-110C, PL-110L, PL-110L-R, PL-110R

FAGOR Convection oven HG9-00

FAGOR Convection oven electric HVG-20-11

FAGOR Convection oven gas COG-061, COG-101, COG-102, COG-201, COG-202, HE9-00, HGP-10, HGV-10, HGV-10-21, HVG-1011, HVG-10-11, HVG-10-11UL, HVG-1021, HVG-10-21, HVG-10-21UL, HVG-10UL, HVG-2.10, HVG-2.10-11, HVG-2.20, HVG-20, HVG-2011, HVG-20-21, HVG-2-20-11, MFHVG-10, MFHVG-10-21, VG-101, VG-102, VG-201, VG-202, VGT-10, VGT-10-21, VGT-2.20, VGT-20, VGT-20-11, VGT-20-21, VGT-2-20-11, VPG-101, VPG-102, VPG-201, VPG-202

FAGOR Fry top electric FTE-705, FTE-710, FTE9-05, FTE9-10, FTG-705, FTG-705V, FTG-710, FTG-710V

FAGOR Fry top gas FTG9-00, FTG9-05, FTG9-05V, FTG9-10, FTG9-10A, FTG9-10V, FTG9-11, FTG9-11CL, FTG9-11CR, FTG9-11L, FTG9-11R, FTG-C9-05, FTG-C9-10

FAGOR Fryer electric FTE9-00

FAGOR Grill gas BG710I

FAGOR Kitchen gas CG-1002, CG-200, CG-2002, CG-2005, CG-210, CG-300, CG-300S, CG-310, CG-700, CG-711, CG-740, CG-741, CG-761, CG9-41, CG9-51CL, CG9-51CR, CG9-51L, CG9-51R, CG9-60, CG9-61, CG9-82, CGE741 (CGE-741), CGE9-41

FAGOR Lava rock grill gas BG705, BG705I, BG710, BG9-00, BG9-05, BG9-05I, BG9-10, BG9-10I

FAGOR Oven under cooktop electric HE9-10, HE9-20



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FAGOR Oven under cooktop gas CG-1502, CG-210G, CG-310G, CGB-761, HG9-10, HG9-20
FAGOR Pasta cooker gas CPG-705, CPG9-05, CPG9-10
FAGOR Pot stove HP-G-15
FAGOR Pot stove gas CG-710, CG-720, CG9-10, CG9-11, CG9-20, CG9-40
FAGOR Stove camp gas HPG-15
GIORIK Pasta cooker CP1, CP22L, CP2L
GIORIK Pasta cooker electric CP1BM, CP23N, CPE66
GIORIK Pasta cooker gas CPG1, CPG1BM, CPG22L, CPG23N, CPG2L, CPG66
HOBART Bain-marie gas BTGDBM, BTGSBM
HOBART Boiling pan gas HG50I7
HOBART Fry top gas BTGDG, BTGDGC, BTGDGRG, BTGDGRGC, BTGDRG, BTGDRGC, BTGSG, BTGSGL, BTGSRG, BTGSRGC
HOBART Kitchen gas BMG2BSTO, BMG4BO, BMG4BOE, BMG6B2O, BMG6BO, BMG6BOE, BMGSTO
HOBART Lava rock grill gas BTGDLG, BTGDLGF, BTGSLG, BTGSLGF
HOBART Pasta cooker gas BCGDPC, BCGSPC, BMGDPC, BMGSPC, HGC77
HOBART Pot stove gas BTG2B, BTG2BSTL, BTG2BSTR, BTG6B, BTGST
LAMBER Dishwasher 01F, 01F DEP, 040F, 040F DEP, 040F EK, 040F EK ADD, 040F EK DEP, 045F, 045F ADD, 045F DEP, 045F EK, 045F EK ADD, 045F EK DEP, 075F, 075F DEP, DSP4, F85, F85 DEP, F92, F92 DEP, GS350, GS581P, GS6, GS6 EK, GS800, GS900, L21 UL, L25 UL, LS415, NS455, NS455 DEP, NS456, NS456 DEP, PT1500M
LAMBER Dishwasher conveyor type A410
LAMBER Dishwasher hood type 015-24L, 015-24L DY, A240, A410 EK, DSP 5, DSP5, GS25, GS25 EK, L18, L20, L21, L21 EK, L21 EK ADD, L21 RGB, L21 RGB ADD, L24 DY PLUS, L24 EK, L25, L25 DY, L25 EK, L305 CV, L305 DY CV
LAMBER Glasswasher/Cupwasher DSP1, DSP2, DSP26, DSP26 ADD, DSP3, GS4 EK, GS400, GS45 EK, GS5 EK, GS581, MINIBAR, S200, S240, S260, S260 ADD, S260 DEP, S280, S280 ADD, S280 DEP, S280 UL, S400 EK, S400 EK ADD, S460 ADD, S460 EK, S460 EK ADD, S480 EK, S480 EK ADD, S510, S510 ADD, S510 DEP, S510 EK, S510 EK ADD, SL1, SL4, SUPER QS, SUPER QS ADD, SUPER QS DEP
LAMBER Pan/utensilwashing machines LP31 EK, LP31-L EK, LP38 EK, LP38-L EK, LP6 EK, LP6L, LP6-L DY, LP6-L EK, LP8 EK, LP8-L DY, LP8-L EK, P700, PT1500, PT1500 EK, PT1500-L EK, PT850, PT850 EK, PT850-L DY, PT850-L EK
LOTUS Bain-marie gas BM-74G, BM-78G, BM-94G, BM-98G, BMT-64G, BMT-66G, BMT-74G, BMT-78G, BMT-94G, BMT-98G
LOTUS Bratt pan gas BRF-64G, BRF-74G, BRF-78G, BRF-94G, BRF-98G
LOTUS Fry top gas FTTxx-610G, FTTxx-64G, FTTxx-66G, FTTxx-68G, FTTxx-712G, FTTxx-74G, FTTxx-76G, FTTxx-78G, FTTxx-94G, FTTxx-98G, FTxx-4G, FTxx-54G, FTxx-56G, FTxx-6G, FTxx-712G, FTxx-74G, FTxx-76G, FTxx-78G, FTxx-8G, FTxx-916G, FTxx-94G, FTxx-98G
LOTUS Fryer electric FMPG-20
LOTUS Fryer gas F11-54G, F13-64G, F13-74G, F13T-74G, F13T-94G, F18-74G, F2-13-78G, F2-13T-78G,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

F2-13T-98G, F2-18-78G, F2-8-74G, F2-8-94G, F2-8T-66G, F2-8T-74G, F2-8T-94G, F8T-63G, FMPG-30, FP-6G, FPG-20, FPG-30, FQ-4G, FQ-6G, FQM-4G

LOTUS Pasta cooker gas CP-6G

LUXIA Dishwasher pull-through CT160

MACH Dishwasher MS350, MS450, MS450E, MS700, MS700E

MACH Dishwasher hood type MS1100, MS1100E, MS1100P, MS1100T, MS1300, MS1300E, MS1300P, MS1300T, MS900, MS900E, MS900T, MS905

MACH Glasswasher/Cupwasher MB630

MACH Pan/utensilwashing machines MLP140, MLP60, MLP60E, MLP70, MLP80

MARENO Boiling pan PI9-6G5

MARENO Boiling pan gas NPD78G8, NPD96G5, NPD98G10, NPD98G15, NPD98G15A, NPI76G5, NPI78G8, NPI96G5, NPI98G10, NPI98G14, NPI98G14A, PD7-6G5, PD9-6G5, PI7-6G5

MARENO Bratt pan electric NBR7-8EF, NBR7-8EI, NBR912EFM

MARENO Bratt pan gas 94-10KBGI, NBR912GFM, NBR912GIM, NBR98GF, NBR98GFM, NBR98GI

MARENO Convection oven gas NC7FE8G24, NC7FG12G44, NC7FG8G32, NC7FGM12G, NC9FG12G52, NC9FG16G72, NC9FG8G32, NC9FG8G36, NC9FG8G48

MARENO Electric oven C7FE-12G

MARENO Fry top gas FT12-9GLC, FT12-9GM, FT12C-9GL, FT12C-9GM, FT12C-9GTLC, FT12C-9GTMC, FT7-4GL, FT7-4GR, FT7-6GL, FT7-6GLC, FT7-6GM, FT7-6GMC, FT7-8GL, FT7-8GLC, FT7-8GLT, FT7-8GM, FT7-8GMC, FT7-8GMT, NFT11C9GTLC, NFT11C9GTMC, NFT74GTLC, NFT74GTLCO, NFT74GTLO, NFT74GTRC, NFT76GLC, NFT76GMC, NFT76GRC, NFT78GTL, NFT78GTLC, NFT78GTLCO, NFT78GTLO, NFT78GTM, NFT78GTMC, NFT78GTR, NFT78GTRC, NFT94GTLC, NFT94GTLO, NFT94GTRC, NFT98GTL, NFT98GTLC, NFT98GTLO, NFT98GTM, NFT98GTMC, NFT98GTR, PM12-9G

MARENO Fryer gas F12C-4G15, F64G8, F66G8, F7-4G10, F7-4G15, F7-4G6, F7-6G10, F7-8G15, F9-4G10, F9-4G15, F9-4G6, F9-6G10, F9-8G15, F9S-4G15, F9S-8G15, FQC-61, FQG-41, NF11C4G10, NF11C9G10, NF74G10, NF74G15, NF74G8, NF76G10, NF76G8, NF78G15, NF78G15T, NF94G15, NF94G23, NF96G10, NF98G15, NF98G23, NFT74G15T, OFQG-41, OFQG-61

MARENO Grill gas NG94G, NG98G

MARENO Kitchen gas C7-12G, C7-4G, C7FE-8G, C7FG-12G, C7FG-8G, C9-12G, C9-12GS, C9-4G, C9-4GP, C9-4GS, C9FE-12G, C9FE-12GS, C9FE-8G, C9FE-8GS, C9FG-12G, C9FG-12GS, C9FG-16G, C9FG-16GS, C9FG-8G, C9FG-8GP, C9FG-8GS, NC7FE12G36, NC9FG48, NS7FG12GS, NT7FG12G, NT9FG12G, T7FG-12G, T7FG-8G, T9F-4G, T9F-6GS, T9FG-12G, T9FG-8G

MARENO Oven under cooktop gas BF7-8G, BF9-12G, BF9-8G, C7FGM-12G, C9FGM-12G

MARENO Pasta cooker gas NPC74G, NPC76G, NPC78G, NPC94G, NPC96G, NPC98G, PC12C-4G, PC12C-9G, PC7-4G, PC7-6G, PC7-8G, PC9-4G, PC9-6G, PC9-8G, PC9S-6G

MARENO Pot stove gas NC712G36, NC74G12, NC78G24, NC912G44, NC94G16, NC94G20, NC98G28, NC98G40

MARENO Solid top range gas NS78GS, NT7FG8, NT9FG8G, T12-9G, T7-8G, T9-8G, T9FE-4G, T9SB-4G, T9V-4G, T9V-6GS

MBM Bain-marie gas GBM45, GBM477, GBM49T, GBM90, GBM99T, GBMA477, GMB90

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MBM Boiling pan gas G1008, G10098, G100I8, G100I98, G1508, G15098, G150I8, G150I98, G50I77
MBM Fry top gas GFT45L, GFT45R, GFT45RC, GFT49L, GFT49R, GFT49RC, GFT90L, GFT90LR, GFT90LRC, GFT90R, GFT90RC, GFT99L, GFT99LC, GFT99LR, GFT99LRC, GFT99R, GFT99RC
MBM Kitchen gas C4FV, C6FV, G2S, G2S9, G2SA11, G2SAP, G4S, G4SF, G4SF-1, G4SF11, G4SF9, G4SF9-2, G4SFE, G4SFE9, G4SFP, G4SFP2P, G6S, G6S9, G6SF2, G6SF29, G6SFA, G6SFA9, G6SFEA, G6SFEA9, G6SFM, G8S, G8SAP, G8SF2, G8SF2E, G8SF2P
MBM Lava rock grill gas GPL45-P, GPL49-P, GPL90-P, GPL99-P
MBM Oven under cooktop electric GT2SFA, GT2SFEA
MBM Pasta cooker gas GC411-SC, GC45, GC49, GC49T, GC902V, GC911-SC, GC992V, GC992VT
MBM Pot stove gas G4S9, G4S9-48, G4SA11, G4SAP
MBM Solid top range gas GT, GT2SD, GT2SD9, GT2SDF, GT2SDFA9, GT2SS9, GT99, GTA911, GTF, GTF9, GTF911
MODULAR Bratt pan gas 90-120-BRG, 90-120-BRGM, 90-80-BRG, 90-80-BRGM, 94 BRG M, 96 BRG M
MODULAR Convection oven gas GCE10T, GCE6T, GME10T, GME10T-S, GME6T, GME6T-S
MODULAR Electric oven 6CE6T, 6ME6T, 6ME6T-S
MODULAR Fryer electric 90-80-FRG-22
MODULAR Fryer gas 65-40FRG, 65-70-FRG, 90-40-FRG-13, 92-FRG-20, 92-FRG-20-S, 94-FRG-20, 94-FRG-20-S
OLIS Fry top gas 110-90FTTG, 110-90FTTG1-2R, 110-90FTTGC, 110-90FTTGC1-2, 110-90FTTGCR, 110-90FTTGG, 110-90FTTGR, 110-90TFTTG, 110-90TFTTG1-2R, 110-90TFTTGC, 110-90TFTTGC1-2R, 110-90TFTTGCR, 110-90TFTTGR, 72-02FTG, 72-02FTG VAL, 72-02FTGC VAL, 72-02FTGR, 72-02FTGR VAL, 72-02TFTG, 72-02TFTG VAL, 72-02TFTGC VAL, 72-02TFTGR, 72-02TFTGR VAL, 74-02FTG, 74-02FTG VAL, 74-02FTG1-2R, 74-02FTG1-2R VAL, 74-02FTGC VAL, 74-02FTGR, 74-02FTGR VAL, 74-02TFTG, 74-02TFTG VAL, 74-02TFTG1-2R, 74-02TFTG1-2R VAL, 74-02TFTGC VAL, 74-02TFTGR, 74-02TFTGR VAL
OLIS Fryer gas 55-45FRG, 55-90FRG, 72-02FRGM, 73-02FRGM, 74-02FRGM, 7FRI-G415, 7FRI-G610, 7FRI-G815
OLIS Kitchen gas 2FX-PCF, 4FX, 4FX-PCF, 72-02CG, 72-02TCG, 74-02-2CTGG, 74-02CG, 74-02CGE, 74-02CGG, 74-02CTG, 74-02CTGE, 74-02CTGG, 74-02TCG, 74-02TCTG, 76-02-4CTGG, 76-02CG, 76-02CGE, 76-02CGEE, 76-02CGFL, 76-02CGG, 76-02CGGE, 76-02CTG, 76-02CTGG, 76-02CTGGE, 76-02TCG, 76-02TCTGG, 7PCF-G120, 7PCF-G121, 7PCF-G160, 7PCF-G161, 7PCF-G800, 7PCF-G811, 7PCF-GE120, 7PCF-GE121, 7PCF-GE160, 7PCF-GE161, 7PCF-GE411, 7PCF-GE800, 7PCFL-G120, 7PC-G120, 7PC-G121, 7PC-G160, 7PC-G161, 7PC-G400, 7PC-G411, 7PC-G800, 7PC-G811, 7PCV-G120, 7PCV-G121, 7PCV-G160, 7PCV-G161, 7PCV-G400, 7PCV-G411, 7PCV-G800, 7PCV-G811, KR
OLIS Lava rock grill 72-02PLG, 72-02PLG, 74-02PLG, 74-02PLG, 92-04PLG, 92-04TPLG, 94-04PLG, 94-04TPLG
OLIS Pasta cooker gas 92-04CPG, 94-04CPG, 94-10CPG, D92-10CPG
OLIS Solid top range gas 94-04CTG, 94-04CTGE, 94-04CTGG, 94-04CTGGSS, 94-04CTGSS, 94-04TCTG, 94-04TCTGSS, 96-04CTGDX, 96-04CTGEDX, 96-04CTGESX, 96-04CTGGDX, 96-04CTGGSX, 96-04CTGSX, 96-04TCTGDX, 96-04TCTGSX, 98-04CTG, 98-04CTGE, 98-04CTGG, 98-04TCTG
SILKO Bain-marie gas CMG9021, CMG9022, CMG9041, CMG9042
SILKO Bratt pan SG84CRM
SILKO Bratt pan gas SG74IRM, SG84IRM, SG94CRM, SG94IRM

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SILKO Fry top gas BG84GLC, BG84GMC, CGG6220, CGG6220C, CGG6220R, CGG6230, CGG6230C, CGG6230LR, CGG6240, CGG6240C, CGG6240LR, CGG9020-1, CGG9020-3, CGG9021-1, CGG9021-3, CGG9022-1, CGG9022-3, CGG9040-1, CGG9040-3, CGG9040-5, CGG9041-1, CGG9041-3, CGG9041-5, CGG9042-1, CGG9042-3, CGG9042-5

SILKO Fryer FG72115

SILKO Fryer gas EFG92115A, FG74215

SILKO Hot plate gas BG82GLC

SILKO Kitchen CTT7045L

SILKO Kitchen gas CCG10652, CCG10652P, CCG10653, CCG10852, CCG9045-1, CCG90652-1, CCG90653-1, CCG9085-1, CCG90852-1, TG84FPS

SILKO Oven under cooktop electric CCG70653, CCG9085, CCG90852

SILKO Oven under cooktop gas CCG7001P, CCG7045, CCG7045P, CCG70652, CCG70652P, CCG90652, CCG90652P, CCG90653

SILKO Pizza oven gas CFS9050, CFS9055

SILKO Pot stove gas CCG9045, CCG9045P, CG84FPS, CG86FPS, CG86HPS, CG88FPS, CTT70653, CTT70653L

SILKO Solid top range gas CTT1045, CTT7042R, CTT7045R, CTT70652, CTT70652L, CTT9045, CTT90652R

ZANUSSI Bain-marie gas MM/G351 (162801), MM/G701 (162802), MM/G350 (162807), MM/G700 (162808), MM/G350F (162809), MM/G700F (162810), MM/G700E (162811), RM/G350D (172501), RM/G700D (172502), 7BMG03T (172507), 7BMG07T (172508), RM/G350F (172509), XM/G350D (175501), XM/G700D (175502), T35GBM (175507), T70GBM (175508), XM/G350F (175509), XM/G700F (175510), CM/G700 (175517), RMG300 (183000), RM/G300D (183010), RM/G300F (183020), PMR/G300 (183021), RM/G300NL (183030), RM/G700 (183100), RM/G700D (183110), RM/G700F (183120), PRM/G700 (183121), RM/G700NL (183130), RMV/G300 (193000), RMV/G300 (193010), RMV/G300 (193020), PRMV/G300 (193021), RMV/G300 (193030), RMV/G700 (193100), RMV/G700 (193110), RMV/G700 (193120), PRMV/G700 (193121), RMV/G700 (193130), PMG600 (272100), PMG600D (272105), HMS/G400 (293000), HMS/G800 (293004), HMA/G800 (293008), HMS/G400 (293041), HMS/G800D (293042), HMA/G800D (293043), HMS/G400NL (293062), HMS/G800 (293063), HMA/G800NL (293064), HM/G400T (293100), HM/G800T (293105), ZPM/G600 (2CM06B), ZHMA/G400 (2KM01B), ZHMA/G80 (2KM03B), ZHMA/G80 (2KM05B), RM/G300 (2SM02B), RM/G700 (2SM04B), RMV/G300 (2SM12B), RMV/G700 (2SM14B), ZHMA/G40 (770315), ZHMA/G801D (770316), ZHMA/G80 (770317), ZHM/G400 (770536), ZHM/G800 (770537), ZHM/G400 (774200), ZHM/G800 (774201)

ZANUSSI Boiling pan gas RPD/G240 (168130), RPD/G260 (168131), RPI/G260 (168132), XPD/G240 (168530), XPD/G260 (168531), XPI/G260 (168532), JPD/G240 (168730), JPD/G260 (168731), JPI/G260 (168732), MPD/G240 (168930), MPD/G260 (168931), MPI/G260 (168932)

ZANUSSI Bratt pan electric HBR/E820 (201554), HBR/E825 (201555), ZBR/E820 (211554), ZBR/E825 (211555), ABR/E820 (221554), ABR/E825 (221555), HBR/E801 (295022), HBR/E803 (295025), HBR/E804 (295027), HBR/E805UK (295028), HBR/E1003 (295033), HBR/E1013 (295061), HBR/E801 (2KB53B), HBR/E803 (2KB54B), HBR/E804 (2KB55B), HBR/E1003 (2KB57B), HBR/E1013 (2KB58B), E7BREHMNF0 (371107), E7BREHSNF0 (371108), Z7BREHMNF0 (372107), Z7BREHSNF0 (372108), A7BREHMNF0 (373107), A7BREHSNF0 (373108)

ZANUSSI Bratt pan gas RMV/G1C (168038), RMV/G2C (168039), XMV/G1C (168438), XMV/G2C (168439),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MMV/G1C (168838), MMV/G2C (168839), PBR/G2FM (178098), PBR/G2IM (178099), OBR/G2FM (178398), OBR/G2IM (178399), TBR/G2FM (178698), TBR/G2IM (178699), HBR/G820 (201534), HBR/G825 (201535), HBR/G821UK (201574), ZBR/G821 (211556), ZBR/G826 (211557), ABR/G820 (221534), ABR/G825 (221535), HBR/G803 (295003), HBR/G804 (295004), HBR/G803 (295006), HBR/G804 (295008), HBR/G803 (295009), HBR/G805 (295012), HBR/G1003 (295013), HBR/G1003 (295014), HBR/G1004 (295018), HBR/G803 (295051), HBR/G804 (295052), HBR/G1013 (295057), HBR/G803 (2KB03B), HBR/G804 (2KB04B), HBR/G1003 (2KB07B), HBR/G1013 (2KB08B), E7BRGHMNF0 (371103), E7BRGHSNF0 (371104), E7BRGHMNF0 (371180), E7BRGHMNF0 (371181), Z7BRGHMNF0 (372103), Z7BRGHSNF0 (372104), Z7BRGHMNF0 (372180), Z7BRGHMNF0 (372181), A7BRGHMNF0 (373103), A7BRGHSNF0 (373104), A7BRGHMNF0 (373180), A7BRGHMNF0 (373181), HBR/G1004 (770213)

ZANUSSI Convection oven FCZ061EBC (238030), FCZ101EBC (238032), FCZ201EBC (238034), FCZ061GBI (238520), FCZ101GBI (238522), FCZ201GBI (238524), FCFG10160H (240221), FCF/G101/1 (240261), AOS202EABU (260089), AOS202EAFU (260094), AOS061GAEU (260095), AOS101GAEU (260096), AOS102GAEU (260097), AOS201GAEU (260098), AOS202GAEU (260099), AOS061GAAU (260148), AOS101GAAU (260149), AOS102GAAU (260150), AOS201GAAU (260151), AOS202GAAU (260152), AOS061EABU (260165), AOS101EABU (260166), AOS201EABU (260167), AOS061EAFU (260168), AOS101EAFU (260169), AOS201EAFU (260170), AOW101EABU (260573), ECFG201-T (260629), ECFG202-T (260644), AOS061GALQ (260690), AOS101GALQ (260692), AOS201GALQ (260696), AOS061EAMQ (260810), AOS101EAMQ (260812), AOS102EAMQ (260814), AOS201EAMQ (260816), AOS061EABQ (260820), AOS101EABQ (260822), AOS102EABQ (260824), AOS201EABQ (260826), AOS061GAPQ (260870), AOS101GAPQ (260872), AOS102GAPQ (260874), AOS201GAPQ (260876), AOS202GAPQ (260878), AOS061EAH1 (267010), AOS101EAH1 (267012), AOS201EAH1 (267014), AOS061EAN1 (267020), AOS101EAN1 (267022), AOS201EAN1 (267024), AOS061EAC1 (267030), AOS101EAC1 (267032), AOS102EAC1 (267033), AOS201EAC1 (267034), AOS061EAE1 (267040), AOS101EAE1 (267042), AOS201EAE1 (267044), AOS061EAF1 (267050), AOS101EAF1 (267052), AOS201EAF1 (267054), AOS102EAS1 (267063), AOS101EAQ1 (267072), AOS201EAQ1 (267074), AOS061EAM1 (267080), AOS101EAM1 (267082), AOS102EAM1 (267083), AOS201EAM1 (267084), AOS202EAM1 (267085), AOS061EAB1 (267090), AOS101EAB1 (267092), AOS102EAB1 (267093), AOS201EAB1 (267094), AOS202EAB1 (267095), AOS061EAK1 (267100), AOS101EAK1 (267102), AOS102EAK1 (267103), AOS201EAK1 (267104), AOS202EAK1 (267105), AOS061EAT1 (267110), AOS101EAT1 (267112), AOS102EAT1 (267113), AOS201EAT1 (267114), AOS202EAT1 (267115), AOS061GAI1 (267520), AOS101GAI1 (267522), AOS061GAP1 (267550), AOS062GAP1 (267551), AOS101GAP1 (267552), AOS102GAP1 (267553), AOS201GAP1 (267554), AOS202GAP1 (267555), AOS061GAU1 (267560), AOS101GAU1 (267562), AOS102GAU1 (267563), AOS201GAU1 (267564), AOS202GAU1 (267565), AOS061EBH1 (268010), AOS101EBH1 (268012), AOS201EBH1 (268014), AOS061EBN1 (268020), AOS101EBN1 (268022), AOS201EBN1 (268024), AOS061EBC1 (268030), AOS101EBC1 (268032), AOS102EBC1 (268033), AOS201EBC1 (268034), AOS061EBE1 (268040), AOS101EBE1 (268042), AOS201EBE1 (268044), AOS061EBF1 (268050), AOS101EBF1 (268052), AOS201EBF1 (268054), AOS061EBK1 (268100), AOS101EBK1 (268102), AOS102EBK1 (268103), AOS201EBK1 (268104), AOS202EBK1 (268105), AOS061GBI1 (268520), AOS101GBI1 (268522), AOS061ECH1 (269010), AOS101ECH1 (269012), AOS201ECH1 (269014), AOS061ECN1 (269020), AOS101ECN1 (269022), AOS201ECN1 (269024), AOS061ECC1

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(269030), AOS101ECC1 (269032), AOS061ECM1 (269080), AOS101ECM1 (269082), AOS102ECM1 (269083), AOS201ECM1 (269084), AOS061ECB1 (269090), AOS101ECB1 (269092), AOS102ECB1 (269093), AOS201ECB1 (269094), AOS061GCP1 (269550), AOS062GCP (269551), AOS101GCP1 (269552), AOS102GCP1 (269553), AOS201GCP1 (269554), AOS202GCP1 (269555), ACFG10160H (697311), RCF101G (697502), RCF201G (697504), RCFG202 (697516)

ZANUSSI Convection oven electric FCZ061EAA (237000), FCZ101EAA (237002), FCZ102EAA (237003), FCZ201EAA (237004), FCZ202EAA (237005), FCZ061EAH (237010), FCZ101EAH (237012), FCZ201EAH (237014), FCZ061EAN (237020), FCZ101EAN (237022), FCZ201EAN (237024), FCZ061EBA (238000), FCZ101EBA (238002), FCZ102EBA (238003), FCZ201EBA (238004), FCZ202EBA (238005), FCZ061EBH (238010), FCZ101EBH (238012), FCZ201EBH (238014), FCZ061EBN (238020), FCZ101EBN (238022), FCZ201EBN (238024), FCZ061ECA (239000), FCZ101ECA (239002), FCZ102ECA (239003), FCZ201ECA (239004), FCZ202ECA (239005), FCZ061ECH (239010), FCZ101ECH (239012), FCZ201ECH (239014), FCZ061ECN (239020), FCZ101ECN (239022), FCZ201ECN (239024), FCVMG62 (247502), AOS061EA (260450), AOS061EB (260451), AOS101EA (260452), AOS101EB (260453), AOS201EA (260454), AOS201EB (260455), AOS061EA3J (260456), AOS061EB3J (260457), AOS101EA3J (260458), AOS101EB3J (260459), AOS201EA3J (260460), AOS201EB3J (260461), AOS061EA2N (260462), AOS061EB2N (260463), AOS101EA2N (260464), AOS101EB2N (260465), AOS201EA2N (260466), AOS201EB2N (260467), AOS102EA2N (260500), AOS102EB2N (260501), AOS202EA2N (260502), AOS202EB2N (260503), AOS061EA0H (260510), AOS061EB0H (260511), AOS101EA0H (260512), AOS101EB0H (260513), AOS201EA0H (260514), AOS201EB0H (260515), AOS102EA (260516), AOS102EB (260517), AOS202EA (260518), AOS202EB (260519), AOS061EAAQ (260600), AOS061EBAQ (260601), AOS101EAAQ (260602), AOS101EBAQ (260603), AOS102EAAQ (260604), AOS102EBAQ (260605), AOS201EAAQ (260606), AOS201EBAQ (260607), AOS202EAAQ (260608), AOS202EBAQ (260609), AOS061EANQ (260610), AOS061EBNQ (260611), AOS101EANQ (260612), AOS101EBNQ (260613), AOS102EANQ (260614), AOS102EBNQ (260615), AOS201EANQ (260616), AOS201EBNQ (260617), AOS202EANQ (260618), AOS202EBNQ (260619), AOS061EACQ (260620), AOS061EBCQ (260621), AOS101EACQ (260622), AOS101EBCQ (260623), AOS201EACQ (260626), AOS201EBCQ (260627), AOS061EAHQ (260630), AOS061EBHQ (260631), AOS101EAHQ (260632), AOS101EBHQ (260633), AOS201EAHQ (260636), AOS201EBHQ (260637), AOS061EBEQ (260641), AOS061EAA1 (267000), AOS101EAA1 (267002), AOS102EAA1 (267003), AOS201EAA1 (267004), AOS202EAA1 (267005), AOS061EBA1 (268000), AOS101EBA1 (268002), AOS102EBA1 (268003), AOS201EBA1 (268004), AOS202EBA1 (268005), AOS061ECA1 (269000), AOS101ECA1 (269002), AOS102ECA1 (269003), AOS201ECA1 (269004), AOS202ECA1 (269005), EJN102EAA (647003), EJN102EBA (648003), EJN102ECA (649003)

ZANUSSI Convection oven gas XfV/G700 (176502), FCZ061GAG (237500), FCZ101GAG (237502), FCZ102GAG (237503), FCZ201GAG (237504), FCZ202GAG (237505), FCZ061GAD (237510), FCZ101GAD (237512), FCZ102GAD (237513), FCZ201GAD (237514), FCZ202GAD (237515), FCZ061GBG (238500), FCZ101GBG (238502), FCZ102GBG (238503), FCZ201GBG (238504), FCZ202GBG (238505), FCZ061GBD (238510), FCZ101GBD (238512), FCZ102GBD (238513), FCZ201GBD (238514), FCZ202GBD (238515), FCZ061GCG (239500), FCZ101GCG (239502), FCZ102GCG (239503), FCZ201GCG (239504), FCZ202GCG (239505), FCZ061GCD (239510), FCZ101GCD (239512), FCZ102GCD (239513), FCZ201GCD (239514), FCZ202GCD

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(239515), FCFG101/0 (240201), FCFG102-0 (240202), FCFG201-0 (240203), FCFG202-0 (240204), FCF102GMS (240224), FCF201GMS (240225), FCFG102-0T (240262), FCFG101-1J (240264), FCFG102-1J (240265), FCFG101-60 (240269), FCFG20 (241200), FCFG20D (241205), FCFG20F (241210), PFCFG20 (241215), FCFG40 (241300), FCFG41 (241301), FCFG40D (241306), FCFG40F (241310), PFCFG40F (241315), FCFG20J (243210), FCFG20J (243212), FCFG40J (243218), FCFG40J (243220), FCFG20J (243234), FCFG20J (243236), FCFG41J (243238), FCFG40J (243240), FCVG10-2 (245402), FCVG10-4 (245404), FCVG10-ISG (245405), FCVG10-2 (245412), FCVG10-4D (245414), FCVG10-2UK (245442), FCVG10-4UK (245444), FCVG10-2 (245482), FCVG10-4 (245484), FCVG20-2 (246402), FCVG20-4 (246404), FCVG20-2 (246412), FCVG20-4D (246414), FCVG20-2UK (246442), FCVG20-4UK (246444), FCVG20-4 (246482), FCVG20-4D (246484), FCVG10-P (256319), FCVG10PUK (257319), FCVG20-P (260319), AOS061GADL (260520), AOS061GBDL (260521), AOS101GADL (260522), AOS101GBDL (260523), AOS102GBDL (260529), AOS102GADL (260530), AOS202GBDL (260531), AOS202GADL (260532), AOS061GA (260550), AOS061GB (260551), AOS101GA (260552), AOS101GB (260553), AOS201GA (260554), AOS201GB (260555), AOS102GB (260559), AOS102GA (260560), AOS202GB (260561), AOS202GA (260562), AOS061GAGQ (260660), AOS061GBGQ (260661), AOS101GAGQ (260662), AOS101GBGQ (260663), AOS102GAGQ (260664), AOS102GBGQ (260665), AOS201GAGQ (260666), AOS201GBGQ (260667), AOS202GAGQ (260668), AOS202GBGQ (260669), AOS061GADQ (260670), AOS061GBDQ (260671), AOS101GADQ (260672), AOS101GBDQ (260673), AOS102GADQ (260674), AOS102GBDQ (260675), AOS201GADQ (260676), AOS201GBDQ (260677), AOS202GADQ (260678), AOS202GBDQ (260679), AOS061GAIQ (260680), AOS101GAIQ (260682), AOS201GAIQ (260686), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), FCVG20PUK (261319), AOS061GAG1 (267500), AOS101GAG1 (267502), AOS102GAG1 (267503), AOS201GAG1 (267504), AOS202GAG1 (267505), AOS061GAD1 (267510), AOS101GAD1 (267512), AOS102GAD1 (267513), AOS201GAD1 (267514), AOS202GAD1 (267515), AOS061GBG1 (268500), AOS101GBG1 (268502), AOS102GBG1 (268503), AOS201GBG1 (268504), AOS202GBG1 (268505), AOS061GBD1 (268510), AOS101GBD1 (268512), AOS102GBD1 (268513), AOS201GBD1 (268514), AOS202GBD1 (268515), AOS061GCG1 (269500), AOS101GCG1 (269502), AOS102GCG1 (269503), AOS201GCG1 (269504), AOS202GCG1 (269505), AOS061GCD1 (269510), AOS101GCD1 (269512), AOS102GCD1 (269513), AOS201GCD1 (269514), AOS202GCD1 (269515), FCFG201 (2FC04B), FCFG202 (2FC05B), FCFC202 (2FC07B), ZOFCV/G102 (2FM16B), ZOFCV/G104 (2FM18B), ZOFCV/G202 (2FM26B), ZOFCV/G204 (2FM28B), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), JCF/G101/1-1 (697361), JCF/G102/1-1 (697362), JCF/G101/1-2 (697391), JCF/G102/1-2 (697392), RCF10GK (697508), AFCV/G101 (697621), AFCV/G103 (697631), SCO/G10-3 (697635), AFCV/G201 (697641), AFCV/G203 (697651), SCO/G20-3 (697655), FF/G20 (697730), FF/G40 (697740), NCF/G101/1 (724051), NCF/G102/1 (724052), COCO20G (724212), 4236N (724236), FCVG10-ISG (724350), ZOFCF/G20D (770347), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104)

ZANUSSI Dishwasher LS360F (500042), LS360DK (500043), LS365F (500052), LS365 (500053), LS365PH (500054), LS540F (500082), LS540DK (500083), LS541F (500092), LS360D (500110), LS365D (500111), LS360 (500120), LS365 (500121), LS360/63 (500130), LS365/63 (500131), LS367 (500145), LS540 (500484), LSDS51 (500585), LSDS5V (500590), LS540D (500615), LS540/63 (500635), LS541 (500800), LS510 (501010), LS520

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(501020), LS520D (501021), LS520F (501022), LS520M (501028), LS520K (501029), LS521 (501030), LS521D (501031), LS521F (501032), LS521M (501038), LS521K (501039), LS521 (501045), ZAE71D (523140), ZA/E71DXUK (523141), ZAE71S (523143), ZA/E71SXUK (523144), ZA/V71DX (523146), ZA/V71SX (523148), LS360 (5CF05B), LS365F (5CF06B), LS540 (5CF09B), 652120Z (5CF10B), ZLS510 (5CF50B), ZLS520 (5CF51B), ZLS521 (5CF52B), ALS540 (690206), ALLS521 (690208), ALLS520 (690210), ALS510 (690212), C51 (727116), C52 (727120), LS720N (727122), LS520ZD (770400), LS521ZD (770401), LSE720Z (770403), LS510MZ (777202), LS520MZ (777203), LS521MZ (777204)

ZANUSSI Dishwasher hood type LS720F (500322), LSE720DK (500323), LSE720PH (500324), LS860F (500332), LS860DK (500333), LS860PH (500334), LS1080F (500342), LS1080UK (500343), LS1080PH (500344), LSE721F (500352), LS861F (500362), LS1080M (500487), LS1080 (500488), LS1080D (500489), LS1080UK (500492), LS1080/63 (500493), LSE721 (500705), LS720 (500706), LSE720UK (500710), LS721UK (500711), LSE720D (500715), LS860 (500847), LS860 (500848), LS860D (500849), LS860UK (500852), LS861UK (500853), LS860/63 (500854), LS861 (500855), LS10D (504000), LS10 (504001), LS10UKRP (504002), LC100 (504003), LS10F (504008), LS12D (504020), LS12 (504021), LS12UK/RP (504022), LC120 (504023), LS12F (504028), LS860 (5CF11B), LS1080 (5CF12B), HT1200elm (698020), HT1000elm (698021), HYDRA1200 (727020), HYDRA1000 (727021), LS860 (770404), LS1080 (770405), LS860 (777407), LS1080 (777408), LSCE10 (777410), LSCE12 (777420)

ZANUSSI Dishwasher pull-through CT92DXE (503181), CT92SXE (503182), CT92DXEUK (503184), CT92SXEU (503185), CT92DXV (503281), CT92SXV (503282), CT92DXVUK (503284), CT92SXVUK (503285), CT140EDX (504181), CT140ESX (504182), CT140EDXUK (504184), CT140SXEU (504185), CT140VDX (504281), CT140VSX (504282), CT141EDX (505181), CT141ESX (505182), CT141EDUK (505184), CT141ESUK (505185), CT141VDX (505281), CT141VSX (505282), CT142DXE (506181), CT142SXE (506182), CT142DXEUK (506184), CT142SXEU (506185), CT142DXV (506281), CT142SXV (506282), CT190DXE (507181), CT190SXE (507182), CT190DXEUK (507184), CT190SXEU (507185), CT190DXV (507281), CT190SXV (507282), CT191DXE (508181), CT191SXE (508182), CT191DXE (508184), CT191SXEU (508185), CT191DXV (508281), CT191SXV (508282), CT192DXE (509181), CT192SXE (509182), CT192DXEUK (509184), CT192SXEU (509185), CT192DXV (509281), CT192SXV (509282), CT240DXE (510181), CT240SXE (510182), CT240DXEUK (510184), CT240SX (510185), CT240DXV (510281), CT240SXVUK (510282), CT241DXE (511181), CT241SXE (511182), CT241DXEUK (511184), CT241SXEU (511185), CT241DXV (511281), CT241SXV (511282), CT92EDXZ (5CT01B), CT92ESXZ (5CT02B), CT92VDXZ (5CT03B), CT92VSXZ (5CT04B), CT140EDXZ (5CT10B), CT140ESXZ (5CT11B), CT140VDXZ (5CT12B), CT141VSXZ (5CT13B), CT141EDXZ (5CT14B), CT141ESXZ (5CT15B), CT141VDXZ (5CT16B), CT141VSXZ (5CT17B), CT142DXEZ (5CT21B), CT142SXEZ (5CT22B), CT142DXVZ (5CT23B), CT142SXVZ (5CT24B), CT190DXEZ (5CT25B), CT190SXEZ (5CT26B), CT190DXV (5CT27B), CT190SXV (5CT28B), CT191DXE (5CT29B), CT191SXE (5CT30B), CT191DXV (5CT31B), CT191SXV (5CT32B), CT192DXE (5CT41B), CT192SXE (5CT42B), CT192DXV (5CT43B), CT192SXV (5CT44B), CT240DXE (5CT45B), CT240SXE (5CT46B), CT240DXV (5CT47B), CT240SXV (5CT48B), CT241DXE (5CT49B), CT241SXE (5CT50B), CT241DXV (5CT51B), CT241SXV (5CT52B)

ZANUSSI Fry top gas MR/G351 (161308), MR/G701 (161309), MR/G350 (161312), MR/G350F (161313), MR/G350NL (161314), MR/G350E (161315), MR/G360 (161316), MR/G360F (161317), MR/G700 (161318),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MR/G700F (161319), MR/G700NL (161320), MR/G700E (161321), MR/G710 (161322), MR/G710F (161323), MR/G715 (161326), MR/G361 (161334), MR/G711 (161335), MR/G716 (161336), RR/G350D (171260), RR/G700D (171261), 7FTGF3L (171262), 7FTGF3R (171265), RR/G360F (171266), 7FTGF7L (171267), RR/G710 (171269), RR/G710F (171270), RR/G350F (171275), RR/G700F (171276), RR/G716 (171281), XR/G350D (174258), XR/G700D (174259), T35GFT (174262), XR/G350F (174263), T36GFT (174264), XR/G360F (174265), T70GFT (174266), XR/G700F (174267), T70GFT (174268), XR/G710F (174269), XR/G350NL (174274), XR/G700NL (174275), CR/G720 (174290), RRV/G300 (191000), RRV/G300D (191010), RRV/G300 (191030), RRV/G700 (191200), RRV/G700 (191210), RRV/G700 (191230), RRV/G311 (191300), RRV/G711 (191400), KRF/GT2R (200201), KRF/GT2RP (200224), QRF/GT2R (210201), QRF/GT2RP (210224), WRF/GT2R (220201), WRF/GT2RP (220224), HRS/G401 (292200), HRS/G401 (292202), HRS/G401F (292203), HRS/G411 (292220), HRS/G411 (292222), HRS/G411 (292223), HRS/G801 (292240), HRS/G801 (292242), HRS/G801 (292245), HRS/G811 (292260), HRS/G811 (292262), HR/G401T (292480), HR/G411T (292481), HR/G801T (292482), HR/G811T (292483), ZHRS/G401 (2KT01B), ZHRA/G411 (2KT02B), ZHRA/G801 (2KT03B), ZHRA/G811 (2KT04B), RRV/G300 (2ST12B), RRV/G300 (2ST13B), RRV/G700 (2ST14B), RRV/G700 (2ST15B), MBHMBBDOPO (588532), MBHMBBHOPO (588533), MBHNBBDPOPO (588536), MBHNBBDPOPO (588537), MBHOBBDPOPO (588541), MBHAGBDDPO (588667), MBHBGBHDPO (588668), MBHCBDDPO (588671), MBHDBGHDPO (588672), MBHFBHDPO (588676), MCHMAADOPO (589092), MCHMABDOPO (589093), MCHMAAHOPO (589094), MCHMABHOPO (589095), MCHNAADOPO (589100), MCHNABDOPO (589101), MCHNAAHOPO (589102), MCHNABHOPO (589103), MCHOOAHOPO (589110), MCHOABHOPO (589111), MCHAEADDPO (589536), MCHAEADDPO (589537), MCHBEAHDPO (589538), MCHBEBHDPO (589539), MCHCEADDPO (589544), MCHCEBDDPO (589545), MCHDEAHDPO (589546), MCHDEBHDPO (589547), MCHFEAHDPO (589550), MCHFEBHDPO (589551), MCHAFADDPO (589556), MCHAFBDDPO (589557), MCHBFAHDPO (589558), MCHBFBHDPO (589559), MCHCFADDPO (589564), MCHCFBDDPO (589565), MCHDFAHDPO (589566), MCHDFBHDPO (589567), MCHFFAHDPO (589570), MCHFFBHDPO (589571), HRA/G401D (770321), HRA/G411D (770322), HRA/G801D (770323), HRA/G811D (770324), ZHR/G401T (770540), ZHR/G401T (770541), ZHR/G801T (770542), ZHR/G811T (770543), ZHR/G801D (774101)

ZANUSSI Fryer A7FRGD1GFK (373229), A7FRGH2GFK (373230), E9FRGD1J4E (391287), E9FRGD1J4O (391288), E9FRGD1J4P (391289)

ZANUSSI Fryer electric KFH/E1 (200352), KFH/E1ELH (200354), KFH/E1EH (200356), HFH/E430 (201039), HFH/G435 (201051), QFH/E1 (210352), QFH/E1ELH (210354), QFH/E1H (210356), ZFH/E430 (211039), ZFH/G435 (211051), WFH/E1 (220352), WFH/E1ELH (220354), WFH/E1EH (220356), AFH/E435 (221051), E9FRED1JFE (391091), E9FRED1JFO (391092), E9FRED1JFP (391093), Z9FRED1JFE (392091), Z9FRED1JFO (392092), Z9FRED1JFP (392093), A9FRED1JFE (393091), A9FRED1JFO (393092), A9FRED1JFP (393093), MBFGGBDDAO (588685)

ZANUSSI Fryer gas MFR/G350 (161901), MFR/G700 (161902), MFR/G350D (161906), MFR/G700D (161907), MFR/G350F (161912), MFR/G700F (161913), MFR/G350E (161914), MFR/G700E (161915), MFR/G380 (161939), MFR/G381 (161940), BF/G1S07 (162304), BFR/G1S14 (162305), RF/G1S07 (168045), RF/G2D07 (168046), RFR/G1S07 (168047), RFR/G2D07 (168048), RFR/G1S14 (168062), RFR/G2D14 (168063), RF/G1S07 (168186), RF/G2D07 (168187), RFR/G1S07 (168188), RFR/G2D07 (168189), XF/G1S07 (168445), XRF/G2D07 (168446),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

XFR/G1S07 (168447), XFR/G2D07 (168448), XFR/G1S14 (168462), XFR/G2D14 (168463), XF/G1S07 (168586), XF/G2D07 (168587), XFR/G1S07 (168588), XFR/G2D07 (168589), JF/G1S07 (168645), JF/G2D07 (168646), JFR/G1S07 (168647), JFR/G2D07 (168648), JFR/G1S14 (168662), JFR/G2D14 (168663), JF/G1S07 (168786), JF/G2D07 (168787), JFR/G2D07 (168788), JFR/G2D07 (168789), MF/G1S07 (168845), MF/G2D07 (168846), MFR/G1S07 (168847), MFR/G2D07 (168848), MFR/G1S14 (168862), MFR/G2D14 (168863), MF/G1S07 (168986), MF/G2D07 (168987), MFR/G1S07 (168988), MFR/G2D07 (168989), RFR/G350 (171501), RFR/G700 (171502), RFR/G350D (171506), RFR/G700D (171507), RFR/G350F (171512), RFR/G700F (171513), 7FRG03T (171540), M35GFR (174501), M70GFR (174502), XFR/G350D (174506), XFR/G700D (174507), XFR/G350F (174512), XFR/G700F (174513), XFR/G351 (174517), CFR/G381 (174539), T35GFR (174540), CFR/G351 (174931), CFR/G700 (174933), PF/G1S07 (178110), PF/G2D07 (178111), PFR/G1S07 (178112), PFR/G2D07 (178113), PFR/G1S14 (178114), PFR/G2D14 (178115), PFR/G2D14HV (178191), PFR/G1S14HV (178198), OF/G1S07 (178410), OFR/G1S07 (178412), OFR/G2D07 (178413), OFR/G1S14 (178414), OFR/G2D14 (178415), TF/G1S07 (178710), TF/G2D07 (178711), TFR/G1S07 (178712), TFR/G2D07 (178713), TFR/G1S14 (178714), TFR/G2D14 (178715), RFR/G301 (196001), RFR/G301 (196022), RFR/G701 (196101), RFR/G701F (196122), KFR/G1A (200336), KFR/G2B (200337), KFR/G1E (200340), KFR/G2F (200341), KFH/G1 (200351), KFH/G1ELH (200353), KFH/G1EH (200355), KFR/G1T (200361), HFH/G430 (201038), HFR/G430 (201040), HFR/G830 (201041), HFH/G400U (201046), HFH/G401U (201047), HFH/G435 (201050), HFRS/G430 (201052), QFR/G1A (210336), QFR/G2B (210337), QFR/G1E (210340), QFR/G2F (210341), QFH/G1 (210351), QFH/G1ELH (210353), QFH/G1EH (210355), QFR/G1T (210361), ZFH/G430 (211038), ZFR/G430 (211040), ZFR/G830 (211041), ZFH/G435 (211050), ZFRS/G430 (211052), WFR/G1A (220336), WFR/G2B (220337), WFR/G1E (220340), WFR/G2F (220341), WFH/G1 (220351), WFH/G1ELH (220353), WFH/G1EH (220355), WFR/G1T (220361), AFR/G430 (221040), AFR/G830 (221041), AFH/G435 (221050), AFRS/G430 (221052), RFR/G301 (25F12B), RFR/G701 (25F14B), E7FRGD1B00 (371066), E7FRGH2B00 (371067), E7FRGD1BF0 (371068), E7FRGH2BF0 (371069), E7FRGD1GF0 (371070), E7FRGH2GF0 (371071), Z7FRGD1B00 (372066), Z7FRGH2B00 (372067), Z7FRGD1BF0 (372068), Z7FRGH2BF0 (372069), Z7FRGD1GF0 (372070), Z7FRGH2GF0 (372071), Z7FRGH2GFH (372159), A7FRGD1B00 (373066), A7FRGH2B00 (373067), A7FRGD1GF0 (373070), A7FRGH2GF0 (373071), E9FRGD1GF0 (391077), E9FRGH2GF0 (391078), E9FRGD1JF0 (391079), E9FRGH2JF0 (391080), E9FRGD1JFE (391081), E9FRGD1JFO (391082), E9FRGD1JFP (391083), E9FRGD1JFT (391084), Z9FRGD1GF0 (392077), Z9FRGH2GF0 (392078), Z9FRGD1JF0 (392079), Z9FRGH2JF0 (392080), Z9FRGD1JFE (392081), Z9FRGD1JFO (392082), Z9FRGD1JFP (392083), Z9FRGD1JFT (392084), A9FRGD1GF0 (393077), A9FRGH2GF0 (393078), A9FRGD1JF0 (393079), A9FRGH2JF0 (393080), A9FRGD1JFE (393081), A9FRGD1JFO (393082), A9FRGD1JFP (393083), A9FRGD1JFT (393084), A9FRGD1JFK (393210), A9FRGH2JFK (393211), MBFDGBEDPO (588632), MBFHGBDDPO (588687), MCFDEAEDPO (589302), MCFDEBEDPO (589303), MCFDAEDPO (589459), MCFDFBEDPO (589460), MCFHEADDPO (589504), MCFHEBDDPO (589505), MCFHFADDPO (589506), MCFHFBDDPO (589507)

ZANUSSI Grill E9GRTDGC0P (391186), E9GRTHGC0P (391187), E9GRTLGC0P (391188), Z9GRGLGC0P (392066), Z9GRTDGC0P (392186), Z9GRTHGC0P (392187)

ZANUSSI Grill electric KGR/E1 (200243), KGR/E2 (200244), QGR/E1 (210243), QGR/E2 (210244), WGR/E1 (220243), WGR/E2 (220244), E9GREDGCF0 (391075), E9GREHGCF0 (391076), Z9GREDGCF0 (392075), Z9GREHGCF0 (392076), A9GREDGCF0 (393075), A9GREHGCF0 (393076)

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI Grill gas MG/G350D (163705), MG/G700D (163706), MG/G350 (163707), MG/G350E (163708), MG/G350F (163709), MG/G350NL (163710), MG/G700 (163711), MG/G700E (163712), MG/G700F (163713), MG/G700NL (163714), MG/G1050 (163715), MG/G1050F (163716), MG/G1051 (163721), AGG12 (169020), AGG24 (169021), AGG36 (169022), AGG48 (169023), AGG12CE (169058), AGG24CE (169059), AGG36CE (169060), AGG48CE (169061), AGG12 (169119), AGG24 (169120), AGG36 (169121), AGG48 (169122), AGG12CE (169148), AGG24CE (169149), AGG36CE (169150), AGG48CE (169151), RG/G350D (173255), RG/G700D (173256), 7GLG03 (173257), 7GLG07 (173261), 7GLG10 (173265), RG/G300 (182000), RG/G310D (182011), RG/G300F (182020), PRG/G300 (182021), RG/G300N (182031), RG/G700 (182100), RG/G710D (182111), RG/G700F (182120), PRG/G700 (182121), RG/G700N (182131), RGG1000 (182200), RG/G1000 (182220), PRG/G1000 (182221), RGV/G300 (192000), RGV/G310 (192011), RGV/G300 (192020), PRGV/G300 (192021), RGV/G300 (192031), RGV/G700 (192100), RGV/G701D (192111), RGV/G700 (192120), PRGV/G700 (192121), RGV/G700 (192131), RGV/G1000 (192200), RGV/G1000 (192220), PRGV/G100 (192221), KGR/G1 (200241), KGR/G2 (200242), KGR/T1 (200249), KGR/T2 (200250), QGR/G1 (210241), QGR/G2 (210242), QGR/T1 (210249), QGR/T2 (210250), WGR/G1 (220241), WGR/G2 (220242), RG/G300 (2SG02B), RG/G700 (2SG04B), RG/G1000 (2SG06B), RGV/G300 (2SG12B), RGV/G700 (2SG14B), RGV/G1000 (2SG16B), E7GRGDGC0P (371042), E7GRGHGC0P (371043), Z7GRGDGC0P (372042), Z7GRGHGC0P (372043), E9GRGDGCF0 (391063), E9GRGHGCF0 (391064), E9GRGHGC0P (391065), E9GRGLGC0P (391066), E9GRTDGC0P (391197), E9GRTHGCF0 (391198), E9GRGDGC0P (391219), Z9GRGDGCF0 (392063), Z9GRGHGCF0 (392064), Z9GRGHGC0P (392065), Z9GRTDGC0P (392197), Z9GRTHGCF0 (392198), Z9GRGDGC0P (392219), A9GRGDGCF0 (393063), A9GRGHGCF0 (393064)

ZANUSSI Hot cupboard gas HTF/G1210 (298101), HTF/G1210 (298102), ZHTF/G121 (2KS08B), HTF/G1210 (770320)

ZANUSSI Kitchen Z7GCGI6CLA (372216), A7GCGI6CLG (373173), A7GCGI6CLA (373216), O7GCGH4CGO (373219), E9GCGHTCGA (391259), E9GCGHTCGB (391260), E9GCGHTCEA (391261), E9GCGLTC1A (391262), E9GCGLTC1B (391263), E9GCGP8CGA (391272), Z9GCGHTCGA (392259), Z9GCGHTCGB (392260), Z9GCGHTCEA (392261), Z9GCGLTC1A (392262), Z9GCGLTC1B (392263), Z9GCGP8SGA (392272)

ZANUSSI Kitchen electric E7GCGH4CGA (371168), E7GCGH4CEA (371169), E7GCGL6C1A (371171), E7GCGL6C2A (371172), E7GCGI6CLG (371173), E7GCGI6CLA (371216)

ZANUSSI Kitchen gas MCF/G1090 (161059), MCF/G1095 (161071), BCF/G2 (162301), PCV/G2 (178002), PCV/G3 (178003), PCF/G2 (178004), PCF/G3 (178005), PCF/G9 (178006), PCV/G2HV (178190), PCF/G3HV (178192), PCV/G3HV (178194), PCF/G2HV (178195), PCV/G2A (178207), PCV/G3A (178208), PCF/G2A (178209), PCF/G3A (178210), OCV/G2 (178302), OCF/G2 (178304), OCF/G3 (178305), OCF/G9UK (178309), TCV/G2 (178602), TCV/G3 (178603), TCF/G2 (178604), TCF/G3 (178605), TCF/G9 (178606), TCF/G9UK (178609), TCV/G2A (178807), TCV/G3A (178808), TCF/G2A (178809), TCF/G3A (178810), HCF/G810 (200002), HCF/G810D (200008), HCF/G1210D (200009), HCF/G1610D (200010), HCF/G810NL (200013), HCF/G1210 (200031), HCF/G1610 (200033), HCF/G810 (200067), HCF/G1210 (200068), HCF/G1610 (200069), HCF/G811 (200070), HCF/G800U (200077), HCF/G1200U (200078), HCF/G1600U (200079), KCF/G2 (200102), KCF/G3 (200104), KCF/G4 (200105), KCF/T2 (200116), KCF/T3 (200117), KCF/T4 (200118), KCF/G2H (200121), KCF/G3A (200143), KCF/G3H (200145), KCF/G2L (200148), KCF/G2G (200152), KCF/G3G (200154), KCF/G4G (200155), KCF/G2HG

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(200157), KCF/G3AG (200161), KCF/G3HG (200162), KCF/G2LG (200164), ZCF/G810 (210002), ZCF/G810D (210008), ZCF/G1210D (210009), ZHCFG1610D (210010), ZCF/G1210 (210031), ZCF/G1610 (210033), ZCF/G810 (210067), ZCF/G1210 (210068), ZCF/G1610 (210069), ZCF/G811 (210070), QCF/G2 (210102), QCF/G3 (210104), QCF/G4 (210105), QCF/T2 (210116), QCF/T3 (210117), QCF/T4 (210118), QCF/G2H (210121), ACF/G810 (220002), ACF/G810D (220008), ACF/G810NL (220013), ACF/G1210 (220031), ACF/G1610 (220033), OCF/G840 (220055), OCF/G1610 (220060), OCF/G1210 (220061), WCF/G2 (220102), WCF/G3 (220104), WCF/G4 (220105), WCF/G2H (220121), PCG810 (272040), PCG1210 (272041), PCG1610 (272042), PCG810F (272043), PCG1210F (272044), PCG1610F (272045), PCG810D (272060), PCG1210D (272061), PCG1610D (272062), PCG800NL (272064), PCG1200NL (272065), PCG1600NL (272066), PCSG810 (272140), PCSG1210 (272141), PCSG1610 (272142), HCF/G800F (290013), PHCF/G800 (290014), HCFG810 (290120), HCF/G810D (290127), ZPC/G810 (2CC02B), ZPC/G1210 (2CC04B), ZPC/G1610 (2CC06B), E7GCGH4CG0 (371002), E7GCGH4CE0 (371003), E7GCGL6C10 (371005), E7GCGL6C20 (371006), E7GCGH4CEN (371125), E7GCGI6CL0 (371215), Z7GCGH4CG0 (372002), Z7GCGH4CE0 (372003), Z7GCGL6C10 (372005), Z7GCGL6C20 (372006), Z7GCGH4CEN (372125), Z7GCGH4CGA (372148), Z7GCGH4CEA (372149), Z7GCGL6C1A (372151), Z7GCGL6C2A (372152), Z7GCGH4CGH (372155), Z7GCGL6C1H (372157), Z7GCGI6CLG (372173), A7GCGH4CG0 (373002), A7GCGH4CE0 (373003), A7GCGL6C10 (373005), A7GCGH4CEN (373125), E9GCGH4CGL (391004), E9GCGH4CG0 (391005), E9GCGH4CGM (391006), E9GCGH4CE0 (391010), E9GCGL6C10 (391013), E9GCGL6C1M (391014), E9GCGL6CL0 (391015), E9GCGL6CLM (391016), E9GCGP8CG0 (391017), E9GCGH4CEN (391164), E9GCTH4CEM (391195), Z9GCGH4SGL (392004), Z9GCGH4SG0 (392005), Z9GCGH4SGM (392006), Z9GCGH4SE0 (392010), Z9GCGL6S10 (392013), Z9GCGL6S1M (392014), Z9GCGL6SL0 (392015), Z9GCGP8SG0 (392017), Z9GCGH4CGL (392029), Z9GCGH4CG0 (392030), Z9GCGH4CGM (392031), Z9GCGH4CE0 (392032), Z9GCGL6C10 (392035), Z9GCGL6C1M (392036), Z9GCGL6CL0 (392037), Z9GCGP8CG0 (392038), Z9GCGH4CEN (392164), Z9GCTH4YEM (392195), A9GCGH4CG0 (393005), A9GCGH4CGM (393006), A9GCGH4CE0 (393010), A9GCGL6C10 (393013), A9GCGP8CG0 (393017)

ZANUSSI Lava rock grill gas RG/G350F (173259), RG/G700F (173263), RG/G1050 (173266), XG/G350D (176255), XG/G700D (176256), T35GCG (176257), XG/G350E (176258), XG/G350F (176259), XG/G350NL (176260), T70GCG (176261), XG/G700E (176262), XG/G700F (176263), XG/G700NL (176264), T105GCG (176265), XG/G1050F (176266), CG/G701 (176272), HG/G400 (204501), HG/G800 (204502), ZG/G400 (214501), ZG/G800 (214502), AG/G400 (224501), AG/G800 (224502)

ZANUSSI Microwave oven AOW101EA (260153)

ZANUSSI Neutral counter HFS/G800 (205001), ZFS/G800 (215001), AFS/G800 (225001)

ZANUSSI Oven under cooktop gas HCF/G1610 (770310)

ZANUSSI Pan/utensilwashing machines LO/E480 (556100), PLO480/E (556115), LO480EUK (556125), LO480E/63 (556130), LO480VAPORESTD (556200), PLO480V (556215), LO480V/63-60HZ (556230), LO/E250 (557100), PLO250E (557115), LO/E250UK (557125), LO250E/63 (557130), LOPE25 (5LP02B), LOPE48 (5LP04B), LO480Z-VAPORE (5LP06B)

ZANUSSI Pasta cooker EKAROMOOOO (580512), UKDROEOOOO (580936), UKDROEOOOQ (580938), MBKDGDDVO (593117), MCKFEADDVO (593340), MCKFEBDDVO (593341)

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI Pasta cooker electric MCP/E700 (163401), MCP/E700D (163403), 7CPE07P (173001), M70EPC (176001), CCP/E700 (176010), RCPE700 (195550), HCP/E400 (204013), HCP/E410 (204014), HCP/E800 (204015), HCP/E810 (204016), HCPS/E400 (204027), HCPS/E410 (204028), ZCP/E400 (214013), ZCP/E410 (214014), ZCP/E800 (214015), ZCP/E810 (214016), ZCPS/E400 (214027), ZCPS/E410 (214028), ACP/E400 (224013), ACP/E410 (224014), ACP/E800 (224015), ACP/E810 (224016), ACPS/E400 (224027), ACPS/E410 (224028), HCP/E800 (295554), HCP/E801 (295555), HCP/E400 (295564), HCP/E401 (295565), AKAROA0000 (582379), AKAROF0000 (582380), DKAROE0000 (591501), EKAROE0000 (591511), AKAROFU00C (599611), AKAROA000C (599612), ZHCP/E800 (770440), ZHCP/E400 (774430), ZHCP/E401 (774435), HCP/E800 (774440), ZHCP/E801 (774445), RCP/E700 (775220)

ZANUSSI Pasta cooker gas MCP/G700 (163402), MCP/G701 (163404), MCP/G710 (163405), MCP/G711 (163406), MCP/G705 (163407), MCP/G706 (163408), CPG2000Z (163999), RCP/G1S (168140), RCP/G2D (168141), XCP/G1S (168540), XCP/G2D (168541), JCP/G1S (168740), JCP/G2D (168741), MCP/G1S (168940), MCP/G2D (168941), 7CPG07P (173002), RCP/G701 (173003), RCP/G706 (173004), M70GPC (176002), M70GPC (176003), XCP/G706 (176004), CCP/G700 (176009), RCP/G700 (195500), HCP/G410D (204002), HCP/G400 (204005), HCP/G410 (204006), HCP/G800 (204007), HCP/G810 (204008), HCPS/G400 (204025), HCP/G400U (204032), HCP/G800U (204033), ZCP/G400 (214005), ZCP/G410 (214006), ZCP/G800 (214007), ZCP/G810 (214008), ZCPS/G400 (214025), ACP/G400 (224005), ACP/G410 (224006), ACP/G800 (224007), ACP/G810 (224008), ACPS/G400 (224025), HCP/G800 (291504), HCP/G801 (291505), HCP/G400 (291514), HCP/G401 (291515), MBKDG0000 (588626), MCKFE0000 (589294), MCKFE0000 (589295), MCKFF0000 (589451), MCKFF0000 (589452), MCKDE0000 (589473), MCKDE0000 (589474), MCKDF0000 (589477), MCKDF0000 (589478), ZHCP/G400 (774400), ZHCP/G401 (774405), ZHCP/G800 (774410), ZHCP/G801 (774415), RCP/G700 (775200)

ZANUSSI Pot stove gas HI/G400 (200047), HI/G800 (200048), HI/G400N (200056), HI/G800N (200057), HC/G411 (200071), HC/G811 (200072), HC/G1211 (200073), KCF/G3HA (200149), ZC/G411 (210071), ZC/G811 (210072), HC/G1211 (210073), QCF/G3A (210143), QCF/G3H (210145), QCF/G2L (210148), QCF/G3HA (210149), HCSG410 (290000), HCS/G410D (290007), HCS/G400 (290010), PHCS/G400 (290011), HCS/G400F (290012), HCS/G400NL (290015), HCS/G400DK (290018), HCSG810 (290100), HCS/G810D (290107), HCS/G800 (290110), HCS/G800F (290112), HCS/G800 (290113), HCS/G800NL (290115), HCS/G800DK (290118), HCF/GE81 (290130), HCF/GE81 (290136), HCF/GE81 (290137), HCF/G800 (290140), HCF/G800NL (290145), HCF/G800DK (290148), HCF/GE80 (290150), HCF/GE80 (290152), PHCF/GE8 (290153), HCFG1210 (290220), HCF/G1210D (290227), HCF/G1200 (290230), HCF/G1200F (290232), PHCF/G1200 (290233), HCF/G1200N (290235), HCF/G1200D (290238), HCFG1610 (290320), HCF/G1610D (290327), HCF/G1600 (290330), HCF/G1600F (290332), PHCF/G1600 (290333), HCF/G1600N (290335), HCF/G1600D (290338), HC/G410 (290350), HC/G810 (290355), HCA/G410 (2KC02B), HCA/G810 (2KC04B), HCA/G810 (2KC06B), HCF/G1210 (2KC08B), ZHCF/G161 (2KC10B), HCF/GE81 (2KC12B), Z7GCGI6CL0 (372215), Z9GCGL6SLM (392016), HCF/GE81 (770211), HCA/G410D (770306), HCA/G810 (770307), HCA/G810 (770308), HCF/G1210 (770309), HC/G400 (770530), HC/G800 (770531), HCA/G410 (774000), HCA/G810 (774001), HCF/GE81 (774010)

ZANUSSI Potato heater gas RM/G700F (172510)

ZANUSSI Solid top range E9STGH10GA (391264), E9STGLT01A (391265), Z9STGH10GA (392264), Z9STGLT01A

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(392265)

ZANUSSI Solid top range electric E7STGH10GA (371217), E7STGL301A (371218)

ZANUSSI Solid top range gas MT/G700D (162501), MTF/G700D (162502), MTF/G1050D (162503), MT/G700 (162504), MTF/G700 (162505), MTF/G1050 (162507), MTF/GE1050 (162508), MT/G700F (162509), MTF/G700F (162510), MTF/G1055F (162512), MTFGE1055F (162513), MT/G350 (162514), MT/G352 (162515), RT/G700D (172251), RTF/G700D (172252), RTF/G1050D (172253), 7TPG07T (172254), 7TPG07F (172255), 7TPG10F (172257), RT/G700F (172259), RTF/G700 (172260), RTF/G1050 (172262), RT/G352 (172263), RT/G351 (172266), XT/G700D (175251), XTF/G700D (175252), XTF/G1050D (175253), T70GST (175254), M70GST/G (175255), M105GST/GA (175257), XT/G700F (175259), XTF/G700F (175260), XTF/G1050F (175262), XT/G352 (175263), CTFGA702 (175264), CT/G700 (175269), RTV/G720 (177002), RTV/G720 (177022), RTFG720 (177102), RTF/G720F (177122), RTF/G1020 (177302), RTF/G1030 (177307), RTF/G1020F (177322), PTV/G2 (178081), PTF/G2 (178082), PSF/G2 (178083), PSV/G2 (178084), PSF/G3 (178085), PTV/G2N (178201), OTV/G2 (178381), OTF/G2 (178382), OSF/G2 (178383), OSV/G2 (178384), TTV/G2 (178681), TTF/G2 (178682), TSF/G2 (178683), TSV/G2 (178684), TSF/G3 (178685), KS/G2 (200230), KSF/G2 (200231), KSCF/G3 (200232), HT/G800 (202502), HT/G800D (202517), HTF/G810 (202518), HTF/G800D (202519), HTF/G1210 (202522), HTF/G1210D (202523), HT/G800NL (202524), HTF/G800NL (202525), HTFG1210NL (202526), QS/G2 (210230), QSF/G2 (210231), QSCF/G3 (210232), ZT/G800 (212502), ZT/G800D (212517), ZTF/G810 (212518), ZTF/G800D (212519), ZTF/G1210 (212522), ZTF/G1210D (212523), WS/G2 (220230), WSF/G2 (220231), WSCF/G3 (220232), AT/G800 (222502), AT/G800D (222517), ATF/G810 (222518), ATF/G800D (222519), ATF/G1210 (222522), ATF/G1210D (222523), AT/G800NL (222524), ATF/G800NL (222525), ATFG1210NL (222526), OTF/G840 (222540), OT/G800 (222543), OTF/G1210 (222544), PTSG810 (272170), PTFG810 (272180), HTS/G800 (298001), HTS/G800 (298002), HTS/G800 (298003), HTS/G800NL (298005), HTFG800 (298011), HTF/G800 (298012), HT/G800F (298013), HTF/G800 (298016), HT/GE800 (298023), HTF/G1200 (298103), HTF/G1200 (298105), HT/G800 (298110), ZPTF/G1000 (2CS04B), ZPTS/G1000 (2CS14B), ZHTS/G800 (2KS04B), ZHTF/G800 (2KS06B), RTV/G720 (2SS14B), RTF/G720 (2SS16B), RTF/G1020 (2SS17B), RTF/G1030 (2SS18B), E7STGH1000 (371007), E7STGH10G0 (371008), E7STGH30G0 (371009), E7STGL3010 (371010), E7STGH3000 (371011), E7STGL5000 (371012), Z7STGH1000 (372007), Z7STGH10G0 (372008), Z7STGH30G0 (372009), Z7STGL3010 (372010), Z7STGH3000 (372011), Z7STGL5000 (372012), Z7STGH100H (372160), A7STGH1000 (373007), A7STGH10G0 (373008), A7STGH30G0 (373009), A7STGL3010 (373010), A7STGH3000 (373011), E9STGH1000 (391018), E9STGH10G0 (391019), E9STGH30G0 (391020), E9STGL3010 (391021), E9STGH10V0 (391214), E9STGL3C30 (391215), Z9STGH1000 (392018), Z9STGH10G0 (392019), Z9STGH30G0 (392020), Z9STGL3010 (392021), Z9STGH10V0 (392214), Z9STGL3C30 (392215), A9STGH1000 (393018), A9STGH10G0 (393019), A9STGL3010 (393021), ZHTA/G800 (770318), ZHTF/G800 (770319), ZHT/G800 (770538), ZHT/G800 (774600)

ZANUSSI Stove camp gas FT/G2 (774100)

ZANUSSI 0214051400

ZANUSSI 0214051401

ZANUSSI 004374

ZANUSSI 214051400



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI 50027478002
ZANUSSI 554054979
ZANUSSI 7070025
ZANUSSI 50054979005
ZANUSSI 50050682009
ZANUSSI 4370000727855
ZANUSSI 727855
ZANUSSI 481851516
ZANUSSI 7CHG727855
ZANUSSI 71054979
ZANUSSI 71050682
ZANUSSI 71027478
ZANUSSI 7D727855
ZANUSSI 71004374

