



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

## **Aprinzator piezoelectric diametru ø18mm #3001020**

Fara TVA: 25,21 Lei

Pret cu TVA: 30,50Lei

Aprinzator piezoelectric diametru ø18mm #3001020

a ø18mm hole is required for the assembly

faston M ø2.4mm

Compatibil cu:

ALPENINOX 0A2127

ALPENINOX 059251

AMBACH 5060408640

ANGELO PO 3166990

ANGELO PO 3005580

ATEL 68CT011

BARON 6A041105

BARON 826630020

BARON BN6A041105

BARTLETT 3836-125

BARTSCHER 01936100

BERTO'S 32188200

COOKMAX

EBERHARDT 235113

ELECTROLUX PROFESSIONAL 0A2127

ELECTROLUX PROFESSIONAL 059251

EMMEPI 8C1850

EMMEPI 809476

EPMS

EPMS 1410013

EPMS 1410014

FAEMA 3991130359

FB FABA PR3G047

FIAMMA RST 4.0.100.0070

FIMAR CO3119

GAYC 12410100

GEV 100009

GIGA E30400



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

GIGA M02100

ICOS I13919

ICOS 39.200.02618

ICOS 52504700

ICOS 16132

IMEGAS 310

INDESIT 483286009198

INDESIT C00497226

JEMI 210075

KÜPPERSBUSCH

LAINOX MA1936100

LOTUS 537002800+

MARENO MA1936100

MARENO 1936100

METOS 6A041105

METOS BN6A041105

MODULAR 672.006.00

NAYATI GS3720

OLIS 6A041105

OLIS BN6A041105

PARRY PIEZO1SP1

RM GASTRO 401540000

SAGI 3166990

SAGI 3005580

SILKO 1936100

SILKO 0100895

SILKO 0100898

TECNOINOX RC00128000

VISCOUNT X07183

WHIRLPOOL 483286009198

WHIRLPOOL C00497226

WHIRLPOOL 159251

WHIRLPOOL 202127

ZANUSSI 0A2127

ZANUSSI 059251

AMBACH Boiling pan gas GKM-50, GKS-100, GKS-150, GKS-60, GKS-80

AMBACH Bratt pan electric GKH-90, GKM-90

AMBACH Convection oven gas GB-90

AMBACH Fry top gas GBP-40-C, GBP-40-L, GBP-40-R, GBP-45-C, GBP-45-I, GBP-45-L, GBP-45-R, GBP-80-1-2-2LR,

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

GBP-80-C, GBP-80-I, GBP-80-L, GBP-80-LR, GBP-80-R, GBP-90-1-2LR, GBP-90-C, GBP-90-I, GBP-90-L, GBP-90-LR,  
GBP-90-R, GUG-40, GUG-40-B, GUG-40-C, GUG-70, GUG-70-1-2LR, GUG-70-B, GUG-70-C, GUG-70-LR

AMBACH Fryer gas GF1-40, GF2-60-ECO, GY1-40, GY2-70

AMBACH Kitchen electric GKE-70, GPSE-80, SIE-105, SIEC-105

AMBACH Kitchen gas GH-80, GKG-70, GPSG-80, SIG-105, SIGC-105

AMBACH Lava rock grill gas GLG-40-CP, GLG-70, GLG-80, GLG-90, GLG-90-BF

AMBACH Pasta cooker gas CPG-40, GPK-40, GUK-45

AMBACH Pot stove gas GHG-120, GHG-80, GRG-105, GRG-70, GRGC-105, SI-105

AMBACH Solid top range gas GK-70, GP-45, GP-90-D, GPS-80

ANGELO PO Bain-marie gas 0A0BMG, 0D0BMG, 1A0BMG, 1D0BMG

ANGELO PO Boiling pan gas 1A1PD1G, 1A1PD2G, 1A1PI1G, 1A1PI1GA, 1A1PI2G, 1A1PI2GA, 1D1PD1G,  
1D1PD2G, 1D1PI1G, 1D1PI1GA, 1D1PI2G, 1D1PI2GA, 1G1PD1G, 1G1PI1G, 2A1PD3G, 2A1PI3G, 2D1PI3G

ANGELO PO Bratt pan gas 0G1BR3G, 1G1BR1G, 1G1BR3G

ANGELO PO Fry top electric 0G0FT7G, 1G0FT7G, 1M0FT5G

ANGELO PO Fry top gas 0A0FT1G, 0A0FT2G, 0A0FT4G, 0A0FT5G, 0B0FT1G, 0B0FT2G, 0B0FT4G, 0B0FT5G,  
0D0FT1G, 0D0FT2G, 0D0FT4G, 0D0FT5G, 0G0FT1G, 0G0FT1G VERS 03-2008, 0G0FT2G, 0G0FT2G VERS  
03-2008, 0G0FT4G, 0G0FT4G VERS 03-2008, 0G0FT5G, 0G0FT5G VERS 03-2008, 0M0FT1G, 0M0FT2G,  
0M0FT4G, 0M0FT5G, 1A0FT1G, 1A0FT2G, 1A0FT3G, 1A0FT4G, 1A0FT6G, 1B0FT1G, 1B0FT2G, 1B0FT3G,  
1B0FT4G, 1B0FT6G, 1D0FT1G, 1D0FT2G, 1D0FT3G, 1D0FT4G, 1D0FT6G, 1G0FT1G, 1G0FT1G VERS 03-2008,  
1G0FT2G, 1G0FT2G VERS 03-2008, 1G0FT3G, 1G0FT3G VERS 03-2008, 1G0FT4G, 1G0FT4G VERS 03-2008,  
1G0FT6G, 1G0FT6G VERS 03-2008, 1M0FT1G, 1M0FT2G, 1M0FT3G, 1M0FT4G, 1M0FT6G, 2M0FT1G, 2M0FT2G,  
2M0FT3G, 2M0FT4G, 2M0FT5G, 2M0FT6G

ANGELO PO Fryer gas 0G0FR5G, 0G0FT7E, 0G1FR7G, 0M0FR1G, 1G0FR6G, 1M0FR2G

ANGELO PO Grill gas 1M0GL1G, 1M0GL2G, 1M0GL3G

ANGELO PO Hot plate gas 0A0FAVA, 0D0FAVA, 1A0TP0

ANGELO PO Kitchen electric 1M1FA1E

ANGELO PO Kitchen gas 1A0FAB, 1A1FAAG, 1A1FABG, 1A1FASG, 1A1TP0G, 1B1FAS2G, 1B1FASG, 1D0FAB,  
1D1FAAG, 1D1FABG, 1G1FABG, 2A1FAAG, 2A1TP3G, 2A1TP6G, 2A1TPSG, 2D1FA1G, 2D1FA4G, 2D1FAAG,  
2D1FAS2G, 2D1FASG, 2D1TP3G, 2D1TP6G, 2D1TPSG, 2G1FABG, 2G1FACG, 3A1FA1G, 3A1FA4G, 3A1FAAG,  
3A1FASG, 3D1FA1G, 3D1FA4G, 3D1FAAG, 3D1FASG

ANGELO PO Lava rock grill 0M0GL1G, 0M0GL2G, 1G0GRG

ANGELO PO Lava rock grill gas 0A0GRG, 0D0GRG, 1A0GRG, 1D0GRG

ANGELO PO Pasta cooker 0B1CP1G

ANGELO PO Pasta cooker gas 0A1CP1G, 0D1CP1G, 0G1CP1G, 0G1CP1G VERS 2004, 191CP1GA, 1A1CP1G,  
1A1CP1GA, 1A1CP2G, 1D1CP1G, 1D1CP1GA, 1D1CP2G, 1G1CP1G, 1G1CP1G VERS 2004, 1G1CP2G, 1G1CP2G  
VERS 2004, MCF20, MCF40

ANGELO PO Pot stove electric 1D0TP0

ANGELO PO Pot stove gas 0M0FA1, 1A0FA2, 1A0FA5, 1A0FAS2, 1A1FA1G, 1A1FA2G, 1A1FA4G, 1A1FA5G,  
1A1FAS2G, 1B0FAS2, 1D0FA2, 1D0FA5, 1D0FAS2, 1D1FA1G, 1D1FA2G, 1D1FA4G, 1D1FA5G, 1D1FAS2G,

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

1D1FASG, 1G1FA0G, 1G1FA0GV, 1G1FAPG, 1G1TP0G, 1M0FA1, 2A0FAS2, 2A1FA1G, 2A1FA4G, 2A1FAS2G, 2A1FASG, 2D0FAS2, 2G1FA0G, 2G1FA0GV, 2G1FADG, 2G1FADGV, 2G1FAPG, 2G1TP3G, G1FAGS, G1FAGST

ANGELO PO Pot stove glass-ceramics 1G0TP0

ANGELO PO Salamander electric 60SM

ANGELO PO Solid top range gas1A1TP0G VERS 2002, 1B0TP0, 1D1TP0G, 1D1TP0G VERS 2002, 2A1TPCG, 2D1TPCG

BARON Boiling pan gas 7NP-G50, 7NP-GI50, 9PF-G100, 9PF-G150, 9PF-GI100, 9PF-GI150

BARON Bratt pan gas 7BR-G100, 7BR-G105, 7BRS-G100, 7BRS-G105, 9BRG-100, 9BRG-105, 9BRG-125

BARON Fry top gas 7FT-G400, 7FT-G410, 7FT-G800, 7FT-G810, 7FT-G820, 7FTTF-G800, 7FTTF-G805, 7FTTF-G820, 7FTTF-G825, 7FTTF-GE800, 7FTTF-GE805, 7FTTF-GE820, 7FTTF-GE825, 7FTT-G400, 7FTT-G405, 7FTT-G410, 7FTT-G415, 7FTT-G800, 7FTT-G805, 7FTT-G810, 7FTT-G815, 7FTT-G820, 7FTT-G825, 7FTTV-G400, 7FTTV-G405, 7FTTV-G410, 7FTTV-G415, 7FTTV-G800, 7FTTV-G805, 7FTTV-G810, 7FTTV-G815, 7FTTV-G820, 7FTTV-G825, 7FTV-G400, 7FTV-G410, 7FTV-G800, 7FTV-G810, 7FTV-G820, 9FT-G400, 9FT-G410, 9FT-G800, 9FT-G810, 9FT-G820, 9FTTF-G800, 9FTTF-G820, 9FTTF-GE800, 9FTTF-GE805, 9FTTF-GE820, 9FTTF-GE825, 9FTT-G400, 9FTT-G405, 9FTT-G410, 9FTT-G415, 9FTT-G800, 9FTT-G805, 9FTT-G810, 9FTT-G815, 9FTT-G820, 9FTT-G825, 9FTTV-G400, 9FTTV-G405, 9FTTV-G410, 9FTTV-G810, 9FTTV-G815, 9FTV-G400, 9FTV-G410, 9FTV-G820

BARON Fryer gas 7FRI-G415, 7FRI-G610, 7FRI-G815

BERTO'S Bain-marie gas G12F4H9-FGP, G9BM4M, SG9BM4M

BERTO'S Boiling pan gas G9P10D, G9P10DA, G9P10I, G9P10IA, G9P15D, G9P15DA, G9P15I, G9P15IA, LXG9P15I, SG9P10D, SG9P10DA, SG9P10I, SG9P10IA, SG9P15D, SG9P15DA, SG9P15I, SG9P15IA

BERTO'S Bratt pan gas G6F6-T-A6, G7BM4M, G7BR8

BERTO'S Fry top gas G6FL3B, G6FL3B-CR, G6FL3B-SX, G6FL3M, G6FL3M-CR, G6FL3M-SX, G6FL6B, G6FL6B-CR, G6FL6B-SX, G6FL6M, G6FL6M-CR, G6FL6M-SX, G6FM6B, G6FM6M, G6FR3B, G6FR3M, G6FR6B, G6FR6M, G7FL4B, G7FL4B-CR, G7FL4B-SX, G7FL4M, G7FL4M-CR, G7FL4M-SX, G7FL8B-2, G7FL8B-2-CR, G7FL8B-2-SX, G7FL8M-2, G7FL8M-2-CR, G7FL8M-2-SX, G7FM8B-2, G7FM8M-2, G7FR4B, G7FR4M, G7FR4M-2, G7FR8B-2, G7FR8M-2, G9FL4M, G9FL4M-CPD, G9FL4M-CR, G9FL4M-SX, G9FL8M-2, G9FL8M-2-CPD, G9FL8M-2-CR, G9FL8M-2-SX, G9FM8M-2, G9FR4M, G9FR8M-2, LXG9FL4-CPD, LXG9FL4-CR, LXG9FL8-2-CPD, LXG9FL8-2-CR, LXG9FM8-2-CPD, LXG9FM8-2-CR, LXG9FR4-CPD, LXG9FR4-CR, LXG9FR8-2-CPD, LXG9FR8-2-CR, SG7FL4B-CPD, SG7FL8B-2-CPD, SG7FM8B-2-CPD, SG7FR4B-CPD, SG7FR8B-2-CPD, SG9FL4M, SG9FL4M-CR, SG9FL8M-2, SG9FL8M-2-CPD, SG9FL8M-2-CR, SG9FM8M-2, SG9FM8M-2-CR, SG9FR4M, SG9FR4M-CR, SG9FR8M-2, SG9FR8M-2-CR

BERTO'S Fryer electric S9GL20-20M

BERTO'S Fryer gas 6GL18B, 6GL18M, 9GL15-15M, 9GL15M, 9GL20-20M, 9GL20M, GL10-10B, GL10-10M, GL10B, GL10M, GL15-15M, GL15M, GL20-20M, GL20M, GL30B, GL30M, GL7-7M, GL8-8B, GL8-8M, GL8B, GL8M, S9GL20M

BERTO'S Grill gas G7WG40M, G7WG80M, SG7WG80M

BERTO'S Kitchen electric G7F6E-FG-A6, G7F6-T, G9TP-FG, SG9F4P-FG, SG9F8P-2FG

BERTO'S Kitchen gas G12F4P9-FGP, G6F4PW-FG1, G6F6PW-FG1, G6F6PW-T, G7F4E-FG, G7F4P2FB, G7F4P-FG,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

G7F4P-FG-AF2, G7F4PW-FG, G7F4PW-FG1, G7F6E-FG, G7F6E-T, G7F6-FG, G7F6P-FG, G7F6P-FG-AF2, G7F6P-T, G7F6P-T-AF2, G7F6PW-FG, G7F6PW-FG1, G7F6PW-T, G7T4P2FB, G7T4P2F-FG1, G7T4P2FM, G7T4P2FM-FG1, G7T4P4FB, G7T4P4F-FG, G7T4P4F-FG1, G7T4P4FM, G7T4P4FM-FG1, G7TP2F-FG, G7TP2F-FG1, G7TP2FM, G7TP2F-T, G7TP-FG, G7TP-FG1, G7TPM, G7TPM-FG1, G9F4-FG, G9F4P-FG, G9F4P-FG-AF2, G9F6-FG, G9F6P-FG, G9F6P-FG-AF2, G9F6P-T, G9F6P-T-AF2, G9F6-T, G9F8-2FG, G9F8P-2FG, G9F8P-2FG-AF2, G9TP2F-FG, G9TP2F-FG1, G9TP2FM, G9TP2F-T, G9TP4F-FG, G9TP4FM, G9TPF-FG, G9TP-FG1, G9TPM, SG7WG40M, SG9F4-FG, SG9F6-FG, SG9F6P-FG, SG9F6P-T, SG9F8-2FG, SG9FL4M-CPD, SG9TP2F-FG, SG9TP2FM, SG9TP4F-FG, SG9TP-FG, SG9TPM

BERTO'S Lava rock grill gas G6PL60B, G6PL60M, G9PL40B, G9PL40M, G9PL80B, G9PL80M, LXG9PL40, LXG9PL80, PLG40B, PLG40BE, PLG40M, PLG40ME, PLG80B, PLG80BE, PLG80M, PLG80ME, SG9PL40M, SG9PL80M

BERTO'S Pasta cooker gas CPG40, CPG40E, CPG80, CPG80E, G6CP6, G9CP40, G9CP40-2, G9CP80, G9CP80-2, LXG9CP40, SG9CP40, SG9CP80

BERTO'S Pot stove gas G6F4PW-FG1-AE

BERTO'S Solid top range gas LXG9TP

FAEMA Coffee machine DUE A, DUE S

FB FABA Crêpe pan gas G400D, G400S

FIAMMA RST Bain-marie gas BMF 11G, BMF 1-1G, BMF 11G SL, BMF 1-1G SP, BMF 6CG

FIAMMA RST Fry top gas PGF 1200, PGF 300, PGF 300-F, PGF 600, PGF 600-F, PGF 800, PGF 800-F, PPGF 600, PPGF 600 CRD, PPGF 600 CRD-T, PPGF 800, PPGF 800 CRD, PPGF 800 CRD-T, PPGF 800CRD, PPGF M 600, PPGF M 600 CRD, PPGF M 800, PPGF M 800 CRD, PPGF M-600 CRD-T, PPGF M-800 CRD-T

FIMAR Lava rock grill gas B115, B50, B80

GIGA Bain-marie gas CBG4, KB4G, OPB4G, SKB40G, TB40G

GIGA Boiling pan gas CPG, CPGI, KP10G, KP10GA, KP15G, KP15GA, KPI10G, KPI10GA, KPI15G, KPI15GA, OPP10G, OPP10GA, OPP15G, OPP15GA, OPPI10G, OPPI10GA, OPPI15G, OPPI15GA

GIGA Bratt pan gas CBRG, CBRG8, CBRGIN

GIGA Fry top gas M7FT4GL, M7FT4GR, M7FT6GL, M7FT6GLR

GIGA Fryer gas CF10DG8M, CF10G4M, CFG15, CFG15D, EM74FRG, EM92FRG, KFG1, KFG15, KFG15D, KFG2, KFG20, KFG20D, M7F4G, M7F8G, OPFG1, OPFG15, OPFG15D, OPFG2, OPFG20, OPFG20D, SKF10GM, SKF20GM, TF10GM, TF20GM

GIGA Grill electric CFTG8, CFTG8C, CFTG8LR, CFTG8R, TT80G

GIGA Grill gas CFTG1, CFTG1C, CFTG1R, CFTG2, CFTG22, CFTG2C, CFTG2C2, CFTG2LR, CFTG2R, CFTG2R2, CFTG3, CFTG3C, CFTG3LR, CFTG3R, CFTG4, CFTG4C, CFTG4R, CFTG6, CFTG62, CFTG6C, CFTG6C2, CFTG6LR, CFTG6R, CFTG6R2, SKT1G, SKT1GC, SKT1GR, SKT2G, SKT2G2, SKT2GC, SKT2GC2, SKT2GLR, SKT2GR, SKT2GR2, SKT3G, SKT3GC, SKT3GLR, SKT40G, SKT40GC, SKT40GR, SKT60G, SKT60G2, SKT60GC, SKT60GC2, SKT60GLR, SKT60GR, SKT60GR2, SKT80G, SKT80GC, SKT80GLR, TT1G, TT1GC, TT1GR, TT2G, TT2G2, TT2GC, TT2GC2, TT2GLR, TT2GR, TT2GR2, TT3G, TT3GC, TT3GLR, TT40G, TT40GC, TT40GR, TT60G2, TT60GC2, TT60GLR, TT60GR2, TT80GC, TT80GLR

GIGA Kitchen electric C4FZFCEP, C6FZFCE, C6FZFCEP, C6FZFCEPV, C6FZFCEV, C6FZFE, C6FZSFCEP, SKC80G

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

GIGA Kitchen gas C2FTPFPG, C2TP2FGP, C4FFCGP, C4FFEP, C4FFGP, C4FZFCE, C4FZFCG, C4FZFCGP, C4FZFE, C4FZFEP, C4FZFG, C4FZFGP, C4FZSFCEP, C4FZSFCGP, C4FZSFEP, C6FFCGP, C6FFEP, C6FFGAP, C6FFGP, C6FZFCG, C6FZFCGP, C6FZFCGPV, C6FZFCGV, C6FZFEP, C6FZFG, C6FZFGA, C6FZFGAP, C6FZFGP, CC120CG, CC80G, CC81CG, CCG120CE, CCG80E, CCG81CE, CCTPFG8, K2FTPFCE, K2FTPFCEG, K2FTPFE, K2FTPFG, K4FFG, K4FSFCG, K4FSFG, K4FZFCG, K4FZFG, K4FZSFCG, K4FZSFG, K6FFG, K6FFGA, K6FZFCG, K6FZFG, K6FZFGA, K8FFG, K8FZFCG, K8FZFG, KTPFCE, KTPFCG, KTPFE, KTPFG, M74FFXE, M74FFXG, M74FMPFG, M74FMPFXG, M74FPFG, M74FPFXG, M76FFXE, M76FFXG, M76FMPFG, M76FMPFXG, M76FPFG, M76FPFXG, SK4FZFCGP, SK6FZFCGP, SKC40G, T6FZ

GIGA Lava rock grillCPLG1, CPLG2, KPLG1, KPLG2, M7PL1G, M7PL2G, OPPLG1, OPPLG2, SKPL1G, SKPL2G, TPLG1, TPLG2

GIGA Oven under cooktop gas CN14FGA

GIGA Pasta cooker gas CCPG4, CCPG82, EM94CPG, KCP4, KCP82, OPCP4, OPCP82, SKCP60G

GIGA Pot stove gasC2FZ, C2FZP, C4FZ, C4FZP, C4FZSP, C6FZ, C6FZP, CCTP8, I2FZ, I4FZ, M62F, M64F, T2FZ, T2FZP, T4FZ, T4FZP, T6FZP, TTP8

JEMI Fry top gasFRT72Y, FRT75

MARENO Bain-marie gas B7-4G, B9-4G, NB7-4G, NB7-8G, NB9-4G, NB9-8G

MARENO Boiling pan PI9-6G5

MARENO Boiling pan gas PD7-6G5, PD9-6G5, PD9-8G10, PD9-8G15, PD9S-8G10, PI7-6G5, PI9-8G10, PI9-8G14

MARENO Bratt pan gas BR7-8GF, BR7-8GI, BR9-12GFM, BR9-12GIM, BR9-8GF, BR9-8GFM, BR9-8GI, BR9-8GIM, BRG-40, BRG-40G

MARENO Convection oven gas NC7FE8G24, NC7FG12G44, NC7FG8G32, NC7FGM12G, NC9FG12G52, NC9FG16G72, NC9FG8G32, NC9FG8G36, NC9FG8G48

MARENO Electric oven C7FE-12G

MARENO Fry top gas BIG-40, FT12-9GLC, FT12-9GM, FT12C-9GL, FT12C-9GM, FT12C-9GTLC, FT12C-9GTMC, FT64GL, FT64GLC, FT64GR, FT66GL, FT66GLC, FT66GM, FT66GMC, FT68GL, FT68GLC, FT68GM, FT68GMC, FT7-4GL, FT7-4GR, FT7-6GL, FT7-6GLC, FT7-6GM, FT7-6GMC, FT7-8GL, FT7-8GLC, FT7-8GLT, FT7-8GM, FT7-8GMC, FT7-8GMT, FTG-40B, FTG-40BLC, FTG-40BR, FTG-60B, FTG-60BLC, FTG-60BR, FTG-60BRR, FTG-80B, FTG-80BLC, FTG-80BR, NFT74GL, NFT74GR, NFT74GTLC, NFT74GTLCO, NFT74GTLO, NFT74GTRC, NFT76GL, NFT76GLC, NFT76GM, NFT76GMC, NFT76GR, NFT76GRC, NFT78GL, NFT78GM, NFT78GR, NFT78GTL, NFT78GTLC, NFT78GTLCO, NFT78GTLO, NFT78GTM, NFT78GTMC, NFT78GTR, NFT78GTRC, NFT94GL, NFT94GR, NFT94GTLC, NFT94GTLO, NFT94GTRC, NFT96GL, NFT96GM, NFT98GL, NFT98GM, NFT98GR, NFT98GTL, NFT98GTLC, NFT98GTLO, NFT98GTM, NFT98GTMC, NFT98GTR, PM12-9G

MARENO Fryer gasF12C-4G15, F64G8, F66G8, F7-4G10, F7-4G15, F7-4G6, F7-6G10, F7-8G15, F9-4G10, F9-4G15, F9-4G22, F9-4G22K, F9-4G6, F9-6G10, F9-8G15, F9-8G22, F9-8G22K, F9S-4G15, F9S-4G22, F9S-4G22K, F9S-8G15, F9S-8G22, F9S-8G22K, FQC-61, FQG-41, NF74G10, NF74G15, NF74G8, NF76G10, NF76G8, NF78G15, NF78G15T, NF94G15, NF94G23, NF96G10, NF98G15, NF98G23, NFT74G15T, OFQG-41, OFQG-61

MARENO Grill gasNG94G, NG98G

MARENO Kitchen gasC7-12G, C7-4G, C7FE-8G, C7FG-12G, C7FG-8G, C9-12G, C9-12G5, C9-4G, C9-4GP, C9-4GS,

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

C9FE-12G, C9FE-12GS, C9FE-8G, C9FE-8GS, C9FG-12G, C9FG-12GS, C9FG-16G, C9FG-16GS, C9FG-8G, C9FG-8GP, C9FG-8GS, CFG-120, NC11FE13G44, NC11FE9G28, NC11FE9G40, NC11FEC13G44, NC11FG13G56, NC11FG9G40, NC11FG9G52, NC11FGC13G56, NC7FE12G36, NC9FG48, NS7FG12GS, NT7FG12G, NT9FG12G, OCFG-120, T7FG-12G, T7FG-8G, T9F-4G, T9F-6GS, T9FG-12G, T9FG-8G

MARENO Lava rock grill gas GL7-4G, GL7-8G, GL9-4G, GL9-8G, GPL64G, GPL68G, NGPL74G, NGPL78G, NGPL94G, NGPL98G, OPLG-40, OPLG-80, PLG-40, PLG-80

MARENO Oven under cooktop gas BF7-8G, BF9-12G, BF9-8G, C7FGM-12G, C9FGM-12G

MARENO Pasta cooker gas PC12C-4G, PC12C-9G, PC7-4G, PC7-6G, PC7-8G, PC9-4G, PC9-6G, PC9-8G, PC9S-6G

MARENO Pot stove gas NC1113G40, NC1113G44, NC114G16, NC114G20, NC119G28, NC119G40, NC11C9G16, NC11C9G20, NC712G36, NC74G12, NC78G24, NC912G44, NC94G16, NC94G20, NC98G28, NC98G40

MARENO Solid top range gas NS78GS, NT7FG8, NT9FG8G, T12-9G, T7-8G, T9-8G, T9FE-4G, T9SB-4G, T9V-4G, T9V-6GS

MODULAR Bain-marie gas 110-50-BMG, 110-90-BMG, 90-40-BMG, 90-80-BMG, 92-BMG, 94-BMG

MODULAR Boiling pan gas 90-80-PGC-150, 90-80-PGD-100, 90-80-PGDA-100, 90-80-PGDA-150, 90-80-PGI-100, 90-80-PGI-150, 90-80-PGIA-100, 90-80-PGIA-150, 94-PG-100-D, 94-PG-100-DA, 94-PG-100-DAS, 94-PG-100-DS, 94-PG-100-I, 94-PG-100-IA, 94-PG-100-IAS, 94-PG-100-IS, 94-PG-150-D, 94-PG-150-DA, 94-PG-150-I, 94-PG-150-IA

MODULAR Bratt pan gas 94 BRG M, 96 BRG M

MODULAR Fry top gas 110-50-FTG, 110-50-FTG-CR, 110-50-FTRG, 110-50-FTRG-CR, 60-30-FTG, 60-30-FTRG, 60-60-FTG, 60-60-FTRG, 60-60-FTRRG, 65-40-FTG, 65-40-FTG-CR, 65-40-FTGS, 65-40-FTRG, 65-40-FTRG-CR, 65-70-FTG, 65-70-FTG-CR, 65-70-FTGS, 65-70-FTRG, 65-70-FTRG-CR, 65-70-FTRRG, 65-70-FTRRG-CR, 90-40-FTG, 90-40-FTRG, 90-80-FTG, 90-80-FTG-CR, 90-80-FTRG, 90-80-FTRG-CR, 90-80-FTRRG, 90-80-FTRRG-CR, 92-FTG-L, 94-FTG-L, 94-FTG-LC, 94-FTG-LR, 94-FTG-LRC, 94-FTG-R, 94-FTG-RC

MODULAR Fryer gas 60-30-FRG, 60-60-FRG, 65-40FRG, 65-70-FRG, 70-FRGS, 90-FRGS, 92-FRG-20, 92-FRG-20-S, 94-FRG-20, 94-FRG-20-S

MODULAR Grill gas 65-40GRG, 65-70GRG

MODULAR Kitchen gas 110-130-CFG, 110-170-CFG, 110-90-CFG, 65-110-CFG, 65-110-CFGG, 65-70-CFG, 65-70-CFGE, 70-110-CFG, 70-70-CFG, 90-120-CFG, 90-120-TPFG, 90-160-CFG, 94-CFG, 96-CFG

MODULAR Lava rock grill 65-40GRL, 65-70GRL, 70-40GRL, 70-70GRL, 90-40-GRL, 90-80-GRL, 92-PLG

MODULAR Pasta cooker gas 110-50-CPG, 70-40CPG, 70-70CPG, 90-40-CPG, 90-80-CPG, 92-CPG, 92-CPG-S, 94-CPG, 94-CPG-S

MODULAR Pot stove gas 60-30-PCG, 60-60-PCG, 60-90-PCG, 60-90-PCG-P, 65-40-PCG, 65-70-PCG

MODULAR Salamander electric SG-GN1-1

MODULAR Solid top range gas 110-90-TPFG, 110-90-TPG, 65-110TPFG, 65-70TPFG, 65-70TPG, 70-110TPFG, 70-70TPFG, 70-70TPG, 90-80-TPFG, 90-80-TPG, 94-TPFG, 94-TPG

OLIS Bain-marie gas 110-45CBG, 110-45TCBG

OLIS Boiling pan gas 74-02NPGD, 74-02NPGI, 7NP-G50, 7NP-GI50, 9PF-G100, 9PF-G150, 9PF-GI100, 9PF-GI150

OLIS Bratt pan gas 7BR-G100, 7BR-G105, 7BRS-G100, 7BRS-G105, 96-04KBGC, 9BRG-100, 9BRG-105, 9BRG-125

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

OLIS Fry top gas 110-90FTTG, 110-90FTTG1-2R, 110-90FTTGC, 110-90FTTGC1-2, 110-90FTTGCR, 110-90FTTGE, 110-90FTTGG, 110-90FTTGR, 110-90TFTTG, 110-90TFTTG1-2R, 110-90TFTTGC, 110-90TFTTGC1-2R, 110-90TFTTGCR, 110-90TFTTGR, 72-02FTG, 72-02FTG VAL, 72-02FTGC VAL, 72-02FTGR, 72-02FTGR VAL, 72-02TFTG, 72-02TFTG VAL, 72-02TFTGC VAL, 72-02TFTGR, 72-02TFTGR VAL, 74-02FTG, 74-02FTG VAL, 74-02FTG1-2R, 74-02FTG1-2R VAL, 74-02FTGC VAL, 74-02FTGR, 74-02FTGR VAL, 74-02TFTG, 74-02TFTG VAL, 74-02TFTG1-2R, 74-02TFTG1-2R VAL, 74-02TFTGC VAL, 74-02TFTGR, 74-02TFTGR VAL, 7FT-G400, 7FT-G410, 7FT-G800, 7FT-G810, 7FT-G820, 7FTTF-G800, 7FTTF-G820, 7FTTF-G825, 7FTTF-GE800, 7FTTF-GE805, 7FTTF-GE820, 7FTTF-GE825, 7FTT-G400, 7FTT-G405, 7FTT-G410, 7FTT-G800, 7FTT-G805, 7FTT-G810, 7FTT-G815, 7FTT-G820, 7FTT-G825, 7FTTV-G400, 7FTTV-G405, 7FTTV-G410, 7FTTV-G415, 7FTTV-G800, 7FTTV-G805, 7FTTV-G810, 7FTTV-G815, 7FTTV-G820, 7FTTV-G825, 7FTV-G400, 7FTV-G410, 7FTV-G800, 7FTV-G810, 7FTV-G820, 92-04FTG, 92-04FTGR, 92-04FTTG, 92-04FTTGC, 92-04FTTGCR, 92-04FTTGR, 92-04TFTG, 92-04TFTGR, 92-04TFTTG, 92-04TFTTGC, 92-04TFTTGCR, 92-04TFTTGR, 94-04FTG, 94-04FTG1-2R, 94-04FTGR, 94-04FTTG, 94-04FTTG1-2R, 94-04FTTGC, 94-04FTTGC1-2R, 94-04FTTGCR, 94-04TFTG, 94-04TFTG1-2R, 94-04TFTGR, 94-04TFTTG, 94-04TFTTG1-2R, 94-04TFTTGC, 94-04TFTTGC1-2R, 94-04TFTTGCR, 94-10FTG, 94-10FTG1-3R, 94-10FTGR, 94-10TFTG, 94-10TFTG1-3R, 94-10TFTGR, 9FT-G400, 9FT-G410, 9FT-G800, 9FT-G810, 9FT-G820, 9FTTF-G800, 9FTTF-G820, 9FTTF-GE800, 9FTTF-GE805, 9FTTF-GE820, 9FTTF-GE825, 9FTT-G400, 9FTT-G405, 9FTT-G410, 9FTT-G415, 9FTT-G800, 9FTT-G805, 9FTT-G810, 9FTT-G815, 9FTT-G820, 9FTT-G825, 9FTTV-G400, 9FTTV-G405, 9FTTV-G410, 9FTTV-G415, 9FTTV-G800, 9FTTV-G805, 9FTTV-G810, 9FTTV-G815, 9FTV-G400, 9FTV-G410, 9FTV-G810, 9FTV-G820

OLIS Fryer gas 55-45FRG, 55-90FRG, 7310-10FRG, 7FRI-G415, 7FRI-G610, 7FRI-G815, 9215-10FRG, 9223-10FRG

OLIS Grill gas 94-10 TFTTGC1-3R

OLIS Kitchen gas 110-135CG, 110-135CG2P, 110-135CGE, 110-135CGE2P, 110-135CGEE, 110-135CGEE2P, 110-135CGEEP, 110-135CGEP, 110-135CGG, 110-135CGG2P, 110-135CGGE, 110-135CGGE2P, 110-135CGGEP, 110-135CGGP, 110-135CGP, 110-135TCG, 110-135TCG2P, 110-135TCGP, 110-45CG, 110-45CG1P, 110-45CGP, 110-45TCG, 110-45TCG1P, 110-45TCGP, 110-90CG, 110-90CG1P, 110-90CGE, 110-90CGE1P, 110-90CGEP, 110-90CGG, 110-90CGG1P, 110-90CGGP, 110-90CGP, 110-90TCG, 110-90TCG1P, 110-90TCGP, 2FX-PCF, 4FX, 4FX-PCF, 72-02CG, 72-02TCG, 74-02-2CTGG, 74-02CG, 74-02CGE, 74-02CGG, 74-02CTG, 74-02CTGE, 74-02CTGG, 74-02TCG, 74-02TCTG, 74-10CGG, 76-02-4CTGG, 76-02CG, 76-02CGE, 76-02CGEE, 76-02CGFL, 76-02CGG, 76-02CGGE, 76-02CTG, 76-02CTGG, 76-02CTGGE, 76-02TCG, 76-02TCTGG, 92-04CG, 92-04CG1P, 92-04CGP, 92-04TCG, 92-04TCG1P, 92-04TCGP, 94-04CCG, 94-04CG, 94-04CG1P, 94-04CGE, 94-04CGE1P, 94-04CGEP, 94-04CGG, 94-04CGG1P, 94-04CGGP, 94-04CGP, 94-04TCG, 94-04TCG1P, 94-04TCGP, 94-10CGG, 96-04CG, 96-04CG2P, 96-04CGE, 96-04CGE2P, 96-04CGEE2P, 96-04CGEEP, 96-04CGEP, 96-04CGFL, 96-04CGFL2P, 96-04CGFLP, 96-04CGG, 96-04CGG2P, 96-04CGGE, 96-04CGGE2P, 96-04CGGEP, 96-04CGGP, 96-04CGP, 96-04TCG, 96-04TCG2P, 96-04TCGP, 98-04CG, 98-04CG2P, 98-04CGE, 98-04CGE2P, 98-04CGEP, 98-04CGG, 98-04CGG2P, 98-04CGGP, 98-04CGP, 98-04TCG, 98-04TCG2P, 98-04TCGP

OLIS Lava rock grill 72-02PLG, 72-02TPLG, 74-02PLG, 74-02TPLG, 92-04PLG, 92-04TPLG, 94-04PLG, 94-04TPLG, 94-10PLG, 94-10TPLG

OLIS Pasta cooker gas 55-45CPG, 55-90CPG, 72-02CPG, 74-02CPG, 92-04CPG, 94-04CPG

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

OLIS Pot stove gas 40SCG4S, 60SCG4S

OLIS Solid top range gas 110-90CTG, 110-90CTGE, 110-90CTGG, 110-90TCTG, 94-04CTG, 94-04CTGE, 94-04CTGG, 94-04CTGGSS, 94-04CTGSS, 94-04TCTG, 94-04TCTGSS, 96-04CTGDX, 96-04CTGEDX, 96-04CTGESX, 96-04CTGGDX, 96-04CTGGSX, 96-04CTGSX, 96-04TCTGDX, 96-04TCTGSX, 98-04CTG, 98-04CTGE, 98-04CTGG, 98-04TCTG

SILKO Bain-marie electric BMG40, BMG60

SILKO Boiling pan gas CPD70150, PG8AD10, PG8AD15, PG8AI10, PG8AI15, PG8ND10, PG8ND15, PG8NI10, PG8NI15

SILKO Bratt pan gas SG74IRM

SILKO Fry top gas BG84GLC, BG84GLL, BG84GLR, BG84GMC, CGG6220, CGG6220C, CGG6220R, CGG6230, CGG6230C, CGG6230LR, CGG6240, CGG6240C, CGG6240LR, CGG7020, CGG7020C, CGG7020R, CGG7021, CGG7021C, CGG7021R, CGG7040, CGG7040C, CGG7040LR, CGG7040LRC, CGG7040R, CGG7041, CGG7041C, CGG7041LR, CGG7041LRC, CGG7041R, CRG7022, EBG72AR

SILKO Fryer FG72115

SILKO Fryer gas CNG50150, CNG50160, CNG70130, CNG70160, CNG70230, CNG90130, CNG90140, CNG90160, CNG90240, EFG92115A, FG72206, FG74215, FG82122, FG82206, FG84222, FG92122, FG92206, FG94222, FGY2122, FGY4222

SILKO Hot plate gas BG82GLC, BG82GLL, BG82GRR

SILKO Kitchen gas CCG6020, CCG6052, CG64FPS, TG84FPS, TG84GPS

SILKO Lava rock grill gas CRG6220, CRG6240

SILKO Oven under cooktop electric CCG60653

SILKO Pasta cooker electric CPI70150, DG72128, DG74228, DG82140, DG84240, DG92142, DG94242

SILKO Pasta cooker gas CNG90160S

SILKO Pot stove gas CFF1GPA, CFF1GPS, CFF1TPA, CFF1TPS, CFF2TPA, CFF2TPS, CFF3TPA, CFF3TPS

TECNOINOX Bain-marie gas BM35G0, BM35G7, BM35GG6, BM4FG7, BM4G7, BM70G0, BM70G7, BM70GG6, BM8FG7, BM8G7

TECNOINOX Boiling pan gas P8DG7, P8IG7

TECNOINOX Bratt pan gas BS8FG7, BS8IG7

TECNOINOX Fry top gas ETC35G7, ETC70G7, ETL35G7, ETL70G7, ETR35G7, ETR70G7, ETRR70G7, FTC35G0, FTC35G7, FTC35GG6, FTC4FG7, FTC4FG9, FTC4G7, FTC4G9, FTC70G0, FTC70G7, FTC70GG6, FTC8FG7, FTC8FG9, FTC8G7, FTC8G9, FTL35G0, FTL35G7, FTL35GG6, FTL4FG7, FTL4FG9, FTL4G7, FTL4G9, FTL70G0, FTL70G7, FTL70GG6, FTL8FG7, FTL8FG9, FTL8G7, FTL8G9, FTR35G0, FTR35G7, FTR35GG6, FTR4FG7, FTR4FG9, FTR4G7, FTR4G9, FTR70G0, FTR70G7, FTR70GG6, FTR8FG7, FTR8FG9, FTR8G7, FTR8G9, FTRR70G0, FTRR70G7, FTRR70GG6, FTRR8FG7, FTRR8G7

TECNOINOX Fryer gas FR35G0, FR35GG6, FR43FG7, FR48FG7, FR70G0, FR70GG6, FR83FG7, FRS35G7, FRS70G7, FRV43FG7, FRV83FG7

TECNOINOX Gas oven BF120GE

TECNOINOX Grill gas GD4FG7, GD4FG9, GD8FG7, GD8FG9

TECNOINOX Kitchen gas EEF105G7, EEF105GG7, EEF105GV7, EEF70GG7, EEF70GV7, EF105GG7, EF12GG9,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

EF70GG7, EF8GG9, EFX105GGE7, EFX12GG9, EFX12GGE9, P2FG16GG9, PF105G0, PF105G6, PF105GG0, PF105GG7, PF105GGG6, PF12GG7, PF5G0, PF5G6, PF5GG0, PF5GGG6, PF70G0, PF70G6, PF70GG0, PF70GG7, PF70GGG6, PF8GG7, PF8SGG7, PFG12GG7, PFG12GG9, PFG8GG7, PFG8GG9, PFG8SGG7, PFG8SGG9, PFL105G0, PFL105G6, PFL105GG0, PFL105GGG6, PFL5G0, PFL5G6, PFL5GG0, PFL5GGG6, PFP105GG7, PFP12GG7, PFP70GG7, PFP8GG7, PFP12GG7, PFP12GG9, PFP8GG7, PFX105GG7, PFX105GGE7, PFX12GG7, PFX12GGE7, PFXG12GG7, PFXG12GG9, PFXG12GGE7, PFXG12GGE9, PPF5G0, PPF5GG0, PPF5GG6, PPF5GGG6, PPFL5G0, PPFL5GG0, PPFL5GG6, PPFL5GGG6

TECNOINOX Lava rock grill gas GG350, GG700, GR35G0, GR35G7, GR35GG6, GR70G0, GR70G7, GR70GG6

TECNOINOX Pasta cooker gas CP35G0, CP35G7, CP35GG6, CP4FG7, CP4FG9, CP70G7, CP8FG7, CP8FG9

TECNOINOX Pot stove gas EEC105FG7, EEC105G7, EEC35FG7, EEC35G7, EEC70FG7, EEC70G7, PC105G0, PC105G6, PC35G0, PC35G6, PC5G0, PC5G6, PC70G0, PC70G6, PCPG12FG9, PCPG12G9, PP5G0, PP5GG6

TECNOINOX Salamander SG

TECNOINOX Solid top range gas PP8FG9, PP8G9, PPC70G7, PPC8FG7, PPC8G7, PPF70GG7, PPF8GG7, PPF8GG9

WHIRLPOOL Fryer electric ADN625

WHIRLPOOL Kitchen gas 854460001000 (ADN600), 854460101000 (ADN601), ADN602, 854460401000 (ADN604), 854460501000 (ADN605), 851235001000 (AGB350WP), 851235301000 (AGB353WP), 851235401000 (AGB354WP), 851235601000 (AGB356WP), 851235701000 (AGB357WP), 851248301000 (AGB483WP), 851248401000 (AGB484WP), 851248501000 (AGB485WP), 851248601000 (AGB486WP), 851248801000 (AGB488WP), 851248901000 (AGB489WP), 851249001000 (AGB490WP), 851249101000 (AGB491WP), 851249201000 (AGB492WP), 851249301000 (AGB493WP), 851249901000 (AGB499WP), 851250001000 (AGB500WP), 851257901000 (AGB579WP), 851258001000 (AGB580WP), 851258101000 (AGB581WP), 851258301000 (AGB583WP), 851258401000 (AGB584WP), 851258901000 (AGB589WP), 851259001000 (AGB590WP)

ZANUSSI Bain-marie gas MM/G350F (162809), MM/G700F (162810), MM/G700E (162811), RM/G350D (172501), RM/G700D (172502), RM/G350F (172509)

ZANUSSI Boiling pan gas MPN/GI760D (162201), MPN/GD760F (162203), MPN/GI760F (162205), RPN/GD760F (172006), RPN/GI760F (172007), HPN/GI815D (202004), HPN/GI816 (202008), ZPN/GI816D (212008), APN/GI816D (222008)

ZANUSSI Bratt pan electric E7BREHMNF0 (371107), E7BREHSNF0 (371108), Z7BREHMNF0 (372107), Z7BREHSNF0 (372108), A7BREHMNF0 (373107), A7BREHSNF0 (373108)

ZANUSSI Bratt pan gas E7BRGHMNF0 (371103), E7BRGHSNF0 (371104), E7BRGHMNF0 (371180), E7BRGHMNF0 (371181), Z7BRGHMNF0 (372103), Z7BRGHSNF0 (372104), Z7BRGHMNF0 (372180), Z7BRGHMNF0 (372181), A7BRGHMNF0 (373103), A7BRGHSNF0 (373104), A7BRGHMNF0 (373180), A7BRGHMNF0 (373181)

ZANUSSI Convection oven NULL (697500)

ZANUSSI Convection oven gas XGV/G700 (176502), FCV/G6L3TOWNGAS (240101), FCV/G6L3 (240102), FCV/G6L3JAP (240116), NULL (240200), NULL (240222), NULL (240260), NULL (240263), NULL (260700), NULL (260722), NULL (697300), JCF/G6-1 (697360), JCF/G6-2 (697390), NULL (697506), ACV/G6C3 (697810), NCV/G6L2 (724242)

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

ZANUSSI Fry top electric E7FTEDSS00 (371052), E7FTEDSR00 (371053), E7FTEHSS00 (371054), E7FTEHSP00 (371055), E7FTEDCS00 (371059), E7FTEHCS00 (371060), Z7FTEDSS00 (372052), Z7FTEDSR00 (372053), Z7FTEHSS00 (372054), Z7FTEHSP00 (372055), Z7FTEDCS00 (372059), Z7FTEHCS00 (372060), Z7FTEDSSQ0 (372188), Z7FTEDSRQ0 (372189), Z7FTEHSSQ0 (372190), Z7FTEHSPQ0 (372191), Z7FTEDCSQ0 (372195), Z7FTEHCSQ0 (372196)

ZANUSSI Fry top gas MR/G350F (161313), MR/G350NL (161314), MR/G350E (161315), MR/G360F (161317), MR/G700F (161319), MR/G700NL (161320), MR/G700E (161321), MR/G710F (161323), RR/G350D (171260), RR/G700D (171261), RR/G720D (171263), RR/G360F (171266), RR/G710F (171270), 7FTGC1L (171272), RR/G1070D (171274), RR/G350F (171275), RR/G700F (171276), PRV/G1FL (178051), PRV/G1FR (178052), PRV/G1CL (178053), PRV/G2FL (178054), PRV/G2FM (178055), PRV/G2CL (178056), PRV/G2FLHV (178204), HR/G403D (200523), HR/G803D (200524), HR/G814D (200526), HR/G403NL (200543), HR/G803NL (200544), HR/G414D (200578), HTR/G411 (202507), HTR/G811 (202508), ZR/G403 (210517), ZR/G803 (210518), ZR/G413 (210519), ZR/G814 (210522), ZR/G403D (210523), ZR/G803D (210524), AR/G403NL (220543), AR/G803NL (220544), E7FTGDSS00 (371029), E7FTGDSR00 (371030), E7FTGHSS00 (371031), E7FTGHSP00 (371032), E7FTGDSS00 (371033), E7FTGDSR00 (371034), E7FTGHSS00 (371035), E7FTGHSP00 (371036), E7FTGDSC00 (371037), E7FTGHCS00 (371038), E7FTGDSC00 (371039), E7FTGHCS00 (371040), E7FTGHCP00 (371041), Z7FTGDSS00 (372029), Z7FTGDSR00 (372030), Z7FTGHSS00 (372031), Z7FTGHSP00 (372032), Z7FTGDH00 (372033), Z7FTGDSR00 (372034), Z7FTGHSS00 (372035), Z7FTGHSP00 (372036), Z7FTGDSC00 (372037), Z7FTGHCS00 (372038), Z7FTGDSC00 (372039), Z7FTGHCS00 (372040), Z7FTGHCP00 (372041), Z7FTGDSS0H (372158), A7FTGDSS00 (373029), A7FTGDSR00 (373030), A7FTGHSS00 (373031), A7FTGHSP00 (373032), A7FTGDSC00 (373037), A7FTGHCS00 (373038), A7FTGHCP00 (373041), E9HOGD1000 (391022), E9HOGH1000 (391023), E9FTGDSS0C (391056), E9FTGDSR0C (391057), E9FTGHSS0C (391058), E9FTGHSP0C (391059), Z9HOGD1000 (392022), Z9HOGH1000 (392023), Z9FTGDSS0C (392056), Z9FTGDSR0C (392057), Z9FTGHSS0C (392058), Z9FTGHSP0C (392059), A9HOGD1000 (393022), A9HOGH1000 (393023), A9FTGDSR0C (393057), A9FTGHSS0C (393058), A9FTGHSP0C (393059)

ZANUSSI Fryer electric MFR/G360 (161911), RFR/G360 (171511), T35GFR (174511)

ZANUSSI Fryer gas BF/G1S07 (162304), XFR/G351 (174517), CFR/G351 (174931), PF/G1S07 (178110), PF/G2D07 (178111), PFR/G1S07 (178112), PFR/G2D07 (178113), OF/G1S07 (178410), OFR/G1S07 (178412), OFR/G2D07 (178413), TF/G1S07 (178710), TF/G2D07 (178711), TFR/G1S07 (178712), TFR/G2D07 (178713), FC1G (201023), FC2G (201025), FCN/1GZ (210357), FCN/2GZ (210359), RF/G1680 (211023), RF/G2480 (211025), E7FRGH1LFT (371072), Z7FRGH1LFT (372072), E9FRG01QF0 (391085), E9FRG02QF0 (391086)

ZANUSSI Grill electric E9GREDGCF0 (391075), E9GREHGCFO (391076), Z9GREDGCF0 (392075), Z9GREHGCFO (392076), A9GREDGCF0 (393075), A9GREHGCFO (393076)

ZANUSSI Grill gas BG/G1 (162316), BG/G2 (162317), MG/G350E (163708), MG/G350F (163709), MG/G350NL (163710), MG/G700E (163712), MG/G700F (163713), MG/G700NL (163714), MG/G1050F (163716), RG/G350D (173255), RG/G700D (173256), 7GLG07 (173261), 7GLG10 (173265), TGV/G1 (178690), TGV/G2 (178691), E7GRGDGC0P (371042), E7GRGHGC0P (371043), Z7GRGDGC0P (372042), Z7GRGHGC0P (372043), Z7GRGDLC0H (372161), E9GRGDGCFO (391063), E9GRGHGCFO (391064), E9GRTDGCFO (391197), E9GRTHGCFO (391198), Z9GRGDGCFO (392063), Z9GRGHGCFO (392064), Z9GRTDGCFO (392197),

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

Z9GRTHGCF0 (392198), A9GRGDGCF0 (393063), A9GRGHGCF0 (393064)

ZANUSSI Kitchen gas HCF/G810D (200008), HCF/G1210D (200009), HCF/G1610D (200010), HCF/G810NL (200013), ZCF/G810D (210008), ZCF/G1210D (210009), ZHCFG1610D (210010), ACF/G810D (220008), ACF/G810NL (220013)

ZANUSSI Lava rock grill gas RG/G350F (173259), RG/G700F (173263), RG/G1050 (173266), E7GRGDLC00 (371044), E7GRGHLC00 (371045), Z7GRGDLC00 (372044), Z7GRGHLC00 (372045), Z7GRGHLC0H (372162), A7GRGDLC00 (373044), A7GRGHLC00 (373045)

ZANUSSI Pasta cooker E9PCGD1MF2 (391201), E9PCGH2MF2 (391202), E9PCED1MF2 (391203), E9PCEH2MF2 (391204)

ZANUSSI Pasta cooker electric E7PCED1KF0 (371098), E7PCEH2KF0 (371099), Z7PCED1KF0 (372098), Z7PCEH2KF0 (372099), A7PCED1KF0 (373098), A7PCEH2KF0 (373099), E9PCED1MF0 (391126), E9PCEH2MF0 (391127), Z9PCED1MF0 (392126), Z9PCEH2MF0 (392127), A9PCED1MF0 (393126), A9PCEH2MF0 (393127)

ZANUSSI Pasta cooker gas BCP/G1 (162320), PCP/G1S (178143), PCP/G2D (178144), OCP/G1S (178443), OCP/G2D (178444), TCP/G1S (178743), TCP/G2D (178744), CR15G (291177), E7PCGD1KF0 (371090), E7PCGH2KF0 (371091), Z7PCGD1KF0 (372090), Z7PCGH2KF0 (372091), A7PCGD1KF0 (373090), A7PCGH2KF0 (373091), E9PCGD1MF0 (391111), E9PCGH2MF0 (391112), Z9PCGD1MF0 (392111), Z9PCGH2MF0 (392112), A9PCGD1MF0 (393111), A9PCGH2MF0 (393112), A9PCGD1MFK (393212)

ZANUSSI Potato heater gas RM/G700F (172510)

ZANUSSI Solid top range QP/G2 (210234), E9STGH10GA (391264), E9STGLT01A (391265), Z9STGH10GA (392264), Z9STGLT01A (392265)

ZANUSSI Solid top range gas MTF/GE1050 (162508), MT/G700F (162509), MTF/G700F (162510), MTF/G1055F (162512), MTFGE1055F (162513), RT/G700F (172259), RTF/G700 (172260), RTF/G1050 (172262), HT/G800D (202517), HTF/G810 (202518), HTF/G800D (202519), HTF/G1210 (202522), HTF/G1210D (202523), HT/G800NL (202524), HTF/G800NL (202525), HTFG1210NL (202526), ZT/G800D (212517), ZTF/G810 (212518), ZTF/G800D (212519), ZTF/G1210 (212522), ZTF/G1210D (212523), AT/G800D (222517), ATF/G800D (222519), ATF/G1210 (222522), ATF/G1210D (222523), AT/G800NL (222524), ATF/G800NL (222525), ATFG1210NL (222526), E9STGH1000 (391018), E9STGH10G0 (391019), E9STGH30G0 (391020), E9STGL3010 (391021), E9GCGH3C00 (391024), E9STGH10V0 (391214), Z9STGH1000 (392018), Z9STGH10G0 (392019), Z9STGH30G0 (392020), Z9STGL3010 (392021), Z9GCGH3C00 (392024), Z9STGH10V0 (392214), A9STGH1000 (393018), A9STGH10G0 (393019), A9STGL3010 (393021)

