

Termostat reglabil 50-310°C EGO 55.17069.210 #COK200BO

Fara TVA: 84,03 Lei

Pret cu TVA: 100,00Lei

Termostat reglabil 50-310°C EGO 55.17069.210 #COK200BO

Temperatura maxima 310°C

Sonda Ø4x110mm

Capilar 1100mm

2 contacte electrice

Ax 23mm

Compatibil cu:

BOSCH 499005

EGO 5517069210, 55.17069.210

00499005, 00492730, BSH499005, 5045172098597

BOSCH CF231250IL/45, CF231253IL/01, JB33AC50/01, JB33UC50/01, JB33UK50/01, JC33AC50/01, JH33AC50/01, JH33UC50/01, E1112N0/03, E1112W0/03, E1122N0/03, E1122N0/10, E1122W0/03, E1122W0/10, E1412N0/03, E1412N0/05, E1412N0/10, E1442B0GR/03, E1442B0GR/05, E1442B0GR/10, E1442N0GR/03, E1442N0GR/05, E1442N0GR/09, E1442N0GR/10, E1442S0GR/03, E1442S0GR/05, E1442S0GR/10, E1442W0GR/03, E1442W0GR/05, E1442W0GR/10, E1544C0/03, E1544C0/10, E1544E0/03, E1544E0/10, E1554A0/03, E1554A0/05, E1554A0/09, E1554A0/10, E1554N0/03, E1554N0/05, E1554N0/09, E1554N0/10, E1922B0/03, E1922N0/03, E1922W0/03, E1952B0/03, E1952N0/03, E1952W0/03, E1972B0/03, E1972N0/03, E1972W0/03, E3322N0/03, E3322N0/10, E3422B0/03, E3422B0/10, E3422N0/03, E3422N0/09, E3422N0/10, E3422S0/03, E3422S0/10, E3422W0/03, E3422W0/10, E3544N0/03, E3544N0/09, E3544N0/10, B1122N0/03, B1122N0/10, B1422A0/05, B1422A0/09, B1422A0/10, B1422N0/05, B1422N0/09, B1422N0/10, B1432N0EU/03, B1432N0EU/10, B1432S0EU/03, B1432S0EU/10, B1452A0/05, B1452A0/09, B1452A0/10, B1452C0/03, B1452C0/10, B1452N0/05, B1452N0/09, B1452N0/10, B1452N0EU/03, B1452N0EU/10, B1452S0EU/03, B1452S0EU/10, B1452W0EU/03, B1452W0EU/10, B1544C0/03, B1544C0/10, B1544E0/03, B1544E0/10, B1554A0/03, B1554A0/10, B1554N0/03, B1554N0/10, B1952N0/03, E1822N0/03, E1822N0/05, E1822N0/10, E1834N0/03, E1834N0/05, E1834N0/09, E1834N0/10, E1864N0/03, E1864N0/05, E1864N0/09, B1844N0/03, B1844N0/05, B1844N0/09, B1844N0/10, E1312B0/03, E1312B0/10, E1312N0/03, E1312N0/10, E1312S0/03, E1312S0/10, E1312W0/03, E1312W0/10, E1322A0/03, E1322A0/10, E1322B0/03, E1322B0/10, E1322N0/03, E1322N0/10, E1322S0/03, E1322S0/10, E1322W0/03, E1322W0/10, E1342N0/03, E1342N0/10, E1342W0/03, E1342W0/10, E1422B0/03, E1422B0/05, E1422B0/10, E1422N0/03, E1422N0/05, E1422N0/10, E1422S0/03, E1422W0/03, E1422W0/05, E1422W0/10, E1426N0/03, E1426N0/05, E1426N0/10, E1432A0/03, E1432A0/05, E1432A0/09, E1432A0/10, E1432B0/03, E1432B0/05, E1432B0/10, E1432N0/03, E1432N0/05, E1432N0/09,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

E1432N0/10, E1432S0/03, E1432S0/05, E1432S0/10, E1432W0/03, E1432W0/05, E1432W0/10, E1452B0/03, E1452B0/05, E1452B0/10, E1452N0/03, E1452N0/05, E1452N0/09, E1452N0/10, E1452W0/03, E1452W0/05, E1452W0/10, E1524A0/03, E1524A0/05, E1524A0/09, E1524A0/10, E1524N0/03, E1524N0/05, E1524N0/09, E1524N0/10, E1544A0/03, E1544A0/05, E1544A0/09, E1544A0/10, E1544B0/03, E1544B0/05, E1544B0/10, E1544N0/03, E1544N0/05, E1544N0/09, E1544N0/10, E1544S0/03, E1544S0/05, E1544S0/10, E1544W0/03, E1544W0/05, E1544W0/10, B1322N0/03, B1322N0/04, B1322N0/05, B1322N0/10, B1342N0EU/03, B1342N0EU/10, B1342S0EU/03, B1342S0EU/10, B1342W0EU/03, B1342W0EU/10, B1422A0/03, B1422N0/03, B1452A0/03, B1452B0/03, B1452B0/05, B1452B0/10, B1452N0/03, B1452S0/03, B1452S0/05, B1452S0/10, B1452W0/03, B1452W0/05, B1452W0/10, B1524A0/03, B1524N0/03, B1524N0/10, B1544A0/03, B1544A0/10, B1544N0/03, B1544N0/10, C17M42N3/01, C17M42N3/03, U12S32N3GB/01, U12S32N3GB/02, U12S32N3GB/04, U12S52N3GB/01, U12S52N3GB/02, U12S52N3GB/04, 3HB458XC/01, 3HB458XC/03, B1142N0GB/04, B1142N0GB/10, B12M22N0/01, B12M22N0/04, B12M22N0/35, B12M22N3/01, B12M22N3/02, B12M32N0EU/01, B12M32N0EU/04, B12M32N0EU/09, B12M32N0EU/35, B12M32N3EU/01, B12M32N3EU/02, B12M42N0FR/01, B12M42N0FR/04, B12M42N0FR/35, B12M42N0GB/01, B12M42N0GB/35, B12M42N3FR/01, B12M42N3FR/02, B12M42S0FR/01, B12M42S0FR/04, B12M42S0FR/35, B12M42W0FR/01, B12M42W0FR/04, B12M42W0FR/35, B12M52N3FR/01, B12M52N3FR/02, B12M52S3FR/01, B12M52S3FR/02, B12M52W3FR/01, B12M52W3FR/02, B12S32N3GB/01, B12S32N3GB/02, B12S32N3GB/04, B12S52N3GB/01, B12S52N3GB/02, B12S52N3GB/04, B1322N0GB/03, B1322N1GB/01, B1322N1GB/10, B1322S0GB/03, B1322S1GB/01, B1322S1GB/10, B1322W0GB/03, B1322W1GB/01, B1322W1GB/10, B1362N0FF/03, B1362N0FF/10, B1362S0FF/03, B1362S0FF/10, B1362W0FF/03, B1362W0FF/10, B1412N0GB/03, B1412N0GB/10, B1422B0GB/03, B1422B0GB/10, B1422C0GB/03, B1422C0GB/10, B1422E0GB/03, B1422E0GB/10, B1422N0GB/03, and models: B1422N0GB/10, B1422S0GB/03, B1422S0GB/10, B1422W0GB/03, B1422W0GB/10, B1426N0/03, B1426N0/04, B1426N0/05, B1426N0/10, B1442B0GB/03, B1442B0GB/10, B1442N0GB/03, B1442N0GB/10, B1442S0GB/03, B1442S0GB/10, B1442W0GB/03, B1442W0GB/10, B1452J0/03, B1452J0/10, B1452N0RU/05, B1452N0RU/10, B1452U0/03, B1452U0/10, B1452V0/03, B1452V0/10, B1462N0FF/03, B1462N0FF/10, B1462S0FF/03, B1462S0FF/10, B1462W0FF/03, B1462W0FF/10, B14M22N0/01, B14M22N0/04, B14M22N0/11, B14M22N0/35, B14M22N3/01, B14M42B0GB/01, B14M42N0/01, B14M42N0/04, B14M42N0/11, B14M42N0/35, B14M42N0AU/01, B14M42N0AU/11, B14M42N0AU/35, B14M42N0EU/01, B14M42N0EU/11, B14M42N0EU/35, B14M42N0GB/01, B14M42N0GB/35, B14M42N0RU/01, B14M42N0RU/11, B14M42N0RU/35, B14M42N0S/01, B14M42N2/01, B14M42N3/01, B14M42N3AU/01, B14M42N3AU/04, B14M42N3AU/05, B14M42N3GB/01, B14M42N3GB/04, B14M42N3RU/01, B14M42S0GB/01, B14M42S0GB/35, B14M42S3GB/01, B14M42S3GB/04, B14M42W0GB/01, B14M42W0GB/35, B14M42W3GB/01, B14M42W3GB/04, B14M52N0/01, B14M52N0/11, B14M52N0/35, B14M62B0GB/01, B14M62B0GB/35, B14M62N0FR/01, B14M62N0FR/11, B14M62N0FR/35, B14M62N0GB/01, B14M62N0GB/35, B14M62N3FR/01, B14M62S0FR/01, B14M62S0FR/11, B14M62S0FR/35, B14M62S0GB/01, B14M62S0GB/35, B14M62S3FR/01, B14M62W0FR/01, B14M62W0FR/11, B14M62W0FR/35, B14M62W0GB/01, B14M62W0GB/35, B14M62W3FR/01, B14M82N3FR/01, B1524N0RU/03, B1524N0RU/10, B1544N0RU/03, B1544N0RU/10, B1554N0RU/03, B1554N0RU/10, B15F42N0EU/01, B15F42N0EU/35, B15H4A0/03, B15H4A0/08, B15H4A0/10, B15H4N0/03, B15H4N0/08, B15H4N0/10, B15M22N0/01, B15M22N0/04, B15M22N0/35, B15M22N2/01, B15M22N3/01, B15M42B0/01, B15M42B0/35, B15M42B3EU/01,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

B15M42C0/01, B15M42C3/01, B15M42J3/01, B15M42N0/01, B15M42N0/04, B15M42N0/35, B15M42N0AU/01, B15M42N0AU/35, B15M42N0EU/01, B15M42N0EU/35, B15M42N0GB/01, B15M42N0GB/35, B15M42N0RU/01, B15M42N0RU/35, B15M42N0S/01, B15M42N0S/35, B15M42N2/01, B15M42N3AU/01, B15M42N3AU/04, B15M42N3AU/05, B15M42N3EU/01, B15M42N3RU/01, B15M42S0/01, B15M42S0/35, B15M42S0EU/01, B15M42S0EU/35

Neff C17M42N3/01, C17M42N3/03, U12S32N3GB/01, U12S32N3GB/02, U12S32N3GB/04, U12S52N3GB/01, U12S52N3GB/02, U12S52N3GB/04,, B12M42N0GB/01/, 1322N0GB/01/, 1322N0GB/03/, 1322N1GB/01/, 1322N1GB/10/, 1322S0GB/01/, 1322S0GB/03/, 1322S1GB/01/, 1322W0GB/01/, 1322W0GB/03/, 1322W1GB/01/, 1322W1GB/10/, 1412N0GB/03/, 1412N0GB/10/, 1422B0GB/01/, 1422B0GB/03/, 1422C0GB/01/, 1422C0GB/03/, 1422E0GB/01/, 1422E0GB/03/, 1422N0GB/01/, 1422N0GB/03/, 1422N0GB/10/, 1422S0GB/01/, 1422S0GB/10/, 1422W0GB/01/, 1422W0GB/03/, 1422W0GB/10/, 1442B0GB/01/, 1442B0GB/03/, 1442B0GB/10/, 1442N0GB/01/, 1442N0GB/03/, 1442N0GB/10/, 1442S0GB/01/, 1442S0GB/03/, 1442S0GB/10/, 1442W0GB/01/, 1442W0GB/03/, W0GB/03/, 1442W0GB/10/, 14M42N0GB/01/, 14M42N0GB/08/, 14M62N0GB/01/, 14M62N0GB/08/, 14M62W0GB/01/, 1524N0GB/01/, 1524N0GB/03/, 1524N0GB/10/, 1524S0GB/01/, 1524S0GB/03/, 15M42N0GB/01/, 15M42N0GB/08/, 15M62N0GB/01/, 1722N0GB/01/, 1722N0GB/02/, 1722N0GB/03/, 1722N0GB/10/, 1722S0GB/01/, 1722S0GB/02/, 1722S0GB/03/, 1722S0GB/10/, 1722W0GB/01/, 1722W0GB/02/, 1722W0GB/03/, 1722W0GB/10/, 17M42N0GB/01/, 17M42N0GB/08/, 17M62N0GB/01

Siemens HB13M250B/01, HB13M250B/03, HB13M550B-10, HB13M550B/01, HB13M550B/03, HB13M650B/01, HB13M650B/03

Tecnik TKC8085/2

Balay 3HB458XCA/01

Bosch HBN13M250B/03

Bosch HBN13B221B/35

Bosch HBM13B150B/45

Bosch HBM13B550B/47

Bosch HBN13N550B/03

Bosch HBM13B261B/45

Bosch HBM43B150B/01

Bosch HBN13M260B/10

Bosch HBM43B250A/45

Bosch HBN13N551B/10

Bosch HBN13N520B/01

Bosch HBM13B120B/01

Bosch HBN13B251B/35

Bosch HBN13N560B/03

Bosch HBN13B261B/35

Bosch HBM13B261B/35

Bosch HBM13B160B/08

Bosch HBN13B261B/70



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Bosch HBN13B251B/01
Bosch HBN13B221B/45
Bosch HBM13B120B/45
Bosch HBM13B550B/45
Constructa CH13850/03
Constructa CH21850/03
Constructa CH26850/03
Constructa CH23850/10
Constructa CH26850/10
Constructa CF26850/05
Constructa CH110250/01
Constructa CF130250/03
Constructa CF130250S/03
Constructa CF210250/01
Constructa CH130250S/03
Constructa CH130220/35
Constructa CH232253/01
Constructa CH232250/45
Constructa CH130250/45
Constructa CF23850/03
Constructa CF26850/01
Constructa CF26850/03
Constructa CH13870/03
Constructa CH23850/01
Constructa CH23850/03
Constructa CH26850/01
Constructa CH23850/05
Constructa CH21850/05
Constructa CF23850/10
Constructa CF23850/05
Constructa CH130290/01
Constructa CF130250S/12
Constructa CF330250/01
Constructa CH232450/01
Constructa CF232450/01
Constructa CF74850/10
Constructa CF130250/01
Constructa CF130250S/01
Constructa CH130250S/01



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Constructa CF110250/35
Constructa CH210253/01
Constructa CF130250/45
Constructa CH210250/45
Constructa CH12850/04
Constructa CH23810/01
Constructa CH23870/01
Constructa CH23810/05
Constructa CH26850/05
Constructa CH14850/05
Constructa CH230250/01
Constructa CH232250/01
Constructa CF130220S/12
Constructa CF130252/01
Constructa CF630250/46
Constructa CH130250/03
Constructa CF230290/01
Constructa CH230252/01
Constructa CH110220/35
Constructa CF230250/45
Constructa CF13850/03
Constructa CF23850/01
Constructa CH11850/01
Constructa CH14850/04
Constructa CH17850/03
Constructa CH23820/03
Constructa CH26810/03
Constructa CH23820/05
Constructa CH21850/10
Constructa CF26850/10
Constructa CH130220/01
Constructa CH232250/35
Constructa CH132253/01
Constructa CF110253/01
Constructa CH110250/03
Constructa CH150250/12
Constructa CF630253/70
Constructa CH130290/03
Constructa CF230250/35



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Constructa CH110250/35
Constructa CF13850/01
Constructa CH11850/03
Constructa CH13850/01
Constructa CH21850/01
Constructa CH26870/10
Constructa CH26820/05
Constructa CH130250/01
Constructa CF230250/01
Constructa CF330250/45
Constructa CH130250S/12
Constructa CH130250/12
Constructa CF130250/12
Constructa CH230250/35
Constructa CH230250/45
Constructa CF130220S/01
Constructa CF130250/35
Constructa CH130293/01
Constructa CF130250S/45
Neff B44M52N3FR/01
Neff B44M42N5GB/01
Neff B44S42N3GB/01
Neff B45M42N3/01
Neff B45M42N0/35
Neff B85H42N0MC/35
Neff B45M42N5/70
Neff Mega 4544 W B1544W0/01
Neff Mega 1922 BExcellent E1922B0/01
Neff Mega 1922 NExcellent E1922N0/01
Neff Mega 1952 NExcellent E1952N0/01
Neff Mega 1972 WExcellent E1972W0/01
Neff B1322N1GB/01
Neff B1322S1GB/01
Neff B1422B0GB/03
Neff B12M22N3/70
Neff B1422B0GB/01
Neff B1442B0GB/01
Neff B1452V0/01
Neff B1462S0FF/03



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff E1432J0/01
Neff E1972B1/01
Neff Mega 1412 N E1412N0/03
Neff Mega 1422 B E1422B0/03
Neff Mega 1422 B E1422B0/01
Neff Mega 1422 N E1422N0/01
Neff Mega 1422 N E1422N0/03
Neff Mega 1432 N E1432N0/01
Neff Mega 1432 N E1432N0/03
Neff Mega 1432 S E1432S0/01
Neff Mega 1442 N E1442N0GR/01
Neff Mega 1452 B E1452B0/03
Neff Mega 1452 N E1452N0/03
Neff Mega 1524 N E1524N0/01
Neff Mega 1544 ENostalgie E1544E0/01
Neff Mega 4342 N EU B1342N0EU/03
Neff Mega 4422 A B1422A0/01
Neff Mega 4422 N B1422N0/01
Neff Mega 4452 S EU B1452S0EU/03
Neff Mega 4452 S EU B1452S0EU/01
Neff Mega 4452 W B1452W0/01
Neff Mega 4524 N B1524N0/01
Neff Mega 4554 A B1554A0/01
Neff Mega MC 1822 N E1822N0/03
Neff Mega MC 4844 N B1844N0/03
Neff Mega 4452 W B1452W0/10
Neff Mega 1544 N E1544N0/09
Neff Mega 1432 N E1432N0/09
Neff Mega 1432 N E1432N0/05
Neff Mega 1426 N E1426N0/10
Neff Mega MC 1864 N E1864N0/09
Neff Mega MC 1822 N E1822N0/05
Neff Mega 4452 S EU B1452S0EU/10
Neff Mega 4452 N B1452N0/09
Neff Mega 4452 N B1452N0/05
Neff Mega 4452 A B1452A0/09
Neff Mega 4422 A B1422A0/09
Neff Mega 4122 N B1122N0/10
Neff Mega 3422 N E3422N0/10



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff Mega 1554 A E1554A0/05
Neff MEGA 1544 CNostalgie E1544C0/10
Neff MEGA 1442N E1442NOGR/09
Neff E1952B2/10
Neff B1422C0GB/10
Neff B1426N0/05
Neff B1322S1GB/10
Neff E1426W0/05
Neff E1426W0/10
Neff B14M42N0EU/01
Neff B15M42W0/01
Neff B85M52N0MC/01
Neff E12M22N0/01
Neff E14M42W0EU/01
Neff E14M63N0/01
Neff E15M74C0/01
Neff E15M74E0/01
Neff E14M22N5/01
Neff B15M42N0EU/35
Neff B12M42N0GB/01
Neff E95I53N0MK/01
Neff E18M43N0/04
Neff B14M42N0RU/11
Neff B14M22N0/11
Neff B15F42N0EU/01
Neff B14M42N0EU/35
Neff B15M42N0S/35
Neff E18I42N3/02
Neff E18M43N3/02
Neff E12M22N3/02
Neff E93M43W3MK/02
Neff E15I42N0/01
Neff B12S32N3GB/04
Neff E15M22N0/04
Neff E95M53N1MK/04
Neff B15M42N0/04
Neff E14M42N0/11
Neff E15M63W3/01
Neff B15M42N3RU/01



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff E35K42N3/01
Neff B15M22N2/01
Neff E18M22N0/35
Neff E18M43N0/35
Neff E15M22S0/35
Neff B14M42N3AU/04
Neff U15M62N0GB/01
Neff U12M42N0GB/35
Neff U17M72S0GB/08
Neff B15M22N5/01
Neff E93M43N3MK/01
Neff E12M22N3/01
Neff E15F42N0/35
Neff E18I42N0/35
Neff E12M22W0/35
Neff B14H2N0/08
Neff B15H4N0/08
Neff E12M22W3/01
Neff E14M42N3/01
Neff E34K22N3/01
Neff E34K22N0/01
Neff B14M42B0GB/01
Neff B15M42N0AU/01
Neff B15M22N0/35
Neff E12M12W0/35
Neff B45M44N0/01
Neff B44M62N0GB/01
Neff B45M42N3AU/04
Neff B44M42N0/01
Neff B45M42N0/01
Neff B44M42N3/01
Neff B95H42N3MK/01
Neff B84H42N5MC/01
Neff U1524N0GB/03
Neff B1142N0GB/04
Neff B1422N0GB/01
Neff B1422S0GB/01
Neff B1426N0/04
Neff B1462W0FF/01



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff E1426W0/03
Neff E1952B1/01
Neff E1972W1/01
Neff Mega 1122 N E1122N0/01
Neff Mega 1122 W E1122W0/03
Neff Mega 1122 W E1122W0/01
Neff Mega 1322 B E1322B0/03
Neff Mega 1342 N E1342N0/03
Neff Mega 1432 A E1432A0/01
Neff Mega 1452 N E1452N0/01
Neff Mega 1952 NExcellent E1952N0/03
Neff Mega 1952 WExcellent E1952W0/03
Neff Mega 3422 N E3422N0/01
Neff Mega 4432 S EU B1432S0EU/01
Neff Mega 4452 A B1452A0/01
Neff Mega 4452 N EU B1452N0EU/01
Neff Mega 4544 ENostalgie B1544E0/01
Neff Mega 4544 N B1544N0/03
Neff Mega MC 1822 N E1822N0/01
Neff Mega MC 1834 N E1834N0/03
Neff Mega MC 4844 N B1844N0/01
Neff U1442N0GB/01
Neff U1722N0GB/02
Neff U1722W0GB/03
Neff U1744N0GB/01
Neff Mega 4322 N B1322N0/05
Neff Mega 1544 S E1544S0/05
Neff Mega 1432 W E1432W0/05
Neff Mega 1432 A E1432A0/10
Neff Mega 1322 B E1322B0/10
Neff Mega MC 4864 N B1864N0/09
Neff Mega MC 4864 N B1864N0/10
Neff Mega MC 1864 N E1864N0/05
Neff Mega MC 1822 N E1822N0/10
Neff Mega 4544E Nostalgie B1544E0/10
Neff Mega 4452 N EU B1452N0EU/10
Neff Mega 4452 A B1452A0/10
Neff Mega 4432 N EU B1432N0EU/10
Neff Mega 4422 N B1422N0/05



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff Mega 4422 A B1422A0/10

Neff E1952B1/05

Neff E1922N1/10

Neff E1972W1/05

Neff E1864N1/10

Neff B1442W0GB/10

Neff B1426N0/10

Neff B1322N1GB/10

Neff B1544N0RU/10

Neff B1554N0RU/10

Neff B1554N0RU/03

Neff B15M74C0/01

Neff E14M22N0/01

Neff E14M42N0EU/01

Neff E95M53N0MK/01

Neff B14M52N0/01

Neff E15M42N5/01

Neff B12M42N0FR/35

Neff B14M62N0FR/01

Neff E93M43B0MK/01

Neff B14H2N0/03

Neff B14M42N0/11

Neff B15M22N3/01

Neff B15M52N3S/01

Neff B15M42S3EU/01

Neff E95M53N3MK/01

Neff B15M42S0GB/01

Neff B14H2N0/10

Neff B14H5N0/10

Neff E35K22N0/35

Neff B12M22N3/02

Neff E18M22N0/04

Neff E15M74N0/04

Neff E12M22N0/04

Neff B12M22N0/04

Neff B95F42N0MK/01

Neff B14M22N3/01

Neff B15M42N3AU/01

Neff B85M52N3MC/01



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff E15M63N3/01
Neff B15M42N0/35
Neff E12M22N0/35
Neff B15M62N0GB/35
Neff E93M43W0MK/35
Neff E95M53W1MK/35
Neff U15M42S0GB/01
Neff U14M62S0GB/08
Neff U17M42N3GB/01
Neff U14M42W3GB/01
Neff E14M42N5/01
Neff E93M43N0MK/11
Neff E14M42N2/01
Neff E18M42N0/35
Neff B14M62S0FR/11
Neff E1452N0/01
Neff B45M42N5FR/01
Neff B45M42N0GB/01
Neff B45M42N3RU/01
Neff B44M42N3S/01
Neff B45M42N3AU/01
Neff Mega 1554 W E1554W0/01
Neff Mega 1952 WExcellent E1952W0/01
Neff Mega 1972 BExcellent E1972B0/01
Neff Mega 1972 NExcellent E1972N0/01
Neff B1322W0GB/03
Neff B1322N0GB/03
Neff B12M32N3EU/70
Neff B1452J0/03
Neff B1452U0/03
Neff B1452V0/03
Neff B1952N1/01
Neff Mega 1312 N E1312N0/01
Neff Mega 1322 N E1322N0/03
Neff Mega 1422 W E1422W0/03
Neff Mega 1544 S E1544S0/01
Neff Mega 1554 N E1554N0/03
Neff Mega 3422 B E3422B0/01
Neff Mega 3422 S E3422S0/03



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff Mega 3422 S E3422S0/01
Neff Mega 3544 N E3544N0/01
Neff Mega 4342 N EU B1342N0EU/01
Neff Mega 4422 N B1422N0/03
Neff Mega 4432 N EU B1432N0EU/03
Neff Mega 4452 CNostalgie B1452C0/03
Neff Mega 4452 N B1452N0/03
Neff Mega 4452 W B1452W0/03
Neff Mega 4524 N B1524N0/03
Neff Mega 4544 ENostalgie B1544E0/03
Neff Mega 4544 N B1544N0/01
Neff Mega 4554 N B1554N0/01
Neff Mega MC 1834 N E1834N0/01
Neff U1422N0GB/02
Neff U1422W0GB/01
Neff U1524N0GB/01
Neff Mega 4342 N EU B1342N0EU/10
Neff Mega 1452 N E1452N0/05
Neff Mega 1452 B E1452B0/10
Neff Mega 1426 N E1426N0/05
Neff Mega 1422 N E1422N0/10
Neff Mega 1422 B E1422B0/10
Neff Mega 1422 B E1422B0/05
Neff Mega MC 4864 N B1864N0/05
Neff Mega MC 4844 N B1844N0/05
Neff Mega MC 1834 N E1834N0/10
Neff Mega 4452 N B1452N0/10
Neff Mega 4422 N B1422N0/10
Neff Mega 3544 N E3544N0/10
Neff Mega 1554 N E1554N0/09
Neff Mega 1554 N E1554N0/05
Neff MEGA 1544 ENostalgie E1544E0/10
Neff Mega 1122 N E1122N0/10
Neff E1952N2/10
Neff E1972N1/05
Neff E1864N1/09
Neff B1322W1GB/10
Neff E1426B0/05
Neff B1544N0RU/03



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff U1442B0GB/10

Neff B12M22N0/01

Neff Mega 4432 S EU B1432S0EU/10

Neff B1452U0/10

Neff B15M42S0/01

Neff B15M74E0/01

Neff Mega 1312 W E1312W0/10

Neff E14M42N0/01

Neff E15M22S0/01

Neff E94M42B0MK/01

Neff B15M42J3/01

Neff B14M42N0/04

Neff B14M42N5/01

Neff B15H4N0/01

Neff B15M42N0RU/01

Neff E15I42N3/01

Neff E95I53N3MK/01

Neff E85M42N3MC/01

Neff B15H4N0/10

Neff E15I42N0/35

Neff E18M43N0/01

Neff E18M22N3/02

Neff E12M22W3/02

Neff E93M43N3MK/02

Neff B12M52N3FR/02

Neff E12M12W3/02

Neff E93M43N0MK/01

Neff E35K74N0/04

Neff B15M22N0/04

Neff E18M42N0/04

Neff E93M43N0MK/04

Neff E14M22N0/04

Neff B15M42B3EU/01

Neff B15M42W3EU/01

Neff B84M42N3MC/01

Neff E15M22N0/35

Neff B14M22N0/35

Neff E95I53N0MK/35

Neff B15M42S0EU/35



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff U14M62N0GB/35
Neff U17M62S0GB/35
Neff U17M42S3GB/03
Neff U14M62B0GB/08
Neff U17M42W0GB/08
Neff U12S53N3GB/01
Neff B84M42N5MC/01
Neff E34K22N0/35
Neff E14M42N0EU/35
Neff E93M43W0MK/11
Neff B45M42N3AU/05
Neff B44M62N0FR/01
Neff B44M42N3GB/04
Neff B85H42N0MC/01
Neff B85H42N3MC/01
Neff B45M42N0GB/35
Neff B44M42N0S/01
Neff B44M42N0GB/01
Neff B45M42N5/01
Neff B44M42N5/01
Neff B44M42N5/70
Neff B1322N0GB/01
Neff B1322S0GB/01
Neff B1322W0GB/01
Neff B1422E0GB/01
Neff B1426N0/03
Neff B1452J0/01
Neff E1426B0/03
Neff E1922N1/01
Neff E1952N1/01
Neff Mega 1422 S E1422S0/01
Neff Mega 1452 B E1452B0/01
Neff Mega 1524 A E1524A0/03
Neff Mega 1544 CNostalgie E1544C0/01
Neff Mega 1544 N E1544N0/03
Neff Mega 1544 W E1544W0/03
Neff Mega 1554 N E1554N0/01
Neff Mega 1922 NExcellent E1922N0/03
Neff Mega 1952 BExcellent E1952B0/03



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff Mega 1972 BExcellent E1972B0/03
Neff Mega 1972 WExcellent E1972W0/03
Neff Mega 3422 N E3422N0/03
Neff Mega 3544 N E3544N0/03
Neff Mega 4122 N B1122N0/01
Neff Mega 4322 N B1322N0/01
Neff Mega 4422 A B1422A0/03
Neff Mega 4432 N EU B1432N0EU/01
Neff Mega 4432 S EU B1432S0EU/03
Neff Mega 4452 N B1452N0/01
Neff Mega 4452 W EU B1452W0EU/01
Neff Mega 4524 A B1524A0/03
Neff Mega 4544 CNostalgie B1544C0/03
Neff Mega 4544 CNostalgie B1544C0/01
Neff Mega MC 1864 N E1864N0/01
Neff Mega MC 4864 N B1864N0/01
Neff U1442S0GB/01
Neff Mega 4452 S B1452S0/05
Neff Mega 1544 N E1544N0/10
Neff Mega 1524 N E1524N0/09
Neff Mega 1452 N E1452N0/10
Neff Mega 1452 N E1452N0/09
Neff Mega 1432 W E1432W0/10
Neff Mega 1432 S E1432S0/10
Neff Mega 1432 A E1432A0/09
Neff Mega 1422 N E1422N0/05
Neff Mega 1322 N E1322N0/10
Neff Mega MC 4844 N B1844N0/10
Neff Mega MC 1834 N E1834N0/09
Neff Mega 4544C Nostalgie B1544C0/10
Neff Mega 4422 A B1422A0/05
Neff Mega 3422 N E3422N0/09
Neff Mega 3422 B E3422B0/10
Neff Mega 1554 N E1554N0/10
Neff MEGA 1412N E1412N0/05
Neff E1952N1/05
Neff E1952N2/09
Neff E1864N1/05
Neff B1142N0GB/10



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff B1422B0GB/10
Neff B1412N0GB/10
Neff B1462N0FF/10
Neff B1452N0RU/05
Neff B1952N1/05
Neff B1452N0RU/10
Neff B14M22N0/01
Neff Mega 4524N B1524N0/10
Neff B15M22N0/01
Neff B15M42S0EU/01
Neff B15M42W0EU/01
Neff B84M42N0MC/01
Neff E12M12W0/01
Neff E14M22B0/01
Neff Mega 3422 S E3422S0/10
Neff B18M42N3/01
Neff B15F42N0EU/35
Neff B15M42N3AU/05
Neff B14M22N0/04
Neff B15M42N5/01
Neff B14H2N0/01
Neff E18I42N0/01
Neff B14H5N0/03
Neff B15H4N0/03
Neff Mega 4952 NExcellent B1952N0/01
Neff Mega 1524 B E1524B0/01
Neff Mega 1922 WExcellent E1922W0/01
Neff Mega 1952 BExcellent E1952B0/01
Neff B1322S0GB/03
Neff B1322W1GB/01
Neff B14M42N3GB/01
Neff B15M74C1/35
Neff B12M22N0/35
Neff B18M42N0/01
Neff E18M22N0/01
Neff B12M32N3EU/02
Neff B15M74C1/01
Neff B15M42N3AU/04
Neff B14M42N3AU/05



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff E12M22W0/04
Neff B14M42N0EU/11
Neff E15M22N5/01
Neff B14M42N3RU/01
Neff B14M42N3AU/01
Neff E14M63N3/01
Neff B14M42N3/01
Neff E15M22N3/01
Neff B85M52N0MC/35
Neff E15M63N1/35
Neff B15M42N0GB/35
Neff B15M42N0AU/35
Neff E14M22W0/35
Neff B14M42N3GB/04
Neff U17M42W0GB/01
Neff U14M62B0GB/01
Neff U17M72N0GB/08
Neff C17M42N3/06
Neff B14M22N5/01
Neff B14M42N5AU/01
Neff B14M42N5GB/01
Neff E12M42N0/04
Neff E34K22N0/11
Neff E18M42N3/01
Neff E93M43B3MK/01
Neff B44M62N3FR/01
Neff B45M62N0GB/35
Neff B45M42N3S/01
Neff B44M42N3GB/01
Neff B44M42N3FR/01
Neff B84H42N3MC/01
Neff B44M62N5FR/01
Neff B45M42N5FR/70
Neff B1422N0GB/03
Neff B1452U0/01
Neff E1972N1/01
Neff Mega 1112 N E1112N0/03
Neff Mega 1112 N E1112N0/01
Neff Mega 1112 W E1112W0/01



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff Mega 1122 N E1122N0/03
Neff Mega 1312 S E1312S0/01
Neff Mega 1322 B E1322B0/01
Neff Mega 1322 N E1322N0/01
Neff Mega 1342 N E1342N0/01
Neff Mega 1422 S E1422S0/03
Neff Mega 1422 W E1422W0/01
Neff Mega 1426 N E1426N0/03
Neff Mega 1426 N E1426N0/01
Neff Mega 1432 W E1432W0/01
Neff Mega 1544 B E1544B0/01
Neff Mega 1544 B E1544B0/03
Neff Mega 1544 CNostalgie E1544C0/03
Neff Mega 1544 ENostalgie E1544E0/03
Neff Mega 1544 N E1544N0/01
Neff Mega 1972 NExcellent E1972N0/03
Neff Mega 4122 N B1122N0/03
Neff Mega 4322 N B1322N0/03
Neff Mega 4322 N B1322N0/04
Neff Mega 4452 A B1452A0/03
Neff Mega 4452 CNostalgie B1452C0/01
Neff Mega 4452 N EU B1452N0EU/03
Neff Mega 4452 W EU B1452W0EU/03
Neff Mega 4524 A B1524A0/01
Neff Mega 4554 A B1554A0/03
Neff Mega 4554 N B1554N0/03
Neff Mega 4952 NExcellent B1952N0/03
Neff Mega MC 1864 N E1864N0/03
Neff Mega MC 4864 N B1864N0/03
Neff Mega 4544 N B1544N0/10
Neff Mega 4452 W B1452W0/05
Neff Mega 4322 N B1322N0/10
Neff Mega 1544 N E1544N0/05
Neff Mega 1524 A E1524A0/09
Neff Mega 1452 W E1452W0/10
Neff Mega 1452 B E1452B0/05
Neff Mega 1432 N E1432N0/10
Neff Mega 1422 W E1422W0/05
Neff Mega 1422 W E1422W0/10



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Neff Mega 1322 W E1322W0/10
Neff Mega 1312 N E1312N0/10
Neff Mega MC 4844 N B1844N0/09
Neff Mega MC 1834 N E1834N0/05
Neff Mega 4554 N B1554N0/10
Neff Mega 4452 W EU B1452W0EU/10
Neff Mega 4452 CNostalgie B1452C0/10
Neff Mega 4452 A B1452A0/05
Neff Mega 4422 N B1422N0/09
Neff E1952B2/05
Neff E1922N1/05
Neff E1972B1/05
Neff E1952N2/05
Neff E1922B1/05
Neff B1422N0GB/10
Neff E1426B0/10
Neff B1452J0/10
Neff B1952N1/09
Neff U1442N0GB/10
Neff U1422S0GB/10
Neff U1722N0GB/10
Neff B1452V0/10
Neff B14M42N0/01
Neff B15M42N0/01
Neff B15M42N0EU/01
Neff Mega 1122 W E1122W0/10
Neff E12M22W0/01
Neff E12M42N0/01
Neff Mega 1342 N E1342N0/10
Neff E15M22N0/01
Neff E15M63N0/01
Neff E15M74N0/01
Neff E94M42N0MK/01
Neff B14M42N5RU/01
Neff B18H4N0/05
Neff B15M42N0GB/01
Neff E14SW7N0/01
Neff B15M42N0S/01
Neff E14M22W3/01



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff E14M22B3/01
Neff B15M42N3EU/01
Neff B15M42C3/01
Neff B15M62S0FR/01
Neff E12M12N0/35
Neff E15M22B0/35
Neff E85M42N0MC/35
Neff E15M74C1/01
Neff E18M42N3/02
Neff B15M74E1/01
Neff E18I42W0/01
Neff E15M63N1/04
Neff B18M42N0/04
Neff E14M42N0RU/01
Neff E95I63N3MK/01
Neff E12M12W0/04
Neff B14M42N0AU/11
Neff E14M22N0/11
Neff B14M42N0S/01
Neff E93M43W3MK/01
Neff B12M22N3/01
Neff B14M42N2/01
Neff B15M42N2/01
Neff B18M42N0/35
Neff E95M53N1MK/35
Neff B15M42S0/35
Neff B15M42N0RU/35
Neff E93M43B0MK/35
Neff E14M22N0/35
Neff B14M62W0FR/35
Neff B95F42N0MK/35
Neff U14M42W0GB/01
Neff E15I42N5/01
Neff E18M43N3/01
Neff E14M63N1/35
Neff E93M43N0MK/35
Neff E93M43B3MK/02
Neff E18M22N3/01
Neff E14M22N3/01



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

Neff U1422W0GB/03

Neff B1422C0GB/03

Neff E15M22N5/70

Siemens HB13MB521B/35

Siemens HB13M650B/10

Siemens HB13M550B/01

Siemens HB13NB621B/45

Siemens HB13NB521B/35

Siemens HB13MB521B/45

Siemens HB13NB521B/70

Siemens HB13M550B/03

Siemens HB13NB621B/46

Siemens HB13NB521B/46

Tecnik HB9TI50GB/11

Tecnik HB7TI01GB/08

JH33AC50/01, 5CD33150/70, JC33AC50/06

