



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Arzator pilot SIT 1 flacara #SMC-1129

Fara TVA: 33,61 Lei

Pret cu TVA: 40,00Lei

Arzator pilot SIT 1 flacara #SMC-1129

producer: SIT

type: 140 series

flame number: 1 flame

without sparking plug, gas nozzle and gasket

Compatibil cu:

ALBA 541933290080

APACH

BARTLETT 3836-148

COLGED RTCP800034

DEXION RTCP800034

EKU

ELETTROBAR RTCP800034

EMMEPI 808353

HOBART

LOTUS

MBM RTCP800034

ASCASO GAS416

ASCASO LO..92

ASCASO MRO..2

ATEL 55CT077

GEV 107133

LF 3020251

SIT 0.140.026

APACH Fry top APTG-47PL, APTG-47PR, APTG-77PL, APTG-77PR

APACH Fryer gas APFG-47-2P

APACH Grill APGG-47P, APGG-77P

APACH Kitchen gas APRG-117FG, APRG-77FG, APRGS-77FG

APACH Pasta cooker APPG-47P, APPG-77P

APACH Pot stove gas APRGS-77P

DEXION Bain-marie gas LX7GBM7, LX7GBMA7, LX9GBM4T, MG046-03-003, MG066-03-006

DEXION Bratt pan MG066-03-015



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

DEXION Convection oven FC006-03-002GM

DEXION Fry top D77GFTA7, LX7GFT11, LX7GFT4, LX7GFT7, LX9GBRAVIT, LX9GFT4, LX9GFT9, MG046-03-001, MG046-03-002, MG046-13-001, MG046-13-002, MG066-03-003, MG066-03-004, MG066-03-005, MG066-13-003, MG066-13-004, MG066-13-005, MG099-05-203, MG099-15-203, MG106-03-003, MG106-03-004, MG106-13-003, MG106-13-004

DEXION Fryer gas LX9GC4SC, LX9GC4TSC, LX9GC9SC, LX9GF4, LX9GF9, MG099-05-007, MG459-04-315, MG459-05-007

DEXION Kitchen gas D77G4SF, LX9G4SF, LX9G6SFA, LX9GTF, LX9GTF2D, MG099-05-010, MG139-04-012, MG139-05-010, MG139-25-010, MG157-03-001, MG157-03-013

DEXION Lava rock grill gas MG086-13-014P

DEXION Oven under cooktop gas LX9GF09

DEXION Pasta cooker MG099-04-318, MG099-05-305, MG459-04-317, MG459-05-305

DEXION Pot stove gas D77GTA, D77GTF, LX9GT2DS, LX9GT2SS, LXGT9, MG117-03-110XL

HOBART Bain-marie gas BTGDBM, BTGSBM, HGBM66, HGBM77

HOBART Boiling pan gas HG50I7

HOBART Bratt pan BCGABP, BCGMBP, BMGMBP

HOBART Convection oven BBGO, HGFO7

HOBART Fry top BTGDG, BTGDGC, BTGDGRG, BTGDGRGC, BTGDRG, BTGDRGC, BTGSG, BTGSGL, BTGSRG, BTGSRGC, HGFT177, HGFT47, HGFT77

HOBART Fryer gas BCGDF, BCGSF, BMGDF, BMGSF, HGF472V

HOBART Kitchen electric HG4SFE7

HOBART Kitchen gas BMG2BSTO, BMG4BO, BMG6B2O, BMG6BO, BMGSTO, HG4SF7, HG4SMFA7, HG6SFA7, HG6SFEA7, HGT2SDFA7, HGT4SF27, HGTF7

HOBART Lava rock grill gas HGPL47, HGPL77

HOBART Pasta cooker BCGDPC, BCGSPC, BMGDPC, BMGSPC, HGC47, HGC77

HOBART Pot stove gas BTG2BSTL, BTG2BSTR, BTGST, HGT2SD7, HGT4S7, HGT7

LOTUS Gas oven FORNO S90 GN2-1 GAS STATICO CARCASSA, FORNO S90 GN3-1 GAS STATICO CARCASSA

MBM Bain-marie gas GBM45, GBM46, GBM477, GBM49T, GBM66, GBM777, GBM90, GBM99T, GBMA477, GBMA777

MBM Boiling pan gas G5077, G50I77

MBM Bratt pan GBR, GBR6, GBR77, GBR9T, GBRA, GBRA9T, GBRAVI9T, GBRI77, GBRVI9T, MG7GBR77, MG7GBRI77

MBM Convection oven FCE108, FCE68, FCG10, FCG108, FCG20, FCG6, FCG68, FGP050, FGP080, FGP160

MBM Fry top GFT106L, GFT106LC, GFT106LR, GFT106LRC, GFT1177LR, GFT1177LRC, GFT408L, GFT408LC, GFT408R, GFT45L, GFT45R, GFT45RC, GFT46L, GFT46R, GFT46RC, GFT477, GFT477L, GFT477LC, GFT477R, GFT477RC, GFT498L, GFT498LC, GFT498R, GFT49L, GFT49R, GFT49RC, GFT66L, GFT66LR, GFT66LRC, GFT66R, GFT66RC, GFT777, GFT777L, GFT777LC, GFT777LR, GFT777LRC, GFT777R, GFT777RC, GFT908L, GFT908LC, GFT908LR, GFT908LRC, GFT908R, GFT90L, GFT90LR, GFT90LRC, GFT90R, GFT90RC, GFT998L, GFT998LC, GFT998LR, GFT998LRC, GFT998R, GFT99L, GFT99LC, GFT99LR, GFT99LRC, GFT99R, GFT99RC, GFTA477L,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

GFTA477LC, GFTA477R, GFTA477RC, GFTA498L, GFTA498LC, GFTA498R, GFTA777, GFTA777C, GFTA777L, GFTA777LC, GFTA777LR, GFTA777LRC, GFTA777R, GFTA777RC, GFTA911LC, GFTA911LR, GFTA911LRC, GFTA998L, GFTA998LC, GFTA998LR, GFTA998LRC, GFTA998R

MBM Fryer gas GF45, GF4772V, GF4772VB, GF4772VS, GF49, GF49T, GF90, GF90-1, GF99, GF99T, MG7GF4772V

MBM Kitchen gas C4FV, C6FV, G2SF6, G2SF6G, G2SSM77, G4SF, G4SF-1, G4SF11, G4SF77, G4SF9, G4SF9-2, G4SFP, G4SFP2P, G6SF2, G6SF29, G6SF77M, G6SF98M, G6SF98MG, G6SFA, G6SFA77, G6SFA9, G6SFM, G6SFM8, G6SFMG8, G8SF2, G8SF2P, MG7G4SF77, MG7G4SF77P, MG7G6SF77M, MG7G6SFA77

MBM Lava rock grill gas GPL408, GPL46P, GPL477, GPL498, GPL777, GPL86-P, GPL908, GPLA477, GPLA498, GPLA777, GPLA998, MG7GPL477, MG7GPL777, MG7GPLA477, MG7GPLA777

MBM Oven under cooktop electric GT2SFA

MBM Oven under cooktop gas GF077, GF09, GF09T, GFB09

MBM Pasta cooker EC9982V-SC, GC408-SC, GC411-SC, GC45, GC47, GC477, GC477-SC, GC49, GC498-SC, GC49T, GC777, GC777-SC, GC90, GC902V, GC9082V-SC, GC911-SC, GC992V, GC992VT, MG7GC477-SC, MG7GC777-SC

MBM Pot stove gas FP01-V, G2SSMA77, G3SF6, G3SF6G, G4SF77P, G4SF8, G4SF98, G4SF98P, G4SM77, G4SMA77, G4SMFA77

MBM Solid top range GT, GT2SD77, GT2SD9, GT2SDF, GT2SDF8, GT2SDFA77, GT2SDFA9, GT2SS9, GT4S77, GT4SF27, GT4SF277, GT4SF2E77, GT77, GT99, GT998, GTA77, GTA8, GTA911, GTF, GTF77, GTF8, GTF9, GTF911, GTF98, GTFE, MG7GTA77, MG7GTF77

MBM Stove camp gas FP01V

