



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Comutator (selector) 0-6 pozitii EGO 46.27266.813 #3057076

Fara TVA: 42,02 Lei

Pret cu TVA: 50,00Lei

Comutator (selector) 0-6 pozitii EGO 46.27266.813 #3057076

type: 7 operating positions

function: 6NO

switching sequence: 0-1-2-3-4-5-6

switching capacity: 16A

shaft diameter: 6x4.6mm

shaft length: 23mm

connection: male faston 6.3mm

Compatibil cu:

BEKO

BOSCH - BALAY

BOSCH - SIEMENS

ELECTROLUX PROFESSIONAL

ASCASO CZA201

ATEL 8013413

EGO 4627266813, 46.27266.813

EPMS 1110187

EPMS 235004

EPMS 235039

GEV 300177

LF 3057076

ALPENINOX 059238

ARCELIK BEKO 163100005

ARDO 502007200, 651067087

ARISTON 482000022580, C00013413

BALAY 00060917, 00420551, 00609300

BOMPANI M00311018, M00311072

BOSCH 00060917, 00420551, 00609300

CANDY 93756641

EGO 4627266813

ELECTROLUX 053408, 059238, 0K2888, 3051703019, , 3285302000, 3581980103, 3872073006, 4627266813



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

EPMS 1110187, 235004, 235039

FORVED SNACKCOMMUT

HOOVER 93756641

HOTPOINT 482000022580, C00013413, C00235537

INDESIT 482000022580, C00013413, C00235537

ROSIERES 93756641

SIEMENS 00060917, 00420551, 00609300

SNACK EXPRESS SNACKCOMMUT

WHIRLPOOL 159238, 481227327007, 481227327021, 481227328048, 481281718139, 481927328054,
481990302262, 482000022580, 771985003713

ZANUSSI 053408, 059238

ZEROWATT 93756641

ARISTON Convection oven 00086 (1010BRAUN), 00086 (1010WEISS), C-L31E1, 05475 (HM10), 05476 (HM10),
05477 (HM10), 05478 (HM10), 13554 (HM10M), 13555 (HM10M), 06386 (HM10V), 05487 (HM24T), 05488
(HM24T), 06269 (HM34T), 06270 (HM34T), 16560 (HM50), 16561 (HM50), 16562 (HM50), 16563 (HM50), 16625
(HM50), 16626 (HM50G), 16627 (HM50G), 16628 (HM50G), 24018 (HM50R(ALU)), 18126 (HM50R(WH)SK),
18125 (HM50RIXSK), 16564 (HM54T), 16565 (HM54T), 16566 (HM54T), 05469 (HS10), 05470 (HS10), 05473
(HS10), 05474 (HS10), 08394 (HS10), 08395 (HS10), 08396 (HS10), HS10.1IX, 06271 (HS100), 06273 (HS100),
06275 (HS100), 08397 (HS10D), 08398 (HS10D), 08399 (HS10D), 13556 (HS10M), 06526 (HS10V), 16552
(HS30), 16553 (HS30), 16554 (HS30), 16555 (HS30), 16559 (HS30), 16556 (HS30G), 16557 (HS30G), 16558
(HS30G), 24017 (HS30R(ALU)), 02032 (I-G04EEDEL), 05250 (I-G04ENR), 02033 (I-G04M), 02034 (I-G04M2N),
02035 (I-G04M2N), 02232 (I-G04M2N)

ARISTON Kitchen gas A5E52FXAG, A5ESH2EWEX, A5-L31E3-70, A5MSH2EWEX, A5-S42E3-70, A6ESC2EWEX,
A6ESC2FXEX, A6-L31E3-75, A6-L31E3-75B, A6MG2FCXEX, A6MMC6AFXEX, A6MSH2FXEX, A6-S42E3-75, 00400
(A6S42E375B), A6V530WEX, A6V530XEX, A6VMH60WAUS, A6VMH60XAUS, 00086 (BL04E03), 00086
(BL04EF02), 00086 (BL04EF02.2), 00086 (BL22EF04.4), 22615 (C085G(W).2EX), 22615 (C085G(W)EX), 22616
(C085G(X)EX), 22616 (C085G(X)EX.2), 22650 (C210G(W)P), 22651 (C21E(W)P), C302E.2(W)SK, C302E.3(W)EX,
26663 (C302EWEX), C302EW-SK, 26056 (C302MWR), C303E.3(W)F, 26057 (C303EWF), C30N1(W)EX,
C30N1(W)R, C30N1WEXS, 27109 (C310EWSKD), C3150EC-SKD, C3150EW-SKD, C315EC-SKD, C315EW-EX,
26668 (C315EWSKD), 26046 (C319MWF), C31N1(W)EX, C31N1WEXS, C31SM1(X)EX, C31SN1(W)EX, 27112
(C320ECSKD), 27111 (C320EWSKD), C320GC-SKD, C325EW-EX, 22326 (C502E(W)), 22606 (C502E(W)R), 06624
(C504E3), 23680 (C510E(C)CKD), 22329 (C510E(W)), 23679 (C510E(W)CKD), 22582 (C514E(W)F), 23074
(C515E(C)CKD), 23073 (C515E(W)CKD), 22617 (C515GD(G)EX), 23071 (C520E(C)SKD), 23069 (C520E(W)SKD),
26037 (C520G(W)SKD), 22618 (C522E(W) EX), 06623 (C531E4), 13479 (C531E4.E), 13480 (C531E4.E), 21695
(C602E(W)F), 22353 (C602M(W)EU), C602M.3(W)EU, 22354 (C602P(A)EU), 06619 (C604E3), C60N1(W)EX,
C60P1(W)SK230, 21690 (C615(W)F), 29445 (C615.5(W)F), 26022 (C615E(C)CKD), 22597 (C615E(W)CKD),
25413 (C615E(W)P), 22600 (C615E(W)P(1)), 21641 (C615E(W)T), C615E.3(W)T, C615EX-CKD, 22604
(C615G(X)P), 25416 (C615G(X)P), 22352 (C615M(W)EU), 22602 (C615M(X)P), 25415 (C615M(X)P),
C615M.3(W)EU, 21642 (C616T(W)T), C616T.3(W)T, 22351 (C617P(X)EU), 21692 (C6191PAF), 21693

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(C6192PBF), 21643 (C619M(W)T), 21644 (C619M(X)T), C619M.3(W)T, C619M.3(X)T, 21644 (C619MXT), 21691 (C619P(W)F), 30187 (C61F7(W)F), C61F8(W)F, C61N1(B)CKD, C61N1(W)CKD, C61N1(X)CKD, C61P1(W)EX, C61P6(W)F, C61SM2(W)T, C61SP1(X)EU, C61SP6(X)T, C61ST6(W)T, 06618 (C631E6), 13475 (C631E6.E), 14896 (C631E6D), 22336 (C970G(C)), 22337 (C970G(W)), 23144 (C975ED(W)CKD), 22625 (C975ED(X)EX), C975ED(XS)EX, 22338 (C980E(C)), 23126 (C980E(C)SKD), C980E(CP), 22339 (C980E(W)), 23125 (C980E(W)SKD), C980E(WH), 26893 (C980G(C)SKD), C980G(CP)SKD, 22626 (C980G(W)EX), 24527 (C980G(W)SKD), C980G(WH)EX, 22340 (C982E(W)), 22630 (C985E(W)P), 22631 (C985E(X)P), C985E(XS)P, 22342 (C985M(W)), 22343 (C985M(X)), 22344 (C987M(W)), C987M(WH), 22345 (C987M(X)), C987M(XS), 22629 (C98G(W)P), CE60N1(W)EX, CE60N1(X)EX, CE60N1WEXS, CE60N1XEXS, CE60P1(W)GR, CE6VP6(W)EU, CX61FA(W)F, CX61P6(W)F, CX61SN1(X)EX, CX61SN1XEXS, CX61SP6(X)T, CX61SP6XTS, 00086 (G04E3BE), 04859 (G0MEGR), 05467 (G0MEGR), 04858 (G1MCGR), 14689 (G1MCR), 05466 (G2VCGR), 04394 (G3SCGB), 07890 (G431E), 13247 (G431E), 07203 (G431E3), 13250 (G431E3), 07942 (G431G2), 13249 (G431G2), 04870 (G504E2F), 04845 (G504E2GB), 05158 (G504E2GB), 02119 (G504E3), 15706 (G504E3.EW), 14683 (G504E3R), 05696 (G521CG4EX), 07334 (G522E3SEX), 05423 (G522E3SKD), 05426 (G522E3SKD), 05427 (G522E3SKD), 15822 (G522E3SKD), 04868 (G531E2F), 02118 (G531E3), 12501 (G531E3.E), 15705 (G531E3.EW), 05422 (G531E3SKD), 05823 (G531E5SKD), 05824 (G531E5SKD), 04086 (G531G4EX), 04873 (G604E3F), 16547 (G604E4(W)SKD), 04857 (G604E4GR), 04635 (G604E6PG), 14688 (G604E6R), 17216 (G604M4(W)GR), 18001 (G604M8(W)R), 05171 (G604M9.2GB), 07579 (G605VGB), 04872 (G631E3F), 04636 (G631E6PG), 12563 (G631E6TR), 07887 (G631E7.E), 15240 (G631E8TR), 12564 (G631E9TR), 13256 (G631M6.EGR), 11560 (G631M6GR), 13258 (G631M8.E), 04634 (G631M8PG), 18405 (G631M8S(X)), 15245 (G631M9S.1TR), 12565 (G631M9STR), 12566 (G631M9STR), 16278 (G631M9STR.1W), 15244 (G631M9TR), 15242 (G631T9TR), 15243 (G631T9TR), 13710 (G650MC), 14692 (G6VE6R), 05802 (G731E5), 12443 (G731E5.E), 13182 (G731G3.EGR), 05895 (G731G3GR), 05286 (G842G5.1EX), 17445 (G842G5.1EX), 06126 (G842G5EX), 17449 (G842G5EX), 05938 (G842G5SEX), 04740 (G931CE5.2EX), 04864 (G931CE5.2EX), 04119 (G931CE5EX), 04123 (G931CE5EX), 05693 (G931CE5SKDGR), 02129 (G941G2), 12525 (G941G2.E), 05241 (G941G3.2), 12538 (G941G3.E), 15742 (G941G3.E(C)), 02132 (G942E2), 12528 (G942E2.E), 04672 (G942E2S), 02130 (G942E3), 02131 (G942E3), 12526 (G942E3.E), 12527 (G942E3.E), 15743 (G942E3.E(C)), 04670 (G942E3S), 16357 (G942E3S(W)BE), 12529 (G942E3S.E), 05430 (G942E3SKD), 05821 (G942E3SKD), 05822 (G942E3SKD), 15821 (G942E3-W-SKD), 02134 (G942E5), 04865 (G942E5.2EX), 13434 (G942E5.E), 13435 (G942E5.E), 16453 (G942E5.E(W)P), 16454 (G942E5.E(X)P), 04124 (G942E5EX), 04638 (G942E5PG), 04671 (G942E5S), 06123 (G942G3EX), 16456 (G942G4(W)PT), 02137 (G942M6), 02138 (G942M6), 04795 (G942M6.2), 04796 (G942M6.2), 12533 (G942M6.E), 12534 (G942M6.E), 14690 (G942M6R), 06344 (G942M6S), 06345 (G942M6S), 12541 (G942M6S.E-W-), 12542 (G942M6S.E-X-), 12083 (GS841E5), 12084 (GS841E5S), 16344 (GVM8(W)), KL04E6PG, 00086 (KL04E72GR), 00963 (KL31E6PG), 00971 (KS42E6PG), M04E1UK, M04E3, 02482 (M31E3), 00003 (P31E5.1), 04856 (P31GE3SGR), 00086 (PBL04E03), 00086 (PBL04EF02.2), 00086 (PBL22EF02.1), 00086 (PBL22EF02.2), S41GE3, 02487 (S42E3), SC41GE2, SC42E2, 04415 (SG42G5.2SKD), 04413 (SGX42G5.2SKD), SP41GE3, SPX41G5, SX42E5, SX42M6, 03071 (XL31EVE8EXP)

ARISTON Kitchen glass-ceramics AUE61KAUS, AUE61XAUS, C3V10M.3(W)F, C3V10MW-F, 27642 (C3V9EWF), C3VM6(W)F, C3VM6(X)F, C3VN1(W)R, C3VN1(X)R, 22154 (C6V7P(W)B), C6V7P.3(W)B, 22097 (C6V9M(W)R),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

21646 (C6V9M(W)T), 21694 (C6V9P(W)F), 22095 (C6V9P(W)R), C6V9P(W)U, C6V9P.3(W)U, C6V9P.5(W)R,
22096 (C6V9PAR), C6VF7(X)R, C6VF8(X)R, C6VF8XU, C6VM3(A)R, C6VM3(W)R, C6VM3(X)R, C6VP1(W)B,
C6VP4(W)R, C6VP4(X)R, C6VP6(A)U, C6VP6(X)T, CE6VM3(A)R, CE6VM3(W)R, CE6VM3(W)RS, CE6VM3(X)NA,
CE6VM3(X)R, CE6VM3(X)RS, CE6VP4(X)R, CE6VP6(A)U

ARISTON Pot stove gas I-P31M, 10866 (P631M), 10867 (P631M), 10868 (P631M), P631M(IX)-EP31A(IX).,
P631M-EP31A, P631M-PPI31A

BEKO Kitchen 7714787600 (BFD6656C), 7786187604 (CSE63110DW), 7787187607 (CSS57100GA)

BOSCH - SIEMENS Kitchen electric EH594HMSW-00, EH594HMSW-01, EH694HMLW-01, EH694HMSW-01,
EH694HMSW-02, EH694HMSW-03, EH694HS-00, EH694HS-01, EH694HS-02, EH696GKL-01, EH696GKL-02,
EH696GKL-03, EH696GKL-04, EH696GKLW-01, EH696GKLW-02, EH696GKLW-03, EH696GKLW-04,
EH696GKS-01, EH696GKS-02, EH696GKS-03, EH696GKS-04, EH696GKSW-01, EH696GKSW-02, EH696GKSW-03,
EH696GKSW-04, EH696HM-01, EH696HM-02, EH696HMS-00, EH696HMS-01, EH696HMS-02, EH696HMSW-00,
EH696HMSW-01, EH696HMSW-02, EH696HMW-01, EH696HMW-02, EH697GKL-02, EH697GKLW-02,
EH697GKS-02, EH697GKSW-02, EH697HM-01, EH697HM-02, EH697HMS-01, EH697HMS-02, EH697HMW-01,
EH697HMW-02, EH698GKL-01, EH698GKLW-01

CANDY Kitchen 39353917 (CFCC66M04HE), 39351812 (CFCC66MV), 39353909 (CFCC66MVHE), 39351788
(CFCC66P31), 39351804 (CFCC66XP31), 39351820 (CFCCS66MSL31)

CANDY Pot stove glass-ceramics 36069607 (PVS31N), 36069003 (PVS31W), 36069615 (PVS31X), 36070605
(PVS32N), 36070001 (PVS32W), 36070613 (PVS32X), 36071603 (PVS40N), 36071009 (PVS40W), 36071611
(PVS40X)

ELECTROLUX Dishwasher ASU4010IB (91175031200), ASU4010IW (91175031300), ASU4010IN (91175031400),
ASU4020I (91175031500), AKE4121IW (92379006500), AKU4117IW (92387001500), AZE4125IW
(92561002000), AZE4129IW (92570000700), AHE4022UA (94972018600)

ELECTROLUX Domestic refrigerator AKU4115IW (92345000500)

ELECTROLUX Electric oven AHE4011NB (94972018200), AHE4011NW (94972018300), AHE4071NB
(94972029800), AHE5031NB (94972030000), AHE5031NW (94972030100), AHE4082UD (94972030200),
AHE4082UN (94972030300), AHE4082UA (94972030400), AHE4092UD (94972030500), AHE4082UD
(94972037700), AHE4082UA (94972037800), AHE4082UN (94972037900), AHE4092UD (94972038000),
AHE4071NS (94972038400), AHE4071NN (94972038500)

ELECTROLUX Kitchen EK6725 (94776009500), ZC661CM (94776009800), AHE4071NW (94972029900),
94300112700 (EKM600301W), 94300112701 (EKM600301W), 94300112702 (EKM600301W), 94300112703
(EKM600301W), 94300130500 (EKM606700W), 94300130502 (EKM606700W), 94300130503 (EKM606700W),
94300455400 (FCM5400CWA)

ELECTROLUX Pot stove electric PX631A (94974029800), PB631A (94974029900), PT631A (94974030000),
PN631A (94974030900), PX631A (94974031800), PX631A (94974031801), PB631A (94974031900), PB631A
(94974031901), PT631A (94974032000), PT631A (94974032001), PN631A (94974032100), ZXF636X
(94974035500), ZXF636X (94974035501), ZXF636X (94974035502), ZXF636N (94974035600), ZXF636N
(94974035601), ZXF636N (94974035602), ZXF636W (94974035700), ZXF636W (94974035701), ZXF636W
(94974035702), ZXF636TDF (94974035800), PX631V (94974041101), PX631V (94974041102), PX631V

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(94974041103), PB631V (94974041201), PB631V (94974041202), PB631V (94974041203), PT631V (94974041301), PT631V (94974041302), PT631V (94974041303), PX631V (94974046800), PB631V (94974046900), PT631V (94974047000), PX631V (94974055500), PX631V (94974055501), PX631V (94974055502)

ELECTROLUX Pot stove gas Z31S (94974007800), Z31W (94974007900), Z031W (94974009400)

HOOVER Pot stove 39355482 (HOB SECTION)

HOTPOINT Electric oven 60HEG

HOTPOINT Kitchen H6M6C2AGXFR, H6MMC2AEWFR, H6MMCAXFR, 088310 (H6MMP6AEW), H6MMP6AGX, H6MSC1AEWFR

HOTPOINT Kitchen electric C120EW, CE60P1(W)GR-HA, EW12P, HL500E, HW150EW

HOTPOINT Kitchen gas C30N1(W)R-HA, C368EWH, CH10456GF S, CI6VE9(W)R-HA, CI6VE97(W)RU-HA, CI6VE97A1XHA, CI6VE97A1XHA.0, CI6VE97XRUA, CX610ST(W)T-HA, CX61SFA(W)F-HA, CX61SFA(W)FHAS, CX61SFAXF-HA, CX61SFAXF-HAS, CX61SP6(W)F-HA, DCN60K, EG 600 P, EG900X S, EK50, EW12C, H5M6C2AGWFR, H5MMC1AGXFR

HOTPOINT Kitchen glass-ceramics 50HEG, 50HEGS, 50HEP, 50HEPS, 50HEPS-E, 52TCW, 52TCWS, 60HEGS, 60HEGS-E, 60HEP, 60HEPS, 60HEPS-E, 61DCW, 62DCBK, 62DCW, 62DCWS, ARC60X, C358EWH, C367EKH, C367EXH, C3BM6(W)F-HA, C3BM6(X)F-HA, C3VN1(W)R-HA, C3VN1(X)R-HA, C3VN17(X)RU-HA, CE6VE6(X)GR-HA, CE6VM3(A)R-HA, CE6VM3(A)R-HAS, CE6VM3(W)R-HA, CE6VM3(X)R-HA, CE6VM37(X)RU-HA, CE6VM3WRHAS, CE6VM3XRHAS, CE6VP4(X)R-HA, CE6VP6(W)EU-HA, CM5V21(X)RFH, DCH50CW, DCN60P, DCN60S, DSC50S, DSC60P, DSC60P-E, DSC60S, DSC60SS, DSC60SS.1, DSC60SS.1-E, DUE61BC, DUE61R, EW36G, EW48K, EW74G, EW74K, EW74P, EW74X, H5VMC5AWFR, H5VSH1AWRU, H5VSH2AXRU, H6V530ARU, H6V560WRU, H6V560XRU, H6V5D60WRU, H6V5D60XRU, H6VMC2AWFR, H6VMC6AWFR, H6VMH5AWEA, H6VMH5AXEA, H6VMH60AAUA, H6VMH6AWGR, H6VMH6AXGR, HAE51G, HAE51GS, HAE51KS, HAE51PS, HAE51XS, HAE60G, HAE60GS, HAE60KS, HAE60KS-E, HAE60P, HAE60PS, HAE60PS-E, HAE60X, HAE60XS, HAE60XS-E, HARE51K, HARE51P, HARE60K, HARE60K-E, HARE60P, HARE60P-E, HM5V22AXRU, HUE52G, HUE52GS, HUE52GS-E, HUE52K, HUE52KS, HUE52KS.0, HUE52KS.0-E, HUE52P, HUE52PS, HUE52PS-E, HUE52X, HUE61GS, HUE61KS, HUE61PS, HUE61X, HUE61XS, HW160EC, HW160EW, HW170EK, HW170EKS, HW170EW, HW170EWS, JLE60P, JLE60P-E, JLE61P

INDESIT Convection oven 04655 (CIE), 04656 (CIE), 05633 (CIE), F004655 (CIE), F004656 (CIE), F005633 (CIE), 15911 (CIE.1), 15912 (CIE.1), F015911 (CIE.1), F015912 (CIE.1), 13395 (CIE2), 13396 (CIE2), F013395 (CIE2), F013396 (CIE2), 04921 (CIEEDEL), F004921 (CIEEDEL), 07422 (CIEV), F007422 (CIEV), 15915 (CIM.1EDEL), F015915 (CIM.1EDEL), 04657 (CIM2), 04658 (CIM2), 05634 (CIM2), F004657 (CIM2), F004658 (CIM2), F005634 (CIM2), 15913 (CIM2.1), 15914 (CIM2.1), F015913 (CIM2.1), F015914 (CIM2.1), 04659 (CIM8), 04660 (CIM8), F004659 (CIM8), F004660 (CIM8), 04922 (CIMEDEL), F004922 (CIMEDEL), 07423 (CIMV), F007423 (CIMV), 12603 (HGK), 12604 (HGK), 12605 (HGK), F012603 (HGK), F012604 (HGK), F012605 (HGK), 25455 (HGK(BK)Z), F025455 (HGK(BK)Z), 24748 (HGK(WH)IB), F024748 (HGK(WH)IB), 22312 (HGK(WH)S), F022312 (HGK(WH)S), 24033 (HGK10(BK)), F024033 (HGK10(BK)), 24034 (HGK10(BR)), F024034 (HGK10(BR)), 24035 (HGK10(IX)), F024035 (HGK10(IX)), 24032 (HGK10(WH)), F024032 (HGK10(WH)), 13947 (HGK2), 13948 (HGK2), F013947 (HGK2), F013948 (HGK2), 24750 (HGK2(BR)IB), F024750 (HGK2(BR)IB), 24749 (HGK2(WH)IB), F024749

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(HGK2(WH)IB), F027827 (HGK2BR-IB.1), 14420 (HGK2EDEL), F014420 (HGK2EDEL), 24690 (HGK2IXIB), F024690 (HGK2IXIB), 27809 (HGK2IXIB.), F027809 (HGK2IXIB.), 27826 (HGK2WHIB.1), F027826 (HGK2WHIB.1), 15209 (HGKAN), F015209 (HGKAN), 12606 (HGKEDEL), F012606 (HGKEDEL), 24689 (HGKIXIB), F024689 (HGKIXIB), 12607 (HGKMR), F012607 (HGKMR), 27825 (HGKWHIB.1), F027825 (HGKWHIB.1), 12608 (HGM), 12609 (HGM), 12610 (HGM), F012608 (HGM), F012609 (HGM), F012610 (HGM), 24037 (HGM10(BK)), F024037 (HGM10(BK)), 24038 (HGM10(BR)), F024038 (HGM10(BR)), 24039 (HGM10(IX)), F024039 (HGM10(IX)), 24036 (HGM10(WH)), F024036 (HGM10(WH)), 14421 (HGM2), 14422 (HGM2), F014421 (HGM2), F014422 (HGM2), 24692 (HGM2(BR)IB), F024692 (HGM2(BR)IB), 24691 (HGM2(WH)IB), F024691 (HGM2(WH)IB), 14423 (HGM2EDEL), F014423 (HGM2EDEL), 24693 (HGM2IXIB), 27811 (HGM2IXIB), F024693 (HGM2IXIB), F027811 (HGM2IXIB), F027810 (HGM2WH-IB), 15210 (HGMAN), F015210 (HGMAN), 12611 (HGMEDEL), F012611 (HGMEDEL), 27807 (HGML(EDEL)), F027807 (HGML(EDEL)), F027807 (HGMLEDEL), 12612 (HGMMR), F012612 (HGMMR), 15211 (HGMRA), F015211 (HGMRA), 12759 (HGMV), 12760 (HGMV), 12761 (HGMV), F012759 (HGMV), F012760 (HGMV), F012761 (HGMV), 12762 (HGMVEDEL), F012762 (HGMVEDEL), 12763 (HGMVMR), F012763 (HGMVMR)

INDESIT Kitchen electric F085434 (I5E52EWKZ), F096876 (I5E52EWKZ-E), F084879 (I5E52EWRU), F085310 (I5E6AEWFR), F088449 (I5E6CAEWFR), F096839 (I5ESH(W)UK-E), F085217 (I5ESH1EWEX), F085512 (I5ESH1EWI), F096841 (I5ESH1EWI), F085917 (I5ESH1EWUA), F088405 (I5ESH1SUK), F085294 (I5ESH1XUK), F096855 (I5ESH1XUK-E), F085438 (I5ESH2AEWKZ), F084881 (I5ESH2AEWRU), F085295 (I5ESHAUK), F084880 (I5ESHAWRU), F085687 (I5ESHAWU), F088404 (I5ESHKUK), F085291 (I5ESHWUK), F085305 (I5M5C1GWFR), F083809 (I6E5H2EWEX), F083517 (I6E6C1AEWFR), F083662 (I6E6C1AWFR), F084291 (I6EMH2AWGR), F083806 (I6ESH2EWKZ), F084207 (I6ESH2EWRU), F084288 (I6ESHAWGR), F083508 (I6EVAWUK), F081212 (IS50EWS), F074372 (IS60EW), F081210 (IS60EWS), F075064 (IT50E1X), F081216 (IT50E1XXS), F081215 (IT50EMS), F075061 (IT50EW), F081213 (IT50EWS), F029140 (K10E.C(W)-R), F025289 (K10EW-R), F035291 (K1E1(W)-R), F067612 (K1E107(W)-RU), F081076 (K1E1WRS), F025274 (K300EW-R), F027056 (K300EW-SK), F027768 (K300EW-SV), F025642 (K300EX-G), F029531 (K300M.B(W)-EU), F026354 (K300MW-EU), F029406 (K301E.C(X)-G), F027540 (K301EX-G), F029438 (K30E.C(W)-F), F025629 (K30EW-B), F025272 (K30EW-F), F025641 (K30EW-G), F029405 (K31E.C(W)-G), F027539 (K31EW-G), F026351 (K322ESW-EU), F026353 (K323MSW-EU), F029433 (K330E.C(W)-R), F026955 (K330ES-I), F025634 (K330EW-I), F025273 (K330EW-R), F029439 (K331.C(W)-F), F026794 (K331EW-T), F030276 (K331M.B(W)-U), F024832 (K331MW-U), F025270 (K331W-F), F026656 (K332EW-EXCKD), F029444 (K332M.C(W)-F), F025271 (K332MW-F), F024168 (K336PSW-U), F043759 (K3E1(A)-IR), F034261 (K3E1(W)-FR), F035943 (K3E1(W)-G), F034134 (K3E11(W)-I), F035283 (K3E11(W)-R), F035944 (K3E11(X)-G), F067629 (K3E117(W)-RU), F041032 (K3E5(W)-FR), F035999 (K3E51(W)-EU), F054090 (K3E51(X)-AG), F067630 (K3E517(W)-RU), F081078 (K3E51WEUS), F033975 (K6E1(W)-SK), F030873 (K6E11(W)-F), F042379 (K6E11(W)-GR), F030874 (K6E11(W)-R), F033171 (K6E32(W)-G), F033172 (K6E32(X)-G), F041034 (K6E51(W)-FR), F033674 (K6E52(W)-EX), F033971 (K6E52(W)-GR), F042380 (K6E55(W)-GR), F014040 (KC3043BG-E), F008391 (KC3043WG-E), F011964 (KC3043WU-E), F008392 (KC3402WG-E), F012768 (KC3402WG-E), F007934 (KC4311WE-E), F013485 (KC4311WE-E), F007950 (KC4311WP-G), F013505 (KC4311WP-G), F007951 (KC4312WP-G), F013504 (KC4312WP-G), F007938 (KC4313WE-E), F013483 (KC4313WE-E), F007952 (KC4313WP-E), F013503

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(KC4313WP-E), F034927 (KD3E11(X)-G), F022735 (KG3030.1WE-F), F012118 (KG3030WE-F), F014326 (KG3043WE-R), F023059 (KG3043WE-R.), F023053 (KG3044BE-G), F017483 (KG3044BE-G.1), F013458 (KG3044WE-G), F023051 (KG3044WE-G.), F015453 (KG4311WEB-E), F013114 (KG4311WE-E), F015494 (KG4311WEN-E), F013675 (KG4311WG-P), F014063 (KG4312WG-P), F013673 (KG4313WE-P), F073398 (KN1E17(W)-RU), F082749 (KN1E17AWRU), F074134 (KN1E1W-UA), F081196 (KN1E1WUAS), F073404 (KN1M117S(W)-RU), F073930 (KN1M11S(W)-BA), F081177 (KN1M11SWBAS), F082424 (KN3E107A(W)-RU), F073595 (KN3E11(W)-EX), F073522 (KN3E11(W)-I), F073452 (KN3E117A(W)-RU), F074146 (KN3E11AWEU), F081197 (KN3E11AWEUS), F081148 (KN3E11WEXS), F081137 (KN3E11WIS), F074470 (KN3E17(W)-RU), F073453 (KN3E517(W)-RU), F073588 (KN3E51XAG), F081147 (KN3E51XAG), F073927 (KN3E62A(W)-BG), F081174 (KN3E62AWBGS), F081096 (KN3E6AWFRS), F011976 (KN6046WN-E.1), F011975 (KN6047WN-M.1), F073434 (KN6E117W-RU), F074133 (KN6E11AW-GR), F081195 (KN6E11AWGRS), F074059 (KN6E11WEX), F081180 (KN6E11WEXS), F073600 (KN6E52(W)-EX), F081150 (KN6E52WEXS), F073274 (KN6E61A(W)-FR), F081108 (KN6E61AWFRS), F073916 (KN6E62A(W)-GR), F081169 (KN6E62AWGRS), F073917 (KN6E76A(W)-GR), F084882 (MVI5V05XRU), F084205 (MVI6E22WRU), F079704 (MVK6E21(W)RF), F086903 (RIT50EWUK)
INDESIT Kitchen gas F088437 (EI5MSCAGXFR), F088438 (EI5VMC5AWFR), F088436 (EI6V6C6AWFR), F085222 (I5MG1GXEX), F085304 (I5MMC2AGWFR), F085308 (I5MMCAGWFR), F088243 (I5MS1WKZ), F085060 (I5MSH20AGWRU), F088231 (I5N65AKXBG), F085689 (I5NSH1AEWU), F089520 (I5NSH2AEWBG), F085435 (I5NSH2AEWKZ), F085059 (I5NSH2AEWRU), F088435 (I6M6CAGWFR), F083526 (I6M6CAGXFR), F083813 (I6M6HAGXFR), F083803 (I6MG1GXEX), F088446 (I6MSAGWFR), F083524 (I6MSCAGWFR), F083663 (I6MSCAWFR), F074364 (IS50E1X), F081206 (IS50E1XXS), F081205 (IS50EAS), F081214 (IT50E(A)S), F085315 (IW5MSCGAWFR), F025288 (K132ESW-R), F027516 (K13GB(W)-E), F035299 (K1M11S(W)-R), 27474 (K3000MWEU), F027474 (K3000MWEU), F029397 (K300E.B(W)-I), F029473 (K300E.B(W)-SK), F029474 (K300E.B(W)-SV), F029434 (K300E.C(W)-R), F025635 (K300EW-I), F027139 (K3200EWEX-SKD), F030313 (K3300ES(W)-EX), F027104 (K3300EW-EX), F034259 (K3M1(W)-FR), F054342 (K3M1(X)-FR), F036007 (K3M11(W)-EX), F035289 (K3M11(W)-R), F038964 (K3M11S(W)-EX), F067431 (K3M1S(W)-FR), F067432 (K3M1S(X)-FR), F033644 (K3M5(W)-U), F047169 (K3M5.A(W)-U), F034260 (K3M51(W)-FR), F054343 (K3M51(X)-FR), F067433 (K3M51S(W)-FR), F067434 (K3M51S(X)-FR), F049274 (K3M56(W)-FR), F067435 (K3M5S(W)-FR), F067247 (K3M5S.A(W)-U), F035290 (K3N11S(W)-R), F036000 (K3N55S(W)-EU), F025203 (K600M(W)-EU), F025090 (K600M(W)-S), F027054 (K600M(W)-SK), F029354 (K600M.C(W)-EU), F023088 (K600V(W)-G), F029361 (K601V.C(W)-G), F028289 (K601VW-G), F023097 (K603M(W)-GR), F029355 (K603M.C(W)-GR), F023082 (K60E(W)-F), F029449 (K60E.C(W)-F), F025813 (K63(W)-F), F023104 (K63(W)-F(1)), F029452 (K63.C(W)-F), F025201 (K630E(W)-GR), F023093 (K630E(W)-S), F029293 (K631M.C(W)-F), F023119 (K631T(W)-T), F029207 (K631T.C(W)-T), F023881 (K632M(W)-F), F029453 (K632M.C(W)-F), F025202 (K633M(W)-GR), F023120 (K636M(W)-T), F024052 (K636T(W)-T), F030871 (K6M1(W)-F), F030869 (K6M11(W)-EX), F067446 (K6M1S(W)-F), F073842 (K6M40S(W)-T), F030842 (K6M5(W)-F), F054344 (K6M5(X)-F), F030846 (K6M52(W)-F), F041035 (K6M56(W)-FR), F067448 (K6M56S(W)-FR), F067449 (K6M5S(W)-F), F031987 (K6M5S(W)-T), F067450 (K6M5S(X)-F), F036899 (K6M91(W)-FR), 21790 (K942XSE), F021790 (K942XSE), F023136 (K970G(C)-I), F028524 (K970G(CP)-I), F023137 (K970G(W)-I), F028555 (K970G(WH)-I), F023141 (K980E(C)-I), F028520 (K980E(CP)-I), F023139 (K980E(W)-I), F028518 (K980E(WH)-I), F023140 (K980ES(W)-I),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

F023138 (K984ES(X)-I), F028528 (K984ES(XS)-I), F029577 (K987MS.C(WH)-I), F029578 (K987MS.C(XS)-I), F025809 (K98G(X)-P), F025084 (K98G(X)-P.1), F007930 (KC3030WF-E), F053849 (KD6E35W), F045735 (KD6E35W(T)), F023776 (KG5220WE-SSKD), F014739 (KG5222WES-EU), F018407 (KG5314WE-SC), F024047 (KG5315WE-SCKD), F011924 (KG7312WE-I), F011948 (KG8413WES-I), F011949 (KG8414XES-I), F016168 (KG9411CG-I.A), F016169 (KG9411WG-I.A), F016176 (KG9413WG-S.A), F016174 (KG9421CE-I.A), F016172 (KG9421WE-I.A), F016173 (KG9421WES-I.), F016171 (KG9424XES-I.), F016506 (KG9424XG-P), F014388 (KGM9426WG-S), F017466 (KGM9426WG-S), F014389 (KGM9426XG-S), F017467 (KGM9426XG-S), F025616 (KM82GX-EX), F007964 (KN3403WI-E), F013516 (KN3403WI-E), F073467 (KN3M117(W)-RU), F073266 (KN3M1S(W)-FR), F081100 (KN3M1S(W)-FRS), F073267 (KN3M1S(X)-FR), F073620 (KN3M21(W)-EX), F073621 (KN3M21X-EX), F073268 (KN3M51S(W)-FR), F081102 (KN3M51SWFRS), F073269 (KN3M51SX-FR), F081103 (KN3M51SXFRS), 76944 (KN3M522SWFR), F076944 (KN3M522SWFR), F081247 (KN3M522SWFRS), F076203 (KN3M522SX-FR), F073270 (KN3M5S(W)-FR), F081104 (KN3M5SWFRS), F073468 (KN3N117S(W)-RU), F073928 (KN3N11SA(W)-BG), F081175 (KN3N11SAWBGS), F074157 (KN3N11SW-EU), F081202 (KN3N11SWEUS), F082421 (KN3N61SAWBG), F073929 (KN3N65SA(W)-BG), F081176 (KN3N65SAWBGS), F082420 (KN3N65SAXBG), F073594 (KN6M21SXEX), F073593 (KN6M21W-EX), F074062 (KN6M40SA(W)-T), F081183 (KN6M40SAWTS), F073284 (KN6M66SA(W)-FR), F081112 (KN6M66SAWFRS), F073291 (KN6M6SA(X)-FR), F081114 (KN6M6SAXFRS), F005809 (KN7312WI-E), F005899 (KN9425WS-G), F005900 (KN9425XS-G), F007057 (KN9426WS-G), F007058 (KN9426XS-G), F044606 (KP 958 MS.B (X)-D)

INDESIT Kitchen glass-ceramics F086490 (DD60C2AAXUK), F088390 (DD60C2CKUK), F088387 (DD60C2CRUK), F086490 (DD60C2CXUK), F096845 (DD60C2CXUK-E), F088242 (I5V51WKZ), F084872 (I5V52WRU), F084876 (I5V55XRU), F085316 (I5V5C1W.1FR), F096857 (I5V5C1W.1FR), F085515 (I5V62AWEU), F085513 (I5V7H6AXEU), F085309 (I5VM1AXFR), F088232 (I5VM6HAWBG), F085317 (I5VMC1AWFR), F088416 (I5VMH1AXCZ), F088413 (I5VMH2AWEU), F088414 (I5VMH5AWCZ), F088418 (I5VMH5AXCZ), F084878 (I5VMH6AXRU), F086209 (I5VSH1AXFR), F084868 (I5VSH2A(W)-RU), F088417 (I5VSH2AWCZ), F084870 (I5VSH2AXRU), F084875 (I5VSHAWRU), F086916 (I5VSHKUK), F096847 (I5VSHKUK-E), F088402 (I5VSHWUK), F083525 (I6M6C6AGWFR), F084259 (I6V52WRU), F084258 (I6V56WRU), F083519 (I6V61AXFR), F083520 (I6V66AWFR), F083518 (I6V6C1A.HWFR), F088426 (I6V6C5AWHU), F088424 (I6V6C5AXHU), F083520 (I6V6C6AWFR), F083812 (I6V6H1AWFR), F084289 (I6VMC6AWGR), F084287 (I6VMC6AXGR), F084373 (I6VMH2A.1WNL), F088412 (I6VMH2APPXGR), F084284 (I6VMH2AWGR), F084571 (I6VMH2AWP), F084290 (I6VMH2AXGR), F084572 (I6VMH2AXNL), F084283 (I6VSH2AWGR), F083805 (I6VSH2WEX), F084257 (I6VSH2WRU), F084818 (I6VSHWKZ), F083506 (I6VV2AWUK), F083807 (I6VV2AXEX), F083504 (I6VV2AXUK), F075078 (ID50C1K), F081223 (ID50C1KS), F075077 (ID50C1W), F081222 (ID50C1WS), F081229 (ID50E1WS), F075087 (ID50E1X), F081225 (ID60C2(A)S), F075092 (ID60C2(K)), F075082 (ID60C2(X)), F075080 (ID60C2A), F084494 (ID60C2AAM), F081231 (ID60C2KS), F096854 (ID60C2KS-E), F081226 (ID60C2MS), F088389 (ID60C2NUK), F088391 (ID60C2RUK), F075079 (ID60C2W), F081224 (ID60C2WS), F096852 (ID60C2WS-E), F081227 (ID60C2XS), F096853 (ID60C2XS-E), F075090 (ID60E2W), F081230 (ID60E2WS), F074367 (IS60C1W), F081207 (IS60C1WS), F074368 (IS60C1X), F081208 (IS60C1XXS), F088395 (IT50C1SUK), F081220 (IT50C1XXS), F081218 (IT50CAS), F088396 (IT50CKUK), F081219 (IT50CMS), F081217 (IT50CWS), F085313 (IW5VMC1AXFR), F085314 (IW5VSC1AWFR), F029442 (K2C10M.C(W)-F), F028646 (K2C10MW-F), F027448

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(K2CEW-F), 26828 (K35CEXF), F026828 (K35CEXF), F029435 (K3C0E.C(W)-R), F026418 (K3C0EW-R), F029402 (K3C0M.B(W)-D), F029441 (K3C0M.C(W)-R), F028697 (K3C0MW-D), F026419 (K3C0MW-R), F028647 (K3C10MW-F), F062261 (K3C11(W)-AUS), F034262 (K3C11(W)-FR), F035281 (K3C11(W)-R), F062262 (K3C11(X)-AUS), F054339 (K3C11(X)-FR), F067626 (K3C117(W)-RU), F029443 (K3C15M.C(W)-F), F035942 (K3C36(X)-G), F041031 (K3C51(W)-FR), F033643 (K3C51(W)-U), F054340 (K3C51(X)-FR), F050524 (K3C51.A(W)-U), F081079 (K3C51WFRS), F096832 (K3C51WFRS), F081073 (K3C51WUS), F049272 (K3C55(W)-FR), F035282 (K3C55(X)-R), F067627 (K3C557(X)-RU), F036374 (K3C76(W)-BG), F036373 (K3C76(X)-BG), F067628 (K3C767(X)-RU), F029471 (K3C7M.B(W)-SK), F029472 (K3C7M.B(W)-SV), F029440 (K3C7M.C(X)-R), 27057 (K3C7MWSK), F027057 (K3C7MWSK), F028000 (K3C7MW-SV), F026829 (K3C7MX-R), F029403 (K3C8P.B(W)-D), F030274 (K3C8P.B(W)-U), F029404 (K3C8P.B(X)-D), F027496 (K3C8PW-D), F026417 (K3C8PW-U), F027497 (K3C8PX-D), 27058 (K3C8PXSK), F027058 (K3C8PXSK), F026407 (K3C8PX-U), F029365 (K3C8V.B(X)-G), F029364 (K3C8V.BA-G), F028467 (K3C8VA-G), F026823 (K3C8VW-G), F026824 (K3C8VX-G), F026827 (K3CEW-F), F030876 (K6C10(W)-R), F067636 (K6C107(W)-RU), F081072 (K6C10WRS), F030875 (K6C11(W)-R), F033168 (K6C32(W)-G), F033169 (K6C32(X)-G), F035976 (K6C320(W)-G), F062258 (K6C320(X)-AUS), F035977 (K6C320(X)-G), F030867 (K6C51(W)-F), F042381 (K6C51(W)-GR), F030863 (K6C51(W)-R), F059003 (K6C51(X)-EX), F060359 (K6C51(X)-F), F068982 (K6C517(W)-RU), F060700 (K6C56(W)-F), F042382 (K6C56(X)-GR), F081080 (K6C56XGRS), F023092 (K6C7E(W)-R), F029462 (K6C7E.E(W)-R), F023091 (K6C7M(W)-R), F027055 (K6C7M(W)-SK), F029454 (K6C7M.C(W)-F), F029290 (K6C7M.C(W)-R), F029292 (K6C7M.C(W)-SK), F029291 (K6C7M.C(W)-SV), F028645 (K6C7MW-F), F027769 (K6C7MW-SV), F024137 (K6C8P(A)-G), F054153 (KD3C1(A)-G), F043095 (KD3C1(M)-G), F034924 (KD3C1(W)-G), F034925 (KD3C11(X)-G), F068885 (KD3C3(K)-G), F043761 (KD3E1(A)-IR), F043096 (KD3E1(M)-G), F053844 (KD6C35A), F068887 (KD6C35K), F039808 (KD6C35M(T)), F053270 (KD6C35W), F053273 (KD6C35X), F039807 (KD6C35X(T)), F031003 (KD6C7EW), F031004 (KD6C7EX), F029986 (KD6C8EX), F053274 (KDP60C), F039821 (KDP60C(T)), F081083 (KDP60CS), F082423 (KN3C107A(W)-RU), F078701 (KN3C11(W)-AUS), F073253 (KN3C11(W)-FR), F081091 (KN3C11(W)-FRS), F073445 (KN3C117A(W)-RU), F073446 (KN3C117AX-RU), F081256 (KN3C11XAUS), F074075 (KN3C12A(W)-C), F081186 (KN3C12AWCZS), F082493 (KN3C17A(W)-RU), F073254 (KN3C51(W)-FR), F073255 (KN3C51(X)-FR), F073447 (KN3C517(W)-RU), F081092 (KN3C51WFRS), F081093 (KN3C51XFRS), F073256 (KN3C55(W)-FR), F073448 (KN3C557X-RU), F081094 (KN3C55WFRS), F074076 (KN3C61A(X)-CZ), F081187 (KN3C61AXCZS), F073924 (KN3C62A(W)), F081160 (KN3C62A(W)US), F081171 (KN3C62AWEUS), F073860 (KN3C62AW-U), F076828 (KN3C650AXU), F081234 (KN3C650AXUS), F074077 (KN3C65A(W)-CZ), F074074 (KN3C65A(X)CZ), F081188 (KN3C65AWCZS), F081185 (KN3C65AXCZS), F073450 (KN3C767AX-RU), F073925 (KN3C76A(W)BG), F073258 (KN3C76A(W)-FR), F081172 (KN3C76AWBGS), F081095 (KN3C76AWFRS), F073926 (KN3C76AX-EU), F081173 (KN3C76AXEUS), F073259 (KN3E6A(W)-FR), F073432 (KN6C107(W)-RU), F082426 (KN6C107A(W)RU), F073431 (KN6C117(W)-RU), F081149 (KN6C11WEXS), F081184 (KN6C11WSKS), F073907 (KN6C12AW-GR), F081163 (KN6C12AWGRS), F078695 (KN6C320XAUS), F081255 (KN6C320XAUS), F073433 (KN6C517(W)-RU), F073271 (KN6C61A(W)-FR), F073813 (KN6C61A(W)-NL), F073272 (KN6C61A(X)-FR), F073812 (KN6C61A(X)-NL), F081105 (KN6C61AWFRS), F081159 (KN6C61AWNLS), F074060 (KN6C61AW-P), F081106 (KN6C61AXFRS), F081158 (KN6C61AXNLS), F073908 (KN6C62A(W)GR), F073909 (KN6C62A(X)-GR), F081164 (KN6C62AWGRS), F073273 (KN6C66A(W)-FR), F073910

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(KN6C66A(W)-GR), F074064 (KN6C66A(W)-SK), F081107 (KN6C66AWFRS), F081166 (KN6C66AWGRS), F073914 (KN6C76A(X)-GR), F081168 (KN6C76AXGRS), F073281 (KN6M1SA(W)-FR), F081111 (KN6M1SAWFRS), F073286 (KN6M6SA(W)-FR), F084873 (MVI5V22WRU), F084260 (MVI6V20WRU), F082422 (MVK5V2(W)RF), F079702 (MVK5V21(W)RF), F079703 (MVK5V75(X)RF), F079706 (MVK6V21WRF), F083458 (MVK6V27WRF), F086904 (RID60C2WUK)

INDESIT Pot stove gas F027880 (EP31(IX)-P631(IX)), F013951 (EP31-P631), F013952 (EP31-P631), F014424 (EP31-P631), 02310 (PPI31), 02311 (PPI31), 05253 (PPI31), 05254 (PPI31), F002310 (PPI31), F002311 (PPI31), F005253 (PPI31), F005254 (PPI31), F012865 (PPI31.1-P631), F012866 (PPI31.1-P631)

ROSIERES Electric oven A0002264 (OVEN SECTION), A0002284 (OVEN SECTION), A0002286 (OVEN SECTION), A0002288 (OVEN SECTION), A0002290 (OVEN SECTION), A0002292 (OVEN SECTION), A0002294 (OVEN SECTION), A0002309 (OVEN SECTION), A0002312 (OVEN SECTION), A0002313 (OVEN SECTION), A0002314 (OVEN SECTION), A0002373 (OVEN SECTION), A0002389 (OVEN SECTION), A0002391 (OVEN SECTION), A0002410 (OVEN SECTION), A0002412 (OVEN SECTION), A0003036 (OVEN SECTION), A0003901 (OVEN SECTION), A0003904 (OVEN SECTION), A0003907 (OVEN SECTION), A0003910 (OVEN SECTION)

ROSIERES Kitchen 39350699 (BE734RB), 39350855 (BE744RB), 39351671 (BM571RU), 39350921 (BM721RB), 39353479 (BM7410RB), 39350830 (BM761RB), 39351671 (CF BM 571 RU), 39350830 (CF BM 761 RB), 39350806 (CF BM 781 MA), 39351697 (CF BM571 RUV), 39351705 (CF BM571RUBM), 33001228 (RBP60IN), 33001229 (RBP60PNX), 33001230 (RBP60RBX), 33001227 (RBT60IN), 33000007 (RCM 647 RB), 33000006 (RCM 696 RB), 33000198 (RCM 6997 RB), 33000145 (RCM 799 IN), 33000849 (RCM6931RB), 33000852 (RCM6971MA), 33000847 (RCM6971RB), 33001149 (RCM6997RB-1), 33001027 (RCM799IN-1), 33001222 (RMP6376PNX), 33001215 (RMP6376RBX)

ROSIERES Kitchen electric 33000047 (RCE 632 RB)

ROSIERES Pot stove gas A0002254 (HOB SECTION), A0002255 (HOB SECTION), A0002257 (HOB SECTION), A0002283 (HOB SECTION), A0002285 (HOB SECTION), A0002287 (HOB SECTION), A0002289 (HOB SECTION), A0002291 (HOB SECTION), A0002315 (HOB SECTION), A0002318 (HOB SECTION), A0002319 (HOB SECTION), A0002320 (HOB SECTION), A0002374 (HOB SECTION), A0002390 (HOB SECTION), A0002392 (HOB SECTION), A0002411 (HOB SECTION), A0003035 (HOB SECTION), A0003900 (HOB SECTION), A0003903 (HOB SECTION), A0003906 (HOB SECTION), A0003909 (HOB SECTION)

WHIRLPOOL Convection oven EH100, EH100CN, EH101, EH101CN, EH101SP, EH102(BR), EH102(SW), EH102(W), EH102CN, EH103CN, EH104CN, EHM200, EHM200CN, EHM201, EHM201CN, EHM201SP, EHM202, EHM202CN, EHM204CN, PSH1, PSH10(BK), PSH10(BR), PSH10(WH), PSH10IX, PSH2, PSH20(BK), PSH20(BR), PSH20(WH), PSH20IX

WHIRLPOOL Kitchen electric ACMK6030IX, ACMK6030WH

WHIRLPOOL Kitchen gas ACMK6110IX2, ACMK6110IX3, ACMK6110WH2, ACMK6433-IX, ACMT6533IX, ACMT6533IX1, ACMT6533IX2, ACMT6533WH, AXMT6434-IX, AXMT6434WH, N4312

WHIRLPOOL Kitchen glass-ceramics ACMK6531WH1, ACMT6533WH1, AXMT6533-IX, AXMT6534-IX, AXMT6534IX-1, AXMT6534IXU

ZANUSSI Kitchen A7ECED2R0K (373223), E9ECMD2Q05 (391180), E9ECMD2Q06 (391181), E9ECMH4Q05 (391182), E9ECMH4Q06 (391183), E9ECMH4QE5 (391184), E9ECMH4QE6 (391185), A9ECED2Q0N (393165),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

A9ECEH4Q0N (393166), A9ECEH4QEN (393167)

ZANUSSI Kitchen electric BC/E1 (162302), BCF/E2 (162303), RC/E1 (168009), RC/E2 (168010), RCV/E2 (168011), RCV/E3 (168012), RCF/E2 (168013), RCF/E2MO (168023), RCF/E2M4 (168024), RCVF/E3MO (168025), RCVF/E3M4 (168026), RC/E1E5 (168027), RCF/E2E5 (168029), MCF/E2Q (168203), RCF/E2Q (168206), XCF/E2 (168413), JCF/E2 (168613), MC/E1 (168809), MC/E2 (168810), MCV/E2 (168811), MCV/E3 (168812), MCF/E2 (168813), MCF/E2E5 (168829), PC/E1 (178013), PC/E2 (178014), PCV/E2 (178015), PCV/E3 (178016), PCF/E2 (178017), PC/E2Q (178018), PCF/E2Q (178019), PCV/E2Q (178020), PC/E2QE5 (178027), PCF/E2QE5 (178028), PC/E1E5 (178035), PC/E2E5 (178036), PCF/E2E5 (178037), OC/E1 (178313), OC/E2 (178314), OCV/E3 (178316), OCF/E2 (178317), OC/E2Q (178318), OCF/E2Q (178319), TC/E1 (178613), TC/E2 (178614), TCV/E2 (178615), TCV/E3 (178616), TCF/E2 (178617), TC/E2Q (178618), TCF/E2Q (178619), TCV/E2Q (178620), TC/E2QE5 (178627), TCF/E2QE5 (178628), TC/E1E5 (178635), TC/E2E5 (178636), TCF/E2E5 (178637), TC/E1M0 (178816), TCF/E2M0 (178817), TCV/E2M0 (178818), TCF/E2QM0 (178819), TCV/E2QM0 (178820), TCF/E3QM0 (178821), TCV/E3QM0 (178822), TC/E1M4 (178829), TCF/E2M4 (178830), TCV/E2M4 (178831), TCF/E2QM4 (178832), TCV/E2QM4 (178833), TCF/E3QM4 (178834), TCV/E3QM4 (178835), HC/E400 (200003), HC/E800 (200004), HCF/E800 (200005), HC/E410 (200040), HC/E810 (200041), HCF/E810 (200042), KC/E1 (200107), KC/E2 (200108), KCF/E2 (200109), KC/E1E5 (200110), KC/E2E5 (200111), KCF/E2E5 (200112), ZC/E400 (210003), ZC/E800 (210004), ZCF/E800 (210005), ZC/E410 (210040), ZC/E810 (210041), ZCF/E810 (210042), QC/E1 (210107), QC/E2 (210108), QCF/E2 (210109), QC/E1E5 (210110), QC/E2E5 (210111), QCF/E2E5 (210112), QC/E2M0 (210128), QC/E2M4 (210129), QCF/E2M0 (210130), QCF/E2M4 (210131), AC/E400 (220003), AC/E800 (220004), ACF/E800 (220005), OCF/E800 (220062), WC/E1 (220107), WC/E2 (220108), WCF/E2 (220109), WC/E1E5 (220110), WC/E2E5 (220111), WCF/E2E5 (220112), ECF/E800 (230005), E7ECED2R00 (371014), E7ECEH4R00 (371015), E7ECEH4RE0 (371016), E7ECEH4Q00 (371017), E7ECEH4QE0 (371018), E7ECEL6R00 (371019), E7ECED2R0N (371126), E7ECEH4R0N (371127), E7ECEH4REN (371128), E7ECEH4QEN (371129), E7ECEH4Q0N (371130), E7ECMD2R05 (371146), E7ECMD2R06 (371147), E7ECMH4RE5 (371148), E7ECMH4RE6 (371149), E7ECMH4QE5 (371150), E7ECMH4QE6 (371151), E7ECML6Q25 (371152), E7ECML6Q26 (371153), Z7ECED2R00 (372014), Z7ECEH4R00 (372015), Z7ECEH4RE0 (372016), Z7ECEH4Q00 (372017), Z7ECEH4QE0 (372018), Z7ECEL6R00 (372019), Z7ECED2R0N (372126), Z7ECEH4R0N (372127), Z7ECEH4REN (372128), Z7ECEH4QEN (372129), Z7ECEH4Q0N (372130), A7ECED2R00 (373014), A7ECEH4R00 (373015), A7ECEH4RE0 (373016), A7ECEH4Q00 (373017), A7ECEH4QE0 (373018), A7ECEL6R00 (373019), A7ECED2R0N (373126), A7ECEH4R0N (373127), A7ECEH4REN (373128), A7ECEH4QEN (373129), A7ECEH4Q0N (373130), E9ECED2Q00 (391039), E9ECEH4Q00 (391040), E9ECEH4QE0 (391041), E9ECED2Q0N (391165), E9ECEH4Q0N (391166), E9ECEH4QEN (391167), Z9ECED2Q00 (392039), Z9ECEH4Q00 (392040), Z9ECEH4QE0 (392041), Z9ECED2Q0N (392165), Z9ECEH4Q0N (392166), Z9ECEH4QEN (392167), A9ECED2Q00 (393039), A9ECEH4Q00 (393040), A9ECEH4QE0 (393041)

ZANUSSI Neutral counter HFS/E800 (205002), ZFS/E800 (215002), AFS/E800 (225002)

ZANUSSI Pot stove electric MC/E2Q (168202), MCV/E2Q (168204), RC/E2Q (168205), RCV/E2Q (168207), XC/E1 (168409), XC/E2 (168410), XCV/E2 (168411), XCV/E3 (168412), JC/E1 (168609), JC/E2 (168610), JCVE2 (168611), JCV/E3 (168612), HC/E400 (230003), HC/E800 (230004)

ZEROWATT Kitchen electric 39354527 (CF ZG266M4PE)



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

