

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta cuptor 1500W (1050+450W) 230V #LFD355088

Fara TVA: 98,32 Lei

Pret cu TVA: 117,00Lei

Rezistenta cuptor 1500W (1050+450W) 230V #LFD355088

power 1500W (1050+450W)

voltage 230V

length 350mm

width 335mm

flange length 100mm

flange width 22mm

bridge length 355mm

suitable for producer CANDY

heating circuits 2

hole distance 88mm

Compatibil cu:

ATEL 41020672

BAUMATIC 41020672

CANDY 41020672

GASFIRE 725216

HOOVER

IBERNA

KELVINATOR TRW3409067

OTSEIN TRW3409067

ROSIERES TRW3409067

ZEROWATT TRW3409067

EPMS 725216

EPMS 725209

EPMS 41020672

GEV LFD355088

LF D355088

IRCA TRW3409067

IRCA 1R0C140Q1001

IRCA 1R18587001

BAUMATIC Electric oven 33701688 (BOMM608X), 33701687 (BOMT608X)

CANDY Dishwasher 33700319 (FCL614PI), 33700464 (FCL614PI)

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

CANDY Electric oven FPE4396x (33701277), 36055176 (73XR340/3GHE), 33701253 (ACOM609XM), 33701293 (CCOM6099-6X), 33701202 (CCOM6099X), 36056133 (CI2006-3EGW), 36056125 (CI2006-3EGX), 36183101 (CI4212-3EGX), 33701532 (CMFM5X), 33701531 (CMFM8X), 33701530 (CMFS4N), 33701529 (CMFS4X), 38000080 (CMG2396DSUK), 36048668 (F110M), 36224616 (F112M), 36224004 (F112N), 36224608 (F112W), 36163012 (F122N), 36163616 (F122W), 36048627 (F140FRW), 36164028 (F142/3N), 36164101 (F142/3W), 36227122 (F222/3CN), 36227114 (F222/3CW), 36227130 (F222/3CX), 36227601 (F222CM), 36227627 (F222CN), 36227619 (F222CW), 36227635 (F222CX), 36227650 (F224CN), 36227643 (F224CW), 36283125 (F242/3CX), 36223626 (F242CX), 36223006 (F242N), 36223600 (F242W), 36223618 (F242X), 36283141 (F243/3CN), 36283133 (F243/3CW), 36223105 (F243/3CX), 36223642 (F243CN), 36223634 (F243CW), 36222156 (F254/3CN), 36222149 (F254/3CW), 36222131 (F254/3CX), 36222644 (F254CN), 36222636 (F254CW), 36222628 (F254CX), 36222602 (F254W), 36054666 (F330/1FRW), 36054658 (F330FRS), 36049633 (F340FRN), 36049625 (F340FRW), 36063642 (F96/3N), 33701294 (FCL602-6AV), 33701295 (FCL602-6GH), 33700771 (FCL602AV), 33700770 (FCL602GH), 33700761 (FCL614-1AV), 33700763 (FCL614-1BA), 33700760 (FCL614-1GH), 33701217 (FCL614-1GHLY), 33700762 (FCL614-1RA), 33701298 (FCL614-6AV), 33701307 (FCL614-6BA), 33701305 (FCL614-6GH), 33701306 (FCL614-6RA), 33701301 (FCL614-6X), 33700321 (FCL614AV), 33700462 (FCL614AV), 33700461 (FCL614GH), 33700320 (FCL614RA), 33700463 (FCL614RA), 33700560 (FCL614X), 33701308 (FCL624-6BA), 33701140 (FCL624BA), 33701139 (FCL624GH), 33700337 (FCL634N), 33700466 (FCL634N), 33700338 (FCL634W), 33700465 (FCL634W), 33900086 (FCO405-6X), 33900069 (FCO405X), 33900079 (FCO405X-1), 33900072 (FCO607X), 33900071 (FCO827XL), 33900080 (FCO827XL), 33701598 (FCS65W), 33701597 (FCS65X), 33701610 (FCXP613X), 33701613 (FCXP615X), 33701488 (FET603AX), 33701490 (FET609AX), 33701491 (FET629AXL), 33701238 (FHE603-6X), 33700985 (FHP3147X), 33700851 (FHP6031-1X), 33700769 (FHP6031X), 33700850 (FHP603-1X), 33700619 (FHP603X), 33700849 (FHP603XL), 33700564 (FHP607X), 33700848 (FHP609X), 33700552 (FHP612X), 33700571 (FHP612X), 33700945 (FHP629XL), 33700846 (FHP646-1X), 33700822 (FHP646X), 33700901 (FHP648-1X), 33700620 (FHP648X), 33700706 (FHP648X), 33701029 (FHP649X), 33700622 (FHP748N), 33700623 (FHP748W), 33700621 (FHP748X), 33700618 (FHP827X), 33700852 (FHP829X), 36297000 (FL501X), 33700042 (FL503X), 33700444 (FL635X), 33700268 (FNP601N), 33700267 (FNP601W), 33700266 (FNP601X), 33700551 (FNP612NX), 33700572 (FNP612NX), 33700264 (FNP612X), 33700384 (FNP615NXUK), 33700455 (FNP615NXUK), 33700273 (FNP615X), 33700263 (FNP622X), 33700274 (FNP815X), 33700272 (FNP815XUK), 33700271 (FNP825X), 33700270 (FNP827AL), 33700269 (FNP827X), 33900015 (FNPC612X), 33900014 (FNPC825X), 33900013 (FNPP612X), 36056604 (FOCI110N), 36056612 (FOCI110S), 36056000 (FOCI110W), 36057602 (FOCI330N), 36057610 (FOCI330S), 36057008 (FOCI330W), 36163632 (FOF123CN), 36048627 (FOF140FRW), 36227106 (FOF222-3CM), 36227122 (FOF222-3CN), 36227130 (FOF222-3CX), 36227601 (FOF222CM), 36227627 (FOF222CN), 36227635 (FOF222CX), 36227650 (FOF224CN), 36283125 (FOF242-3CX), 36223626 (FOF242CX), 36283141 (FOF243-3CN), 36223105 (FOF243-3CX), 36223642 (FOF243CN), 36222156 (FOF254-3CN), 36222131 (FOF254-3CX), 36222644 (FOF254CN), 36222628 (FOF254CX), 36105609 (FOF311FRX), 36054666 (FOF330-1FRW), 36054633 (FOF330FRN), 36054658 (FOF330FRS), 36054625 (FOF330FRW), 36049633 (FOF340FRN), 36049625 (FOF340FRW), 33700452 (FOFNP601N), 33700453 (FOFNP601W), 33700451 (FOFNP601X), 33700458 (FOFNP612X), 33700454 (FOFNP615X), 33700459

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(FOFNP815X), 33700470 (FOFNP815XUK), 33700457 (FOFNP825X), 33700460 (FOFNP827X), 36105153 (FOFP601AL), 36105013 (FOFP601X), 33700091 (FOFP612AL), 33700089 (FOFP612N), 33700090 (FOFP612X), 33700092 (FOFP622N), 33700093 (FOFP622X), 36105120 (FOFP632CAL), 36105138 (FOFP632CW), 33700139 (FOFP636N), 33700140 (FOFP636W), 33700138 (FOFP636X), 33700004 (FOFP815AL), 33700094 (FOFP815N), 33700095 (FOFP815WUK), 33700002 (FOFP815X), 33700097 (FOFP815XUK), 33700005 (FOFP825AL), 33700007 (FOFP825X), 33700001 (FOFP827AL), 33700003 (FOFP827X), 36296101 (FOFP827X), 36291136 (FOFP835CAL), 36291151 (FOFP835CN), 36291144 (FOFP835CW), 33700098 (FOFP835CX), 36003168 (FOFR122-3N), 36003150 (FOFR122-3W), 36164028 (FOFR142-3N), 36164101 (FOFR142-3W), 36059616 (FOR100-1GH), 36055671 (FOR340-1FRW), 36055697 (FOR340FRTF), 36282127 (FOR43-3BD), 36282135 (FOR43-3GHE), 36055127 (FOR43BA), 36055119 (FOR43BD), 36055101 (FOR43GH), 36055010 (FOR43X), 33701024 (FP206X), 33700995 (FP52XV), 36105153 (FP601AL), 36105112 (FP601N), 36105104 (FP601W), 36294122 (FP622XAUS), 36105120 (FP632CAL), 33700141 (FP636AL), 33700022 (FP815NUK), 33700023 (FP815XUK), 36291136 (FP835CAL), 33701250 (FPE206-6X), 33701277 (FPE439-6X), 33701478 (FPE439A-6X), 33701247 (FPE502-6N), 33701248 (FPE502-6W), 33701246 (FPE502-6X), 33701249 (FPE52-6VX), 39300207 (FPE52-6VX), 33701450 (FPE549-6N), 33701449 (FPE549-6W), 33701448 (FPE549-6X), 33701264 (FPE6021-6X), 33701469 (FPE602-61X), 33701245 (FPE602-6N), 33701262 (FPE602-6NXL), 33701244 (FPE602-6W), 33701261 (FPE602-6WISR), 33701263 (FPE602-6WXL), 33701181 (FPE602-6X), 33701480 (FPE602A-6N), 33701481 (FPE602A-6W), 33701482 (FPE602A-6WXL), 33701479 (FPE602A-6X), 33701237 (FPE603-6NX), 33701203 (FPE603-6WX), 33701256 (FPE6071-6X), 33701251 (FPE6091-6X), 33701258 (FPE609-6WXL), 33701254 (FPE609-6X), 33701501 (FPE609A-6WXL), 33701483 (FPE609A-6X), 33701484 (FPE609A-6XL), 33701240 (FPE629-6NX), 33701241 (FPE629-6NXL), 33701242 (FPE629-6WXL), 33701199 (FPE629-6X), 33701239 (FPE629-6XL), 33701499 (FPE629A-6WXL), 33701495 (FPE629A-6X), 33701497 (FPE629A-6XL), 39000373 (FPE629A-6XL), 33701279 (FPE649-6N), 33701280 (FPE649-6W), 33701278 (FPE649-6X), 33701486 (FPE649A-6N), 33701487 (FPE649A-6W), 33701485 (FPE649A-6X), 33701265 (FPE829-6XL), 36105104 (FPP601W), 36294114 (FPP622N), 33701101 (FPP209X), 33701093 (FPP405X), 33700991 (FPP435X), 33701141 (FPP439X), 33700886 (FPP502-1W), 33700883 (FPP502-1X), 33700644 (FPP502N), 33700645 (FPP502W), 33700643 (FPP502X), 33700944 (FPP6020X), 33700876 (FPP6021-1X), 33700870 (FPP602-1N), 33701077 (FPP602-1NXL), 33700884 (FPP602-1W), 33701076 (FPP602-1WXL), 33700649 (FPP6021X), 33700869 (FPP602-1X), 33701379 (FPP602-1X), 33700897 (FPP602-1XOS), 33700647 (FPP602N), 33700648 (FPP602W), 33700646 (FPP602X), 33700674 (FPP602XOS), 33700992 (FPP603NX), 33701092 (FPP6078XL), 33700650 (FPP607X), 33700673 (FPP607XOS), 33700671 (FPP607XTW), 33700943 (FPP6090X), 33700963 (FPP6091X), 33701079 (FPP609NXL), 33701078 (FPP609WLX), 33700877 (FPP609X), 33701206 (FPP609XFR), 33700878 (FPP609XL), 33700993 (FPP629NX), 33701137 (FPP629NXL), 33701138 (FPP629WXL), 33700899 (FPP629X), 33700844 (FPP629XL), 33700887 (FPP646-1N), 33700871 (FPP646-1W), 33700888 (FPP646-1X), 33700670 (FPP646N), 33700839 (FPP648-1N), 33700873 (FPP648-1W), 33700875 (FPP648-1X), 33700711 (FPP648N), 33701030 (FPP648NX), 33700712 (FPP648W), 33701031 (FPP648WX), 33700710 (FPP648X), 33700881 (FPP649N), 33700880 (FPP649W), 33700882 (FPP649X), 33700970 (FPP649XL), 33700636 (FPP827X), 33700964 (FPP8291X), 33700840 (FPP829X), 33700892 (FPP829XL), 33700832 (FST201-1N), 33700833 (FST201-1W), 33700834 (FST201-1X), 33701284 (FST201-6N), 33701198

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(FST201-6X), 33700616 (FST201N), 33700617 (FST201W), 33700615 (FST201X), 33700835 (FST247-1N), 33700837 (FST247-1W), 33700836 (FST247-1X), 33700613 (FST247N), 33700614 (FST247W), 33700612 (FST247X), 33701288 (FST249-6N), 33701287 (FST249-6W), 33701103 (FST249W), 33701100 (FST249X), 33700767 (FVH703X), 33700708 (FVH748N), 33700709 (FVH748W), 33700707 (FVH748X), 33700863 (FVP702-1Xdisp), 33700730 (FVP702X), 33700765 (FVP702XDISP), 33700731 (FVP727X), 33700729 (FVP727XDISP), 33700861 (FVP729XDISP), 33700862 (FVP748-1X), 33700713 (FVP748X), 33701290 (FVPE702-6Xdisp), 33701272 (FXE623X), 33701160 (FXMH629NX), 33701149 (FXMH7490X), 33701243 (FXP609NX), 33701154 (FXP649NX), 33701155 (FXP649WX), 31137169 (LBLFC635H), 33700518 (R100-3GH), 36059103 (R100-3GH), 36055671 (R340/1FRW), 36055184 (R340/3SDE), 36055697 (R340FRTF), 36282135 (R43/3GHE), 36282143 (R43/3XE), 36282119 (R43-3BA), 33700472 (R43-3GH), 36282192 (R43-3GHCR), 36282168 (R43-3RA), 36282002 (R43-3X), 36282143 (R43-3XE), 36056158 (UCCI2006-3GW), 36056117 (UCCI2006-3N), 36056109 (UCCI2006-3W), 36056034 (UCCI2006-3X), 36056653 (UCCI2006N), 36056646 (UCCI2006W), 36025021 (UCCI2006WE), 36056026 (UCCI2006X), 36025633 (UCCI2006XE), 36025112 (UCCI2012-3W), 36025039 (UCCI2012-3WE), 36025120 (UCCI2012-3X), 36025104 (UCCI2012-3XE), 36183010 (UCCI310-1DW), 36058642 (UCCI310-1W), 36183606 (UCCI310DN), 36183614 (UCCI310DS), 36183002 (UCCI310DW), 36058634 (UCCI310EN), 36058626 (UCCI310EW), 36057651 (UCCI330-1W), 36057636 (UCCI330EN), 36057644 (UCCI330ES), 36057628 (UCCI330EW), 36183135 (UCCI4206-3N), 36183127 (UCCI4206-3W), 36183119 (UCCI4206-3X), 36183036 (UCCI4206X), 36183200 (UCCI4212-3GX), 36183168 (UCCI4212-3N), 36183192 (UCCI4212-3NE), 36183150 (UCCI4212-3W), 36183184 (UCCI4212-3WE), 36183143 (UCCI4212-3X), 36183176 (UCCI4212-3XE), 36056638 (UCCI422N), 36056620 (UCCI422W), 36056018 (UCCI422X), 36025013 (UCCI512EW), 36025625 (UCCI512EX), 36057115 (UCCI5412-3N), 36057107 (UCCI5412-3W), 36057024 (UCCI5412-3X), 36057123 (UCCI5412-3XE), 36057735 (UCCI5412N), 36057727 (UCCI5412W), 36057016 (UCCI5412X), 36057743 (UCCI5412XE), 36058659 (UCCI542EN), 36058667 (UCCI542EW), 36183648 (UCCI542W), 36183622 (UCCI642X), 36057701 (UCCI654EN), 36057719 (UCCI654EW), 36057693 (UCCI654EX), 36057685 (UCCI654N), 36057677 (UCCI654W), 36057669 (UCCI654X), 36184620 (UCCI96DM), 36184000 (UCCI96DW), 36324101 (UCFLC20W), 36324002 (UCFLC20X), 36323103 (UCFLC60N), 33900009 (UCFLP100-1W), 36309003 (UCFLP100W), 33900007 (UCFLP101-1X), 36314110 (UCFLP101W), 36314003 (UCFLP101X), 33900008 (UCFLP501-1X), 36315117 (UCFLP501W), 36315000 (UCFLP501X), 36308112 (UCFPC612N), 36308005 (UCFPC612X), 36307106 (UCFPC825AL), 36307007 (UCFPC825X), 33900006 (UCFPP612X), 36317006 (UCFPP612X), 36316008 (UCFPP825X), A0001896 (UPPEROVENSECTI), A0001898 (UPPEROVENSECTI), A0002307 (UPPEROVENSECTI), A0002321 (UPPEROVENSECTI), A0002322 (UPPEROVENSECTI), A0002383 (UPPEROVENSECTI)
CANDY Kitchen A0002247 (HOBSECTION), A0002248 (HOBSECTION), A0002249 (HOBSECTION), A0002250 (HOBSECTION), A0002252 (HOBSECTION), A0002259 (HOBSECTION), A0002295 (HOBSECTION), A0002297 (HOBSECTION), A0002299 (HOBSECTION), A0002301 (HOBSECTION), A0002317 (HOBSECTION), A0002379 (HOBSECTION), A0002381 (HOBSECTION), A0002393 (HOBSECTION), A0002395 (HOBSECTION), A0002397 (HOBSECTION), A0002399 (HOBSECTION), A0002401 (HOBSECTION), A0002403 (HOBSECTION), A0002405 (HOBSECTION), A0002407 (HOBSECTION), A0003002 (HOBSECTION), A0003005 (HOBSECTION), A0003008 (HOBSECTION), A0003011 (HOBSECTION), A0003014 (HOBSECTION), A0002245 (OVENSECTION), A0002246



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(OVENSECTION), A0002251 (OVENSECTION), A0002258 (OVENSECTION), A0002261 (OVENSECTION), A0002262 (OVENSECTION), A0002263 (OVENSECTION), A0002265 (OVENSECTION), A0002296 (OVENSECTION), A0002298 (OVENSECTION), A0002300 (OVENSECTION), A0002302 (OVENSECTION), A0002380 (OVENSECTION), A0002382 (OVENSECTION), A0002387 (OVENSECTION), A0002394 (OVENSECTION), A0002396 (OVENSECTION), A0002398 (OVENSECTION), A0002400 (OVENSECTION), A0002402 (OVENSECTION), A0002404 (OVENSECTION), A0002406 (OVENSECTION), A0002408 (OVENSECTION), A0002999 (OVENSECTION), A0003003 (OVENSECTION), A0003006 (OVENSECTION), A0003009 (OVENSECTION), A0003012 (OVENSECTION), A0003015 (OVENSECTION)

CANDY Pot stove 36105112 (FOFP601N)

GASFIRE Electric oven 36109601 (FOFI1020MT N), 36109619 (FOFI1020MT W), 33701299 (GF 6200 NX), 33701106 (GS 200 NX)

HOOVER Electric oven 33700113 (FOHMO635X), 33700116 (FOHMO837X), 33701044 (HCM 906 NPP), 33701713 (HCM 906AX), 33701227 (HCM 906X), 33701226 (HCM906-6BPP), 33701225 (HCM906-6XPP), 33700115 (HMO 635 B), 33700114 (HMO 635 W), 33700329 (HMO 635-1 W), 33700301 (HMO 635-1 X), 33700508 (HMO 635-1B), 33700507 (HMO 635-1W), 33700506 (HMO 635-1X), 33700548 (HMO 837X), 33701176 (HO 145B), 33701178 (HO 145W), 33701177 (HO 145X), 33701171 (HO 446 BXP), 33701172 (HO 446 WXP), 33701716 (HO 446A-6 BXP), 33701717 (HO 446A-6 WXP), 33701231 (HO145-6B), 33701233 (HO145-6W), 33701232 (HO145-6X), 33701212 (HO445-6VX), 33701715 (HO445A-6VX), 33701220 (HO446-6BXP), 33701219 (HO446-6WXP), 33701221 (HO446-6XPP), 33701714 (HO446A-6XPP), 33701681 (HO786VX WIFI), 33701710 (HO929-6VX), 33701174 (HOA 1BX), 33701705 (HOA10X), 33701711 (HOA1WX), 33701168 (HOC 024X), 33700691 (HOC 706 N), 33701052 (HOC 709 X), 33701179 (HOC 709BX), 33701224 (HOC024-6X), 33701222 (HOC1060-6B), 33701223 (HOC1060-6X), 33700940 (HOC1060X), 33700921 (HOC706NX), 33700905 (HOC706X), 33701229 (HOC709-6BX), 33701230 (HOC709-6X), 33700676 (HOP 114 X), 33700783 (HOP 114-1 X), 33700248 (HOP 115 B), 33700247 (HOP 115 W), 33700246 (HOP 115 X), 33700504 (HOP 115B), 33700503 (HOP 115W), 33700678 (HOP 116 B), 33700679 (HOP 116 W), 33700677 (HOP 116 X), 33700784 (HOP 2061 B), 33700786 (HOP 2061 W), 33700785 (HOP 2061 X), 33700249 (HOP 355 X), 33700505 (HOP 355X), 33700787 (HOP 4063 X), 33700789 (HOP 4074 X), 33700788 (HOP 4075 VX), 33700250 (HOP 455 X), 33700509 (HOP 455X), 33700942 (HOP2060X), 33700941 (HOP4060X), 33700537 (HOS 316 ABX UK), 33700300 (HOS 316 AX UK), 33700495 (HOS 316AX UK), 33700791 (HOS 4064 BX), 33700790 (HOS 4064 X), 33700793 (HOS 4075 VX), 33700251 (HOS 456 X), 33700496 (HOS 456X), 33700252 (HOS 556 X), 33700497 (HOS 556X), 33700541 (HOS316ABXUK), 33700794 (HOS4075VXDISPLAY), A0001901 (LOWER OVEN SECTI), A0002272 (LOWER OVEN SECTI), A0002274 (LOWER OVEN SECTI), A0002276 (LOWER OVEN SECTI), A0002278 (LOWER OVEN SECTI), A0002280 (LOWER OVEN SECTI), A0002282 (LOWER OVEN SECTI), A0002358 (LOWER OVEN SECTI), A0002370 (LOWER OVEN SECTI), A0002372 (LOWER OVEN SECTI), A0002378 (LOWER OVEN SECTI), A0002253 (OVEN SECTION), A0001900 (UPPER OVEN SECTI), A0002271 (UPPER OVEN SECTI), A0002273 (UPPER OVEN SECTI), A0002275 (UPPER OVEN SECTI), A0002277 (UPPER OVEN SECTI), A0002279 (UPPER OVEN SECTI), A0002281 (UPPER OVEN SECTI), A0002357 (UPPER OVEN SECTI), A0002369 (UPPER OVEN SECTI), A0002371 (UPPER OVEN SECTI), A0002377 (UPPER OVEN SECTI)

IBERNA Electric oven 33700797 (FI 0012-1 X), 36238111 (FI 010-3 N), 36238103 (FI 010-3 W), 36238012 (FI

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

010-3 X), 33700336 (FI 0506 X), 33700494 (FI 0506X), 33700335 (FI 0536 N), 33700334 (FI 0536 W),
33700333 (FI 0536 X), 33700486 (FI 0536W), 33700484 (FI 0536X), 36292126 (FI 110-3 X), 33700191 (FI 200
W), 33700192 (FI 200 X), 33700212 (FI 610 X), 36238004 (FI010N), 36238608 (FI010W), 36238616 (FI010X),
33700485 (FI0536N), 36238004 (FO FI 010 N), 36238608 (FO FI 010 W), 36238616 (FO FI 010 X), 36292001
(FO FI110-3 W), 36238624 (FO RI 010 GH), 33701701 (IBOM600X), 36238129 (RI 010-3 GH)

KELVINATOR Electric oven 36185601 (FO FK 3030 M)

KELVINATOR Oven under cooktop electric 36182608 (UC CIK 303 M), 36182004 (UC CIK 303 W)

OTSEIN Electric oven 36188506 (FO OTS 80 M), 36188001 (FO OTS 80 W)

ROSIERES Convection oven 93964096 (93964096)

ROSIERES Electric oven 33700102 (FC 3161-1 IN), 33700101 (FC 3162 IN IL), 33700516 (FC3163-1IN),
36193613 (FO F 123 IN), 36193001 (FO F 123 PN), 36193605 (FO F 123 RB), 36194611 (FO F 143 IN),
36194009 (FO F 143 PN), 36194603 (FO F 143 RB), 36196616 (FO F 144 IN), 36196004 (FO F 144 PN),
36196608 (FO F 144 RB), 36197002 (FO F141RU GH), 36197606 (FO F141RU SD), 36008019 (FO FR 2020IN),
36008639 (FO FR 2020PN), 33700103 (FOFC3161IN), 33700121 (FOFC3163IN), 36109643 (FOFI1020-1IN),
36109635 (FOFI1020-1PN), 36109627 (FOFI1020-1RB), 36109650 (FOFI1029-1IN), 36109668 (FOFI1029-1RB),
36161636 (FOFI1040-1PN), 36161628 (FOFI1040-1RB), 36008027 (FOFR2020-3IN), 36008118 (FOFR2020-3PN),
36008100 (FOFR2020-3RB), 36279016 (FOFR2040-3IN), 36279008 (FOFR2040IN), 36008126 (FR2020-3INIL),
36008134 (FR2029-3INIL), 93935401 (MFD217PN/FOUR), 93935419 (MFD217RB/FOUR), 39348008
(MFD417PN), 93935427 (MFD417PN/FOUR), 93935435 (MFD417RB/FOUR), A0002264 (OVEN SECTION),
A0002284 (OVEN SECTION), A0002286 (OVEN SECTION), A0002288 (OVEN SECTION), A0002290 (OVEN
SECTION), A0002292 (OVEN SECTION), A0002294 (OVEN SECTION), A0002309 (OVEN SECTION), A0002312
(OVEN SECTION), A0002313 (OVEN SECTION), A0002314 (OVEN SECTION), A0002373 (OVEN SECTION),
A0002389 (OVEN SECTION), A0002391 (OVEN SECTION), A0002410 (OVEN SECTION), A0002412 (OVEN
SECTION), A0003036 (OVEN SECTION), A0003901 (OVEN SECTION), A0003904 (OVEN SECTION), A0003907
(OVEN SECTION), A0003910 (OVEN SECTION), 33701036 (R2IN1X), 33701019 (RF 3313 IN), 33701020 (RF
3313 PN), 33701021 (RF 3313 RB), 33701131 (RF 43 IN), 33701132 (RF 43 PN), 33701432 (RFA1BX),
33701430 (RFA1IN), 33701431 (RFA1NX), 33700759 (RFD 7434 MIN), 33700756 (RFI 4324 IN), 33700757 (RFI
4324 PN), 33700758 (RFI 4324 RB), 33700824 (RFI4004MIN), 33701303 (RFI4064MIN), 33700825
(RFI4204MIN), 33701304 (RFI4264MIN), 33701467 (RFI4264MIN RC), 33700756 (RFI4324IN), 33701534
(RFN5282IN), 33701424 (RFO265IN), 33701425 (RFO265PN), 33701426 (RFO265RB), 33701435 (RFO465BX),
33701433 (RFO465IN), 33701434 (RFO465NX), 93710770 (TRI4FOUR)

ZEROWATT Electric oven 33701738 (ZEF0012-6), 33701739 (ZEF6200NX)



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

