

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta cuptor 2000W 240V #LFD355089

Fara TVA: 93,00 Lei

Pret cu TVA: 110,67Lei

Rezistenta cuptor 2000W 240V #LFD355089

bracket 445mm

length 315/195mm

width 358mm

flange 100x22mm

Compatibil cu:

CANDY 41020728

HOOVER 41020728

ATEL 92749688

GASFIRE

IBERNA

KELVINATOR

OTSEIN

ROSIERES

EPMS 725306

EPMS 41020728

GEV LFD355089

LF D355089

IRCA 1R28595001

CANDY Dishwasher 33700319 (FCL614PI), 33700464 (FCL614PI)

CANDY Electric oven 36055176 (73XR340/3GHE), 36056133 (CI2006-3EGW), 36056125 (CI2006-3EGX), 36183101 (CI4212-3EGX), 38000080 (CMG2396DSUK), 36048668 (F110M), 36224616 (F112M), 36224004 (F112N), 36224608 (F112W), 36163012 (F122N), 36163616 (F122W), 36048627 (F140FRW), 36164028 (F142/3N), 36164101 (F142/3W), 36227122 (F222/3CN), 36227114 (F222/3CW), 36227130 (F222/3CX), 36227601 (F222CM), 36227627 (F222CN), 36227619 (F222CW), 36227635 (F222CX), 36227650 (F224CN), 36227643 (F224CW), 36283125 (F242/3CX), 36223626 (F242CX), 36223006 (F242N), 36223600 (F242W), 36223618 (F242X), 36283141 (F243/3CN), 36283133 (F243/3CW), 36223105 (F243/3CX), 36223642 (F243CN), 36223634 (F243CW), 36222156 (F254/3CN), 36222149 (F254/3CW), 36222131 (F254/3CX), 36222644 (F254CN), 36222636 (F254CW), 36222628 (F254CX), 36222602 (F254W), 36054666 (F330/1FRW), 36054658 (F330FRS), 36049633 (F340FRN), 36049625 (F340FRW), 36063642 (F96/3N), 33700771 (FCL602AV), 33700770 (FCL602GH), 33700761 (FCL614-1AV), 33700763 (FCL614-1BA), 33700760 (FCL614-1GH), 33700321 (FCL614AV), 33700462 (FCL614AV), 33700461 (FCL614GH), 33700320 (FCL614RA), 33700463 (FCL614RA),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

33700560 (FCL614X), 33700337 (FCL634N), 33700466 (FCL634N), 33700338 (FCL634W), 33700465 (FCL634W), 33700769 (FHP6031X), 33700619 (FHP603X), 33700564 (FHP607X), 33700552 (FHP612X), 33700571 (FHP612X), 33700620 (FHP648X), 33700706 (FHP648X), 33700622 (FHP748N), 33700623 (FHP748W), 33700621 (FHP748X), 33700618 (FHP827X), 36224129 (FL100N), 39631007 (FL100N), 36297000 (FL501X), 33700042 (FL503X), 33700444 (FL635X), 33700268 (FNP601N), 33700267 (FNP601W), 33700266 (FNP601X), 33700265 (FNP602XUK), 33700551 (FNP612NX), 33700572 (FNP612NX), 33700264 (FNP612X), 33700384 (FNP615NXUK), 33700455 (FNP615NXUK), 33700273 (FNP615X), 33700263 (FNP622X), 33700274 (FNP815X), 33700272 (FNP815XUK), 33700271 (FNP825X), 33900015 (FNPC612X), 33900014 (FNPC825X), 33900013 (FNPP612X), 36056604 (FOCI110N), 36056612 (FOCI110S), 36056000 (FOCI110W), 36057602 (FOCI330N), 36057610 (FOCI330S), 36057008 (FOCI330W), 36163632 (FOF123CN), 36048627 (FOF140FRW), 36227106 (FOF222-3CM), 36227122 (FOF222-3CN), 36227130 (FOF222-3CX), 36227601 (FOF222CM), 36227627 (FOF222CN), 36227635 (FOF222CX), 36227650 (FOF224CN), 36283125 (FOF242-3CX), 36223626 (FOF242CX), 36283141 (FOF243-3CN), 36223105 (FOF243-3CX), 36223642 (FOF243CN), 36222156 (FOF254-3CN), 36222131 (FOF254-3CX), 36222644 (FOF254CN), 36222628 (FOF254CX), 36105609 (FOF311FRX), 36054666 (FOF330-1FRW), 36054633 (FOF330FRN), 36054658 (FOF330FRS), 36054625 (FOF330FRW), 36049633 (FOF340FRN), 36049625 (FOF340FRW), 33700452 (FOFNP601N), 33700453 (FOFNP601W), 33700451 (FOFNP601X), 33700456 (FOFNP602XUK), 33700458 (FOFNP612X), 33700454 (FOFNP615X), 33700459 (FOFNP815X), 33700470 (FOFNP815XUK), 33700457 (FOFNP825X), 36105153 (FOFP601AL), 36105013 (FOFP601X), 33700060 (FOFP602XUK), 33700091 (FOFP612AL), 33700089 (FOFP612N), 33700090 (FOFP612X), 33700092 (FOFP622N), 33700093 (FOFP622X), 36105120 (FOFP632CAL), 36105138 (FOFP632CW), 33700139 (FOFP636N), 33700140 (FOFP636W), 33700138 (FOFP636X), 36291136 (FOFP835CAL), 36291151 (FOFP835CN), 36291144 (FOFP835CW), 33700098 (FOFP835CX), 36003168 (FOFR122-3N), 36003150 (FOFR122-3W), 36164028 (FOFR142-3N), 36164101 (FOFR142-3W), 36059616 (FOR100-1GH), 36055671 (FOR340-1FRW), 36055697 (FOR340FRTF), 36282127 (FOR43-3BD), 36282135 (FOR43-3GHE), 36055127 (FOR43BA), 36055119 (FOR43BD), 36055101 (FOR43GH), 36055010 (FOR43X), 36105153 (FP601AL), 36105112 (FP601N), 36105104 (FP601W), 36294122 (FP622XAUS), 36105120 (FP632CAL), 36105146 (FP632CN), 36105138 (FP632CW), 33700141 (FP636AL), 36291136 (FP835CAL), 36291151 (FP835CN), 36105104 (FPP601W), 36294114 (FPP622N), 33700638 (FPP403N), 33700639 (FPP403W), 33700637 (FPP403X), 33700768 (FPP406X), 33700641 (FPP407N), 33700642 (FPP407W), 33700640 (FPP407X), 33700644 (FPP502N), 33700645 (FPP502W), 33700643 (FPP502X), 33700649 (FPP6021X), 33700647 (FPP602N), 33700648 (FPP602W), 33700646 (FPP602X), 33700674 (FPP602XOS), 33700650 (FPP607X), 33700673 (FPP607XOS), 33700671 (FPP607XTW), 33700670 (FPP646N), 33700711 (FPP648N), 33700712 (FPP648W), 33700710 (FPP648X), 33700636 (FPP827X), 33700616 (FST201N), 33700617 (FST201W), 33700615 (FST201X), 33700613 (FST247N), 33700614 (FST247W), 33700612 (FST247X), 33700767 (FVH703X), 33700707 (FVH748X), 33700730 (FVP702X), 33700765 (FVP702XDISP), 33700731 (FVP727X), 33700729 (FVP727XDISP), 33700713 (FVP748X), 33700518 (R100-3GH), 36059103 (R100-3GH), 36055671 (R340/1FRW), 36055184 (R340/3SDE), 36055697 (R340FRTF), 36282135 (R43/3GHE), 36282143 (R43/3XE), 36282119 (R43-3BA), 33700472 (R43-3GH), 36282192 (R43-3GHCR), 33700020 (R43-3GHCRUK), 36282168 (R43-3RA), 36282143 (R43-3XE), 36282150 (R43-3XUK), 36056158 (UCCI2006-3GW), 36056117

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(UCCI2006-3N), 36056109 (UCCI2006-3W), 36056034 (UCCI2006-3X), 36056653 (UCCI2006N), 36056646 (UCCI2006W), 36025021 (UCCI2006WE), 36056026 (UCCI2006X), 36025633 (UCCI2006XE), 36025112 (UCCI2012-3W), 36025039 (UCCI2012-3WE), 36025120 (UCCI2012-3X), 36025104 (UCCI2012-3XE), 36183010 (UCCI310-1DW), 36058642 (UCCI310-1W), 36183606 (UCCI310DN), 36183614 (UCCI310DS), 36183002 (UCCI310DW), 36058634 (UCCI310EN), 36058626 (UCCI310EW), 36057651 (UCCI330-1W), 36057636 (UCCI330EN), 36057644 (UCCI330ES), 36057628 (UCCI330EW), 36183135 (UCCI4206-3N), 36183127 (UCCI4206-3W), 36183119 (UCCI4206-3X), 36183036 (UCCI4206X), 36183200 (UCCI4212-3GX), 36183168 (UCCI4212-3N), 36183192 (UCCI4212-3NE), 36183150 (UCCI4212-3W), 36183184 (UCCI4212-3WE), 36183143 (UCCI4212-3X), 36183176 (UCCI4212-3XE), 36056638 (UCCI422N), 36056620 (UCCI422W), 36056018 (UCCI422X), 36025013 (UCCI512EW), 36025625 (UCCI512EX), 36057115 (UCCI5412-3N), 36057107 (UCCI5412-3W), 36057024 (UCCI5412-3X), 36057123 (UCCI5412-3XE), 36057735 (UCCI5412N), 36057727 (UCCI5412W), 36057016 (UCCI5412X), 36057743 (UCCI5412XE), 36058659 (UCCI542EN), 36058667 (UCCI542EW), 36183648 (UCCI542W), 36183622 (UCCI642X), 36057701 (UCCI654EN), 36057719 (UCCI654EW), 36057693 (UCCI654EX), 36057685 (UCCI654N), 36057677 (UCCI654W), 36057669 (UCCI654X), 36184620 (UCCI96DM), 36184000 (UCCI96DW), 36324101 (UCFLC20W), 36324002 (UCFLC20X), 36323103 (UCFLC60N), 33900009 (UCFLP100-1W), 36309003 (UCFLP100W), 33900007 (UCFLP101-1X), 36314110 (UCFLP101W), 36314003 (UCFLP101X), 33900008 (UCFLP501-1X), 36315117 (UCFLP501W), 36315000 (UCFLP501X), 36308112 (UCFPC612N), 36308005 (UCFPC612X), 33900006 (UCFPP612X), 36317006 (UCFPP612X)

CANDY Pot stove 36105112 (FOFP601N)

GASFIRE Electric oven 36109601 (FOFI1020MT N), 36109619 (FOFI1020MT W)

HOOVER Electric oven 33700691 (HOC 706 N)

IBERNA Electric oven 36238111 (FI 010-3 N), 36238103 (FI 010-3 W), 36238012 (FI 010-3 X), 33700336 (FI 0506 X), 33700494 (FI 0506X), 33700335 (FI 0536 N), 33700334 (FI 0536 W), 33700333 (FI 0536 X), 33700486 (FI 0536W), 33700484 (FI 0536X), 36292126 (FI 110-3 X), 33700191 (FI 200 W), 33700192 (FI 200 X), 33700212 (FI 610 X), 33700485 (FI0536N), 36238004 (FO FI 010 N), 36238608 (FO FI 010 W), 36238616 (FO FI 010 X), 36292001 (FO FI110-3 W), 36238624 (FO RI 010 GH), 36238129 (RI 010-3 GH)

KELVINATOR Electric oven 36185601 (FO FK 3030 M)

KELVINATOR Oven under cooktop electric 36182608 (UC CIK 303 M), 36182004 (UC CIK 303 W)

OTSEIN Electric oven 36188506 (FO OTS 80 M), 36188001 (FO OTS 80 W)

ROSIERES Electric oven 33700102 (FC 3161-1 IN), 33700101 (FC 3162 IN IL), 33700516 (FC3163-1IN), 36193613 (FO F 123 IN), 36193001 (FO F 123 PN), 36193605 (FO F 123 RB), 36194611 (FO F 143 IN), 36194009 (FO F 143 PN), 36194603 (FO F 143 RB), 36196616 (FO F 144 IN), 36196004 (FO F 144 PN), 36196608 (FO F 144 RB), 36197002 (FO F141RU GH), 36197606 (FO F141RU SD), 36008019 (FO FR 2020IN), 36008639 (FO FR 2020PN), 33700103 (FOFC3161IN), 33700121 (FOFC3163IN), 36109643 (FOFI1020-1IN), 36109635 (FOFI1020-1PN), 36109627 (FOFI1020-1RB), 36109650 (FOFI1029-1IN), 36109668 (FOFI1029-1RB), 36161636 (FOFI1040-1PN), 36161628 (FOFI1040-1RB), 36008027 (FOFR2020-3IN), 36008118 (FOFR2020-3PN), 36008100 (FOFR2020-3RB), 36279016 (FOFR2040-3IN), 36279008 (FOFR2040IN), 36008126 (FR2020-3INIL), 36008134 (FR2029-3INIL)



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

