



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

**Termostat reglabil 233°C EGO 55.17049.010 ZANUSSI 3890796075
#COK205ZN**

Fara TVA: 84,03 Lei

Pret cu TVA: 100,00Lei

Termostat reglabil 233°C EGO 55.17049.010 ZANUSSI 3890796075 #COK205ZN

Dimensiune bulb: ø3x195mm

Lungime capilar: 1180mm

Compatibil cu:

ZANUSSI 3890796075

ELECTROLUX 3890796075

LF 5126127

RX66TM 947740709 01 REX-ELECTROLUX RXP660MSA 947740710 01 REX-ELECTROLUX RBP660MSA
947740712 01 REX-ELECTROLUX RB660MSA 947740714 00 REX-ELECTROLUX RB660MSA 947740714 01
REX-ELECTROLUX M6835MCW 947740738 00 ARTHURMARTINELUX M6835MCW 947740738 01
ARTHURMARTINELUX M6837MCW 947740739 00 ARTHURMARTINELUX M6837MCW 947740739 01
ARTHURMARTINELUX CMC6041W 947740753 00 FAURE CMC6041W 947740753 01 FAURE CMC6042W
947740755 00 FAURE CMC6042W 947740755 01 FAURE CZC6046X 947740757 00 FAURE CZC6046X
947740757 01 FAURE ZCM641X 947740760 00 ZANUSSI-ELECTROLUX ZCM641X 947740760 01
ZANUSSI-ELECTROLUX ZCM640W 947740761 00 ZANUSSI-ELECTROLUX PPX665AMS 947740764 00 ZOPPAS
PPX665AMS 947740764 01 ZOPPAS PXA660AMS 947740766 00 ZOPPAS PXA660AMS 947740766 01 ZOPPAS
PX660AMS 947740767 00 ZOPPAS PX660AMS 947740767 01 ZOPPAS PW660AMS 947740769 00 ZOPPAS
PW660AMS 947740769 01 ZOPPAS PX650AMS 947740773 00 ZOPPAS PW650AMS 947740775 00 ZOPPAS
EKM6740 947740780 01 ELECTROLUX EKM6745X 947740781 01 ELECTROLUX ZCM6650W 947740782 00
ZANUSSI ZCM6650W 947740782 01 ZANUSSI EKM6701 947740783 00 ELECTROLUX ZCM6600W 947740784 00
ZANUSSI EKM6700 947740786 00 ELECTROLUX EKM6715 947740791 00 ELECTROLUX EKM6715X 947740792
00 ELECTROLUX EKM6702 947740797 00 ELECTROLUX EKM6703 947740798 00 ELECTROLUX EKM6704
947740799 00 ELECTROLUX EKM6705 947740800 00 ELECTROLUX ZCM6601W 947740808 00 ZANUSSI
ZCM6603W 947740810 00 ZANUSSI ZCM6603X 947740811 00 ZANUSSI ZCM6605W 947740814 00 ZANUSSI
ZCM6605X 947740815 00 ZANUSSI CZC6046X 947740817 00 FAURE EKM6722X 947740818 00 ELECTROLUX
EKM6716X 947740820 00 ELECTROLUX EKM6707 947740821 00 ELECTROLUX EKM6707X 947740822 00
ELECTROLUX EKM6709 947740824 00 ELECTROLUX EKM6709X 947740825 00 ELECTROLUX EKM6711
947740826 00 ELECTROLUX EKM6711X 947740827 00 ELECTROLUX EKM6712 947740828 00 ELECTROLUX
E6866MCW 947760270 00 ARTHURMARTINELUX ZCE641X 947760276 00 ZANUSSI-ELECTROLUX ZCE641X
947760276 01 ZANUSSI-ELECTROLUX ZCE640W 947760277 00 ZANUSSI-ELECTROLUX ZCE640W 947760277



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

01 ZANUSSI-ELECTROLUX EKE6740 947760282 00 ELECTROLUX EKE6740 947760282 01 ELECTROLUX
EKC6730 947760283 00 ELECTROLUX EKC6730 947760283 01 ELECTROLUX EKC6730 947760284 00
ELECTROLUX EKC6730 947760284 01 ELECTROLUX EKC6735 947760285 00 ELECTROLUX EKC6735
947760285 01 ELECTROLUX EKC6735 947760285 02 ELECTROLUX EKC6735 947760286 00 ELECTROLUX
EKC6735 947760286 01 ELECTROLUX EKC6735 947760286 02 ELECTROLUX EKC6740 947760287 00
ELECTROLUX EKC6740 947760287 01 ELECTROLUX EKC6740 947760287 02 ELECTROLUX EKC6740X
947760290 00 ELECTROLUX EKC6750 947760291 00 ELECTROLUX EKC6750X 947760292 00 ELECTROLUX
EKC6750X 947760292 01 ELECTROLUX EKC6750X 947760292 02 ELECTROLUX EKC6745 947760293 00
ELECTROLUX EKC6745 947760293 02 ELECTROLUX EKC6745X 947760294 00 ELECTROLUX ZCS6652W
947760295 00 ZANUSSI ZCS6652W 947760295 01 ZANUSSI ZCC6652W 947760296 00 ZANUSSI ZCC6652W
947760296 01 ELECTROLUX ZCC6655W 947760297 00 ZANUSSI ZCC6655W 947760297 01 ZANUSSI
ZCC6655X 947760298 00 ZANUSSI ZCC6657W 947760299 00 ZANUSSI ZCC6657W 947760299 01 ZANUSSI
ZCC6657X 947760300 00 ZANUSSI SN6010 947760301 00 ELEKTRO HELIOS SN6010 947760301 01 ELEKTRO
HELIOS SN6010 947760302 00 ELEKTRO HELIOS SN6010 947760302 01 ELEKTRO HELIOS SK6060 947760303
00 ELEKTRO HELIOS SK6060 947760304 00 ELEKTRO HELIOS SK6060 947760304 01 ELEKTRO HELIOS SK6310
947760305 00 ELEKTRO HELIOS SK6310 947760305 01 ELEKTRO HELIOS SK6310 947760306 00 ELEKTRO
HELIOS SK6310 947760306 01 ELEKTRO HELIOS FEH60P2/4 947760307 00 ELECTROLUX FEH60G2/4
947760308 00 ELECTROLUX ESK6105 947760312 00 ELEKTRA ESK6105 947760312 01 ELEKTRA ESK6145
947760313 00 ELEKTRA ESK6145 947760313 01 ELEKTRA ESK6155 947760314 00 ELEKTRA EKC6701
947760315 00 ELECTROLUX EKC6701X 947760316 00 ELECTROLUX EKC6702 947760317 00 ELECTROLUX
ZCS6600W 947760318 00 ZANUSSI ZCS6601W 947760319 00 ZANUSSI ZCS6602W 947760320 00 ZANUSSI
ZCS6603W 947760321 00 ZANUSSI ZCC6600W 947760322 00 ZANUSSI ZCC6600X 947760323 00 ZANUSSI
EKC6700 947760324 00 ELECTROLUX E6866MCW 947760338 00 ARTHURMARTINELUX E6866MCW 947760338
01 ARTHURMARTINELUX EKC6706 947760343 00 ELECTROLUX EKC6706X 947760344 00 ELECTROLUX
ZCC6601W 947760345 00 ZANUSSI FGQ020NE 949711452 00 REX-ELECTROLUX FGQ020XE 949711453 00
REX-ELECTROLUX FGR020GE 949711454 00 REX-ELECTROLUX FGR020XE 949711455 00 REX-ELECTROLUX
HR3000IA 949711467 00 CORBERO HI5000IA 949711468 00 CORBERO ZOS745QX 949711538 00 ZANUSSI
ZOS745QX 949711538 01 ZANUSSI ZOS865QX 949711539 00 ZANUSSI ZOS865QX 949711539 01 ZANUSSI
EOB3712W 949711548 00 ELECTROLUX EOB3712X 949711549 00 ELECTROLUX FNQ011B 949711559 00
REX-ELECTROLUX FNQ011N 949711560 00 REX-ELECTROLUX FNQ011XN 949711561 00 REX-ELECTROLUX
FMQ041B 949711562 00 REX-ELECTROLUX FMQ041N 949711563 00 REX-ELECTROLUX FMQ041XN 949711564
00 REX-ELECTROLUX FMQ041X 949711565 00 REX-ELECTROLUX FMQ051B 949711566 00 REX-ELECTROLUX
FMQ051N 949711567 00 REX-ELECTROLUX FMQ051NS 949711568 00 REX-ELECTROLUX FMQ051X 949711569
00 REX-ELECTROLUX FMQ051X 949711569 01 REX-ELECTROLUX FMS041X 949711579 00 REX-ELECTROLUX
FMS041X 949711579 01 REX-ELECTROLUX FMS041X 949711579 02 REX-ELECTROLUX FMS051X 949711580 00
REX-ELECTROLUX FMS051X 949711580 01 REX-ELECTROLUX FMS051X 949711580 02 REX-ELECTROLUX
FMT04NC 949711583 00 REX-ELECTROLUX FMR041G 949711584 00 REX-ELECTROLUX FMR041R 949711585
00 REX-ELECTROLUX FMR041X 949711586 00 REX-ELECTROLUX FMR051G 949711587 00 REX-ELECTROLUX
FMR051R 949711588 00 REX-ELECTROLUX FMR051B 949711589 00 REX-ELECTROLUX FMRS041G 949711590



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

00 REX-ELECTROLUX FMRS041R 949711591 00 REX-ELECTROLUX FMS051XX 949711592 00 REX-ELECTROLUX FMS051XX 949711592 01 REX-ELECTROLUX FMS051XX 949711592 02 REX-ELECTROLUX FMNC041G 949711593 00 REX-ELECTROLUX FMNC041X 949711594 00 REX-ELECTROLUX ZOB655W 949711658 00 ZANUSSI ZOB655N 949711659 00 ZANUSSI ZOB655X 949711660 00 ZANUSSI ZOB893QX 949711665 00 ZANUSSI ZOB893QX 949711665 01 ZANUSSI ZOB893QA 949711666 00 ZANUSSI ZOB647QW 949711688 00 ZANUSSI ZOB647QN 949711689 00 ZANUSSI ZOB647QX 949711690 00 ZANUSSI ZOB647QX 949711690 01 ZANUSSI ZOB667QX 949711691 00 ZANUSSI ZOB667QX 949711691 01 ZANUSSI ZOB667QA 949711692 00 ZANUSSI ZBC749N 949711693 00 ZANUSSI EOB3730X 949711695 00 ELECTROLUX FMRS041S 949711699 00 REX-ELECTROLUX ZBS663X 949711713 00 ZANUSSI ZOB691N 949711718 00 ZANUSSI ZOB691N 949711718 01 ZANUSSI ZOB691C 949711719 00 ZANUSSI ZOB691C 949711719 01 ZANUSSI ZOB656X 949711728 00 ZANUSSI ZOB682X 949711729 00 ZANUSSI ZOB689X 949711730 00 ZANUSSI ZOB689W 949711731 00 ZANUSSI ZOB689SX 949711736 00 ZANUSSI ZOB689SX 949711736 01 ZANUSSI ZOB689SW 949711737 00 ZANUSSI ZOB660X 949711741 00 ZANUSSI EOB3750X 949711755 00 ELECTROLUX EOB3740X 949711766 00 ELECTROLUX ZBF361X 949711769 00 ZANUSSI ZOB160W 949711776 00 ZANUSSI ZOB160X 949711777 00 ZANUSSI ZBF260W 949711778 00 ZANUSSI ZBF260X 949711779 00 ZANUSSI ZBF360W 949711780 00 ZANUSSI ZBF360B 949711781 00 ZANUSSI ZBF360X 949711782 00 ZANUSSI ZBQ465X 949711786 00 ZANUSSI EOB2700W 949711793 00 ELECTROLUX EOB2700W 949711793 01 ELECTROLUX EOB2700B 949711794 00 ELECTROLUX EOB2700B 949711794 01 ELECTROLUX EOB2700X 949711795 00 ELECTROLUX EOB2700X 949711795 01 ELECTROLUX EOB5700W 949711796 00 ELECTROLUX EOB5700W 949711796 01 ELECTROLUX EOB5700K 949711797 00 ELECTROLUX EOB5700K 949711797 01 ELECTROLUX EOB5700X 949711798 00 ELECTROLUX EOB5700X 949711798 01 ELECTROLUX ZKB7524W 949711804 00 ZANKER ZKB7524N 949711805 00 ZANKER ZKB7524X 949711806 00 ZANKER ZKB7528X 949711807 00 ZANKER ZOB345W 949711814 00 ZANUSSI ZOB345N 949711815 00 ZANUSSI ZOB345X 949711816 00 ZANUSSI ZOB645W 949711817 00 ZANUSSI ZOB645N 949711818 00 ZANUSSI ZOB645X 949711819 00 ZANUSSI ZOB665N 949711820 00 ZANUSSI ZOB665X 949711821 00 ZANUSSI ZOB865QX 949711823 00 ZANUSSI ZOB865QX 949711823 01 ZANUSSI ZOB865QA 949711824 00 ZANUSSI ZOB865QXR 949711825 00 ZANUSSI ZOB865QXR 949711825 01 ZANUSSI ZOB865QAR 949711826 00 ZANUSSI ZBM140XK 949711827 00 ZANUSSI OE60B 949711833 00 ELECTROLUX OE60X 949711834 00 ELECTROLUX RK3310W 949711838 00 ROSENLEW RK3320W 949711841 00 ROSENLEW G. I. 949711851 00 NO BRAND ZOB891X 949711857 00 ZANUSSI ZOB891QW 949711858 00 ZANUSSI ZOB891QN 949711859 00 ZANUSSI ZOB891QX 949711860 00 ZANUSSI ZOB891QX 949711860 01 ZANUSSI ZOB660X 949711893 00 ZANUSSI ZOB660X 949711893 01 ZANUSSI ZBQ465X 949711898 00 ZANUSSI ZBQ465X 949711898 01 ZANUSSI JLBIO601 949711935 00 JOHN LEWIS FMQ051MX 949711986 00 REX-ELECTROLUX ZBM140XK 949712025 00 ZANUSSI ZOU647QW 949721433 00 ZANUSSI ZOU647QN 949721434 00 ZANUSSI ZOU647QX 949721435 00 ZANUSSI ZOU647QX 949721435 01 ZANUSSI ZOU667QX 949721436 00 ZANUSSI ZOU667QX 949721436 01 ZANUSSI ZOU657W 949721466 00 ZANUSSI ZOU657B 949721467 00 ZANUSSI ZOU657X 949721468 00 ZANUSSI ZOU682W 949721469 00 ZANUSSI ZOU682B 949721470 00 ZANUSSI ZOU682X 949721471 00 ZANUSSI ZOU854X 949721472 00 ZANUSSI ZOU882X 949721473 00 ZANUSSI ZOU667QN 949721486 00 ZANUSSI EON1600W 949721512 00 ELECTROLUX EON1600B 949721513 00 ELECTROLUX EON1600X 949721514 00 ELECTROLUX EON3600W



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

949721515 00 ELECTROLUX EON3600B 949721516 00 ELECTROLUX EON3600X 949721517 00 ELECTROLUX
ZOU645N 949721518 00 ZANUSSI ZOU645X 949721519 00 ZANUSSI ZOU345X 949721557 00 ZANUSSI
RA3310W 949721562 00 ROSENLEW ZOU882X 949721565 00 ZANUSSI FGQ020XE 949711453, FMRS041G
949711438, SK6060 940002000 ELEKTRO HELIOS SK6060 940002000 ELEKTRO HELIOS ZCC6653W 940002002
ZANUSSI ZCC6653W 940002002 ZANUSSI ZCC6653W 940002002 ZANUSSI SK6060 940002003 ELEKTRO
HELIOS EKC6001 940002004 ELECTROLUX EKC6001 940002004 ELECTROLUX EKC6001 940002004
ELECTROLUX EKC6001 940002004 ELECTROLUX EKC6001 940002005 ELECTROLUX EKC6001 940002005
ELECTROLUX EKC6001 940002005 ELECTROLUX EKC6001 940002005 ELECTROLUX SK6400 940002010
ELEKTRO HELIOS SK6400/4 940002011 ELEKTRO HELIOS SK6402 940002012 ELEKTRO HELIOS RKK601
940002013 ROSENLEW RKK601 940002013 ROSENLEW RKK601 940002013 ROSENLEW RKK601 940002013
ROSENLEW SK6402 940002014 ELEKTRO HELIOS SK6402 940002014 ELEKTRO HELIOS SK6402 940002014
ELEKTRO HELIOS EKC60001W 940002015 ELECTROLUX EKC60001W 940002015 ELECTROLUX SK6403
940002017 ELEKTRO HELIOS ZCC6656W 940002101 ZANUSSI ZCC6656W 940002101 ZANUSSI ZCC6601W
940002103 ZANUSSI ZCC6601W 940002103 ZANUSSI ZCC6601W 940002103 ZANUSSI ZCC6600W 940002104
ZANUSSI ZCC6600W 940002104 ZANUSSI ZCC6600W 940002104 ZANUSSI ZCC6600W 940002104 ZANUSSI
ZCC6600W 940002104 ZANUSSI ZCC6600X 940002105 ZANUSSI ZCC6600X 940002105 ZANUSSI ZCC6600X
940002105 ZANUSSI ZCC6600X 940002105 ZANUSSI ZCC6600X 940002105 ZANUSSI ZCC6600X 940002105
ZANUSSI SK6310 940002106 ELEKTRO HELIOS ZCE6601W 940002108 ZANUSSI ZCE6601W 940002108
ZANUSSI ZCC6656X 940002110 ZANUSSI ZCC6656X 940002110 ZANUSSI ZCC6658W 940002111 ZANUSSI
ZCC6658X 940002112 ZANUSSI SK6310 940002113 ELEKTRO HELIOS EKC6005 940002114 ELECTROLUX
EKC6005 940002114 ELECTROLUX EKC6005 940002114 ELECTROLUX EKC6005 940002115 ELECTROLUX
EKC6005 940002115 ELECTROLUX EKC6005 940002115 ELECTROLUX EKC6005 940002115 ELECTROLUX
EKC60050 940002116 ELECTROLUX EKC60050 940002116 ELECTROLUX EKC60050 940002116 ELECTROLUX
EKC60050X 940002117 ELECTROLUX EKC60050X 940002117 ELECTROLUX EKC60050X 940002117
ELECTROLUX EKC60353 940002118 ELECTROLUX EKC60353X 940002119 ELECTROLUX EKC6025 940002120
ELECTROLUX EKC6025 940002120 ELECTROLUX EKC6025X 940002121 ELECTROLUX EKC6025X 940002121
ELECTROLUX EKC60050X 940002123 ELECTROLUX EKC60050X 940002123 ELECTROLUX EKC60050X
940002123 ELECTROLUX EKC60351 940002126 ELECTROLUX EKC60351 940002126 ELECTROLUX EKC60351
940002126 ELECTROLUX EKC60351 940002126 ELECTROLUX EKC601300W 940002127 ELECTROLUX
EKC601300W 940002127 ELECTROLUX EKC601300W 940002127 ELECTROLUX EKC601300W 940002127
ELECTROLUX EKC601300X 940002128 ELECTROLUX EKC601300X 940002128 ELECTROLUX EKC601300X
940002128 ELECTROLUX EKC601300X 940002128 ELECTROLUX FEH60G2100 940002132 ELECTROLUX
FEH60G2100 940002132 ELECTROLUX FEH60G2100 940002132 ELECTROLUX FEH60G2100 940002132
ELECTROLUX EKC60055 940002134 ELECTROLUX EKC60055 940002134 ELECTROLUX EKC60350 940002140
ELECTROLUX EKC60350 940002140 ELECTROLUX EKC60350 940002140 ELECTROLUX EKD600500W
940002142 ELECTROLUX EKD600500W 940002142 ELECTROLUX EKD600500W 940002142 ELECTROLUX
EKD600500W 940002142 ELECTROLUX EKD600500X 940002143 ELECTROLUX EKD603500W 940002144
ELECTROLUX EKD603500W 940002144 ELECTROLUX EKD603500W 940002144 ELECTROLUX EKD603500W
940002144 ELECTROLUX EKD603500X 940002145 ELECTROLUX EKD603500X 940002145 ELECTROLUX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

EKD603500X 940002145 ELECTROLUX SK6405 940002146 ELEKTRO HELIOS SK6405/4 940002147 ELEKTRO HELIOS SK6407 940002148 ELEKTRO HELIOS SK6407 940002149 ELEKTRO HELIOS SK6407 940002149 ELEKTRO HELIOS SK6407 940002149 ELEKTRO HELIOS EKC601501W 940002150 ELECTROLUX EKC601501W 940002150 ELECTROLUX EKC601501W 940002150 ELECTROLUX EKC601501X 940002151 ELECTROLUX EKC601501X 940002151 ELECTROLUX EKC603504W 940002152 ELECTROLUX EKC603505W 940002154 ELECTROLUX EKC603505W 940002154 ELECTROLUX EKC603505X 940002155 ELECTROLUX EKC603505X 940002155 ELECTROLUX CMCI630W 940002156 FAURE CMCI630W 940002156 FAURE CMCI630W 940002156 FAURE CMCI630W 940002156 FAURE CMCI630W 940002156 FAURE CMCI630S 940002157 FAURE CMCI630S 940002157 FAURE CMCI630S 940002157 FAURE CMCI630S 940002157 FAURE CMCI630S 940002157 FAURE CMCI630S 940002157 FAURE EKC601301W 940002160 ELECTROLUX EKC601301X 940002161 ELECTROLUX EKC601503W 940002162 ELECTROLUX EKC601503X 940002163 ELECTROLUX EKC60005W 940002167 ELECTROLUX EKC60005W 940002167 ELECTROLUX EKC60005W 940002168 ELECTROLUX EKC60007W 940002169 ELECTROLUX EKC60007W 940002169 ELECTROLUX EKD60005W 940002171 ELECTROLUX EKD60005W 940002171 ELECTROLUX EKD60008W 940002172 ELECTROLUX EKD60008W 940002172 ELECTROLUX EKD60008X 940002173 ELECTROLUX EKD60008X 940002173 ELECTROLUX EKD603502X 940002175 ELECTROLUX EKD603501W 940002178 ELECTROLUX EKD603501X 940002179 ELECTROLUX CMCI631W 940002180 FAURE CMCI631S 940002181 FAURE SK6408 940002182 ELEKTRO HELIOS EKC60007X 940002228 ELECTROLUX ZCS6653W 940002400 ZANUSSI ZCS6653W 940002400 ZANUSSI SN6010 940002401 ELEKTRO HELIOS SN6010 940002402 ELEKTRO HELIOS SN6400 940002404 ELEKTRO HELIOS SN6400/4 940002405 ELEKTRO HELIOS RKL601 940002406 ROSENLEW RKL601 940002406 ROSENLEW RKL601 940002406 ROSENLEW ZCS6603W 940002500 ZANUSSI ZCE641X 940002501 ZANUSSI-ELECTROLUX ZCE641X 940002501 ZANUSSI-ELECTROLUX ZCE640W 940002502 ZANUSSI-ELECTROLUX ZCE640W 940002502 ZANUSSI-ELECTROLUX ZCE640W 940002502 ZANUSSI-ELECTROLUX ZCS6602W 940002503 ZANUSSI ZCS6602W 940002503 ZANUSSI ZCS6602W 940002503 ZANUSSI EKE6005 940002504 ELECTROLUX EKE6005 940002504 ELECTROLUX EKE6005 940002504 ELECTROLUX EKE601300W 940002505 ARTHURMARTINELUX EKE601300W 940002505 ARTHURMARTINELUX FEH60P2100 940002506 ELECTROLUX FEH60P2100 940002506 ELECTROLUX FEH60P2100 940002506 ELECTROLUX EKE601301W 940002508 ARTHURMARTINELUX EKE601301W 940002508 ARTHURMARTINELUX EKE60007W 940002509 ELECTROLUX EKE60007W 940002509 ELECTROLUX CMC6041W 943001100 FAURE CMC6041W 943001100 FAURE CMC6041W 943001100 FAURE EKM603300W 943001104 ARTHURMARTINELUX EKM603300W 943001104 ARTHURMARTINELUX EKM60032 943001105 ELECTROLUX EKM60032 943001105 ELECTROLUX EKM60032 943001105 ELECTROLUX EKM60332 943001106 ELECTROLUX EKM60332 943001106 ELECTROLUX EKM6717X 943001107 ELECTROLUX EKM6717X 943001107 ELECTROLUX EKM6717X 943001107 ELECTROLUX EKM600300W 943001108 ARTHURMARTINELUX EKM600300W 943001108 ARTHURMARTINELUX EKM600300W 943001108 ELECTROLUX EKM600300W 943001108 ARTHURMARTINELUX EKM601300W 943001109 ELECTROLUX EKM601300W 943001109 ELECTROLUX EKM601300W 943001109 ELECTROLUX EKM603500W 943001110 ELECTROLUX EKM603500W 943001110 ELECTROLUX EKM603500W 943001110 ELECTROLUX EKM603500X 943001111 ELECTROLUX EKM603500X 943001111 ELECTROLUX EKM601300X 943001112 ELECTROLUX EKM601300X 943001112 ELECTROLUX EKM601300X 943001112 ELECTROLUX 31006ML-WN 943001113 AEG ELECTROLUX 31006ML-MN



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

943001114 AEG ELECTROLUX 37006ML-WN 943001115 AEG ELECTROLUX EKM601301W 943001116
ELECTROLUX EKM601301X 943001117 ELECTROLUX EKM601301X 943001117 ELECTROLUX EKM601301X
943001117 ELECTROLUX EKM601301X 943001117 ELECTROLUX EKM601301X 943001117 ELECTROLUX
EKM603501W 943001118 ELECTROLUX EKM603501W 943001118 ELECTROLUX EKM603501W 943001118
ELECTROLUX EKM603501W 943001118 ELECTROLUX EKM603501W 943001118 ELECTROLUX EKM603501W
943001118 ELECTROLUX EKM603501W 943001118 ELECTROLUX EKM603501X 943001119 ELECTROLUX
EKM603501X 943001119 ELECTROLUX EKM603501X 943001119 ELECTROLUX EKM603501X 943001119
ELECTROLUX EKM603501X 943001119 ELECTROLUX EKM603501X 943001119 ELECTROLUX EKM600301W
943001127 ELECTROLUX EKM600301W 943001127 ELECTROLUX EKM600301W 943001127 ELECTROLUX
EKM600301W 943001127 ELECTROLUX ZCM640W 943001500 ZANUSSI-ELECTROLUX ZCM640W 943001500
ZANUSSI-ELECTROLUX ZCM640W 943001500 ZANUSSI-ELECTROLUX PX650AMS 943001501 ZOPPAS
PW650AMS 943001502 ZOPPAS ZCM6651W 943001503 ZANUSSI CZC6046X 943001504 FAURE CZC6046X
943001504 FAURE CZC6046X 943001504 FAURE PPX665AMS 943001505 ZOPPAS PW660AMS 943001506
ZOPPAS ZCM6601W 943001507 ZANUSSI ZCM6601W 943001507 ZANUSSI ZCM6601W 943001507 ZANUSSI
ZCM6603W 943001508 ZANUSSI ZCM6603W 943001508 ZANUSSI ZCM6603W 943001508 ZANUSSI ZCM641X
943001511 ZANUSSI-ELECTROLUX ZCM641X 943001511 ZANUSSI-ELECTROLUX PX660AMS 943001512
ZOPPAS EKK60331 943001514 ELECTROLUX EKK60331 943001514 ELECTROLUX EKK60331 943001514
ELECTROLUX EKK60331 943001514 ELECTROLUX EKK60331X 943001515 ELECTROLUX EKK60331X
943001515 ELECTROLUX EKK60331X 943001515 ELECTROLUX EKK60331X 943001515 ELECTROLUX EKK6005
943001516 ELECTROLUX EKK6005 943001516 ELECTROLUX EKK6005 943001516 ELECTROLUX EKK6005
943001516 ELECTROLUX EKK6005 943001516 ELECTROLUX EKK6005 943001516 ELECTROLUX EKK6003
943001518 ELECTROLUX EKK60330 943001519 ELECTROLUX EKM60350 943001520 ELECTROLUX EKM60350
943001520 ELECTROLUX EKM60350 943001520 REX-ELECTROLUX EKM60350 943001520 REX-ELECTROLUX
EKK601301W 943001521 ELECTROLUX EKK601301W 943001521 ELECTROLUX EKK601301X 943001522
ELECTROLUX EKK601301X 943001522 ELECTROLUX EKK601301X 943001522 ELECTROLUX EKK601301X
943001522 ELECTROLUX EKK601302X 943001523 ELECTROLUX EKK601302X 943001523 ELECTROLUX
EKK601302X 943001523 ELECTROLUX EKK601302X 943001523 ELECTROLUX EKK603500X 943001524
ELECTROLUX EKK603500X 943001524 ELECTROLUX EKK603300W 943001528 ELECTROLUX EKK603301X
943001529 ELECTROLUX EKK601300W 943001530 ELECTROLUX EKK601300W 943001530 ELECTROLUX
RKK651300X 943001531 REX-ELECTROLUX RKK651300X 943001531 REX-ELECTROLUX RKK651300X
943001531 REX-ELECTROLUX RKK651300X 943001531 REX-ELECTROLUX RKK651300X 943001531
REX-ELECTROLUX RKK661301X 943001532 REX-ELECTROLUX RKK661301X 943001532 REX-ELECTROLUX
RKK661301X 943001532 REX-ELECTROLUX RKK661301X 943001532 REX-ELECTROLUX RKK651300W
943001533 REX-ELECTROLUX RKK651300W 943001533 REX-ELECTROLUX RKK651300W 943001533
REX-ELECTROLUX RKK651300W 943001533 REX-ELECTROLUX RKK651300W 943001533 REX-ELECTROLUX
RKK661301W 943001535 REX-ELECTROLUX RKK661301W 943001535 REX-ELECTROLUX RKK661301W
943001535 REX-ELECTROLUX RKK661301W 943001535 REX-ELECTROLUX RKK661300W 943001536
REX-ELECTROLUX EKK603302X 943001537 ELECTROLUX EKK603302X 943001537 ELECTROLUX CZC6046W
943001538 FAURE 31006GM-WN 943001539 AEG ELECTROLUX 37006GM-WN 943001540 AEG ELECTROLUX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

EKK601303W 943001541 ELECTROLUX EKK601303X 943001542 ELECTROLUX EKK603502W 943001543
ELECTROLUX EKK603502W 943001543 ELECTROLUX EKK603502X 943001544 ELECTROLUX EKK603502X
943001544 ELECTROLUX EKK603503X 943001545 ELECTROLUX RKK661305W 943001546 REX-ELECTROLUX
RKK661305W 943001546 REX-ELECTROLUX PP66AMX 943001547 ZOPPAS PP66AMX 943001547 ZOPPAS
PP66AMX 943001547 ZOPPAS PP66AMX 943001547 ZOPPAS PP66AMX 943001547 ZOPPAS PP66AMW
943001548 ZOPPAS PP66AMW 943001548 ZOPPAS PP66AMW 943001548 ZOPPAS PP66AMW 943001548
ZOPPAS PP66AMW 943001548 ZOPPAS PP65AMX 943001549 ZOPPAS PP65AMX 943001549 ZOPPAS PP65AMX
943001549 ZOPPAS PP65AMX 943001549 ZOPPAS PP65AMX 943001549 ZOPPAS PP65AMW 943001550
ZOPPAS PP65AMW 943001550 ZOPPAS PP65AMW 943001550 ZOPPAS PP65AMW 943001550 ZOPPAS
PP65AMW 943001550 ZOPPAS PP65AMW 943001550 ZOPPAS EKK603504X 943001551 ELECTROLUX
EKK603504X 943001551 ELECTROLUX EKK603504X 943001551 ELECTROLUX EKK603504X 943001551
ELECTROLUX EKK603504X 943001551 ELECTROLUX EKK603504X 943001551 ELECTROLUX EKK601304W
943001553 ELECTROLUX EKK601304X 943001554 ELECTROLUX EKK603505W 943001555 ELECTROLUX
EKK603505W 943001555 ELECTROLUX EKK603505W 943001555 ELECTROLUX EKK603505X 943001556
ELECTROLUX EKK603505X 943001556 ELECTROLUX EKK603505X 943001556 ELECTROLUX EKK603506X
943001557 ELECTROLUX EKK603506X 943001557 ELECTROLUX EKK603506X 943001557 ELECTROLUX
EKK603504W 943001558 ELECTROLUX EKK603504W 943001558 ELECTROLUX EKK603505W 943001564
ELECTROLUX EKK603505W 943001564 ELECTROLUX EKK603505W 943001564 ELECTROLUX EKK603505X
943001565 ELECTROLUX EKK603505X 943001565 ELECTROLUX EKK603505X 943001565 ELECTROLUX
EKK603505X 943001565 ELECTROLUX EKK601305X 943001566 ELECTROLUX EKK601305X 943001566
ELECTROLUX EKK601305X 943001566 ELECTROLUX EKK603507X 943001568 ELECTROLUX EKK603507X
943001568 ELECTROLUX EKK603507X 943001568 ELECTROLUX EKK603507X 943001568 ELECTROLUX
ZCM6601W 943001570 ZANUSSI ZCM6601W 943001570 ZANUSSI ZCM6601W 943001570 ZANUSSI
RKK651300X 943001571 REX-ELECTROLUX RKK651300X 943001571 REX-ELECTROLUX RKK661301X
943001572 REX-ELECTROLUX RKK661301X 943001572 REX-ELECTROLUX RKK661301X 943001572
REX-ELECTROLUX RKK651300W 943001573 REX-ELECTROLUX RKK651300W 943001573 REX-ELECTROLUX
RKK651300W 943001573 REX-ELECTROLUX RKK661301W 943001574 REX-ELECTROLUX RKK661301W
943001574 REX-ELECTROLUX RKK661301W 943001574 REX-ELECTROLUX RKK661305W 943001575
REX-ELECTROLUX RKK661305W 943001575 REX-ELECTROLUX RKK661305W 943001575 REX-ELECTROLUX
RKK661399X 943169001 REX-ELECTROLUX RKK663399X 943169002 REX-ELECTROLUX RKK661388X
943169004 REX-ELECTROLUX RKK761399X 943169006 REX-ELECTROLUX ZCM760GX 943169009 ZANUSSI
EKM70150X 943169010 ELECTROLUX ZCM760DCX 943169011 ZANUSSI RKK661399X 943169020
REX-ELECTROLUX RKK761399X 943169021 REX-ELECTROLUX ZCM640W 947740761 ZANUSSI-ELECTROLUX
EKM6710 947740789 ELECTROLUX EKM6710X 947740790 ELECTROLUX EKM6730X 947740793 ELECTROLUX
EKM6741 947740833 ELECTROLUX EKM6746X 947740834 ELECTROLUX EKM6713 947740835 ELECTROLUX
EKM6713X 947740836 ELECTROLUX EKM6717X 947740840 ELECTROLUX EKM6717X 947740840 ELECTROLUX
RXP650MSA 947740844 REX-ELECTROLUX RBP650MSA 947740846 REX-ELECTROLUX RX660TME 947740859
REX-ELECTROLUX RXP660MSA 947740861 REX-ELECTROLUX RBP660MSA 947740863 REX-ELECTROLUX
RB660MSA 947740865 REX-ELECTROLUX M6835MCW 947740874 ARTHURMARTINELUX M6835MCW



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

947740874 ARTHURMARTINELUX M6835MCW 947740874 ARTHURMARTINELUX M6837MCW 947740875
ARTHURMARTINELUX M6837MCW 947740875 ARTHURMARTINELUX CMC6041W 947740886 FAURE CMC6041W
947740886 FAURE CMC6042W 947740887 FAURE CMC6042W 947740887 FAURE EKM6701 947740888
ELECTROLUX ZCM6600W 947740889 ZANUSSI EKM6702 947740892 ELECTROLUX EKM6702 947740892
ELECTROLUX EKM6703 947740893 ELECTROLUX EKM6703 947740893 ELECTROLUX EKM6704 947740894
ELECTROLUX EKM6705 947740895 ELECTROLUX ZCM641X 947740900 ZANUSSI-ELECTROLUX ZCM640W
947740901 ZANUSSI-ELECTROLUX PPX665AMS 947740902 ZOPPAS PX660AMS 947740903 ZOPPAS PW660AMS
947740905 ZOPPAS PX650AMS 947740907 ZOPPAS PW650AMS 947740909 ZOPPAS ZCM6650W 947740912
ZANUSSI EKM6700 947740914 ELECTROLUX EKM6710 947740917 ELECTROLUX EKM6710X 947740918
ELECTROLUX EKM6715 947740919 ELECTROLUX EKM6715X 947740920 ELECTROLUX EKM6730X 947740921
ELECTROLUX ZCM6601W 947740930 ZANUSSI ZCM6603W 947740931 ZANUSSI ZCM6603X 947740932
ZANUSSI ZCM6605W 947740933 ZANUSSI ZCM6605X 947740934 ZANUSSI CZC6046X 947740936 FAURE
CZC6046X 947740936 FAURE EKM6722X 947740937 ELECTROLUX EKM6716X 947740939 ELECTROLUX
EKM6707 947740940 ELECTROLUX EKM6707 947740940 ELECTROLUX EKM6707X 947740941 ELECTROLUX
EKM6709 947740943 ELECTROLUX EKM6709X 947740944 ELECTROLUX EKM6711 947740945 ELECTROLUX
EKM6711X 947740946 ELECTROLUX EKM6712 947740947 ELECTROLUX EKM6700X 947740952 ELECTROLUX
EKM6700X 947740952 ELECTROLUX EKM6035 947740955 ELECTROLUX EKM60350 947740957 ELECTROLUX
EKK60331 947740958 ELECTROLUX EKK60331X 947740959 ELECTROLUX EKM6726X 947740962 ELECTROLUX
M6832MCW 947740964 ARTHURMARTINELUX EKK601301W 947740970 ELECTROLUX EKK601301X 947740971
ELECTROLUX EKK601100W 947740972 ELECTROLUX EKK601302X 947740974 ELECTROLUX EKK603500X
947740975 ELECTRA EKK603302X 947740977 ELECTROLUX EKK603300W 947740978 ELECTROLUX
EKK603301X 947740979 ELECTROLUX EKM601300W 947740981 ELECTROLUX EKM601300X 947740982
ELECTROLUX EKM603500W 947740983 ELECTROLUX EKM603500X 947740984 ELECTROLUX EKK601300W
947740985 ELECTROLUX ZCM6651W 947740987 ZANUSSI EKK6003 947740988 ELECTROLUX EKM60032
947740989 ELECTROLUX EKK60330 947740990 ELECTROLUX EKM60332 947740991 ELECTROLUX EKK6005
947740996 ELECTROLUX EKM600300W 947741002 ARTHURMARTINELUX EKM603300W 947741004
ARTHURMARTINELUX RKK651300X 947741005 REX-ELECTROLUX RKK651300W 947741006 REX-ELECTROLUX
RKK661301X 947741014 REX-ELECTROLUX RKK661301W 947741016 REX-ELECTROLUX RKK661300W
947741018 REX-ELECTROLUX CZC6046W 947741022 FAURE EKC6730 947760283 ELECTROLUX EKC6730
947760284 ELECTROLUX EKC6740X 947760290 ELECTROLUX EKC6750 947760291 ELECTROLUX EKC6745X
947760294 ELECTROLUX ESK6155 947760314 ELEKTRA EKC6704 947760327 ELECTROLUX EKC6704X
947760328 ELECTROLUX EKC6705 947760337 ELECTROLUX ZCE6601W 947760341 ZANUSSI EKE6741
947760348 ELECTROLUX EKC6731 947760349 ELECTROLUX EKC6731 947760350 ELECTROLUX EKC6736
947760351 ELECTROLUX EKC6736 947760352 ELECTROLUX EKC6741 947760353 ELECTROLUX EKC6741X
947760354 ELECTROLUX EKC6751 947760355 ELECTROLUX EKC6751X 947760356 ELECTROLUX EKC6746
947760357 ELECTROLUX EKC6705 947760362 ELECTROLUX ZCE641X 947760366 ZANUSSI-ELECTROLUX
ZCE640W 947760367 ZANUSSI-ELECTROLUX ZCS6652W 947760368 ZANUSSI ZCC6652W 947760369 ZANUSSI
ZCC6655W 947760370 ZANUSSI ZCC6655X 947760371 ZANUSSI ZCC6657W 947760372 ZANUSSI ZCC6657X
947760373 ZANUSSI SN6010 947760374 ELEKTRO HELIOS SN6010 947760375 ELEKTRO HELIOS SK6060



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

947760376 ELEKTRO HELIOS SK6060 947760377 ELEKTRO HELIOS SK6310 947760378 ELEKTRO HELIOS SK6310 947760379 ELEKTRO HELIOS FEH60P2 947760380 ELECTROLUX FEH60G2 947760381 ELECTROLUX ESK6145 947760386 ELEKTRA EKC6701 947760388 ELECTROLUX EKC6701X 947760389 ELECTROLUX ZCS6600W 947760391 ZANUSSI ZCS6602W 947760393 ZANUSSI ZCS6603W 947760394 ZANUSSI ZCC6600W 947760395 ZANUSSI ZCC6600X 947760396 ZANUSSI EKC6700 947760397 ELECTROLUX EKC6704 947760398 ELECTROLUX EKC6704X 947760399 ELECTROLUX E6866MCW 947760404 ARTHURMARTINELUX E6866MCW 947760404 ARTHURMARTINELUX ZCE6601W 947760406 ZANUSSI EKC6706 947760408 ELECTROLUX EKC6706X 947760409 ELECTROLUX ZCC6601W 947760410 ZANUSSI EKC6707X 947760418 ELECTROLUX EKC6707X 947760418 ELECTROLUX EKC60353 947760419 ELECTROLUX EKC60353X 947760420 ELECTROLUX EKC60351 947760423 ELECTROLUX FEH60P2100 947760424 ELECTROLUX FEH60G2100 947760425 ELECTROLUX EKC601300W 947760429 ELECTROLUX EKC601300X 947760430 ELECTROLUX ZCS6653W 947760431 ZANUSSI ZCC6653W 947760432 ZANUSSI ZCC6656W 947760433 ZANUSSI ZCC6656X 947760434 ZANUSSI ZCC6658W 947760435 ZANUSSI ZCC6658X 947760436 ZANUSSI EKC60350 947760443 ELECTROLUX EKE6005 947760444 ELECTROLUX EKC6001 947760445 ELECTROLUX EKC6001 947760446 ELECTROLUX EKC6005 947760447 ELECTROLUX EKC6005 947760448 ELECTROLUX EKC60050 947760449 ELECTROLUX EKC60050X 947760450 ELECTROLUX EKC6025 947760451 ELECTROLUX EKC6025X 947760452 ELECTROLUX EKC60055 947760453 ELECTROLUX EKC60055 947760454 ELECTROLUX EKE601300W 947760457 ARTHURMARTINELUX EKC60050X 947760459 ELECTROLUX ZOB647QW 949711688 ZANUSSI FMRS041S 949711699 REX-ELECTROLUX OE60X 949711834 ELECTROLUX ZOB662X 949711849 ZANUSSI EOB3738X 949711850 ELECTROLUX EOB3000X 949711867 ELECTROLUX ZOB690SN 949711870 ZANUSSI ZOB765X 949711988 ZANUSSI FS50X 949711997 REX-ELECTROLUX FS60X 949711998 REX-ELECTROLUX FQ11N 949712001 REX-ELECTROLUX FQ11X 949712002 REX-ELECTROLUX FQ50B 949712003 REX-ELECTROLUX FQ50N 949712004 REX-ELECTROLUX FQ50XN 949712005 REX-ELECTROLUX FQ50X 949712006 REX-ELECTROLUX FQ60B 949712007 REX-ELECTROLUX FQ60N 949712008 REX-ELECTROLUX FQ60NS 949712009 REX-ELECTROLUX FQ60X 949712010 REX-ELECTROLUX FQG20NE 949712021 REX-ELECTROLUX FQG20XE 949712022 REX-ELECTROLUX FMR051BA 949712031 REX-ELECTROLUX FMRS041BA 949712032 REX-ELECTROLUX TBF610WH 949712037 TRICITY BENDIX TBF610X 949712038 TRICITY BENDIX TBF650WH 949712039 TRICITY BENDIX TBF650X 949712040 TRICITY BENDIX ZOB655W 949712070 ZANUSSI ZOB655N 949712071 ZANUSSI ZOB655X 949712072 ZANUSSI ZOB893QX 949712077 ZANUSSI RK3310W 949712096 ROSENLEW ZOB656X 949712135 ZANUSSI ZOB682X 949712136 ZANUSSI EOB3730X 949712139 ELECTROLUX EOB3740X 949712140 ELECTROLUX EOB3750X 949712141 ELECTROLUX FNQ011N 949712150 REX-ELECTROLUX FNQ011XN 949712151 REX-ELECTROLUX FMQ041B 949712152 REX-ELECTROLUX FMQ041N 949712153 REX-ELECTROLUX FMQ041XN 949712154 REX-ELECTROLUX FMQ041X 949712155 REX-ELECTROLUX FMQ051N 949712157 REX-ELECTROLUX FMQ051NS 949712158 REX-ELECTROLUX FMQ051X 949712159 REX-ELECTROLUX FMQ051MX 949712160 REX-ELECTROLUX G. I. 949712165 NO BRAND FMS041X 949712175 REX-ELECTROLUX FMS051X 949712176 REX-ELECTROLUX FMT041NC 949712179 REX-ELECTROLUX FMR041G 949712180 REX-ELECTROLUX FMR041R 949712181 REX-ELECTROLUX FMR041X 949712182 REX-ELECTROLUX FMR051G 949712183 REX-ELECTROLUX FMR051R 949712184 REX-ELECTROLUX FMR051BA 949712186 REX-ELECTROLUX FMRS041G 949712187 REX-ELECTROLUX FMRS041R 949712188



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

REX-ELECTROLUX FMRS041S 949712189 REX-ELECTROLUX FMRS041BA 949712190 REX-ELECTROLUX
FMS051XX 949712191 REX-ELECTROLUX FMNC041G 949712192 REX-ELECTROLUX FMNC041X 949712193
REX-ELECTROLUX FGQ020NE 949712199 REX-ELECTROLUX FGQ020XE 949712200 REX-ELECTROLUX
FGR020GE 949712201 REX-ELECTROLUX FGR020XE 949712202 REX-ELECTROLUX ZOB647QW 949712206
ZANUSSI ZOB647QN 949712207 ZANUSSI ZOB647QX 949712208 ZANUSSI ZOB667QX 949712209 ZANUSSI
ZBC749N 949712210 ZANUSSI ZOB345W 949712218 ZANUSSI ZOB345N 949712219 ZANUSSI ZOB345X
949712220 ZANUSSI ZOB645W 949712221 ZANUSSI ZOB645X 949712223 ZANUSSI ZOB665X 949712225
ZANUSSI ZOB865QX 949712226 ZANUSSI ZOB865QXR 949712228 ZANKER-ELECTROLUX ZOB865QAR
949712229 ZANUSSI ZOS865QX 949712230 ZANUSSI ZOB765X 949712231 ZANUSSI ZKB7524W 949712233
ZANKER ZKB7524N 949712234 ZANKER ZKB7524X 949712235 ZANKER ZOB891X 949712243 ZANUSSI
ZOB691N 949712244 ZANUSSI ZOB691C 949712245 ZANUSSI ZOB891QW 949712246 ZANUSSI ZOB891QN
949712247 ZANUSSI ZOB891QX 949712248 ZANUSSI ZOB662X 949712254 ZANUSSI EOB3712X 949712258
ELECTROLUX EOB3738X 949712260 ELECTROLUX JLBIO5601 949712265 JOHN LEWIS JLBIO5601 949712265
JOHN LEWIS ZOB660X 949712268 ZANUSSI ZOB660X 949712268 ZANUSSI EOB2700W 949712272
ELECTROLUX EOB2700B 949712273 ELECTROLUX EOB2700X 949712274 ELECTROLUX EOB5700W 949712275
ELECTROLUX EOB5700K 949712276 ELECTROLUX EOB5700X 949712277 ELECTROLUX ZOB160W 949712286
ZANUSSI ZOB160X 949712287 ZANUSSI ZBF260W 949712288 ZANUSSI ZBF260X 949712289 ZANUSSI
ZBF360W 949712290 ZANUSSI ZBF360B 949712291 ZANUSSI ZBF360X 949712292 ZANUSSI ZBQ465X
949712297 ZANUSSI TBF610WH 949712312 TRICITY BENDIX TBF610X 949712313 TRICITY BENDIX TBF650WH
949712314 TRICITY BENDIX TBF650X 949712315 TRICITY BENDIX OE60B 949712322 ELECTROLUX OE60X
949712323 ELECTROLUX ZBM140XK-A 949712325 ZANUSSI ZOB689W 949712326 ZANUSSI ZOB689X
949712327 ZANUSSI ZOB689SX 949712331 ZANUSSI EOB3000X 949712333 ELECTROLUX ZOB690SN
949712366 ZANUSSI EOG1733K 949712374 ELECTROLUX EOG1733W 949712375 ELECTROLUX EOG1733X
949712386 ELECTROLUX FM205W 949712387 FAURE FM205N 949712388 FAURE FM205X 949712389 FAURE
HR3000IA 949712401 CORBERO HI5000IA 949712402 CORBERO FS50X 949712404 REX-ELECTROLUX
ZOB668W 949712408 ZANUSSI ZOB668N 949712409 ZANUSSI ZOB668X 949712410 ZANUSSI ZOB892X
949712411 ZANUSSI ZOB646X 949712412 ZANUSSI ZBQ465X 949712426 ZANUSSI MSF616X 949712444
MOFFAT ZOB669X 949712446 ZANUSSI EOB33030X 949712447 ELECTROLUX JLBIO5601 949712448 JOHN
LEWIS ZOB665N 949712564 ZANUSSI FQG20NE 949712603 REX-ELECTROLUX FQG20NE 949712603
REX-ELECTROLUX FQG20NE 949712603 REX-ELECTROLUX FQG20NE 949712603 REX-ELECTROLUX FQG20XE
949712604 REX-ELECTROLUX FQG20XE 949712604 REX-ELECTROLUX FQG20XE 949712604 REX-ELECTROLUX
FQG20XE 949712604 REX-ELECTROLUX EOG23400W 949712637 ELECTROLUX EOG23400W 949712637
ELECTROLUX EOG23400W 949712637 ELECTROLUX EOG23400K 949712638 ELECTROLUX EOG23400K
949712638 ELECTROLUX EOG23400K 949712638 ELECTROLUX EOG23400K 949712638 ELECTROLUX
EOG23400K 949712638 ELECTROLUX FRG20GE 949712708 REX-ELECTROLUX FRG20GE 949712708
REX-ELECTROLUX FRG20GE 949712708 REX-ELECTROLUX FRG20GE 949712708 REX-ELECTROLUX FRG20XE
949712709 REX-ELECTROLUX FRG20XE 949712709 REX-ELECTROLUX FRG20XE 949712709 REX-ELECTROLUX
FRG20XE 949712709 REX-ELECTROLUX EOG23400X 949712730 ELECTROLUX EOG23400X 949712730
ELECTROLUX EOG23400X 949712730 ELECTROLUX EOG23400X 949712730 ELECTROLUX EOG23400X



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

949712730 ELECTROLUX EOG23400X 949712730 ELECTROLUX EOG23400X 949712730 ELECTROLUX
EOG23400X 949712730 ELECTROLUX FQG20XE 949713217 REX-ELECTROLUX FQG20XE 949713217
REX-ELECTROLUX FQG20XE 949713217 REX-ELECTROLUX FQG20XE 949713217 REX-ELECTROLUX FQG20XE
949713217 REX-ELECTROLUX FRG20GE 949713234 REX-ELECTROLUX FRG20GE 949713234 REX-ELECTROLUX
FRG20GE 949713234 REX-ELECTROLUX FRG20GE 949713234 REX-ELECTROLUX FRG20XE 949713235
REX-ELECTROLUX FRG20XE 949713235 REX-ELECTROLUX FRG20XE 949713235 REX-ELECTROLUX FRG20XE
949713235 REX-ELECTROLUX FG23XE 949713975 REX-ELECTROLUX FG23XE 949713975 REX-ELECTROLUX
EOG1400AOX 949713996 ELECTROLUX EOG1400AOX 949713996 ELECTROLUX EOG1400AOX 949713996
ELECTROLUX EOG1400AOX 949713996 ELECTROLUX FRG23GE 949719903 REX-ELECTROLUX FRG23GE
949719903 REX-ELECTROLUX FRG23XE 949719904 REX-ELECTROLUX FRG23XE 949719904 REX-ELECTROLUX
ZKH7415OSG 949721622 ZANKER RA3310W 949721742 ROSENLEW ZOU657X 949721753 ZANUSSI ZOU682X
949721754 ZANUSSI ZOU854X 949721755 ZANUSSI ZOU345X 949721787 ZANUSSI ZOU647QN 949721790
ZANUSSI ZOU647QX 949721791 ZANUSSI ZOU667QX 949721792 ZANUSSI ZOU657W 949721793 ZANUSSI
EON3600W 949721868 ELECTROLUX EON3600B 949721869 ELECTROLUX EON3600X 949721870 ELECTROLUX
ZOU645X 949721871 ZANUSSI ZOU668N 949721908 ZANUSSI ZOU668X 949721909 ZANUSSI ZOU655W
949721910 ZANUSSI ZOU655X 949721911 ZANUSSI, 3890796075

