

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Rezistența cuptor 1300W 220V CANDY 92741487 #LFD355305

Fara TVA: 67,23 Lei

Pret cu TVA: 80,00Lei

Rezistența cuptor 1300W 220V CANDY 92741487 #LFD355305

Lungime: 360mm

Latime: 350mm

Dimensiune flansa: 70x22mm

Compatibil cu:

CANDY 92741487

GASFIRE 92741487

HOOVER 92741487

KELVINATOR 92741487

OTSEIN 92741487

ROSIERES 92741487

ZEROWATT 92741487

EPMS 725034

EPMS 92741487

GEV LFD355305

LF D355305

IRCA 1R08064001

CANDY Electric oven 36048601 (F110N), 36048619 (F110S), 36048007 (F110W), 36048635 (F140FRN), 36048627 (F140FRW), 36049609 (F310N), 36049617 (F310S), 39695002 (F310S), 36049005 (F310W), 36054658 (F330FRS), 36054609 (F330N), 36054617 (F330S), 36054005 (F330W), 36049633 (F340FRN), 36049625 (F340FRW), 36047009 (FLK330N), 36056604 (FOCI110N), 36056612 (FOCI110S), 36056000 (FOCI110W), 36057602 (FOCI330N), 36057610 (FOCI330S), 36057008 (FOCI330W), 36048627 (FOF140FRW), 36105609 (FOF311FRX), 36054633 (FOF330FRN), 36054658 (FOF330FRS), 36054625 (FOF330FRW), 36049633 (FOF340FRN), 36049625 (FOF340FRW), 36059616 (FOR100-1GH), 36055671 (FOR340-1FRW), 36055697 (FOR340FRTF), 36059616 (R100/1GH), 36059624 (R100/1SD), 36055671 (R340/1FRW), 36055648 (R340AM), 36055689 (R340FRGH), 36055697 (R340FRTF), 36055630 (R340GH), 36055606 (R340M), 36055663 (R340SD), 36055655 (R340TF), 36055002 (R340W), 36058642 (UCCI310-1W), 36183606 (UCCI310DN), 36183614 (UCCI310DS), 36183002 (UCCI310DW), 36058634 (UCCI310EN), 36058626 (UCCI310EW), 36057651 (UCCI330-1W), 36057636 (UCCI330EN), 36057644 (UCCI330ES), 36057628 (UCCI330EW), 36184000 (UCCI96DW)

CANDY Kitchen 35269000 (C5530W), 35269604 (C5531M), 35269620 (C5539/1W), 35269612 (C5539W), 35271006 (C5544W), 35271600 (C5545M), 35271014 (CC55049F), 35269018 (CC5531F), 35269026

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(CC55329F), 35269646 (CC55385F), 35271022 (CC5544F), 35271048 (CC55F04), 35269034 (CC55F31), 35269059 (CC59AF310), 35271030 (CC59F041), 35269042 (CC59F310), 33000101 (CC951E), 35318005 (CEE5447JF), 35269000 (CFC5530W), 35269604 (CFC5531M), 35268630 (CFC5540-1W), 35271006 (CFC5544W), 35271600 (CFC5545M), 35238609 (CFC942EL), 35271014 (CFCC55049F), 35269018 (CFCC5531F), 35269638 (CFCC5531HE), 35269026 (CFCC55329F), 35269646 (CFCC55385F), 35302009 (CFCC5540E), 35271022 (CFCC5544F), 35302017 (CFCC55E), 35271048 (CFCC55F04), 35269034 (CFCC55F31), 35269059 (CFCC59AF310), 35271030 (CFCC59F041), 35269042 (CFCC59F310), 35306018 (CFCC951E), 35238021 (CFCC952E), 33000100 (CFCC952EX), 35238625 (CFCC952EX), 35306000 (CFCC9541E), 35238013 (CFCC9542EL), 35238617 (CFCC9542ELX), 33000121 (CFCEE5447JF), 35302025 (CFCGE54J), 35317007 (CFCME5417JF), 35257005 (CFCS5531LE), 35317007 (CME5417JF)

GASFIRE Domestic refrigerator 34000370 (FO FX 1010RC), 36108009 (FO FX 1010RC)

GASFIRE Electric oven 36083004 (FC 11-1 CL W), 36083608 (FC 11-1CL GH), 36084002 (FC 15-1 CL W), 36084622 (FC 15-1CL GH), 36084630 (FC 15-1CL TF), 36161602 (FO FI1040MPN), 36161610 (FO FI1040MPW), 36161008 (FO FX 1040MP), 36109601 (FOFI1020MT N), 36109619 (FOFI1020MT W)

GASFIRE Kitchen 35286004 (CF G 1095 E), 35263615 (CF G 1096 E), 35263623 (CF G 1096 EC), 35285618 (CF G 1154 E), 35262617 (CF G 1554 E), 35264639 (CF G 1596 EX), 35287614 (CF G1554 ESX), 35264654 (CF G1596 ESX)

HOOVER Kitchen gas 35323112 (CFHG3942 AEXS), 33000095 (CFHG3942EC), 33000092 (HGE 54 FW), 33000093 (HGE 54 FX)

KELVINATOR Electric oven 36126605 (FO FK 303 M), 36126001 (FO FK 303 W), 36185601 (FO FK 3030 M)

KELVINATOR Oven under cooktop electric 36182608 (UC CIK 303 M), 36182004 (UC CIK 303 W)

OTSEIN Electric oven 36188506 (FO OTS 80 M), 36188001 (FO OTS 80 W)

ROSIERES Dishwasher 32927618 (TRIPLE40), 32927006 (TRIPLE41), 32927626 (TRIPLE44), 32928004 (TRIPLES2), 32923625 (TRISTAR40), 32923005 (TRISTAR41), 32923609 (TRISTAR44), 32922601 (TRISTARS2)

ROSIERES Domestic refrigerator 35267608 (CF 340 FR)

ROSIERES Electric oven 36193613 (FO F 123 IN), 36193001 (FO F 123 PN), 36193605 (FO F 123 RB), 36194611 (FO F 143 IN), 36194009 (FO F 143 PN), 36194603 (FO F 143 RB), 36196616 (FO F 144 IN), 36196004 (FO F 144 PN), 36196608 (FO F 144 RB), 36197002 (FO F141RU GH), 36197606 (FO F141RU SD), 36109643 (FOFI1020-1IN), 36109635 (FOFI1020-1PN), 36109627 (FOFI1020-1RB), 36161636 (FOFI1040-1PN), 36161628 (FOFI1040-1RB), 39696604 (FS54RB)

ROSIERES Kitchen 35266006 (311RB), 35267004 (341RB), 35266006 (CF 311 RB FR), 35267004 (CF 341 RB FR), 35267012 (CF CE 424 RB), 35289008 (CF RB9542 ES), 35289602 (CF RB9542 ET), 35255009 (CFRX 9542 ES), 35266014 (CM421RB)

ROSIERES Kitchen electric 35314004 (CF CV 435RB), 33000082 (CFRCE5325 RB)

ROSIERES Kitchen gas 35266014 (CF CM 421 RB), 35247667 (CF RB 5440 E), 33000081 (CFRCM532 RB)

ZEROWATT Kitchen gas 35322122 (CF HG 154 ES), 35322114 (CF HG154 EXS), 35319003 (CF HG3942 E), 35285667 (CF ZG 154 E), 35285675 (CF ZG 154 ES), 35285659 (CF ZG 154 EX), 35286012 (CF ZG 3941 E), 35263011 (CF ZG 3942 E), 35287648 (CF ZG154AEXS), 35278019 (CF ZG154EBUL), 35263631 (CF ZG3942 EC), 35321108 (CFHG3942AEXS), 35313006 (CFZG1531AES), 35264100 (CFZG3942AEXS)



**Kalva Solutions SRL**  
PLOIESTI, str. Cuza Voda nr.9 D8B parter  
Tel.: 0737095202

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

