

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Rezistența cuptor 2000W 230V FAGOR 77X2277 #COK105FA

Fara TVA: 58,82 Lei

Pret cu TVA: 70,00Lei

Rezistența cuptor 2000W 230V FAGOR 77X2277 #COK105FA

Diametru exterior: ø192mm

Diametru interior: ø182mm

Dimensiune flansa: 70x22mm

Compatibil cu:

ATEL 38FA020

BACKER FACSA 9800V0713003

DE DIETRICH 9800V0713003

EPMS 723061, 77X2277

FAGOR BRANDT 77X2277, CCM002830

GEV LFD355197

LF D355197

IRCA 1R0C992001, 1R47604001

MIELE 1R47604001

THERMOR 1R47604001

DE DIETRICH Domestic refrigerator 7X8177 (UMP301E1), 7X8313 (UMP412E1), 7X8319 (UMP501E1), 7DF0587 (UMP501J1), 7X8322 (UMP511E1), 7X8324 (UMP615E1), 7X8328 (UMP616E1)

DE DIETRICH Electric oven DMP501E1/1 (DMP501E1), DMP501E2/1 (DMP501E2), 7DF0751 (DOC310BE1), DOC310BE11 (DOC310BE1), 7DF0749 (DOC310WE1), 7DF0800 (DOC310XE1), 7DF0752 (DOC310ZE1), 7DF0807 (DOC315DF1), 7DF0806 (DOC315EF1), 7DF0758 (DOC410BE1), DOC410BE11 (DOC410BE1), 7DF0757 (DOC410WE1), DOC410WE11 (DOC410WE1), 7X9494 (DOC410XA1), 7DF0759 (DOC410XE1), DOC410XE11 (DOC410XE1), 7X0454 (DOC410XJ1), 7X8938 (DOC505XE1), 7X9564 (DOC505XE1), 7X9377 (DOC540BE1), 7X9376 (DOC540WE1), 7X9497 (DOC540XA1), 7X9723 (DOC540XA1), 7X9375 (DOC540XE1), 7X9374 (DOC560XE1), 8X0530 (DOC710B), 8X0535 (DOC710W), 8X0518 (DOC710X), 8X0637 (DOC740X), 8X0633 (DOC760X), 7X0723 (DOD328BU1), 7X0724 (DOD328WU1), 7X0727 (DOD328XU1), 7X1699 (DOD338XU1), 7DF0773 (DOD348WG1), 7DF0804 (DOD348XG1), 7X1463 (DOD428XU1), 7X9368 (DOD428XU1), 7X1314 (DOD438BU1), 7X8425 (DOD438BU1), 7X1295 (DOD438WU1), 7X8491 (DOD438WU1), 7X1105 (DOD438XU1), 7X8914 (DOD438XU1), 7DF0788 (DOD448BG1), 7DF0813 (DOD448BG1), 7DF0787 (DOD448WG1), 7DF0815 (DOD448WG1), 7X0171 (DOD448XA1), 8X0409 (DOD448XA1), 7DF0789 (DOD448XG1), 7DF0814 (DOD448XG1), 7X1787 (DOE405WJ1), 7X9682 (DOE405WJ1), 7X1789 (DOE405XJ1), 7X9679 (DOE405XJ1), 7X8659 (DOE505BE1), 7X9562 (DOE505BE1), 7X8553 (DOE505WE1), 7X9560 (DOE505WE1), 7X8497 (DOE505XE1), 7X9559 (DOE505XE1), 8X0627 (DOE705X), DOP330BE11 (DOP330BE1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

DOP330WE11 (DOP330WE1), DOP330XE11 (DOP330XE1), DOP340BE11 (DOP340BE1), DOP340WE11 (DOP340WE1), DOP340XE11 (DOP340XE1), DOP340ZE11 (DOP340ZE1), DOP350BE11 (DOP350BE1), DOP370WE11 (DOP370WE1), 7X9393 (DOP430WJ1), 7X9394 (DOP430XJ1), 7DF0780 (DOP440BE1), DOP440BE11 (DOP440BE1), 7DF0790 (DOP440WE1), DOP440WE11 (DOP440WE1), 7X1660 (DOP440WJ1), DOP440WJ11 (DOP440WJ1), 7DF0786 (DOP440XE1), DOP440XE11 (DOP440XE1), 7X1657 (DOP440XJ1), 7DF0792 (DOP440ZE1), 7DF0797 (DOP450BE1), DOP450BE11 (DOP450BE1), 7DF0795 (DOP450WE1), DOP450WE11 (DOP450WE1), 7DF0796 (DOP450XE1), DOP450XE11 (DOP450XE1), 7DF0812 (DOP450ZE1), 8X0287 (DOP455XD1), 7DF0811 (DOP458BF1), 7DF0810 (DOP458WF1), 7DF0809 (DOP458XF1), 7DF0776 (DOP460BE1), DOP460BE11 (DOP460BE1), 7DF0775 (DOP460WE1), DOP460WE11 (DOP460WE1), 7DF0778 (DOP460XE1), DOP460XE11 (DOP460XE1), 8X0285 (DOP465XD1), 7DF0777 (DOP470BE1), 7DF0774 (DOP470WE1), 7DF0779 (DOP470XE1), 7DF0793 (DOP470ZE1), 8X0284 (DOP475XD1), 8X0283 (DOP475ZD1), 7DF0782 (DOP490BE1), 7DF0781 (DOP490WE1), 7DF0783 (DOP490XE1), 7X9744 (DOP490XT1), 7DF0784 (DOP490ZE1), 8X0277 (DOP495XD1), 8X0282 (DOP495ZD1), 7X8941 (DOP505BE1), 7X8940 (DOP505WE1), 7X8942 (DOP505XE1), 8X0612 (DOP705X), 8X0453 (DOP720B), 8X0455 (DOP720W), 8X0444 (DOP720X), 8X0464 (DOP740B), DOP740B1 (DOP740B), DOP740B1-E (DOP740B), DOP740B2 (DOP740B), DOP740B2-E (DOP740B), DOP740B3 (DOP740B), DOP740B3-E (DOP740B), DOP740BS1 (DOP740BS), DOP740BS1-E (DOP740BS), DOP740BS2 (DOP740BS), DOP740BS3 (DOP740BS), 8X0466 (DOP740W), DOP740W1 (DOP740W), DOP740W1-E (DOP740W), DOP740W2 (DOP740W), DOP740W2-E (DOP740W), DOP740W3 (DOP740W), DOP740W3-E (DOP740W), DOP740WS1 (DOP740WS), DOP740WS2 (DOP740WS), DOP740WS3 (DOP740WS), 8X0460 (DOP740X), DOP740X1 (DOP740X), DOP740X2 (DOP740X), 8X0551 (DOP750B), DOP750B1 (DOP750B), 8X0555 (DOP750W), 8X0541 (DOP750X), DOP750X1 (DOP750X), DOP750X4 (DOP750X), 8X0548 (DOP750Z), DOP760W1 (DOP760), 8X0596 (DOP760B), DOP760B1 (DOP760B), 8X0595 (DOP760W), 8X0593 (DOP760X), 8X0586 (DOP770B), 8X0582 (DOP770W), DOP770W1 (DOP770W1), 8X0569 (DOP770X), DOP770X1 (DOP770X), 8X0580 (DOP770Z), DOP785W1 (DOP785W), DOP785W2 (DOP785W), 8X0605 (DOP790B), 8X0599 (DOP790W), 8X0607 (DOP790X), DOP790X2 (DOP790X), DOP790X4 (DOP790X), 8X0606 (DOP790Z), DOP840BB1 (DOP840BB), DOP840BB2 (DOP840BB), DOP960X2 (DOP960X), 7DF0184 (FA4441E1), REP-005273 (FA4441E2), REP-005274 (FA4441E3), 7DF0366 (FA4447E3), 7DF0365 (FA4641E3), 7DF0192 (FA4647E0), 7DF0192 (FA4647E1), REP-005310 (FA4647E2), REP-005310 (FA4647E3), REP-005302 (FA5447E2), REP-005365 (FA5447E2), REP-005303 (FA5447E3), 7DF0207 (FA5447S1), REP-005355 (FA5447S3), 7DF0367 (FA6449E1), 7DF0412 (FA6449E1), 7DF0432 (FB4422U1), 7DF0369 (FB4448E1), 7DF0415 (FB4448E1), FB4448E11 (FB4448E1), 7DF0193 (FB4641E0), 7DF0193 (FB4641E1), 7DF0193 (FB4641E2), REP-005316 (FB4641E3), 7DF0389 (FB4827E3), 7DF0342 (FE7447E4), 7DF0402 (FE7447E4), 7DF0353 (FM1442D1), 7DF0419 (FM1442D1), 7DF0473 (FM1442D2), 7DF0357 (FM1632D1), FM1632D21 (FM1632D2), 7DF0359 (FM1642D1), 7DF0350 (FM1648D1), FM1648D21 (FM1648D2), 7DF0362 (FM2642D1), 7DF0421 (FM2642D1), 7DF0433 (FM4422U1), 7DF0198 (FM4441E1), 7DF0198 (FM4441E2), REP-005333 (FM4441E3), 7DF0346 (FM4441E4), 7DF0198 (FM4441J1), 7DF0371 (FM4445E1), 7DF0406 (FM4445E1), 7DF0197 (FM4447E1), REP-005332 (FM4447E3), 7DF0343 (FM4447E4), 7DF0308 (FM4447U1), 7DF0308 (FM4447U2), REP-005393 (FM4447U3), 7DF0370 (FM4448E1), 7DF0403 (FM4448E1), 7DF0474 (FM4448E2), 7DF0199 (FM4641E0), 7DF0199 (FM4641E1), 7DF0199 (FM4641E2), REP-005334 (FM4641E3), 7DF0345 (FM4641E4), 7DF0481 (FM4642D1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

7DF0434 (FM4827U1), 7DF0360 (FM4942D1), 7DF0372 (FM5642D1), 7DF0354 (FM6448D1), 7DF0401 (FM6448D1), 7DF0352 (FW1442D1), 7DF0418 (FW1442D1), 7DF0355 (FW1632D1), 7DF0358 (FW1642D1), 7DF0420 (FW1642D1), 7DF0351 (FW1648D1), 7DF0417 (FW1648D1), 7DF0364 (FW2642D1), 7DF0400 (FW2642D1), REP-005453 (FW4422U1), 7DF0194 (FW4427E1), REP-005321 (FW4427E2), 7DF0374 (FW4427E3), REP-005322 (FW4427E3), FW4441E11 (FW4441E1), REP-005275 (FW4441E1), FW4441E21 (FW4441E2), REP-005276 (FW4441E2), FW4441E31 (FW4441E3), REP-005277 (FW4441E3), 7DF0368 (FW4445E1), 7DF0407 (FW4445E1), 7DF0187 (FW4447E1), FW4447E11 (FW4447E1), FW4447E21 (FW4447E2), REP-005294 (FW4447E2), FW4447E31 (FW4447E3), REP-005295 (FW4447E3), FW4448E11 (FW4448E1), FW4448E12 (FW4448E1), REP-005446 (FW4448E1), 7DF0380 (FW4449E1), 7DF0413 (FW4449E1), REP-005317 (FW4641E0), REP-005317 (FW4641E1), REP-005317 (FW4641E2), REP-005318 (FW4641E3), 7DF0480 (FW4642D1), REP-005312 (FW4647E11), REP-005313 (FW4647E3), 7DF0303 (FW4821E1), REP-005381 (FW4821E2), REP-005382 (FW4821E3), 7DF0435 (FW4822U1), 7DF0387 (FW4827E33), FW5447E31 (FW5447E3), 7DF0386 (FW5449E1), 7DF0416 (FW5449E1), REP-005386 (FW5847E2), 7DF0330 (FW5867U3), 7DF0398 (FW5867U3), 7DF0399 (FW5867U3), REP-005418 (FW6449E1), REP-005442 (FW6449E1), REP-005414 (FX1442D1), REP-005450 (FX1442D1), REP-005415 (FX1632D1), REP-005416 (FX1642D1), REP-005451 (FX1642D1), REP-005413 (FX1648D1), REP-005449 (FX1648D1), REP-005417 (FX2642D1), REP-005436 (FX2642D12), REP-005454 (FX4422U1), REP-005323 (FX4427E1), REP-005324 (FX4427E2), 7DF0379 (FX4427E3), REP-005325 (FX4427E3), FX4441E11 (FX4441E1), REP-005278 (FX4441E1), FX4441E21 (FX4441E2), REP-005279 (FX4441E2), FX4441E31 (FX4441E3), REP-005280 (FX4441E3), FX4441E21 (FX4441J2), REP-005279 (FX4441J2), FX4445E11 (FX4445E1), FX4445E12 (FX4445E1), REP-005420 (FX4445E1), REP-005438 (FX4445E1), FX4445J1/1 (FX4445J1), FX4447E11 (FX4447E1), REP-005296 (FX4447E1), FX4447E21 (FX4447E2), REP-005297 (FX4447E2), FX4447E31 (FX4447E3), REP-005298 (FX4447E3), FX4448E11 (FX4448E1), FX4448E12 (FX4448E1), FX4449E11 (FX4449E1), FX4449E12 (FX4449E1), REP-005423 (FX4449E1), REP-005444 (FX4449E1), REP-005320 (FX4641E0), REP-005319 (FX4641E1), REP-005320 (FX4641E2), REP-005320 (FX4641E3), 7DF0479 (FX4642D1), REP-005314 (FX4647E0), REP-005314 (FX4647E1), REP-005314 (FX4647E2), REP-005315 (FX4647E3), REP-005383 (FX4821E1), REP-005384 (FX4821E2), REP-005385 (FX4821E3), REP-005455 (FX4822U1), 7DF0384 (FX4827E3), FX5447E31 (FX5447E3), REP-005358 (FX5447S1), REP-005359 (FX5447S3), FX5449E11 (FX5449E1), FX5449E12 (FX5449E1), FX5847E31 (FX5847E3), FX5847E32 (FX5847E3), REP-005405 (FX5867U3), REP-005435 (FX5867U3), REP-005419 (FX6449E1), REP-005443 (FX6449E1), MC2110B1 (MC2110B), MC2110N1 (MC2110N), MC2110RB1 (MC2110RB), MC2110RN1 (MC2110RN), MC2110X1 (MC2110X), MP3110B1 (MP3110B), MP3110N1 (MP3110N), MP3140B1 (MP3140B), UMP414E1/1 (UMP414E1)  
DE DIETRICH Kitchen 7DC0188 (CD7434F1), CD7434F11 (CD7434F1), 7DC0178 (CD8437E1), 7DC0182 (CD8439E1), 7DC0181 (CD8457E1), CD8457E11 (CD8457E1), CD8457E12 (CD8457E1), CD8499F11 (CD8499F1), 7DC0177 (CW8437F1), CW8437F11 (CW8437F1), CW8437F12 (CW8437F1), DCI1198W1 (DCI1198W), DCI1198W2 (DCI1198W), DCI1198W3 (DCI1198W), DCI295WE11 (DCI295WE1), DCI999B1 (DCI999B), DCM1050W1 (DCM1050W), DCM190AE11 (DCM190AE1), DCM350WE12 (DCM350WE1), 7DC0328 (DCM440WE1), 7DC0363 (DCM440WE1), 7DC0373 (DCM630W), DCM630W1 (DCM630W), DCM630W2 (DCM630W), DCM630W3 (DCM630W), 7DC0372 (DCM640A), 7DC0370 (DCM640W), 7DC0401 (DCM740W),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

DCM940W1 (DCM940W), DCM940W2 (DCM940W)

DE DIETRICH Kitchen gas 7DC0175 (CE9000E1), 7DC0329 (DCM450WE1), 7DC0362 (DCM450WE1), DCM450WE11 (DCM450WE1), DCM450WE12 (DCM450WE1), 7DC0330 (DCM450XE1), 7DC0361 (DCM450XE1), DCM450XE11 (DCM450XE1), DCM450XE12 (DCM450XE1), 7DC0336 (DCM469WE1), 7DC0391 (DCM469WE1), 7DC0371 (DCM650W), 7DC0376 (DCM650X), 7DC0400 (DCM750W), DCM750W1 (DCM750W), DCM750W2 (DCM750W), DCM750W3 (DCM750W)

DE DIETRICH Kitchen glass-ceramics 7DC0183 (CB8479F1), 7DC0185 (CD7474F1), CD7474F11 (CD7474F1), 7DC0186 (CD8479E1), 7DC0323 (DCI399AE1), DCI399AE13 (DCI399AE1), 7DC0324 (DCI399WE1), DCI399WE11 (DCI399WE1), DCI399WE12 (DCI399WE1), DCI399WE13 (DCI399WE1), 7DC0325 (DCI399XE1), DCI399XE12 (DCI399XE1), 7DC0332 (DCI499AE1), 7DC0368 (DCI499AE1), 7DC0331 (DCI499WE1), 7DC0369 (DCI499WE1), 7DC0333 (DCI499XE1), 7DC0367 (DCI499XE1), DCI499XE11 (DCI499XE1), 8X0011 (DCI499XU1), 7DC0396 (DCI798X), 7DC0399 (DCI799A), 7DC0398 (DCI799W), DCI799W1 (DCI799W), 7DC0397 (DCI799X), DCI799X1 (DCI799X), DCI799X2 (DCI799X), DCI900X1 (DCI900X), DCI900X (DCI900XU1), 7DC0334 (DCV469WE1), 7DC0366 (DCV469WE1), 7DC0389 (DCV469WE1), 7DC0335 (DCV469XE1), 7DC0378 (DCV469XE1), 7DC0390 (DCV469XE1), 7DC0392 (DCV768W), DCV768W1 (DCV768W), 7DC0393 (DCV768X), DCV768X1 (DCV768X), 7DC0394 (DCV769W), 7DC0395 (DCV769X)

DE DIETRICH Kitchen induction 7DC0176 (CE9005E1)

DE DIETRICH Steam oven REP-005434 (F5867U3)

FAGOR BRANDT Electric oven 5H-760B1 (5H-760B), 5H-760B2 (5H-760B), 5H-760B3 (5H-760B), 5H-760B4 (5H-760B), 5H-760B5 (5H-760B), 5H-760B6 (5H-760B), 5H-760N1 (5H-760N), 5H-760N2 (5H-760N), 5H-760N3 (5H-760N), 5H-760N4 (5H-760N), 5H-760N5 (5H-760N), 5H-760N6 (5H-760N), 5H-760X1 (5H-760X), 5H-760X2 (5H-760X), 5H-760X3 (5H-760X), 5H-760X4 (5H-760X), 5H-760X5 (5H-760X), 5H-760X6 (5H-760X), 5H-770X1 (5H-770X), 5H-770X2 (5H-770X), 5H-770X3 (5H-770X), 5H-775X1 (5H-775X), 5H-775X2 (5H-775X), 5H-780X1 (5H-780X), 5H-780X2 (5H-780X), 5H-790X1 (5H-790X), 5H-860X1 (5H-860X), BMC140X1 (BMC140X), BMC140X-2 (BMC140X), BMC140X3 (BMC140X), BMC141X1 (BMC141X), BMC141X2 (BMC141X), BMC240B1 (BMC240B), BMC240X1 (BMC240X), BMC241X1 (BMC241X), BMP160B-1 (BMP160B), BMP160B-2 (BMP160B), BMP160W-1 (BMP160W), BMP160W-2 (BMP160W), BMP161X1 (BMP161X), BMP161X2 (BMP161X), BMP260B1 (BMP260B), BMP260X-2 (BMP260X), BMP261X1 (BMP261X), BP411WU11 (BP411WU1), BP411XU11 (BP411XU1), FAC74J1N2 (FAC74J1N), FAC74J1N3 (FAC74J1N), FAP24B1U1 (FAP24B1U), FAP24C1U1 (FAP24C1U), FAQ25B1U1 (FAQ25B1U), FAQ25W1U1 (FAQ25W1U), FAQ75J1N1 (FAQ75J1N), FAQ75J1N2 (FAQ75J1N), FAQ75W1N1 (FAQ75W1N), FAQ75X1N1 (FAQ75X1N), FBI961X1 (FBI961X), FBI981X1 (FBI981X), FBP25B1G1 (FBP25B1G), FBP25W1G1 (FBP25W1G), FBP25X1G1 (FBP25X1G), FBP75J1N1 (FBP75J1N), FC222MN11 (FC222MN1), FC222WN11 (FC222WN1), FC222XN11 (FC222XN1), FC222ZN11 (FC222ZN1), FC223XN11 (FC223XN1), FC272WN11 (FC272WN1), FC272XN11 (FC272XN1), FC422MN11 (FC422MN1), FC422MN12 (FC422MN1), FC422WN11 (FC422WN1), FC422WN12 (FC422WN1), FC422XN11 (FC422XN1), FC422XN12 (FC422XN1), FC422ZN11 (FC422ZN1), FC422ZN12 (FC422ZN1), FC472XN11 (FC472XN1), FC472XN12 (FC472XN1), FC622WN11 (FC622WN1), FC622XGN11 (FC622XGN1), FC622XN11 (FC622XN1), FC672XN11 (FC672XN1), FE222BS11 (FE222BS1), FE222BS12 (FE222BS1), FE222WS11 (FE222WS1), FE222WS12 (FE222WS1), FE222XS11 (FE222XS1), FE222XS12 (FE222XS1), FE222ZS11 (FE222ZS1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

FE222ZS12 (FE222ZS1), FE411WU11 (FE411WU1), FE411XU11 (FE411XU1), FE422BS11 (FE422BS1),  
FE422WS11 (FE422WS1), FE422XS11 (FE422XS1), FE422ZS11 (FE422ZS1), FE610WN11 (FE610WN1),  
FE610XN11 (FE610XN1), FE612XN11 (FE612XN1), FE622BS11 (FE622BS1), FE622WS11 (FE622WS1),  
FE622XS11 (FE622XS1), FP224MN11 (FP224MN1), FP224MN12 (FP224MN1), FP224WN11 (FP224WN1),  
FP224WN12 (FP224WN1), FP224XN11 (FP224XN1), FP224XN12 (FP224XN1), FP225BS11 (FP225BS1),  
FP225BS12 (FP225BS1), FP225BS13 (FP225BS1), FP225WS11 (FP225WS1), FP225WS12 (FP225WS1),  
FP225WS13 (FP225WS1), FP225XS11 (FP225XS1), FP225XS12 (FP225XS1), FP225XS13 (FP225XS1),  
FP228MN11 (FP228MN1), FP228MN12 (FP228MN1), FP228XN11 (FP228XN1), FP228XN12 (FP228XN1),  
FP228ZN11 (FP228ZN1), FP228ZN12 (FP228ZN1), FP229BS11 (FP229BS1), FP229BS12 (FP229BS1), FP229BS13  
(FP229BS1), FP229WS11 (FP229WS1), FP229WS12 (FP229WS1), FP229WS13 (FP229WS1), FP229XS11  
(FP229XS1), FP229XS12 (FP229XS1), FP229XS13 (FP229XS1), FP230XN11 (FP230XN1), FP424MN11  
(FP424MN1), FP424MN12 (FP424MN1), FP424WN11 (FP424WN1), FP424WN12 (FP424WN1), FP424XN11  
(FP424XN1), FP424XN12 (FP424XN1), FP424ZN11 (FP424ZN1), FP424ZN12 (FP424ZN1), FP428MN11  
(FP428MN1), FP428MN12 (FP428MN1), FP428XN11 (FP428XN1), FP428XN12 (FP428XN1), FP611XN11  
(FP611XN1), FP624WN11 (FP624WN1), FP624XGN11 (FP624XGN1), FP624XN11 (FP624XN1), FP624ZN11  
(FP624ZN1), FP628XGN11 (FP628XGN1), FP628XN11 (FP628XN1), FP667XS11 (FP667XS1), HH-229PX1  
(HH-229PX)

FAGOR BRANDT Kitchen glass-ceramics EMIC800X1 (EMIC800X), KN173W1G1 (KN173W1G), KN173W1G2  
(KN173W1G), KNA43W1N1 (KNA43W1N), KNA84W1N1 (KNA84W1N), KNA85W1N1 (KNA85W1N), KNW95W1N1  
(KNW95W1N), KQS83W1N1 (KQS83W1N), KQW93W1N1 (KQW93W1N), KV571WN11 (KV571WN1), KV571WN12  
(KV571WN1), KV571XN11 (KV571XN1), KV571XN12 (KV571XN1), KV600WN11 (KV600WN1)

THERMOR Electric oven 7HF0116 (FP80MB), 7HF0119 (FP80MB), 7HF0130 (FP80MB), 7HF0149 (FP80MB),  
7HF0146 (FP80MN), REP-006685 (FP80MN), REP-006688 (FP80MN), REP-006703 (FP80MN)

