

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Bec cuptor 300°C E14 15W 230V #3221041

Fara TVA: 16,81 Lei

Pret cu TVA: 20,00Lei

Bec cuptor 300°C E14 15W 230V #3221041

socket type E14

voltage 230V

power 15W

length 48mm

diameter 22mm

temperature max. 300°C

version IMPORT

lens length 20mm

application for oven lamp

Lumen 70lm

lifetime 1000h

Compatibil cu:

ALPENINOX 0H7035

ANGELO PO 32W0780

ASCASO CVT.20

ATEL 3192560070, 33CU507

BAKE OFF 146600012, 33CU507

BARTLETT 33CU507, 3882-146

BAUKNECHT 33CU507

BEKO 33CU507

BERTO'S 33CU507

BERTOS 23155100

BEST FOR 146600012, 33CU507

BONNET 33CU507, 70597E

CAPIC 33CU507, E201060

COLGED 33CU507, RTFOC00658

CONVOTHERM 33CU507, 5005040

COOKMAX 33CU507

COVEN 33CU507, EMPLLAHO

CUPPONE 33CU507, 91310190, ME0000375



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

DE DIETRICH 33CU507
DEXION 33CU507
ELECTROLUX 0H7035, 3192560070, 33CU507
ELETTROBAR 33CU507, RTFOC00658
ELICA 3055C
EPMS 145001, 145029, 71S7913, 824610198
FAGOR 71S7913
FAGOR BRANDT 824610198
FOINOX 10341, 35.0003.01, 824610198
FRANKE 177038, 824610198
FRIMA 30240200, 824610198
FRIULINOX 824610198, 995412
GARBIN 824610198, LAM002
GEV 359740
LF 3221041
GIORIK 359740, 6061052
HAKA 359740, 9064
HENDI 3221041, 904947
HORECAPARTS 3221041, 904947
HOTPOINT 359740
IGNIS 359740
IKEA 359740
INDESIT 359740, C00015910
INOXTREND 359740, C6085-05
JUNO 211020, 565265, 846098
KITCHENAID 359740
KREFFT 359740
KÜPPERSBUSCH 184001, 359740, 407288
LOTUS 359740, 537005400
MARENO 2861900, 359740, MA2861900
MAYTAG 359740
MBM 359740, RTFOC00658
PALUX 047635, 359740
PARRY 359740
PHILIPS 359740
PIZZA GROUP 359740, 5371260
POLARIS 1640401, 359740
RATIONAL 30240200, 359740
REPAGAS 1230009, 359740



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ROSINOX 359740, RX27610120

SAGI 32W0780, 359740

SIRMAN 359740

SMEG 359740, 824610072, 824610198, 824610204, 824610591

STUDIO 54 359740, 64740085

TECNOEKA 01950108400, 359740

TECNOINOX 359740, RC00566000

THERMOR 359740

THIRODE 359740, 70597E

TORNATI 321006, 359740

UNOX KVE1480A, KVT1235A, VT1200A

VEDETTE 359740

WHIRLPOOL 154319, 359740, 481913488135, 771985010335

ZANUSSI 0H7035, 359740

ARISTON Convection oven 00086 (1010BRAUN), 00086 (1010WEISS), C545G(X)AG, CISFBG(WH), CISFBGIX, C-L31E1, C-L40E1, DB62IX, 26518 (FB11(BR)GB), 26517 (FB11(WH)GB), 26973 (FB20AC(WH)), 25505 (FB21(BK)), 25504 (FB21(WH)), 25502 (FB21A(BK)), 26634 (FB21A(BR)), 25501 (FB21A(WH)), 25503 (FB21AIX), 25506 (FB21IX), 26974 (FB22AC(IX)), 26975 (FB22AC(WH)), 26214 (FB26(BK)), 26155 (FB26(WH)), 26154 (FB26C(BK)), 26164 (FB26C(WH)), 26521 (FB36(BK)GB), 26519 (FB36(BR)GB), 26522 (FB36(IX)GB), 26520 (FB36(WH)GB), 26526 (FB51(ALU)GB), 25492 (FB51(BK)), 25493 (FB51(BR)), 26525 (FB51(IX)GB), 25491 (FB51(WH)), 26615 (FB51A(ALU)), 25489 (FB51A(BK)), 25490 (FB51A(IX)), 25488 (FB51A(WH)), 25494 (FB51IX), 26984 (FB52AC(BK)), 26983 (FB52AC(WH)), 26982 (FB52C(IX)), 26993 (FB56C(BK)), 26991 (FB56C(IX)), 26992 (FB56C(WH)), 26381 (FB86(AN)), 25500 (FB86(BK)), 25498 (FB86(IX)), 25499 (FB86(WH)), 25967 (FB86P BK), 25966 (FB86P IX), 25968 (FB86P WH), 26215 (FB97C(BK)), 26158 (FB97C(IX)), 26159 (FB97C(WH)), 25508 (FBG(BK)), 25509 (FBG(IX)), 25507 (FBG(WH)), 25523 (FC52(AN)), 25522 (FC52(IX)), 26646 (FC52C(AN)), 26645 (FC52C(IX)), 26647 (FC55C(IX)), 25531 (FC87(AN)), 25530 (FC87(IX)), 26649 (FC87C(AN)), 26648 (FC87C(IX)), 25532 (FC88C(IX)), 25971 (FC97 P (AN)), 25972 (FC97 P (IX)), 26363 (FC98P IX), 23991 (FD51(ALU)), 18183 (FD51(BK)), 22279 (FD51(ICE)), 21669 (FD51(MR)), 18182 (FD51(WH)), 22282 (FD51IX), FD771P BK, 24616 (FD771P ICE), 24615 (FD771P MR), 21954 (FD771P WH), 24617 (FD771PIX), 25839 (FD772PBK), 25840 (FD772PWH), 24619 (FD781P ICE), 24618 (FD781P MR), 21955 (FD781PBK), 21956 (FD781PWH), 18186 (FD86C(BK)), 18185 (FD86C(WH)), 18188 (FD87C(BK)), 22280 (FD87C(ICE)), 21670 (FD87C(MR)), 18187 (FD87C(WH)), 22284 (FD87CIX), 23992 (FD88C(ALU)), 18190 (FD88C(BK)), 22281 (FD88C(ICE)), 21671 (FD88C(MR)), 18189 (FD88C(WH)), 22285 (FD88CIX(AL)), 22296 (FD88D(ICE)), 22273 (FD88D(MR)), 22274 (FD88DIX), 18574 (FG21(BK)IB), 18573 (FG21(BR)IB), 18572 (FG21(WH)IB), 18229 (FG21DR(BR)), 18228 (FG21R(BK)), 18227 (FG21R(WH)), 18106 (FG22(BR)GB), 18105 (FG22(WH)GB), 24738 (FM22M(ALU)), 22199 (FM22M(OG)), 15246 (FM22MIXAUS.1), 11280 (FM27M), 11955 (FM27M), 12847 (FM27M), 24739 (FM27M(ALU)), FM27MC(IX)EX220-60, 14151 (FM27MFR), 14152 (FM27MFR), 22089 (FM27MIXEX), 22053 (FM27MIXIR), 18122 (FM27MIXSK), 18576 (FM51(BR)IB), 18575 (FM51(WH)IB), 24019 (FM51R(ALU)), 18610 (FM51R(OW)), 18124 (FM51R(WH)SK), 24121 (FM51RC(IX)AG), 18123 (FM51RIXSK),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

22739 (FM54T(AL)), 22200 (FM54T(OS)), 22109 (FM54TRA), 25478 (FM571R(BK)), 25477 (FM571R(WH)), 18524 (FM743DC(OW)), 17867 (FM743TC(GN)), 18525 (FM743TC(OW)), 18545 (FM743TC(PA)), 22056 (FM752RC(WH)IR), 22057 (FM752RCIXIR), 25363 (FM771RC(BK)), 25362 (FM771RC(BR)), 25361 (FM771RC(WH)), 25364 (FM772RC(IX)), 18107 (FM87CIXGB), 18569 (FM87FC(BK)IB), 18567 (FM87FC(BR)IB), 18568 (FM87FC(WH)IB), 22088 (FM87R(WH)AUS), 22087 (FM87RIXAUS), 22055 (FM87VC(BK)IR), 22054 (FM87VC(WH)IR), 25513 (FO52(ALU)), 25514 (FO52(AN)), 25512 (FO52(IX)), 26643 (FO52C(BK)), 26642 (FO52C(WH)), 26641 (FO52CIX), 26616 (FO55(ALU)), 25516 (FO55(AN)), 25515 (FO55(IX)), 26527 (FO55C(IX)), 26644 (FO85C(IX)), 25518 (FO87(ALU)), 25519 (FO87(AN)), 26530 (FO87C(ALU)), 26529 (FO87C(AN)), 26528 (FO87C(IX)), 25521 (FO88C(AN)), 25520 (FO88C(IX)), 26157 (FO97C(ALU)), 26165 (FO97C(AN)), F026216 (FO97C(IX)), 26217 (FO97C(WH)), 25969 (FO97P (AN)), FO97P (IX), 26362 (FO98P IX), 26523 (FR34S(AN)GB), 26524 (FR34S(WH)GB), 25496 (FR54(AN)), 25495 (FR54(BR)), 25497 (FR54(WH)), 25511 (FRG(AN)), 25510 (FRG(BR)), 18578 (FS41(BR)IB), 18577 (FS41(WH)IB), 18570 (FS46C(BR)IB), 18571 (FS46C(WH)IB), 22137 (FS50IX), 25524 (FT85(AN)), 25527 (FT85(AV)), 25528 (FT85(OS)), 25525 (FT85(OW)), 25526 (FT85(PA)), 25529 (FT85(RA)), 26156 (FT95C(AN)), 26455 (FT95C(OW)), 26501 (HB10A(ALU)), 26498 (HB10A(BK)), 26499 (HB10A(IX)), 26500 (HB10A(OW)), 26497 (HB10A(WH)), 26976 (HB20AC(WH)), 26977 (HB22AC(IX)), 26978 (HB22AC(WH)), 26505 (HB50A(ALU)), 26503 (HB50A(BK)), 25891 (HB50A(IX)), 26504 (HB50A(OW)), 26502 (HB50A(WH)), 26507 (HB50ER(ALU)), 26506 (HB50ER(IX)), 26987 (HB52AC(BK)), 26986 (HB52AC(WH)), 26985 (HB52C(IX)), 26996 (HB56C(BK)), 26994 (HB56C(IX)), 26995 (HB56C(WH)), 22224 (HD50(BK)), 24020 (HD50(ICE)), 22225 (HD50(MR)), 24021 (HD50IX), 18194 (HD87C(BK)), 22226 (HD87C(MR)), 18191 (HD87C(WH)), 18194 (HD87C(WH)), 24018 (HM50R(ALU)), 18126 (HM50R(WH)SK), 18125 (HM50RIXSK), 22222 (HM55R(BK)), 22221 (HM55R(WH)), 22223 (HM55RIX), 26509 (HO10(ALU)), 26510 (HO10(BM)), 26508 (HO10(IX)), 26512 (HO50(ALU)), 26511 (HO50(IX)), 26997 (HO87EC(IX)), 26515 (HO87EF(ALU)), 26516 (HO87EF(BM)), 26514 (HO87EF(IX)), 24017 (HS30R(ALU)), I-F2UK, I-FG2, 00086 (I-FG2.1), 00476 (I-FG2.1), 00477 (I-FG2.1), I-FV4UK, IV-F2, IV-FM10EL, IV-FM10ELUK, IV-FM8, IV-FM8GUK, 17869 (PS41(BK)), 17871 (PS41(OW)), 17870 (PS41(WH)), 18542 (PS41IX), 00086 (SOA2)

ARISTON Domestic refrigerator 00096 (RF290L)

ARISTON Kitchen gas A5-L31E3-70, A5-L40G3S-70, A5-S42E3-70, A6-L31E3-75, A6-L31E3-75B, A6-L40G3S-75, A6-S42E3-75, 00400 (A6S42E375B), 00086 (BL04E03), 00086 (BL04EF02), 00086 (BL04EF02.2), BL04VE5UK, 00086 (BL22EF04.4), 00086 (BL31E08F), BL40G5UK, BL40VE5UK, 23681 (C050GD(W)TSKD), 22612 (C055GD(W).2EX), 23281 (C055GD(W)AG), 22612 (C055GD(W)EX), 23123 (C055GD(X)SKD), 23124 (C055GD(X)TSKD), 23701 (C0571GD(X)EX), 22585 (C057GPWF), 22587 (C057GPXF), 23777 (C065G(X)EX), 23693 (C065GP(X)AG), 23779 (C065GPD(X)AG), 27694 (C065GPDAG), 22349 (C067GP(W)), 22350 (C067GP(X)), C067GPX-F, 22615 (C085G(W).2EX), 22615 (C085G(W)EX), 22616 (C085G(X)EX), 22616 (C085G(X)EX.2), 22644 (C140G(W)F), 22643 (C145E(W)I), 22641 (C145E(X)P), 22647 (C145E(X)R), 24359 (C145EW), 24355 (C145EXR), 22645 (C145G(W)F), 24357 (C147G(W)), 22640 (C147G(W)I), 22646 (C147G(W)R), 24354 (C147G(W)R), 24358 (C147G(X)), 22642 (C147G(X)I), C14G(W), 24356 (C14GWI), 22650 (C210G(W)P), 22651 (C21E(W)P), 22649 (C240G(W)P), 22652 (C244G(W)AGSKD), 22326 (C502E(W)), 22606 (C502E(W)R), 23680 (C510E(C)CKD), 22329 (C510E(W)), 23679 (C510E(W)CKD), 22582 (C514E(W)F), 23074 (C515E(C)CKD), 23073 (C515E(W)CKD), 22617 (C515GD(G)EX), 23071 (C520E(C)SKD), 23069 (C520E(W)SKD),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

26037 (C520G(W)SKD), 22618 (C522E(W) EX), 22324 (C540G(C)), 23075 (C540G(C)TSKD), 22620 (C540G(W)EX), 23076 (C540G(W)TSKD), 22330 (C542G(W)), 23274 (C5441G(W)AG), 22980 (C544G(W)AG), 22583 (C544G(W)F), 22608 (C5451G(X)R), 23272 (C545G(W)AG), 22607 (C545G(W)R), 22621 (C545G(X)EX), 22623 (C545GD(W)EX), 23273 (C545M(W)AG), 22327 (C547M(W)), 22609 (C547M(W)R), 22328 (C547M(X)), 21695 (C602E(W)F), 22353 (C602M(W)EU), C602M.3(W)EU, 22354 (C602P(A)EU), 21690 (C615(W)F), 29445 (C615.5(W)F), 26022 (C615E(C)CKD), 22597 (C615E(W)CKD), 25413 (C615E(W)P), 22600 (C615E(W)P(1)), 21641 (C615E(W)T), C615E.3(W)T, C615EX-CKD, 22604 (C615G(X)P), 25416 (C615G(X)P), 22352 (C615M(W)EU), 22602 (C615M(X)P), 25415 (C615M(X)P), C615M.3(W)EU, 21642 (C616T(W)T), C616T.3(W)T, 22351 (C617P(X)EU), 21692 (C6191PAF), 21693 (C6192PBF), 21643 (C619M(W)T), 21644 (C619M(X)T), C619M.3(W)T, C619M.3(X)T, 21644 (C619MXT), 21691 (C619P(W)F), 22601 (C6401G(W)P), 25414 (C6401G(W)P), 23810 (C640G(C)TSKD), 22605 (C640G(W)P), 25417 (C640G(W)P), 22596 (C640G(W)TSKD), 26462 (C640G(W)TSKD), 18504 (C642G(W)), 21639 (C644E(W)T), C644E.3(W)T, 22527 (C644G(W)AG), 21640 (C644T(W)T), C644T.3(W)T, 23809 (C645G(C)TSKD), 26463 (C645G(C)TSKD), 23047 (C645G(W)AG), 22593 (C645G(W)EX), 21684 (C645G(W)F), 22595 (C645G(W)TSKD), C645GW-ALG, 22524 (C645P(W)AG), 23044 (C645P(X)AG), 22594 (C646M(W)IR), 23980 (C646M(X)IR), 21687 (C6471GAF), 21686 (C647BT(W)F), 18668 (C647E(W)), 22981 (C647E(W)O), C647E.3(W)I, 18667 (C647G(W)), 22884 (C647G(W)B), 21685 (C647G(W)F), 22102 (C647G(W)R), 18503 (C647G(X)), 24528 (C647G(X)EU), 22101 (C647GAR), 18664 (C647M(W)), 18663 (C647P(W)), 18662 (C647P(X)), C647P.3(X)I, 22153 (C647PT(W)B), C647PT.3(W)B, 18665 (C647PV(W)), 28501 (C647WEX), 18666 (C648BX), C648GTW-F, C648PT.3XB, C648PT.4XI, 18661 (C648PTX), 22885 (C648PTXB), 21647 (C649B(W)T), C649MT.3(W)F, C649MTW-F, 18669 (C649P(A)), 18670 (C649P(B)), 22099 (C649P(W)R), 22100 (C649P(X)R), C649P.4(A)I, C649PT(W)U, C649PT(X)U, 24471 (C649PT(XA)), C649PT.3(W)U, C649PT.3(X)U, C649PT.3XAU, C649PTXAU, 22098 (C649PV(A)R), 21688 (C649PV(W)F), C649PV(X)U, C649PV.3(X)U, C658P.3(X)T, 21645 (C658PXT), 23011 (C659BX), 18496 (C659BX.1), 22523 (C659BXAG), 22886 (C659BXX), 27541 (C659P(X)UK), C659P.4XF, C659P.4XI, 23012 (C659PX), 18506 (C659PX.1), 21689 (C659PXF), 22598 (C659PXNG), 26465 (C659PXNG.), 22334 (C940G(C)), 22333 (C940G(W)), 22335 (C942G(W)), 23682 (C945GD(G)CKD), 22341 (C945M(W)), 23148 (C947GD(W)CKD), 22627 (C94G(W)P), 22704 (C954GD(W)EX), C954GD(WH)EX, 22348 (C955ED(X)), C955ED(XS), 22703 (C955GD(X)EX), C955GD(XS)EX, 22628 (C95G(X)P), C95G(XS)P, 22702 (C95GD(W)EX), 25962 (C9601G(W)EX), C9601G(WH)EX, 22624 (C960G(W)EX), 22705 (C965G(W)EX), 22346 (C967GP(W)), 22347 (C967GP(X)), C967GP(XS), 23149 (C967GPD(X)CKD), 25961 (C96G(W)EX), C96G(WH)EX, 22336 (C970G(C)), 22337 (C970G(W)), 23144 (C975ED(W)CKD), 22625 (C975ED(X)EX), C975ED(XS)EX, 22338 (C980E(C)), 23126 (C980E(C)SKD), C980E(CP), 22339 (C980E(W)), 23125 (C980E(W)SKD), C980E(WH), 22626 (C980G(W)EX), 24527 (C980G(W)SKD), C980G(WH)EX, 22340 (C982E(W)), 22630 (C985E(W)P), 22631 (C985E(X)P), C985E(XS)P, 22342 (C985M(W)), 22343 (C985M(X)), 22344 (C987M(W)), C987M(WH), 22345 (C987M(X)), C987M(XS), 22629 (C98G(W)P), 00086 (G04E3BE), 00086 (G40G6BE), G40M9, 02963 (G40M9BE), 21529 (G440G2(W)AG), 21527 (G440G5WAGSKD), 02119 (G504E3), 02118 (G531E3), 02798 (G540G3), 22149 (G540G4.2(W)AG), 04788 (G540G5.2), 22145 (G540G6(X)AG), G540G6.2(X)AG-skD, 22148 (G540M5.2(W)AG), 16547 (G604E4(W)SKD), 18001 (G604M8(W)R), 12563 (G631E6TR), 15240 (G631E8TR), 12564 (G631E9TR), 18405 (G631M8S(X)), 15245 (G631M9S.1TR), 12565 (G631M9STR), 12566 (G631M9STR), 15244 (G631M9TR), 15242 (G631T9TR), 15243

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(G631T9TR), 18000 (G640E4(W)R), 15239 (G640E5.1TR), 12562 (G640E5TR), 15241 (G640T5TR), 12443 (G731E5.E), 12441 (G740E3.E), 07943 (G740G2), 07944 (G740G2), 13262 (G740G2), 13263 (G740G2), 12442 (G740G3.E), 12444 (G740G5.E), 12445 (G740G5.E), 12446 (G740G5.E), 12447 (G740G5S.E), 07945 (G742G2), 07946 (G742G2), 13264 (G742G2), 13265 (G742G2), 13667 (G84CG3(W)TSKD), 17452 (G84CG3(W)TSKD), 13668 (G84CG5(X)TSKD), 17453 (G84CG5(X)TSKD), 22141 (G84PG5(W)AG), 22142 (G84PG5(X)AG), 02128 (G940G2), 02125 (G940G3), 02126 (G940G3), 02133 (G940G5), 04791 (G940G5.2), 02136 (G940G6), 04794 (G940G6.2), 02135 (G940M5), 04793 (G940M5.2), 02129 (G941G2), 02132 (G942E2), 04672 (G942E2S), 02130 (G942E3), 02131 (G942E3), 04670 (G942E3S), 02134 (G942E5), 04865 (G942E5.2EX), 04124 (G942E5EX), 02137 (G942M6), 02138 (G942M6), 04795 (G942M6.2), 04796 (G942M6.2), 21989 (G94DG3(G)CKD), 21990 (G94DG4S(W)CKD), 21774 (G94DG6(W)), 21991 (G95PDG5S(X)CKD), 21775 (G960G6(W)), GX40E7, GX40M8, KL04E6PG, 00086 (KL04E72GR), 00963 (KL31E6PG), KL40EVEA(B), KL40GSUK, KL40VE7H(W), KL40VESUK, 00971 (KS42E6PG), 00162 (L400G4), 00086 (L401E2), 00165 (L401G4SX), M04E1UK, M04E3, 02482 (M31E3), M40G3, MC40G2, MX40G5, MX40M5, 00003 (P31E5.1), 04856 (P31GE3SGR), P40E3, P40G3, 00004 (P40GE5.1), PBL04E01UK, 00086 (PBL04E03), 00086 (PBL04EF02.2), 00086 (PBL22EF02.1), 00086 (PBL22EF02.2), PBL40G01UK, PBL40GBE, 01549 (PBL40GF02.4), 00005 (PX40GE5.1), 00086 (S401E2), 00167 (S401G02S), 03605 (S401G4SX), S40G3, S41GE3, 02487 (S42E3), SC40G2, SC41GE2, SC42E2, SGX4CG5IT, SP40G3, SP41GE3, SPX40G5, SPX41G5, SX40G5, SX42E5, SX42M6, SX4PGE5, 03071 (XL31EVE8EXP)

ARISTON Kitchen glass-ceramics 22611 (C050GD(W)EX), 22154 (C6V7P(W)B), C6V7P.3(W)B, 22097 (C6V9M(W)R), 21646 (C6V9M(W)T), 21694 (C6V9P(W)F), 22095 (C6V9P(W)R), C6V9P(W)U, C6V9P.3(W)U, C6V9P.5(W)R, 22096 (C6V9PAR), C6V9PW-SK230, C6V9PW-SK400, C6V9PX-SK230, C6V9PX-SK400

ARISTON Microwave oven 02352 (CO1000TG), 02177 (MO500), 00351 (MO650), 04680 (MO651), 00352 (MO690)

BAUKNECHT Domestic refrigerator IVU13592, KDI2800A, KDI2800ALH, KDIK2400A, KDUC12112AF, KGA326OPTIMAIN, KGI2900A, KGI2900A1, KGI2900ALH, KGI2900ALH1, KGI2902B, KGI2920B1, KGI2920B1L, KGI2920B1LH, KGI2920BLH, KGI3100A, KGI3100A1, KGI3100ALH, KGI3100ALH1, KGI3100B, KGI3102A, KGI3103A, KGIF3200B, KGIK3100A, KGIK3100A1, KGIK3109A, KGIK3109A+, KGIK3109A1, KGIK3200A, KGIK3200B, KRA2000, KRA20001, KRI1500A, KRI1502B, KRI1503A, KRI1503B, KRI1504A+, KRI1509A, KRI1509A+, KRI1509ALH, KRI1800A, KRI1803A, KRI1809A, KRI1809A1, KRI18583, KRI2203A, KRI22583, KRIC15563, KRIC18563, KRIC2269, KRIC2269LH, KRIF2200A, KRIK2200A, KRIK2200ALH, KRIK2202B, KRIK2209A, KRIK2209A1, KRIK2209ALH, 855094601000 (KRVA3009), 855094601005 (KRVA3009), KVA2000, KVA20001, KVI1300A, KVI1300ALH, KVI1302B, KVI1303B, KVI1304A+, KVI1304A++, KVI1309A, KVI1309ALH, KVI1600A, KVI1609A, KVI1620A, KVI1620A1, KVI1620A1L, KVI1620A1LH, KVI1620ALH, KVIE1300A, KVIE1309A1, KVIE1309A, KVIE2000A, KVIE2009A, KVIE2009ALH, KVIE2529A, KVIE2529ALH, KVIE3029A, KVIE3029ALH, KVIF2000A, KVIF2009A, KVIF2169, KVIF3029A, KVIF3029ALH, KVIK2000A, KVIK2002B, KVIK2009A, KVIL1369, UGI1000B, URI1440A, URI1441A+, URIE1500A, UVI1302A, UVI1340A, UVI1340A1, UVI1340A1L, UVI1340A1LH, UVI1340ALH, UVI1341A+, UVI1349A, UVI1349A1, UVI1349ALH, UVI1349ALH1, UVI1920A++, UVI1920A++LH, UVIE1400A

BEKO Domestic refrigerator B1752HCA (7224247619), 7511720022 (SSA245)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

BERTO'S Convection oven FPE6TURBO, FPG12, FPG6, PASTRYEM, PASTRYVIPEMU, SNACKE, SNACKELS, WAVE12TURBO, WAVE2-3, WAVE6, WAVE6TURBO, WAVE-E5, WAVG12, WAVG5U, WAVG6

BERTO'S Electric oven WAVE12

BERTO'S Kitchen gas G4F-FCD8, G4F-FSD8

BERTO'S Pot stove electric E2FD8, E2FQS4, E2FS4, E4FDQ8, E4F-FCD8

BOSCH - SIEMENS - BALAY Chest freezer GTE30A00

BOSCH - SIEMENS - BALAY Domestic refrigerator KSL2320

CONVOTHERM Convection oven OD6.10

CUPPONE Pizza oven electric BASE 520-1, BASE 520-2, BASE 520-3, BASE 620-1, BASE 620-2, BASE 620-3, BASE 720-1.4, BASE 720-1.6, BASE 720-2.4, BASE 720-2.6, BASE 720-3.4, MICRO, TIZIANO TZ420-1M, TIZIANO TZ425-1M, TIZIANO TZ425-2M, TIZIANO TZ430-1M, TIZIANO TZ430-2M, TIZIANO TZ435-1M, TIZIANO TZ435-2M
DE DIETRICH Domestic refrigerator KG9266F11 (KG9266F1), RG6170F51 (RG6170F5)

DE DIETRICH Electric oven 2684 (2684), 3922 (4922), 6805A, 844 (844), 7X0800 (DOC310XH1), 7X8938 (DOC505XE1), 7X9564 (DOC505XE1), 7X0723 (DOD328BU1), 7X0724 (DOD328WU1), 7X0727 (DOD328XU1), 7X1699 (DOD338XU1), 7DF0773 (DOD348WG1), 7DF0804 (DOD348XG1), 7X1463 (DOD428XU1), 7X9368 (DOD428XU1), 7X1314 (DOD438BU1), 7X8425 (DOD438BU1), 7X1295 (DOD438WU1), 7X8491 (DOD438WU1), 7X1105 (DOD438XU1), 7X8914 (DOD438XU1), 7DF0788 (DOD448BG1), 7DF0813 (DOD448BG1), 7DF0787 (DOD448WG1), 7DF0815 (DOD448WG1), 7X0171 (DOD448XA1), 8X0409 (DOD448XA1), 7DF0789 (DOD448XG1), 7DF0814 (DOD448XG1), 8X0706 (DOD617X), 7X1787 (DOE405WJ1), 7X9682 (DOE405WJ1), 7X1789 (DOE405XJ1), 7X9679 (DOE405XJ1), 7X8659 (DOE505BE1), 7X9562 (DOE505BE1), 7X8553 (DOE505WE1), 7X9560 (DOE505WE1), 7X8497 (DOE505XE1), 7X9559 (DOE505XE1), DOP340XH11 (DOP340XH1), DOP350BH11 (DOP350BH1), DOP350WH11 (DOP350WH1), 7X8941 (DOP505BE1), 7X8940 (DOP505WE1), 7X8942 (DOP505XE1), FB4837F11 (FB4837F1), FB4837F12 (FB4837F1), FB4837F13 (FB4837F1), FB6747U32 (FB6747U3), FB6747U33 (FB6747U3), FB6747U34 (FB6747U3), FC541BF14 (FC541BF1), FG6747U32 (FG6747U3), FG6747U33 (FG6747U3), FG6747U34 (FG6747U3), REP-005194 (FG6747U3), 7DF0353 (FM1442D1), 7DF0419 (FM1442D1), 7DF0357 (FM1632D1), FM1632D21 (FM1632D2), 7DF0360 (FM4942D1), 7DF0372 (FM5642D1), 7DF0352 (FW1442D1), 7DF0418 (FW1442D1), 7DF0358 (FW1642D1), 7DF0420 (FW1642D1), 7DF0364 (FW2642D1), 7DF0400 (FW2642D1), 7DF0330 (FW5867U3), 7DF0398 (FW5867U3), 7DF0399 (FW5867U3), REP-005414 (FX1442D1), REP-005450 (FX1442D1), REP-005416 (FX1642D1), REP-005451 (FX1642D1), REP-005417 (FX2642D1), REP-005436 (FX2642D1), REP-005405 (FX5867U3), REP-005435 (FX5867U3)

DE DIETRICH Gas oven 7DF0318 (FX0441E2), 7DF0318 (FX0441E2B), 7DF0318 (FX0441E2N)

DE DIETRICH Kitchen 2934 (2934), 7DC0188 (CD7434F1), CD7434F11 (CD7434F1), 7DC0180 (CD8436F1), CD8436F11 (CD8436F1), CD8436F12 (CD8436F1), 7DC0178 (CD8437E1), 7DC0182 (CD8439E1), 7DC0181 (CD8457E1), CD8457E11 (CD8457E1), CD8457E12 (CD8457E1), CD8499F11 (CD8499F1), 7DC0173 (CD9830H1), 7DC0179 (CW8436F1), CW8436F11 (CW8436F1), 7DC0177 (CW8437F1), CW8437F11 (CW8437F1), CW8437F12 (CW8437F1), DCI1198W1 (DCI1198W), DCI1198W2 (DCI1198W), DCI1198W3 (DCI1198W), DCI295WE11 (DCI295WE1), DCM1050W1 (DCM1050W), DCM190AE11 (DCM190AE1), DCM350WE12 (DCM350WE1), 7DC0328 (DCM440WE1), 7DC0363 (DCM440WE1), 7DC0373 (DCM630W),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

DCM630W1 (DCM630W), DCM630W2 (DCM630W), DCM630W3 (DCM630W), 7DC0372 (DCM640A), 7DC0370 (DCM640W), 7DC0401 (DCM740W)

DE DIETRICH Kitchen gas 7DC0322 (DCG300WE1), 7DC0321 (DCG310WE1), 7DC0327 (DCG440WE1), 7DC0364 (DCG440WE1), 7DC0375 (DCG550W), 7DC0379 (DCG550X), 7DC0374 (DCG630W), 7DC0329 (DCM450WE1), 7DC0362 (DCM450WE1), DCM450WE11 (DCM450WE1), DCM450WE12 (DCM450WE1), 7DC0330 (DCM450XE1), 7DC0361 (DCM450XE1), DCM450XE11 (DCM450XE1), DCM450XE12 (DCM450XE1), 7DC0336 (DCM469WE1), 7DC0391 (DCM469WE1), 7DC0371 (DCM650W), 7DC0376 (DCM650X), 7DC0400 (DCM750W), DCM750W1 (DCM750W), DCM750W2 (DCM750W), DCM750W3 (DCM750W)

DE DIETRICH Kitchen glass-ceramics 7DC0183 (CB8479F1), 7DC0185 (CD7474F1), CD7474F11 (CD7474F1), 7DC0184 (CD8476F1), 7DC0186 (CD8479E1), 7DC0323 (DCI399AE1), DCI399AE13 (DCI399AE1), 7DC0324 (DCI399WE1), DCI399WE11 (DCI399WE1), DCI399WE12 (DCI399WE1), DCI399WE13 (DCI399WE1), 7DC0325 (DCI399XE1), DCI399XE12 (DCI399XE1), 7DC0332 (DCI499AE1), 7DC0368 (DCI499AE1), 7DC0331 (DCI499WE1), 7DC0369 (DCI499WE1), 7DC0333 (DCI499XE1), 7DC0367 (DCI499XE1), DCI499XE11 (DCI499XE1), 8X0011 (DCI499XU1), 7DC0396 (DCI798X), 7DC0399 (DCI799A), 7DC0398 (DCI799W), DCI799W1 (DCI799W), 7DC0397 (DCI799X), DCI799X1 (DCI799X), DCI799X2 (DCI799X), DCI900X1 (DCI900X), 7DC0334 (DCV469WE1), 7DC0366 (DCV469WE1), 7DC0389 (DCV469WE1), 7DC0335 (DCV469XE1), 7DC0378 (DCV469XE1), 7DC0390 (DCV469XE1), 7DC0392 (DCV768W), DCV768W1 (DCV768W), 7DC0393 (DCV768X), DCV768X1 (DCV768X), 7DC0394 (DCV769W), 7DC0395 (DCV769X)

DE DIETRICH Steam oven 7DF0388 (DM5161E1), 7DF0735 (DOV400XE1), 7DF0799 (DOV499XE1), DOV499XE11 (DOV499XE1), 7DF0390 (DW5161E1), REP-005427 (DX5161E1), REP-005434 (F5867U3)

DEXION Electric oven electric 48FEMD

ELECTROLUX Electric oven E57415-4-M R05 (94032015300), FOV10P 901 562 09 (94406500000), B4101-5-B IT R08 (94418119500), B4101-5-B IT R08 (94418119501), B4101-5-M IT R08 (94418119600), B4101-5-M IT R08 (94418119601), B4101-5-A IT R08 (94418119700), B4101-5-A IT R08 (94418119701), B5741-5-B IT R08 (94418121300), B5741-5-M IT R08 (94418121400), B8831-5-M IT R08 (94418122300), B8831-5-A (94418122400), B8871-5-M IT R08 (94418123000), B9831-5-M EU R08 (94418124500), B9831-5-M EU R08 (94418124501), B9831-5-M IT R08 (94418124700), CB4100-1-M EURO (94418164200), CB4140-1-M EURO (94418164600), CB6100-1-W EURO (94418169800), CB6100-1-B EURO (94418169900), CB6100-1-M EURO (94418170000), CB6100-1-A EURO (94418170100), CB8100-1-W EURO (94418170600), CB8100-1-B EURO (94418170700), CB8100-1-M EURO (94418170800), CB8100-1-A EURO (94418170900), CB8140-1-W EURO (94418171000), CB8140-1-B EURO (94418171100), CB8140-1-M EURO (94418171200), CB8140-1-A EURO (94418171300), CB1100-2-W EURO (94418176800), CB1100-2-B EURO (94418176900), CB1100-2-M EURO (94418177000), CB3100-1-M ITALY (94418181900), EOB68000X EU ENV (94418193500), EOB68000A EU ENV (94418193600), EOC69400X EU1 SMART (94418196700), EOB3660R ELUX ITALY (94418253200), EOB4630K ELUX ITALY (94418253300), EOB4630X ELUX ITALY (94418253400), EOC5630X ELUX ITALY (94418253500), EOB6680K ELUX ITALY (94418253600), EOB6680X ELUX ITALY (94418253700), EOB 6635K ELUX ITALY (94418257300), EOB 6635X ELUX ITALY (94418257400), EOB 5665R ELUX ITALY (94418257500), EOB 5632W ELUX ITALY (94418257600), EOB 5632K ELUX ITALY (94418257700), EOB 5632X ELUX ITALY (94418257800), EOB 4612P ELUX ITALY (94418257900), EOB 4612L ELUX ITALY (94418258000), EOB 4612S ELUX ITALY

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(94418258100), EOB 3612R ELUX ITALY (94418258200), EOB6696X EU R05 (94418274300), EOB68000X EU2 (94418285100), B1100-4-M EURO (94418506900), B1100-4-W EURO (94418507000), B3101-4-B EURO (94418507200), B3101-4-M EURO (94418507300), B3101-4-W EURO (94418507400), B4101-4-A EURO (94418508000), B4101-4-B EURO (94418508100), B4101-4-M EURO (94418508200), B4101-4-W EURO (94418508300), B8831-4-M EURO (94418508700), B8831-4-A EURO (94418508800), B8871-4-M EURO (94418509000), B9831-4-M EURO (94418509300), B6831-4-M (94418517400), B6831-4-A (94418517500), B5741-4-A EU R05 (94418532800), B5741-4-B EU R05 (94418532900), B5741-4-M EU R05 (94418533000), B8831-4-M EU NR05 (94418533100), B8831-4-A EU NR05 (94418533200), B8871-4-M EU NR05 (94418533300), B8871-4-A EU NR05 (94418533400), B4101-4-A EU R05 (94418534000), B4101-4-B EU R05 (94418534100), B4101-4-M EU R05 (94418534200), B9831-4-M EU NR05 (94418534600), B9871-4-M EU NR05 (94418534700), B9831-4-M EU R05 (94418543700), B8875-5-M IT (94418547200), FQP100XE (94971258900), FQP100XE (94971258901), FQP100XE (94971258902), FQP100XE (94971301600), FOV10P - 901 562 09 (94971305000), FYB455X (94971307900), FQP70XE (94971308000), FQP70XE (94971308001), 94971312800 (EOC68341X)

ELECTROLUX Kitchen 30006VE-W (94031310700), CE6100-1-W EURO (94031673300), CE6100-1-B EURO (94031673400), CE6100-1-M EURO (94031673500), CE6100-1-A EURO (94031673600), CE6140-1-M EURO (94031673900), CE8100-1-W EURO (94031674100), CE8100-1-B EURO (94031674200), CE8100-1-M EURO (94031674300), CE8100-1-A EURO (94031674400), CE8140-1-W EURO (94031674500), CE8140-1-B EURO (94031674600), CE8140-1-M EURO (94031674700), CE1100-2-W EURO (94031679400), CE1100-2-B EURO (94031679500), CE1100-2-M EURO (94031679600), E4101-4-M EU R05 (94032028700), E4101-5-M DE R08 (94032039801), E4101-5-M EU R08 (94032039901)

FAGOR BRANDT Chest freezer CM3728CO5000

FAGOR BRANDT Domestic refrigerator CO32AN (CO32AN), SC23BWJN (SC23BWJN), SC23CWJN1 (SC23CWJN), SC24AN (SC24AN), SC25AN (SC25AN), SC27CIJN (SC27CIJN)

FAGOR BRANDT Electric oven 921010069 (2HF-40B), 921010069/1 (2HF-40B), 921010050 (2HF-40I), 921010050/1 (2HF-40I), 921010078 (2HF-40N), 921010078/1 (2HF-40N), 921010096 (2HF-45B), 921010096/1 (2HF-45B), 921010087 (2HF-45I), 921010087/1 (2HF-45I), 921010103 (2HF-45N), 921010103/1 (2HF-45N), 5H-720B2 (5H-720B), 5H-720N1 (5H-720N), 5H-720N2 (5H-720N), 5H-720X1 (5H-720X), 5H-720X2 (5H-720X), 5H-721B1 (5H-721B), 5H-721N1 (5H-721N), 5H-721X1 (5H-721X), 5H-730B1 (5H-730B), 5H-730B2 (5H-730B), 5H-730N1 (5H-730N), 5H-730N2 (5H-730N), 5H-730X1 (5H-730X), 5H-730X2 (5H-730X), 5H-740B1 (5H-740B), 5H-740B2 (5H-740B), 5H-740N1 (5H-740N), 5H-740N2 (5H-740N), 5H-740X1 (5H-740X), 5H-740X2 (5H-740X), 5H-741B1 (5H-741B), 5H-741N1 (5H-741N), 5H-741N4 (5H-741N), 5H-741X1 (5H-741X), 5H-741X2 (5H-741X), 5H-745B1 (5H-745B), 5H-745N1 (5H-745N), 5H-745X1 (5H-745X), 5H-750B1 (5H-750B), 921110344 (5H-750BEPOCA), 5H-750N1 (5H-750N), 5H-750N2 (5H-750N), 921110353 (5H-750NEPOCA), 5H-760B1 (5H-760B), 5H-760B2 (5H-760B), 5H-760B3 (5H-760B), 5H-760B4 (5H-760B), 5H-760B5 (5H-760B), 5H-760B6 (5H-760B), 5H-760N1 (5H-760N), 5H-760N2 (5H-760N), 5H-760N3 (5H-760N), 5H-760N4 (5H-760N), 5H-760N5 (5H-760N), 5H-760N6 (5H-760N), 5H-760X1 (5H-760X), 5H-760X2 (5H-760X), 5H-760X3 (5H-760X), 5H-760X4 (5H-760X), 5H-760X5 (5H-760X), 5H-760X6 (5H-760X), 5H-770X1 (5H-770X), 5H-770X2 (5H-770X), 5H-770X3 (5H-770X), 5H-775X1 (5H-775X), 5H-775X2 (5H-775X), 5H-780X1 (5H-780X), 5H-780X2 (5H-780X), 5H-790X1

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(5H-790X), 5H-860X1 (5H-860X), 5HV-440X1 (5HV-440X), BCE120B1 (BCE120B), BCE120W1 (BCE120W), BCE120W-3 (BCE120W), BCE120WCH1 (BCE120WCH), BCE220B1 (BCE220B), BCE220W-1 (BCE220W), BCP150B-1 (BCP150B), BCP150W-1 (BCP150W), BMC130B1 (BMC130B), BMC130B-1 (BMC130B), BMC130B2 (BMC130B), BMC130W1 (BMC130W), BMC130W2 (BMC130W), BMC130X1 (BMC130X), BMC131X1 (BMC131X), BMC131X2 (BMC131X), BMC140X1 (BMC140X), BMC140X-2 (BMC140X), BMC140X3 (BMC140X), BMC141X1 (BMC141X), BMC141X2 (BMC141X), BMC141XCH (BMC141XCH), BMC230B-1 (BMC230B), BMC230X-1 (BMC230X), BMC231X11 (BMC231X), BMC240B1 (BMC240B), BMC240X1 (BMC240X), BMC241X1 (BMC241X), BMCR175B-1 (BMCR175B), BMP160B-1 (BMP160B), BMP160B-2 (BMP160B), BMP160BCH1 (BMP160BCH), BMP160W-1 (BMP160W), BMP160W-2 (BMP160W), BMP160WCH1 (BMP160WCH), BMP160XCH1 (BMP160XCH), BMP161X1 (BMP161X), BMP161X2 (BMP161X), BMP260B1 (BMP260B), BMP260X-2 (BMP260X), BMP261X1 (BMP261X), BMPR180B1 (BMPR180B), BP411WU11 (BP411WU1), BP411XU11 (BP411XU1), C2240B2 (C2240B), C2240B3 (C2240B), FAC74J1N2 (FAC74J1N), FAC74J1N3 (FAC74J1N), FAP24B1U1 (FAP24B1U), FAP24C1U1 (FAP24C1U), FAP24W1U1 (FAP24W1U), FAP24X1U1 (FAP24X1U), FAP31W1N1 (FAP31W1N), FAQ25B1U1 (FAQ25B1U), FAQ25W1U1 (FAQ25W1U), FAQ75J1N1 (FAQ75J1N), FAQ75J1N2 (FAQ75J1N), FAQ75W1N1 (FAQ75W1N), FAQ75X1N1 (FAQ75X1N), FBI961X1 (FBI961X), FBI981X1 (FBI981X), FBP25B1G1 (FBP25B1G), FBP25W1G1 (FBP25W1G), FBP25X1G1 (FBP25X1G), FBP75J1N1 (FBP75J1N), FC1032X1 (FC1032X), FC1041X1 (FC1041X), FC212XN11 (FC212XN1), FC212XN12 (FC212XN1), FC222MN11 (FC222MN1), FC222WN11 (FC222WN1), FC222XN11 (FC222XN1), FC222ZN11 (FC222ZN1), FC223XN11 (FC223XN1), FC232BF11 (FC232BF1), FC232WF11 (FC232WF1), FC241BF11 (FC241BF1), FC241WF11 (FC241WF1), FC242BF11 (FC242BF1), FC242WF11 (FC242WF1), FC242XF11 (FC242XF1), FC242ZF11 (FC242ZF1), FC243DF11 (FC243DF1), FC243EF11 (FC243EF1), FC272WN11 (FC272WN1), FC272XN11 (FC272XN1), FC289B1 (FC289B), FC289C1 (FC289C), FC300BS11 (FC300BS1), FC300WS11 (FC300WS1), FC342XF11 (FC342XF1), FC342XF12 (FC342XF1), FC342XF13 (FC342XF1), FC422MN11 (FC422MN1), FC422MN12 (FC422MN1), FC422WN11 (FC422WN1), FC422WN12 (FC422WN1), FC422XN11 (FC422XN1), FC422XN12 (FC422XN1), FC422ZN11 (FC422ZN1), FC422ZN12 (FC422ZN1), FC432BF11 (FC432BF1), FC432WF11 (FC432WF1), FC432XF11 (FC432XF1), FC442BF11 (FC442BF1), FC442WF11 (FC442WF1), FC442XF11 (FC442XF1), FC472XN11 (FC472XN1), FC472XN12 (FC472XN1), FC520BS11 (FC520BS1), FC520WS11 (FC520WS1), FC520XS11 (FC520XS1), FC541BF11 (FC541BF1), FC541BF12 (FC541BF1), FC541BF13 (FC541BF1), FC541BF14 (FC541BF1), FC541WF11 (FC541WF1), FC541WF12 (FC541WF1), FC541WF13 (FC541WF1), FC541WF14 (FC541WF1), FC541XF11 (FC541XF1), FC541XF12 (FC541XF1), FC541XF13 (FC541XF1), FC541XF14 (FC541XF1), FC622WN11 (FC622WN1), FC622XGN11 (FC622XGN1), FC622XN11 (FC622XN1), FC632BF11 (FC632BF1), FC632FB11 (FC632BF1), FC632WF11 (FC632WF1), FC632XF11 (FC632XF1), FC632XF12 (FC632XF1), FC632XF13 (FC632XF1), FC641BF11 (FC641BF1), FC641BF12 (FC641BF1), FC641BF13 (FC641BF1), FC641WF11 (FC641WF1), FC641WF12 (FC641WF1), FC641XF11 (FC641XF1), FC641XF12 (FC641XF1), FC642BF11 (FC642BF1), FC642BF12 (FC642BF1), FC642WF11 (FC642WF1), FC642WF12 (FC642WF1), FC642XF11 (FC642XF1), FC642XF12 (FC642XF1), FC672XN11 (FC672XN1), FC935X1 (FC935X), FE200BS11 (FE200BS1), FE200BS12 (FE200BS1), FE200WCKD1 (FE200WCKD), FE200WCKD2 (FE200WCKD), FE200WS11 (FE200WS1), FE200WS12 (FE200WS1), FE200XN11 (FE200XN1), FE200XN12 (FE200XN1), FE201XU12 (FE201XU1), FE210WN11 (FE210WN1), FE210XN11 (FE210XN1), FE210XN12 (FE210XN1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FE211BS11 (FE211BS1), FE211BS12 (FE211BS1), FE211WS11 (FE211WS1), FE211WS12 (FE211WS1),
FE211XS12 (FE211XS1), FE211XS13 (FE211XS1), FE212BF11 (FE212BF1), FE212BF12 (FE212BF1),
FE212WCKD1 (FE212WCKD), FE212WF11 (FE212WF1), FE212WF12 (FE212WF1), FE212XCKD1 (FE212XCKD),
FE212XF11 (FE212XF1), FE212XF12 (FE212XF1), FE213XN11 (FE213XN1), FE213XN12 (FE213XN1), FE222BS11
(FE222BS1), FE222BS12 (FE222BS1), FE222WS11 (FE222WS1), FE222WS12 (FE222WS1), FE222XS11
(FE222XS1), FE222XS12 (FE222XS1), FE222ZS11 (FE222ZS1), FE222ZS12 (FE222ZS1), FE300BF11 (FE300BF1),
FE300WF11 (FE300WF1), FE310XU11 (FE310XU1), FE410WN11 (FE410WN1), FE410WN12 (FE410WN1),
FE410XN11 (FE410XN1), FE410XN12 (FE410XN1), FE411WU11 (FE411WU1), FE411XU11 (FE411XU1),
FE412XN11 (FE412XN1), FE412XN12 (FE412XN1), FE422BF11 (FE422BF1), FE422BF12 (FE422BF1), FE422BF13
(FE422BF1), FE422BS11 (FE422BS1), FE422WF11 (FE422WF1), FE422WF12 (FE422WF1), FE422WF13
(FE422WF1), FE422WS11 (FE422WS1), FE422XF11 (FE422XF1), FE422XS11 (FE422XS1), FE422ZS11
(FE422ZS1), FE600XS11 (FE600XS1), FE601WS11 (FE601WS1), FE601XS11 (FE601XS1), FE610WN11
(FE610WN1), FE610XN11 (FE610XN1), FE611BS11 (FE611BS1), FE611WS11 (FE611WS1), FE611XS11
(FE611XS1), FE612XN11 (FE612XN1), FE622BS11 (FE622BS1), FE622WS11 (FE622WS1), FE622XS11
(FE622XS1), FMCR395-1 (FMCR395), FMCR395-2 (FMCR395), FMCV290B1 (FMCV290B), FMP293B1 (FMP293B),
FMP293C1 (FMP293C), FMPV294B1 (FMPV294B), FMPV294B2 (FMPV294B), FMPV294C1 (FMPV294C),
FMPV294C2 (FMPV294C), FMPV294C2 (FMPV294CL), FMPV394B1 (FMPV394B), FMPV394B2 (FMPV394B),
FMPV394C1 (FMPV394C), FMPV394C2 (FMPV394C), FP1052X1 (FP1052X), FP1061B1 (FP1061B), FP1061W1
(FP1061W), FP1371X1 (FP1371X), FP211XN11 (FP211XN1), FP212XN11 (FP212XN1), FP212XN12 (FP212XN1),
FP224MN11 (FP224MN1), FP224MN12 (FP224MN1), FP224WN11 (FP224WN1), FP224WN12 (FP224WN1),
FP224XN11 (FP224XN1), FP224XN12 (FP224XN1), FP225BS11 (FP225BS1), FP225BS12 (FP225BS1), FP225BS13
(FP225BS1), FP225WS11 (FP225WS1), FP225WS12 (FP225WS1), FP225WS13 (FP225WS1), FP225XS11
(FP225XS1), FP225XS12 (FP225XS1), FP225XS13 (FP225XS1), FP228MN11 (FP228MN1), FP228MN12
(FP228MN1), FP228XN11 (FP228XN1), FP228XN12 (FP228XN1), FP228ZN11 (FP228ZN1), FP228ZN12
(FP228ZN1), FP229BS11 (FP229BS1), FP229BS12 (FP229BS1), FP229BS13 (FP229BS1), FP229WS11
(FP229WS1), FP229WS12 (FP229WS1), FP229WS13 (FP229WS1), FP229XS11 (FP229XS1), FP229XS12
(FP229XS1), FP229XS13 (FP229XS1), FP230XN11 (FP230XN1), FP252BF11 (FP252BF1), FP252BF12 (FP252BF1),
FP252WF11 (FP252WF1), FP252WF12 (FP252WF1), FP252XF11 (FP252XF1), FP252XF12 (FP252XF1),
FP252XF13 (FP252XF1), FP254BF11 (FP254BF1), FP254BF12 (FP254BF1), FP254WF11 (FP254WF1), FP254WF12
(FP254WF1), FP261BF11 (FP261BF1), FP261BF12 (FP261BF1), FP261BF13 (FP261BF1), FP261WF11
(FP261WF1), FP261WF12 (FP261WF1), FP261WF13 (FP261WF1), FP262BF11 (FP262BF1), FP262BF12
(FP262BF1), FP262WF11 (FP262WF1), FP262WF12 (FP262WF1), FP262XF11 (FP262XF1), FP262XF12
(FP262XF1), FP262XF13 (FP262XF1), FP262ZF11 (FP262ZF1), FP262ZF12 (FP262ZF1), FP263DF11 (FP263DF1),
FP263DF12 (FP263DF1), FP263DF13 (FP263DF1), FP263EF11 (FP263EF1), FP263EF12 (FP263EF1), FP263EF13
(FP263EF1), FP265BF11 (FP265BF1), FP265BF12 (FP265BF1), FP265WF11 (FP265WF1), FP265WF12
(FP265WF1), FP271BF11 (FP271BF1), FP271WF11 (FP271WF1), FP291B1 (FP291B), FP291B2 (FP291B),
FP291C2 (FP291C), FP362BF11 (FP362BF1), FP362BF12 (FP362BF1), FP362BF13 (FP362BF1), FP362WF11
(FP362WF1), FP362WF12 (FP362WF1), FP362WF13 (FP362WF1), FP362XF11 (FP362XF1), FP362XF12
(FP362XF1), FP362XF13 (FP362XF1), FP365BF11 (FP365BF1), FP365BF12 (FP365BF1), FP365BF13 (FP365BF1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FP365WF11 (FP365WF1), FP365WF12 (FP365WF1), FP365WF13 (FP365WF1), FP391C1 (FP391C), FP391C2 (FP391C), FP411XN11 (FP411XN1), FP411XN12 (FP411XN1), FP424MN11 (FP424MN1), FP424MN12 (FP424MN1), FP424WN11 (FP424WN1), FP424WN12 (FP424WN1), FP424XN11 (FP424XN1), FP424XN12 (FP424XN1), FP424ZN11 (FP424ZN1), FP424ZN12 (FP424ZN1), FP428MN11 (FP428MN1), FP428MN12 (FP428MN1), FP428XN11 (FP428XN1), FP428XN12 (FP428XN1), FP452BF11 (FP452BF1), FP452BF12 (FP452BF1), FP452WF11 (FP452WF1), FP452WF12 (FP452WF1), FP452WF13 (FP452WF1), FP452WF14 (FP452WF1), FP452XF11 (FP452XF1), FP452XF12 (FP452XF1), FP462BF11 (FP462BF1), FP462BF12 (FP462BF1), FP462WF11 (FP462WF1), FP462WF12 (FP462WF1), FP462WF13 (FP462WF1), FP462WF14 (FP462WF1), FP462XF11 (FP462XF1), FP462XF12 (FP462XF1), FP462ZF11 (FP462ZF1), FP462ZF12 (FP462ZF1), FP464BF11 (FP464BF1), FP464BF12 (FP464BF1), FP464WF11 (FP464WF1), FP464WF12 (FP464WF1), FP464XF11 (FP464XF1), FP465BF11 (FP465BF1), FP465BF12 (FP465BF1), FP465WF11 (FP465WF1), FP465WF12 (FP465WF1), FP465WF13 (FP465WF1), FP465WF14 (FP465WF1), FP551BF11 (FP551BF1), FP551WF11 (FP551WF1), FP551XF11 (FP551XF1), FP561BF11 (FP561BF1), FP561WF11 (FP561WF1), FP561XF11 (FP561XF1), FP562X1 (FP562X), FP562X2 (FP562X), FP611XN11 (FP611XN1), FP624WN11 (FP624WN1), FP624XGN11 (FP624XGN1), FP624XN11 (FP624XN1), FP624ZN11 (FP624ZN1), FP628XGN11 (FP628XGN1), FP628XN11 (FP628XN1), FP652BF11 (FP652BF1), FP652WF11 (FP652WF1), FP652XF11 (FP652XF1), FP662BF11 (FP662BF1), FP662BF12 (FP662BF1), FP662WF11 (FP662WF1), FP662XF11 (FP662XF1), FP662XF12 (FP662XF1), FP662ZF11 (FP662ZF1), FP663DF11 (FP663DF1), FP663EF11 (FP663EF1), FP664BF11 (FP664BF1), FP664BF12 (FP664BF1), FP664WF11 (FP664WF1), FP664WF12 (FP664WF1), FP664XF11 (FP664XF1), FP664XF12 (FP664XF1), FP665BF11 (FP665BF1), FP665WF11 (FP665WF1), FP665XF11 (FP665XF1), FP666BF11 (FP666BF1), FP666WF11 (FP666WF1), FP666XF11 (FP666XF1), FP667XS11 (FP667XS1), FP852BF11 (FP852BF1), FP852BF12 (FP852BF1), FP871B2 (FP871B), FP980X1 (FP980X), FPR396-1 (FPR396), FPR396-2 (FPR396), FPR396-3 (FPR396), FPV292B1 (FPV292B), FPV292C1 (FPV292C), HH-229PX1 (HH-229PX), HM480X1 (HM480X), HM480X2 (HM480X), 921010149 (HM-480X), HP197B1 (HP197B), 921110148 (HP-197B), HP197N1 (HP197N), 921110157 (HP-197N), HP197X1 (HP197X), 921110139 (HP-197X), HPM198B1 (HPM198B), HPM198B2 (HPM198B), 921110175 (HPM-198B), HPM198N1 (HPM198N), HPM198N2 (HPM198N), 921110184 (HPM-198N), HPM198X1 (HPM198X), HPM198X2 (HPM198X), 921110166 (HPM-198X), HPM-199CX1 (HPM-199CX), MC4210RB1 (MC4210RB), MP4122VB1 (MP4122VB), MP4122VB2 (MP4122VB), MP4122VN1 (MP4122VN), MP4122VN2 (MP4122VN), MP4320VB1 (MP4320VB), MP4320VB2 (MP4320VB), MP4320VN1 (MP4320VN), MP4320VN2 (MP4320VN), MP4320VV1 (MP4320VV), MP4320VV2 (MP4320VV), MP4327VB1 (MP4327VB), MP4327VB2 (MP4327VB), MP4327VN1 (MP4327VN), MP4327VN2 (MP4327VN), MP4330EX1 (MP4330EX), MP4330EX2 (MP4330EX), MP4330EX3 (MP4330EX), MP4330RB1 (MP4330RB), MP4330RB2 (MP4330RB), MP4330RN1 (MP4330RN), MP4330RN2 (MP4330RN), OH311XU11 (OH311XU1), P4120EX-1 (P4120EX), P4120EX-2 (P4120EX), P4120VB1 (P4120VB), P4120VB2 (P4120VB), P4120VN1 (P4120VN), P4120VN2 (P4120VN), P4127VB1 (P4127VB), P4127VB2 (P4127VB), P4127VB3 (P4127VB), P4127VB2 (P4127VB2), P4127VN1 (P4127VN), P4127VN2 (P4127VN), P4127VN3 (P4127VN2), P4222VB1 (P4222VB), P4222VB2 (P4222VB), P4222VN1 (P4222VN), P4222VN2 (P4222VN), SFP665K1 (SFP665K)

FAGOR BRANDT Kitchen BCM6653W1 (BCM6653), GPE60W-1 (GPE60W), KG360WE11 (KG360WE1), KG360WE12 (KG360WE1), KG360WE13 (KG360WE1), KG360WE14 (KG360WE1), KG361TE11 (KG361TE1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KG361TE12 (KG361TE1), KG361TE13 (KG361TE1), KG361TE14 (KG361TE1), KG361WE11 (KG361WE1),
KG361WE12 (KG361WE1), KG361WE13 (KG361WE1), KG361WE14 (KG361WE1), KG361XE11 (KG361XE1),
KG361XE12 (KG361XE1), KG361XE13 (KG361XE1), KG361XE14 (KG361XE1), KG362WE11 (KG362WE1),
KG362WE12 (KG362WE1), KG362WE13 (KG362WE1), KG362WE14 (KG362WE1), KG362WE15 (KG362WE1),
KG363WE11 (KG363WE1), KG363WE12 (KG363WE1), KG363WE13 (KG363WE1), KG363WE14 (KG363WE1),
KG363WE15 (KG363WE1), KG559WE11 (KG559WE1), KG560WE11 (KG560WE1), KG561TE11 (KG561TE1),
KG561WE11 (KG561WE1), KG561XE11 (KG561XE1), KG561XE12 (KG561XE1), KG566WE11 (KG566WE1),
KGC1013W1 (KGC1013W), KGC605T1 (KGC605T), KGC605W1 (KGC605W), KGC605W2 (KGC605W), KGC605X1
(KGC605X), KGE600W1 (KGE600W), KGE600W2 (KGE600W), KGE602W1 (KGE602W), KGP610W1 (KGP610W),
KI360WE11 (KI360WE1), KI360WE12 (KI360WE1), KI360WE13 (KI360WE1), KI365WE11 (KI365WE1),
KI365WE13 (KI365WE1), KI365WE14 (KI365WE1), KIP712W1 (KIP712W), KITB6349/2 (KITB6349), KITB6349-1
(KITB6349), KITB6349-2 (KITB6349), KITB6349-3 (KITB6349), KM263WE11 (KM263WE1), KM264WE11
(KM264WE1), KM265TE11 (KM265TE1), KM265TE12 (KM265TE1), KM265TE13 (KM265TE1), KM265WE11
(KM265WE1), KM265WE12 (KM265WE1), KM265WE13 (KM265WE1), KM266WE11 (KM266WE1), KM267WE11
(KM267WE1), KM360WE11 (KM360WE1), KM360WE12 (KM360WE1), KM361TE11 (KM361TE1), KM361WE11
(KM361WE1), KM361WE12 (KM361WE1), KM362WE11 (KM362WE1), KM362WE12 (KM362WE1), KM363WE11
(KM363WE1), KM363WE12 (KM363WE1), KM363WE13 (KM363WE1), KM364WE11 (KM364WE1), KM364WE12
(KM364WE1), KM365TE11 (KM365TE1), KM365TE12 (KM365TE1), KM365TE13 (KM365TE1), KM365TE14
(KM365TE1), KM365TE15 (KM365TE1), KM365WE11 (KM365WE1), KM365WE12 (KM365WE1), KM365WE13
(KM365WE1), KM365WE14 (KM365WE1), KM365XE11 (KM365XE1), KM365XE13 (KM365XE1), KM365XE14
(KM365XE1), KM365XE15 (KM365XE1), KM365XE16 (KM365XE1), KM366WE11 (KM366WE1), KM366WE12
(KM366WE1), KM366WE13 (KM366WE1), KM366WE14 (KM366WE1), KM367WE11 (KM367WE1), KM367WE12
(KM367WE1), KM367WE13 (KM367WE1), KM367WE14 (KM367WE1), KM460WE11 (KM460WE1), KM465WE11
(KM465WE1), KM465WE12 (KM465WE1), KM466WE11 (KM466WE1), KM468WA12 (KM468WA1), KM468WA13
(KM468WA1), KM559WE11 (KM559WE1), KM561WE11 (KM561WE1), KM565TE11 (KM565TE1), KM565WE11
(KM565WE1), KM565XE11 (KM565XE1), KM566WE11 (KM566WE1), KMB6242-1 (KMB6242), KMB6242-5
(KMB6242), KMB6242-6 (KMB6242), KMB6343-1 (KMB6343), KMB6343-2 (KMB6343), KMB6343-5 (KMB6343),
KMB6346/2 (KMB6346), KMB6346-1 (KMB6346), KMB6346-2 (KMB6346), KMB6346-3 (KMB6346), KMB6346-4
(KMB6346), KMC1103W1 (KMC1103W), KMC601W1 (KMC601W), KMC606W1 (KMC606W), KMC606W2
(KMC606W), KMC909W1 (KMC909W), KMC909W2 (KMC909W), KME1002W1 (KME1002W), KMG265XE11
(KMG265XE1), KMP1010W1 (KMP1010W), KMP1015W1 (KMP1015W), KMP1015W2 (KMP1015W), KMP1115W1
(KMP1115W), KMP612W1 (KMP612W), KMP615T1 (KMP615T), KMP615W1 (KMP615W), KMP617W1 (KMP617W),
KMP715T1 (KMP715T), KMP715T2 (KMP715T), KMP715T3 (KMP715T), KMP715W1 (KMP715W), KMP715W2
(KMP715W), KMP715W3 (KMP715W), KMPC1000W1 (KMPC1000W), KMPM1001W1 (KMPM1001W), KR360WE11
(KR360WE1), KR360WE12 (KR360WE1), KR360WE13 (KR360WE1), KR360WE14 (KR360WE1), KR361WE11
(KR361WE1), KR361WE12 (KR361WE1), KR365WE11 (KR365WE1), KR365WE13 (KR365WE1), KR365WE14
(KR365WE1), KR365WE15 (KR365WE1), KTB6342/1 (KTB6342), KTB6342/2 (KTB6342), KTB6342/5 (KTB6342),
KTB6342-1 (KTB6342), KTB6342-2 (KTB6342), KTB6342-5 (KTB6342), KTB6345/6 (KTB6345), KTB6345/8
(KTB6345), KTB6345-1 (KTB6345), KTB6345-2 (KTB6345), KTB6345-5 (KTB6345), KTB6345-6 (KTB6345),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KTB6345-7 (KTB6345), KTB6345-8 (KTB6345), KTC6342-1 (KTC6342), KTC6342-2 (KTC6342), KTC6342-5 (KTC6342), KTB6345/8 (KTC6345), KTC6345-1 (KTC6345), KTC6345-2 (KTC6345), KTC6345-4 (KTC6345), KTC6345-5 (KTC6345), KVTB6348/1 (KVTB6348), KVTB6348/2 (KVTB6348), KVTB6348-1 (KVTB6348), KVTB6348-2 (KVTB6348), MB64SBW-2 (MB64SBW), MB64SBW3 (MB64SBW), MBM61BW-5 (MBM61BW), KMB6346-1 (VER280HYB)

FAGOR BRANDT Kitchen electric ETB632-1 (ETB632), ETB632-2 (ETB632), ETB632-3 (ETB632), KE261WE11 (KE261WE1), KE269WE11 (KE269WE1), KE270WE11 (KE270WE1), KE360TE11 (KE360TE1), KE360TE12 (KE360TE1), KE360WE11 (KE360WE1), KE360WE12 (KE360WE1), KE361WE11 (KE361WE1), KE361WE12 (KE361WE1), KE361WE13 (KE361WE1), KE361WE14 (KE361WE1), KE361WE15 (KE361WE1), KE369WE11 (KE369WE1), KE369WE12 (KE369WE1), KE375WE11 (KE375WE1), KE560WE11 (KE560WE1), KE569WE11 (KE569WE1), KE569WE12 (KE569WE1), KE60B1 (KE60B), KEC660W1 (KEC660W), KEL66W1 (KEL66W), KEL77-1 (KEL77-1W), KIP710X2 (KIP710X), KMA13W1N1 (KMA13W1N), KMP1015T1 (KMP1015T), KMP1018W1 (KMP1018W)

FAGOR BRANDT Kitchen gas KG362WB11 (KG362WB1), KG362WB12 (KG362WB1), KG362WB13 (KG362WB1), KG362WB14 (KG362WB1), KG362WB15 (KG362WB1), KG365TE11 (KG365TE1), KG365TE12 (KG365TE1), KG365TE13 (KG365TE1), KG365WE11 (KG365WE1), KG365WE12 (KG365WE1), KG365WE13 (KG365WE1), KG366TE11 (KG366TE1), KG366TE12 (KG366TE1), KG366TE13 (KG366TE1), KG366WE11 (KG366WE1), KG366WE12 (KG366WE1), KG366WE13 (KG366WE1), KG369XE11 (KG369XE1), KG369XE12 (KG369XE1), KG369XE13 (KG369XE1), KG36TA11 (KG36TA1), KG36WA11 (KG36WA1), KG466WE11 (KG466WE1), KG468WA12 (KG468WA1), KG468WA13 (KG468WA1), KG468WA14 (KG468WA1), KG46TA11 (KG46TA1), KG564WE11 (KG564WE1), KG564WE12 (KG564WE1), KG564WE13 (KG564WE1), KG56TA11 (KG56TA1), KG56TA12 (KG56TA1), KG56WA11 (KG56WA1), KG56WA12 (KG56WA1), KG66TA11 (KG66TA1), KG66TA12 (KG66TA1), KG66WA11 (KG66WA1), KG66WA12 (KG66WA1), KGC1005W1 (KGC1005W), KM268WB11 (KM268WB1), KMC1001W1 (KMC1001W), KMC1001W2 (KMC1001W), MB66SBW-2 (MB66SBW)

FAGOR BRANDT Kitchen glass-ceramics KI469WE11 (KI469WE1), KI569WE11 (KI569WE1), KI569WE12 (KI569WE1), KIP615W1 (KIP615W), KIP710W1 (KIP710W), KIP710W2 (KIP710W), KIP710W3 (KIP710W), KIP711W1 (KIP711W), KIP711W2 (KIP711W), KIP711W3 (KIP711W), KN173W1G1 (KN173W1G), KN173W1G2 (KN173W1G), KNA13W1N1 (KNA13W1N), KNA43W1N1 (KNA43W1N), KNA84W1N1 (KNA84W1N), KNA85W1N1 (KNA85W1N), KNW95W1N1 (KNW95W1N), QQS83W1N1 (QQS83W1N), KQW93W1N1 (KQW93W1N), KV261WE11 (KV261WE1), KV261WE12 (KV261WE1), KV267WE11 (KV267WE1), KV268WE11 (KV268WE1), KV269WE11 (KV269WE1), KV360WE11 (KV360WE1), KV361WE11 (KV361WE1), KV361WE12 (KV361WE1), KV361WE13 (KV361WE1), KV361WE14 (KV361WE1), KV367WE11 (KV367WE1), KV367WE12 (KV367WE1), KV368WE11 (KV368WE1), KV369WE11 (KV369WE1), KV369WE12 (KV369WE1), KV371WE11 (KV371WE1), KV372WE11 (KV372WE1), KV373WE11 (KV373WE1), KV373XE11 (KV373XE1), KV374WE11 (KV374WE1), KV374WE12 (KV374WE1), KV374XE11 (KV374XE1), KV374XE12 (KV374XE1), KV462WE11 (KV462WE1), KV462WE12 (KV462WE1), KV560WE11 (KV560WE1), KV561WE11 (KV561WE1), KV567WE11 (KV567WE1), KV567WE13 (KV567WE1), KV568WE11 (KV568WE1), KV568WE13 (KV568WE1), KV571WN11 (KV571WN1), KV571WN12 (KV571WN1), KV571XN11 (KV571XN1), KV571XN12 (KV571XN1), KV600WN11 (KV600WN1), KVC660W1 (KVC660W), KVC660W2 (KVC660W), KVE255-1 (KVE255), KVE255-2 (KVE255), KVP3000-1 (KVP3000),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KVP3000-2 (KVP3000), KVP3000B-1 (KVP3000B), KVP661W1 (KVP661W), KVP661W2 (KVP661W), VTB632-1 (VTB632), VTB632-2 (VTB632), VTB6325-1 (VTB6325)

FAGOR BRANDT Microwave oven FV400XS11 (FV400XS1), FV600XS11 (FV600XS1)

FAGOR BRANDT Pot stove CFF-631MP1 (CFF-631MP), CFF-631P1 (CFF-631P), CFF-631P2 (CFF-631P), CFF-631P3 (CFF-631P)

FAGOR BRANDT Pot stove gas BIP63WEU1-1 (BIP63WEU1), BIP63WEU1-2 (BIP63WEU1), CFF-64GA11 (CFF-64GA1), CFF-64GA12 (CFF-64GA1)

FAGOR BRANDT Pot stove glass-ceramics BIC63WEU1-1 (BIC63WEU1), KV250-1 (KV250), KV250-2 (KV250)

FOINOX Blast chiller BC50 2AM

FOINOX Convection oven Blu Pastry 3D, Blu Pastry M, Blu Pastry Vip, FC 12G, FC05 G GU, FC05E, FC05EU, FC05EU BRANDT, FC05G, FC05GU, FC06 GA GDG, FC06E, FC06EA, FC06EDG, FC06EEA, FC06G, FC-06G, FC06GA, FC06GDG, FC06SE, FC06SEA, FC06SEDG, FC12E, FC-12E, FC12EA, FC-12EA EDG, FC12EDG, FC12G, FC12GA, FC-12GA GDG, FC12GDG, FC12SE, FC-12SE, FC12SEA, FC-12SEA SEDG, FC12SEDG, FC20E, FC20EA, FC20EDG, FC20G, FC20GA, FC20GDG, FC50EM, FE 1-2, FE 2-3, MIDI005 ED, MIDI005 EEP ED, MIDI005 EM, MIDI005 GEP, MIDI005 GM, MM06EBM, MM100 EEPA, MM100 EEPE, MM23 EM, MM60 GEPA, MM60 GEPE, W41E, WGN4ME

FOINOX Gas oven LCM06EEP1, LCM06GEP1, LCM10EM1, LCM10GEP1

FOINOX Pastry oven electric FP 05E, FP 05EA EDG, FP 10E, FP10EA, FP10EDG

FOINOX Pastry oven gas FP 10G, FP05G, FP05GA GDG, FP10GA GDG

FOINOX Steam oven electric BASIC VAP, BASIC VAP2

FRIULINOX Blast chiller ABM1, ABM2, ARP121, ARP122, ARP141, ARP211, ARP212

FRIULINOX Display cabinet refrigerated AE14, AE21, AE7, AF750, AFP121, AFP122, AFP141, AFP142, AFR7, ALM1, ALM2, APM1, APM2, AR6-2, AR750, ARCI1, ARCI2, ARCT1, ARCT2, ARF121, ARF122, ARF141, ARF211, ARF212, ARF7, ARFP21

FRIULINOX Refrigerated cupboard AF12 -20, AF12 -20 VTR, AF12 PA, AF12-14, AF12-14 VTR, AF12-14 VTRP, AF14, AF14 -20 VTR, AF14 -25, AF14 ICE, AF14 PA, AF21 -20, AF6 -20, AF6 -20 VTR, AF6 PA, AF6-1, AF6-7, AF6-7 VTR, AF7, AF7 -20 VTR, AF7 -25, AF7 ICE, AF7 PA, AF7 VTR, AF7-14, AFT -25, AP12-14, AP14, AP14 -4, AP21 4, AP21 -4, AP6, AP6 -4, AP6-12, AP6-7, AP7, AP7 -4, AP7 -4 CAS, AP7-14, AR 14 +2 VTR, AR PIZ, AR12 +12, AR12 +12 VTR, AR12 +2, AR12 +2 VTR, AR12 -2, AR12 -2 VTR, AR12 PA, AR12-14, AR12-14 VTR, AR14, AR14 +2, AR14 +2 VTR, AR14 -2, AR14 -2 VTR, AR14 PA, AR14 PIZ, AR14 S-V, AR21 +2, AR21 +2 VTR, AR21 -2, AR21 -2 VTR, AR21 S-V, AR6 +2, AR6 +2 VTR, AR6 -2, AR6 -2 VTR, AR6 PA, AR6-12, AR6-12 VTR, AR6-7, AR6-7 VTR, AR7, AR7 + CAS, AR7 +2, AR7 +2 CAS, AR7 +2 VTR, AR7 -2, AR7 -2 CAS, AR7 -2 VTR, AR7 PA, AR7 S-V, AR7-14, AR7-14 VTR, ARCI1 VTR, ARCI2 VTR, ARCT1 VTR, ARCT2 VTR, ARF142, ARF142 +2, ARF142 -2, ARF142 -2+2, ARF142 VTR, ARF212 VTR, ARP142, ARP142 +2, ARP142 -2, ARP142 -2+2, ARP7, ARR12 VTR, ARR122, ARR141, ARR142 +2, ARR142 -2, ARR142 -2+2, ARR142 VTR, ARR212, ARR212 VTR, ARR7, ARRF14, ARRF21, ARRF21 VTR, ARRP14, ARRP21, ARRR21

GARBIN Convection oven 43 P UMI, 43 PE

GIORIK Convection oven EF10GM, EF4, EF4PM, EF5GM, EF6PM, EF7GM, EF8PE, EF8PM, GF10GM, GF4PE, GF4PM, GF5GM, GF6PE, GF6PM, GF7GM, GF8PE, GF8PM



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

HOTPOINT Chest freezer CS1A 300 H TK, CS1A300HTK, CS1A400

HOTPOINT Convection oven BD31B, BD31P, BD32B, BD32K, BD32N, BD32P, BD32T, BD35AL, BD42SS, BD51X, BD81B, BD81G, BD81N, BD81P, BD81S, BD81YS, BS11B, BS11P, BS22B, BS22G, BS22N, BS22P, BS32B, BS32K, BS32N, BS32P, BS41B, BS41D, BS41G, BS41N, BS41P, BS41X, BS42B, BS42K, BS42N, BS42P, BS45AL, BS52SS, BS61B, BS61P, BS61S, BS61YS, BS62B, BS62K, BS62P, BS62S, BS72SS, BU62B, BU62G, BU62N, BU62P, BU62S, BU62X, BU62YS, BU65AL, BU71B, BU71K, BU71N, BU71P, BU72B, BU72K, BU72N, BU72P, BU72S, BU82SS, SC98PX(T), SD97PC, SD97PI, SD98PI, SE102PX, SE48101PGX, SE48101PX, SQ102PI, ST98PX

HOTPOINT Kitchen glass-ceramics EW41B, EW91S

IGNIS Chest freezer ICF270, ICF2701, ICF271, ICF271B, SF401

IGNIS Domestic refrigerator A211G1, ARG340ALH, ARG341ALH, ARL100A, ARL100A1, ARL100BK, ARL100BK1, ARL100K, ARL100KG01, ARL100KG01GB, ARL101K, ARL101K1, ARL101KG01, ARL103G, ARL130A, ARL130A+, ARL130A1, ARL177, ARL359G, ARL392, ARL392A+, ARL804A, CFS300S60065381, CFS340S20065383, CFS340S60065381, DPA39, DPA391G, DPA391G1, DPA395M, DPA396NFG, DPA39AL

IKEA Domestic refrigerator 00123534CB626WFRIGORIFERI, 40015071, CB603W30123518, CB604W90123520, CB607W70123521, CB625W20123533, CB626W00123534, CB635W70123535, CB646WCH50123536, CB654WGB80123525, CBI603W54536910, CBI604W74537310, CBI605W04537610, CBI607W84535810, CBI607W94537210, CBI613W, CBI613W34537010, CBI614W, CBI614W54537410, CBI643W34537010, CBI643W50016230, CBI645W10016232, CBI645WCBI605W10016232, CBI647W30016231, CBI654W24537510, CBU625W10015063, CBU626W40015066, CBU635W40015071, CBU646W40017249, OBI613W34537010

IKEA Domestic refrigerator electric 00157699CFS171FRIGORIFERI, 00199500CF124FRIGORIFERIIK, 00245540CFNE120A+FRIGORIF, 30245553CBEF181A+FRIGORIF, 40245538CAV120A+FRIGORIFE, 50094690FORSTIGCFS500AL1, 50245552CBEF180A+FRIGORIF, 60245537CAV121A+FRIGORIFE, 70199498CF120FRIGORIFERIIK, CFS100W140094676, CFS101W00154686, CFS110W, CFS140W180094679, CFS141W60154688, CFS400AL, CFS400AL170094689, CFS500AL, CFS500AL150094690

IKEA Domestic refrigerator gas 20015067, 20199491C124FRIGORIFERIIK, 853975396016 (30027098), 30199481C94FRIGORIFERIIK, 40176554CFS660SFRIGORIFER, 40199490C120FRIGORIFERIIK, 50199480C91FRIGORIFERIIK, 60182484CB180FRIGORIFERIC, 60199489C121FRIGORIFERIIK, 64538310, 70199479C90FRIGORIFERIIK, 70245551CBRA160A+FRIGORIF, 80199501CB160FRIGORIFERIC, 90199505CB1805FRIGORIFERI, CB18110182486, CB601W20123509, CB602W80123511, CB605W30123523, CB645WCH10123524, CB651WGB40123513, CB652WGB20123514, CB656WGB30123537, CB901W10123538, CBI602W64536410, CBI610W20018315, CBI611W, CBI611W84535810, CBI612W, CBI612W30027098, CBI633W74538710, CBI641W, CBI651W, CBI651W70016229, CBI902W, CBI902W20019287, CBI911W, CBI911W40019286, CBU632, CBU632W64538310, CBU636W, CBU636W20015067, CBU656W30079332, CFS050S50065372, CFS050S90065370, CFS051S70065371, CFS051SL70065371, CFS054S90065370, CFS110W120094677, CFS111W80154687, CFS300S20065383, CFS310S40065382, CFS660S40176554

IKEA Domestic refrigerator glass-ceramics 40157697CFS170, 40157697CFS170FRIGORIFERI, 60107847, CB18060182484, CB18430182485, CB610W60123512, CB641W00123510, CBI601W44535510, CBI641W90016228

KITCHENAID Domestic refrigerator ARC04511, KR6040



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KÜPPERSBUSCH Convection oven ECD106, ECD110, ECD120, ECD220

LOTUS Chaffing dish electric RI-4EM, RI-4EMX

LOTUS Electric oven FORNO MAXI ELETTRICO MULTIFUNZIONE S65, FORNO MAXI ELETTRICO STATICO S65

LOTUS Gas oven FORNO MAXI GAS STATICO S65

MAYTAG Chest freezer MFC1209TWW, MFC1210TAW

MBM Convection oven FEC023, FEMD023, FEMD48

PALUX Coffee machine AROMACARAT

PALUX Filter coffee machine AROMACARINA

PALUX Salamander SALAMANDER

PHILIPS Domestic refrigerator ARG596KGWP, ARG991KGR

POLARIS Refrigerated cupboard BT120, BT124, BT140, BT144, BT60, BT62, BT70, BT70G, BT72, BTV120, BTV124, BTV140, BTV144, BTV60, BTV62, BTV70, BTV72, KBT120, KBT122, KBT124, KBT140, KBT142, KBT144, KBT40, KBT60, KBT62, KBT70, KBT70G, KBT72, KBTV60, KBTV70, KC105-35, KC25-45, KC35-13, KC35-35, KC45-12, KC60-60, KC70-70, KC90-30, KCTN105-35, KCTN25-45, KCTN30-30, KCTN35-13, KCTN35-35, KCTN45-12, KCTN70-70, KP140, KP60, KP70, KPBT105-35, KPBT25-45, KPBT35-35, KPBT70-70, KPC90-30, KPTN105-35, KPTN25-45, KPTN35-13, KPTN35-35, KPTN70-70, KTN120, KTN122, KTN124, KTN140, KTN142, KTN144, KTN35-13, KTN40, KTN45-12, KTN60, KTN62, KTN70, KTN72, KTNV60, KTNV70, KUBT140, KUBT142, KUBT144, KUBT70, KUBT72, KUC105-35, KUC25-45, KUC35-13, KUC35-35, KUC45-12, KUC70-70, KUCTN105-35, KUCTN25-45, KUCTN35-13, KUCTN35-35, KUCTN45-12, KUCTN70-70, KUP70, KUPBT105-35, KUPBT25-45, KUPBT35-13, KUPBT35-35, KUPBT45-12, KUPBT70-70, KUPTN105-35, KUPTN25-45, KUPTN35-13, KUPTN35-35, KUPTN70-70, KUTN140, KUTN142, KUTN144, KUTN70, KUTN72, P140, P144, P70, P72, TN120, TN124, TN140, TN144, TN60, TN62, TN70, TN72, TNN120, TNN124, TNN60, TNN62, TNV120, TNV124, TNV140, TNV144, TNV60, TNV62, TNV70, TNV72

SMEG Chest freezer CO142, CO202, CO230, CO232, CO302, CO312, CO402

SMEG Convection oven ALFA341EK, ALFA341VE, ALFA341XM

SMEG Domestic refrigerator CB320APC, CF33BP, CF33BPNF, CF33S2PNF, CF33SP, CF33SPNF, CF33X2PNF, CF33XP, CF33XPNF, CF36BP, CF36BPNF, CF36X2PNF, CF36XP, CF36XPNF, FA120A, FA120AP, FA120APS, FA120AS, FA340BP, FAB10BRN, FAB10BRO, FAB10BRR, FAB10HLB, FAB10HLIT, FAB10HLNE, FAB10HLP, FAB10HLR, FAB10HRB, FAB10HRDS, FAB10HRIT, FAB10HRNE, FAB10HRNE-1, FAB10HRP, FAB10HRP-1, FAB10HRR, FAB10LB, FAB10LNE, FAB10LO, FAB10LP, FAB10LR, FAB10LUJ, FAB10NE, FAB10NES, FAB10O, FAB10OS, FAB10P, FAB10PS, FAB10R, FAB10RB, FAB10RDSU, FAB10RNE, FAB10RNEC, FAB10RO, FAB10ROC, FAB10RP, FAB10RR, FAB10RRC, FAB10RS, FAB10RUJ, FAB10RUJC, FAB10UJ, FAB10UJS, FC320BNF, FC420BNF, FD250A, FD250AP, FD250AP1, FD250APS, FD250APS1, FD32AP, FD32AP1, FD32APS, FD32APS1

SMEG Electric oven 4080.0, 4081.0, ALFA10, ALFA10X, ALFA10XA, ALFA10XA3, ALFA10XAB, ALFA10XAK, ALFA11, ALFA11-1, ALFA11-1B, ALFA11AM, ALFA11GM, ALFA11LP, ALFA135B1, ALFA135BE, ALFA135BM, ALFA135BV, ALFA135GH, ALFA135V6, ALFA135VE, ALFA135VM, ALFA135X, ALFA135X1, ALFA135XB, ALFA135XE, ALFA135XM, ALFA135XP, ALFA135XV, ALFA136BM, ALFA141GH, ALFA141VE, ALFA141XE, ALFA15, ALFA151X, ALFA15A, ALFA15N, ALFA15X, ALFA161X, ALFA161XK, ALFA20, ALFA200X, ALFA200XE, ALFA200XM, ALFA201XE, ALFA201XM, ALFA20A, ALFA20EB, ALFA21, ALFA21I, ALFA21IP, ALFA241EK, ALFA241VE,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ALFA241XM, ALFA25, ALFA30, ALFA30A, ALFA30B, ALFA30F, ALFA30N, ALFA30T, ALFA30V, ALFA30X, ALFA30XA, ALFA30XG, ALFA30XM, ALFA31V, ALFA35, ALFA35XA, ALFA50X, ALFA51X, ALFA51XGN, ALPHA30K, APF2B, APF2N, APF5X, APF6B, APF6N, APF8B, APF8PF, BU135XV, CL104, CL204, F170P, F170P-5, F51, F51EB, F52MF, F53MF, F53MFEB, F88MFEB, FI170P, FI170P-5, FOVP, HS600MF, HS600MFEB, N550, N550A, N550AEB, N552MF, N552MFEB, N588MF, N588MFEB, OA102W, OA204W, RFF404, RFT644, RFT744, RFT844, RFT844B, RFT844V, S1055MF1 (S1055MF1), S1055MF-5 (S1055MF-5), S1055MFB5 (S1055MFB), S1055MFB1 (S1055MFB1), S1055MFB5, S1055MFX1 (S1055MFX1), S1055MFX5 (S1055MFX5), S1065MF1, S1065MF5, S1065MFB1, S1065MFB5, S1065MFX1, S1065MFX5, S1085MF1, S1085MFA1, S1085MFA5, S1085MFP1, S1085MFP5, S1085MFB1, S1085MFB5, S1085MFX1, S1085MFX5, S1100MF5 (S1100MF5), S1100MFB5, S1100MFX5, S16MF, S16MFEB, S18EMF, S2010MF1, S2010MF-5, S2010MFB1, S2010MFB5, S2010MFP5, S2010MFX1, S2010MFX5, S20XMF, S20XMFR, S285PMF5, S285PMFB5, S285PMFX5, S300, S300EB, S300X, S320, S320EB, S320X, S340, S340-1, S340EB, S340EB-1, S340G, S340GEB, S340GX, S350X, S350X-1, S360, S360-1, S360EB, S360EB-1, S360X, S370, S370EB, S380X, S390, S390EB, S392, S392EB, S395X, S398X, S4, S400, S400EB, S4C, S4CEB, S4EB, S500EB, S500X, S54, S54EB, S550, S550EB, S550X, S57, S57EB, S59MF, S59MFEB, S5EB, S6, S600, S600EB, S650, S650EB, S6EB, S6NE, S800MF, S800MFEB, S810G, S810GEB, S890, S890EBMFR, S890MF, S890MFEB, S890MFR, S9, S940, S940EB, S950X, S970, S970EB, S980X, S990EBR, S990R, S990XR, S9EB, S9NE, SA1010MFX, SA1010X1 (SA1010X), SA1010X-5 (SA1010X), SA1010X1, SA1010X-5, SA10XMF-1, SA340EB, SA360EB, SA360X, SA370EB, SA370EB-1, SA370EB-2, SA380X, SA380X-1, SA380X-2, SA388X, SA390EB, SA390NE, SA392EB, SA392NE, SA395X, SA398X, SA600, SA600-1, SA600EB-1, SA650EB, SA650NE, SA890WR, SA920MF, SA920MF-1, SA920MFEB, SA920MFW1, SA990REB, SA990RNE, SA990XR, SA999X, SC100ALU, SC100EBO, SC100NE, SC100SG, SC2010MFB, SC2010MFW, SC2010MFX, SDK1055X, SDK500XMF, SE100EB, SE100NE, SE100X, SE1045, SE1045B, SE1055MF (SE1055MF), SE1055MFB, SE1055MFX, SE1055X, SE105EB, SE105NE, SE105X, SE1065MF, SE1065MFB, SE1065MFX, SE1066MFX, SE1066MX5, SE106EB, SE106NE, SE106X, SE1075MF, SE1075MFA, SE1075MFP, SE1085MA5, SE1085MF, SE1085MFA, SE1085MFB, SE1085MFP, SE1085MFV, SE1085MP5, SE108EB, SE108NE, SE108X, SE10XMF, SE2010MAZ, SE2010MBL, SE2010MF, SE2010MFB, SE2010MFP, SE2010MFX, SE2010MVA, SE2010MVS, SE20XMFR (SE20XMFR), SE20XMFR1 (SE20XMFR), SE20XMFR5 (SE20XMFR), SE20XMFR7 (SE20XMFR), SE20XMFR8 (SE20XMFR), SE285PMF, SE285PMFB, SE285PMFX, SE320, SE320-1, SE320EB, SE320EB-1, SE320X, SE330, SE330B, SE330EB, SE340, SE340-1, SE340EB, SE340EB-1, SE360, SE360EB, SE360X, SE365MF (SE365MF), SE365MFEB, SE370MF, SE370MFEB, SE375MF, SE375MFB, SE375MFEB, SE375MFG, SE385MF, SE385MFEB, SE390MF, SE390MF1, SE390MFB1, SE390MFEB, SE392MF, SE392MFEB, SE398X, SE500MF, SE500MFEB, SE500XMF, SE600MF, SE600MF1, SE600MFB1, SE600MFEB, SE650MF, SE650MFEB, SE800, SE800EB, SE800MF, SE800MFEB, SE810MF, SE810MFEB, SE820MF, SE820MFEB, SE90, SE90EB, SE90MB, SE90X, SE910MFB, SE910MFF, SE92, SE92EB, SE95, SE95EB, SE95X, SE96, SE96EB, SE96MB, SE96X, SF16EBMF, SF16MF, SF290MF, SF290MFEB, SF4P, SF4PEB, SF54, SF54EB, SF59, SF59EB, SF59MF, SF59MFEB, SF800EBMF, SF800MF, SF800MF1, SF800MFB1, SF810MF, SF810MF1, SF810MFB1, SF810MFEB, SG40, SG40NL, SI2010MFX, SI2011MX5, SM800, SM800-1, SM800A, SM800B-1, SM800EB, SM800EB-1, SM800MF, SM800MFA, SM800MFB, SM800MFEB, SM800MFP, SM800MFV, SM800P-1, SM800V-1, SO66PMFA, SO66PMFA5, SO66PMFP, SO66PMFP5, SO66PMFX, SO66PMFX5, SP370MF, SP370MFEB, SP500XMF, SP600MF, SP600MFEB, SP680MFG, SP710B, SP710W, SP711B,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SP711W, SP730MFB, SP730MFW, SP731B, SP731W, SP750B, SP750W, SP751MFB, SP751MFW, SP761B, SP761W, SP7800G, SP800G, SP9000B, SP9000W, SP9000X, UK1065X, UK1065X-1, UK1065X-5, UK2010X, UK2010X-1, WE320, WE320EB, WE320X, WE360, WE360EB, WE360X, WE800, WE800EB, WEF610B, WEF610N, WEF630B, WEF630N, WI16MF, WI16MFEB, WI18EMF, WI20XMF, WI20XMFR, WI300, WI300EB, WI300X, WI320, WI320EB, WI320X, WI340, WI340-1, WI340EB, WI340EB-1, WI350X, WI350X-1, WI360, WI360EB, WI360X, WI370, WI370EB, WI380X, WI390, WI390EB, WI392, WI392EB, WI395X, WI398X, WI4, WI400, WI400EB, WI500, WI500EB, WI500X, WI54, WI54EB, WI550, WI550EB, WI550X, WI59MF, WI59MFEB, WI6, WI600, WI600EB, WI650, WI650EB, WI800MF, WI800MFEB, WI9, WI940, WI940EB, WI950X, WI970, WI970EB, WI980X, WI990EBR, WI990R, WI990XR, WI9EB

SMEG Gas oven SNZ340GSS, SNZ340GW, SP340G, SP340GW, WI340G, WI340GEB, WI340GX

SMEG Kitchen CB856V

SMEG Kitchen electric SCE66MPX5 (SCE66MPX5), SUK61CPX5

SMEG Kitchen gas 3C53-1, 3C54, 3C54E, 3C54V, 3C54XE, 3C65, 3C65-1, 3C65E, 3C65MF, 3C65MFV, 3C65V, 3C65XE, 3C67-1, 3C70, 3C850, 3C850E, 3C852, 3C852V, 3C853-1, 3C854, 3C854E, 3C854V, 3C854XE, 3C85BT, 3C85XT, 4C80, A1, A1A, A1VA, AP631, B603MFV, C7GPX8 (C7GPX), C85BTV, C85XTV, C92GPX, CB53-1, CB54, CB54-1, CB622-1, CB65, CB651, CB65-1, CB652-1, CB653V, CB65MF, CB661, CB663V, CB664MF, CB664MFV, CB67-1, CB851, CB852, CB853V, CB854-1, CB854-1V, CB855, CB857BT, CB857BTV, CBE54, CBE54-1, CBE65, CBE65-1, CBE65MF, CBV54, CBV622-1, CBV65, CBV652-1, CE6GPX, CE92GPX, CI54, CI54-1, CI54V, CI65, CI65-1, CI65MF, CI65MFV, CIE65MF/1 (CIE65), CIE65MF, CIE65MF-1, CIV54-1, CIV65, CIV65-1, CP60X6, CS19 (CS19), CS19/1 (CS19), CS19-1PF (CS19), CS19-2 (CS19), CS19-2ES (CS19), CS19-5 (CS19), CS19-6 (CS19), CS19NL (CS19NL), CS19NL1 (CS19NL), CS19NL2 (CS19NL), CS19NL-5 (CS19NL), CS19NL-6 (CS19NL), CSA19, CV594, CV694, FS64MF, FS64MFCW, FS64MFLP, FS64MFW, FS64MFX, FS64MFXLP, MB150, MB160, MB160V, MB50, MB60, MBE60, MBE60-1, MCF150, MCF160, MCF160V, MCF50, MCF60, MCFE60, MCFE60-1, NZ634EWP, NZ634GSS, NZ634GW, S505EB, S514X, S523-1EB, S524EB, S525-1EB, S610MFEB, S610MFX, S614X, S615-1X, S623-1EB, S624EB, S625-1EB, S626MFEB, S650M, S651CF, S660M, S661CF, S850, S852, S852V, S852X, S852XV, S853-1, S854XQV, S854XV, S855-1X, S855-1XV, SBA1, SCD61MPX5, SCE61MPX5, SE783MF, SE783MFEB, SE784MF, SE784MFEB, SE852, SE852X, SE854X-1, SEP784CF, SEP784M, SF683MF, SF683MFEB, SF684CF, SF684CF1, SF684M, SF684M1, SF684MF, SNL854X, SNL854X1, SUK160MB, SUK160MCF, SUK160V, SUK61MPX5, SUK65G, SUK65MF, SUK854X, V602MFV, W514X, W524EB, W601MFV, W610MFEB, W610MFX, W614X, W624EB, W625-1EB, W626MFEB, W650M, W651CF, W660M, W661CF, W850, W8521X, W852X, W8530, W8531X, W8534, W8535X, WB54, WB540, WB540V, WB54V, WB56-1, WB60, WB65, WB650, WB650V, WB65V, WB66-1, WB68MF, WCF61, WUK65G, WUK65MF, WUK854X, WX54, WX540, WX64-1, WX65, WX650, WX650V, WX65V, X604MFV

SMEG Kitchen glass-ceramics SCE64MPX5, SUK61IPX5

SMEG Kitchen induction C92IPX, CE92 IPX (CE92IPX)

SMEG Microwave oven WI4EB

TECNOEKA Convection oven 440, 610, 610 GRILL, 611, 648, 740-000-0000, 900, 900.3, 940.3 GRILL, KF1000G, KF1001G-IX-AL, KF1001G-LPG-IX-AL, KF412, KF412U, KF620D U IX, KF723, KF723 GRILL, KF723M, KF723U, KF733, KF733D UD, KF911, KF911IX, KF912, KF912 GRILL, KF912IX, KF921, KF931, KF933AL, KF933AL U,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KF937, KF937UD, KF964AL, KF964ALM, KF964I, KF964IM, KF965, KF965M

TECNOEKA Kitchen electric KC 96M, KC 96MS, KC 96V, KC 96VS, KC 97IM, KCP 96V, KCP 96VS, KCP5 96V, KCR 96V

TECNOEKA Kitchen gas KC 97VG-A, KCP 97VG-A, TCFG

TECNOEKA Pastry oven gas KF1001G IX AL

TECNOINOX Electric oven BF105E

TECNOINOX Gas oven BF105G

TECNOINOX Kitchen electric PF70E0, PFC70E0, PFC70E60, PFL105E0, PFL105E2, PFL105E60, PFL105E62

TECNOINOX Kitchen gas PF105G0, PF5G0, PF70G0, PFL105G0, PFL105G6, PFL105GG0, PFL105GGG6, PFL5G0, PFL5G6, PFL5GG0, PFL5GGG6, PPFL5G0, PPFL5GG0, PPFL5GGG6, PPFL5GGG6

THERMOR Electric oven 7HF076 (F5325S), 7HF0104 (FC13MB), 7HF080 (FC13MB), REP-006670 (FC13MN), REP-006751 (FC13MN), REP-006680 (FC55CN), REP-006700 (FC55CN), 7HF0111 (FC55MB), 7HF0124 (FC55MB), 7HF0139 (FC55MB), 7HF079 (FC55MB), 7HF0141 (FC55MN), REP-006681 (FC55MN), REP-006695 (FC55MN), 7HF0117 (FC55MX), 7HF0125 (FC55MX), 7HF0137 (FC55MX), 7HF0097 (FE11MB), 7HF0142 (FE11MB), 7HF082 (FE11MB), 7HF0097 (FE11MN), 7HF0140 (FE11MN), REP-006753 (FE11MN), 7HF0113 (FP75CB), 7HF0121 (FP75CB), 7HF0133 (FP75CB2), REP-006692 (FP75CN), REP-006705 (FP75CN2), 7HF0106 (FP75MB), 7HF083 (FP75MB), 7HF0118 (FP75MB2), 7HF0156 (FP75MB2), REP-006672 (FP75MN), 7HF0105 (FP76CB), 7HF0123 (FP76CB), 7HF0150 (FP76CB), 7HF0154 (FP76CN), FP76CN2 (FP76CN), REP-006671 (FP76CN), REP-006694 (FP76CN), 7HF0107 (FP76MB), 7HF0126 (FP76MB), 7HF0153 (FP76MB), 7HF0151 (FP76MN), REP-006673 (FP76MN), REP-006697 (FP76MN), 7HF0108 (FP77MB), 7HF0127 (FP77MB), 7HF0147 (FP77MB), 7HF0145 (FP77MN), REP-006698 (FP77MN), 7HF0116 (FP80MB), 7HF0119 (FP80MB), 7HF0130 (FP80MB), 7HF0149 (FP80MB), 7HF0146 (FP80MN), REP-006685 (FP80MN), REP-006688 (FP80MN), REP-006703 (FP80MN), REP-006682 (FRC15MN), 7HF0096 (FRP14MB), 7HF0128 (FRP14MB), REP-006699 (FRP14MB), REP-006747 (FRP14MB), REP-006665 (FRP14MN), REP-006748 (FRP14MN), 7HF0007 (FRP14MN-1), 7HF0135 (FRP14MN-1), 7HF0138 (FRP14MN-1), REP-006748 (FRP14MN-1), 7HF072 (FVP86MB), FVP86MB2 (FVP86MB), 7HF0002 (FVP86MB1), FVP86MB1 (FVP86MB1), 7HF0003 (FVP86MN), 7HF0004 (FVP86MN), FVP86MN1 (FVP86MN), FVP86MN2 (FVP86MN), 7HF0095 (FVP87MB), 7HF0122 (FVP87MB), 7HF0152 (FVP87MB), FVP87MB1 (FVP87MB), 7HF0155 (FVP87MN), 7HF0171 (FVP87MN), FVP87MN1 (FVP87MN), REP-006664 (FVP87MN), REP-006693 (FVP87MN)

THERMOR Kitchen 7HC0128 (IV657PBB), 7HC0129 (IV657PBB), 7HC0094 (T656MCBB), 7HC0123 (T656MCBB), 7HC0091 (T656MPRN), 7HC0132 (T656MPRN), 7HC0133 (T656MPRN), 7HC0100 (T656PBB), 7HC0111 (T656PBB), 7HC0139 (T656PBB), 7HC0146 (T656PBB), 7HC0095 (T657MPBB), 7HC0115 (T657MPBB), 7HC0135 (T657MPBB), 7HC0145 (T657MPBB), 7HC0101 (T657PBB), 7HC0109 (T685MPBB), 7HC0112 (T685MPBB), 7HC0137 (T685MPBB)

THERMOR Kitchen electric 7HC0099 (E637MPBB), 7HC0136 (E637MPBB)

THERMOR Kitchen gas 7HC0126 (M657PBB)

THERMOR Kitchen glass-ceramics 7HC0102 (V647PBB), 7HC0138 (V647PBB)

TORNATI FORNI Convection oven TF60-GAS, TF90-GAS, TF99-GAS

TORNATI FORNI Pizza oven electric EUROPA-66, EUROPA-69

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

VEDETTE Kitchen 7VC0083 (69KPA), 7VC0100 (69KPA), 7VC0112 (69KPA), 7VC0137 (69KPA), 7VC0145 (69KPA), 7VC0148 (69KPA), 7VC0096 (69KPABD), 7VC0110 (69KPABD), 7VC0113 (69KPABD), 7VC0128 (69KPABD), 7VC0147 (69KPABD), 7VC0149 (69KPABD), 7VC0153 (MPT63B), 7VC0155 (MPT63C), 7VC0161 (MPT64B), VGE630B1 (VGE630B), 7VC0210 (VMC630B), 7VC0195 (VME620B), VME620B1 (VME620B), VME620B2 (VME620B), VME620B3 (VME620B), 7VC0178 (VME64B), 7VC0193 (VME64B), VME64B1 (VME64B), VME64B2 (VME64B), 7VC0198 (VMP640B), VMP640B1 (VMP640B), 7VC0174 (VMP65B), 7VC0184 (VMP65B), VMP65B1 (VMP65B), VMP65B2 (VMP65B), 7VC0188 (VMP66B), VMP66B1 (VMP66B)

VEDETTE Kitchen electric 7VC0181 (VEE61B), 7VC0191 (VEE61B), 7VC0202 (VEE61B), VEE61B1 (VEE61B), VEE61B2 (VEE61B), VEE61B3 (VEE61B)

VEDETTE Kitchen gas 7VC0197 (VGC620B), VGC620B1 (VGC620B), 7VC0175 (VGC62B), 7VC0187 (VGC62B), VGC62B1 (VGC62B), VGC62B2 (VGC62B), 7VC0196 (VGE610B), VGE610B1 (VGE610B), VGE610B2 (VGE610B), VGE610B3 (VGE610B), 7VC0180 (VGE61B), 7VC0186 (VGE61B), VGE61B1 (VGE61B), VGE61B2 (VGE61B), 7VC0211 (VGE620B), 7X9474 (VGE63B), VGE63B1 (VGE63B)

VEDETTE Kitchen glass-ceramics 7VC0179 (VVC6

