

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Regulator energie EGO 50.57071.010 #COK357UN

Fara TVA: 54,62 Lei

Pret cu TVA: 65,00Lei

Regulator energie EGO 50.57071.010 #COK357UN

Voltage 240V

Switching capacity: 13A

Turn direction: right

Shaft diameter: 6x4.6 mm

Mounting thread: M4

Function: single-circuit

Shaft length: 23mm

Producer: EGO

No. 50.57071.010

power release: 6-100 %

Compatibil cu:

AEG 3150788242

AMBACH 5061616087

BAKE OFF 373506020

BARTLETT 3843-137, 4400-175

BERTOS 27114900

BEST FOR 373506020

CAPIC E402540

COLGED RIC0001299, RTCU800066

CORSAIR 01-110

DEXION RIC0001299

EGO 5017071000, 5057071010

ELETTROBAR RIC0001299, RTCU800066

EMMEPI 806287

FAGOR 12024522, S333001000

FALCON 737630011, E2512, E2512/22-LD22

FIMAR CO1953

FOINOX 0280

GARBIN REG001, REG100

GICO 539205

HENDI 3350024



magazin online HORECA  
Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

HORECAPARTS 3350024

INDESIT C00019090

LF 3350024

LINCAT EN10

MBM RIC0001299, RTCU800066

METOS 6A049320

MODULAR 661.058.00

MORICE DE0952

OLIS 6A049320

PARRY SATT37071

REPAGAS 1230018

ROSINOX RX94045299

SILKO 0108231

SMEG 818731068

STALGAST C004333

UNOX KVE009, VE023

VAUCONSANT 06-1505, 06.1505

VISCOUNT 926561-01, 926570-01

AMBACH Boiling pan electric EKK-100, EKK-40

ARISTON Convection oven 05127 (A2010), 05128 (A2010), A2010-2, 05123 (A2011), 05124 (A2011), A2011-1, A2011-2, 05125 (A2012), 05126 (A2012), 10814 (A2013), 10815 (A2013), 14171 (A2014), 14172 (A2014), 17343 (A2210), 17344 (A2210), 17345 (A2211), 17346 (A2211), 26518 (FB11(BR)GB), 26517 (FB11(WH)GB), 26521 (FB36(BK)GB), 26519 (FB36(BR)GB), 26522 (FB36(IX)GB), 26520 (FB36(WH)GB), 12032 (FG211), 12033 (FG211), 18106 (FG22(BR)GB), 18105 (FG22(WH)GB), 05738 (FM272GB), 05739 (FM272GB), 05740 (FM373FGB), 05741 (FM373FGB), 05742 (FM374GGB), 05743 (FM374GGB), 05744 (FM374GGB), 17528 (FM37G.1AUS), 17529 (FM37G.1AUS), 06426 (FM37GAUS), 06427 (FM37GAUS), 18107 (FM87CIXGB), 16540 (FM87FCGB), 16541 (FM87FCGB), 02292 (FM8FUK), 02293 (FM8FUK), 02344 (FM8GUK), 26523 (FR34S(AN)GB), 26524 (FR34S(WH)GB), 05733 (FS211GB), 05734 (FS211GB), 11320 (FS211GB.1), 11321 (FS211GB.1), 16529 (FS41GB), 16530 (FS41GB), 05745 (FV242DGB), 05746 (FV242DGB), 05735 (FV271GB), 05736 (FV271GB), 05737 (FV271GB), 14651 (FV271GB), 16536 (FV34DGB), 16537 (FV34DGB), 16538 (FV34DGB), FV37GB., 02288 (FV4UK), 02289 (FV4UK), 02290 (FV8UK), 02291 (FV8UK), I-F2UK, I-FV4UK, 05368 (IV-FM8GAUS), 05369 (IV-FM8GAUS), IV-FM8GUK, 00086 (SOA2)

ARISTON Kitchen gas 04394 (G3SCGB), 13259 (G4ST.EGB), 04905 (G4STGB), 05171 (G604M9.2GB), 16424 (G640M9.2GB), 05166 (G640M9.EGB), 16344 (GVM8(W)), KL40EVEA(B), KL40VESUK

BAKE OFF Convection oven EASY 6 G

BERTO'S Bain-marie electric E6BM3B, E6BM3M, E6BM6B, E7BM4B, E7BM4M, E7BM8M, E9BM4M, E9BM8M, LXE9BM4, SE7BM4B, SE7BM4M, SE9BM4M, SE9BM8M

BERTO'S Convection oven FMG10M, FMG6M, FPE6TURBO, FPG12, FPG6, WAVE12TURBO, WAVE6,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

WAVE6TURBO, WAVE-E5, WAVG12, WAVG5U, WAVG6

BERTO'S Electric oven WAVE12

BERTO'S Grille6PL60B, E6PL60M, E9PL40M, E9PL80M, EGRM4, EGRS4, PLE40BE, PLE40ME, PLE80BE, PLE80ME, SE9PL40M, SE9PL80M

BERTO'S Kitchen glass-ceramics E6P2M-VTR, E6P4B-VTR, E6P4M-VTR, E6P4-VTR-FE1, E9P2MP-VTR, E9P4MP-VTR, E9P4P-VTR-FE1, LXE9P2P-VTR, LXE9P4P-VTR, SE9P2MP-VTR, SE9P4MP-VTR

BERTO'S SalamanderSA-E48, SA-E60, SA-E60-E, SA-E68M, SA-E68M-E

CAPIC Bratt pan W291811, W295011, W295012, W295013, W295014, W295015, W295017, W295021, W295022, W295023, W295024, W295025, W381811, W381821, W381831, W385011, W385012, W385013, W385014, W385015, W385021, W385022, W385023, W385024, W385025

DEXION Convection oven FC006-03-002GM, FC008-03-641EM, FC020-03-001EM

DEXION Fry top ME046-03-000V, ME066-03-000V

DEXION Kitchen glass-ceramics LX7EVC4F

DEXION Pot stove glass-ceramics LX7EVC2

DEXION Potato heater ME046-03-005

FIMAR Salamander SAL600

FOINOX Pastry oven electric FDE10-155M, FDE55M

FOINOX Pastry oven gas FDG10-155M, FDG55M

GARBIN Convection oven PRO 523M

GARBIN Steam oven electric 101 GX, 104 PX, 45 G, 45 GX, 46 PX, 61 G, 61 GX, 64 P, 64 PX, PRO 10MB

GARBIN Steam oven gas 101 FGX, 104 FGX, 45 FGX, 61 FGX, 64 FGX

HOBART Convection oven HFCE6

HOBART Pot stove glass-ceramics HEVC26, HEVC46

HOTPOINT Convection oven BS43B, BS43B-1, BS43K, BS43K-1, BS43W, BS43W-1, BS53X, BS53X-1, KSO33CX, KSO33CXs, SC36EB, SC36EK, SC36EW, SC36EX, SD33X, SD33X.1, SH31K, SH31W, SH33K, SH33KS, SH33W, SH33WS, SH33X, SH33XS, SHA33CX, SHB33JK, SHD33JX, SHS31X, SHS33CX, SHS33CXs, SHS33X, SHS33XK, SHS33XKS, SHS33XS, SKD33JCX, SY11B, SY11W, SY36B, SY36B-1, SY36K, SY36K-1, SY36W, SY36W-1, SY36X, SY36X-1, SY37W, SY37W-1, SY37X, SY37X-1

HOTPOINT Kitchen electric HL500E, HW150EW

HOTPOINT Kitchen gas EK50

HOTPOINT Kitchen glass-ceramics 52TCW, 52TCWS, C358EWH, DCH50CW, EW36G, HAE51G, HAE51GS, HAE51KS, HAE51PS, HAE51XS, HARE51K, HARE51P, HUE53G, HUE53GS, HUE53K, HUE53P, HUE53PS, HUE53PS-E, HUI614K, HW160EC, HW160EW, HW170EK, HW170EKS, HW170EW, HW170EWS

MBM Convection oven FCE10, FCE108, FCE20, FCE6, FCE68, FCG10, FCG108, FCG20, FCG6, FCG68, FEP050, FEP080, FEP160, FGP050, FGP080, FGP160

MBM Grill EPL46, EPL66

MBM Pot stove glass-ceramics EVC26, EVC277, EVC46, EVC477, EVC4F77, MG7EVC277, MG7EVC477, MG7EVC4F77

MBM Potato heater ECC46

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

MODULAR Boiling pan electric 90-80-PED-100, 90-80-PED-150, 90-80-PEI-100, 90-80-PEI-150, 90-80-PEI-50

MODULAR Boiling pan gas 70-80-PGI50

MODULAR Kitchen electric 70-40PVE

MODULAR Pasta cooker 70-CPE, 70-CPG, 90-CPE, 90-CPG

MODULAR Pot stove glass-ceramics 70-70-CFVE, 70-70-PVE

MODULAR Salamander SE-GN1-1, SE-GN2-3

OLIS Boiling pan electric 74-02NPEI, 7NP-EI50

OLIS Bratt pan 9BR-E100, 9BR-E105, 9BRS-E100, 9BRS-E105

OLIS Electric oven CV10E, CV10E-2, CV10E-S, CV10E-S2, CV20E, CV20E-2, CV20E-S, CV20E-S2, CV21E, CV21E-2, CV21E-S, CV21E-S2, CV6E, CV6E-2, CV6E-S, CV6E-S2, CVM10E, CVM10E-2, CVM10E-S, CVM10E-S2, CVM20E, CVM20E-2, CVM20E-S, CVM20E-S2, CVM21E, CVM21E-2, CVM21E-S, CVM21E-S2, CVM6E, CVM6E-2, CVM6E-S, CVM6E-S2, CVP10E, CVP10E-2, CVP10E-S, CVP10E-S2, CVP20E, CVP20E-2, CVP20E-S, CVP20E-S2, CVP21E, CVP21E-2, CVP21E-S, CVP21E-S2, CVP6E, CVP6E-2, CVP6E-S, CVP6E-S2, FC10E, FC10E-2, FC10E-2S, FC10E-S, FC20E, FC20E-2, FC20E-2S, FC20E-S, FC21E, FC21E-2, FC21E-2S, FC21E-S, FC6E, FC6E-2, FC6E-2S, FC6E-S, FCM10E, FCM10E-2, FCM10E-2S, FCM10E-S, FCM10E-S2, FCM20E, FCM20E-2, FCM20E-2S, FCM20E-S, FCM21E, FCM21E-2, FCM21E-2S, FCM21E-S, FCM6E, FCM6E-2, FCM6E-2S, FCM6E-S, FCV10E, FCV10E-2, FCV10E-2S, FCV10E-S, FCV20E, FCV20E-2, FCV20E-S, FCV21E, FCV21E-2, FCV21E-2S, FCV21E-S, FCV6E, FCV6E-2, FCV6E-2S, FCV6E-S

OLIS Gas oven CV10G, CV10G-2, CV10G-S, CV10G-S2, CV20G, CV20G-2, CV20G-S, CV20G-S2, CV21G, CV21G-2, CV21G-S, CV21G-S2, CV6G, CV6G-2, CV6G-S, CV6G-S2, CVM10G, CVM10G-2, CVM10G-S, CVM10G-S2, CVM20G, CVM20G-2, CVM20G-S, CVM20G-S2, CVM21G, CVM21G-2, CVM21G-S, CVM21G-S2, CVM6G-S, CVM6G-S2, CVP10G, CVP10G-2, CVP10G-S, CVP10G-S2, CVP20G, CVP20G-2, CVP20G-S, CVP20G-S2, CVP21G, CVP21G-2, CVP21G-S, CVP21G-S2, CVP6G, CVP6G-2, CVP6G-S, CVP6G-S2, FC10G, FC10G-2, FC10G-2S, FC10G-S, FC20G, FC20G-2, FC20G-2S, FC20G-S, FC21G, FC21G-2, FC21G-2S, FC21G-S, FC6G, FC6G-2, FC6G-2S, FC6G-S, FCM10G, FCM10G-2, FCM10G-2S, FCM10G-S, FCM20G, FCM20G-2, FCM20G-2S, FCM20G-S, FCM21G, FCM21G-2, FCM21G-2S, FCM21G-S, FCM6G, FCM6G-2, FCM6G-2S, FCM6G-S, FCV10G, FCV10G-2, FCV10G-2S, FCV10G-S, FCV20E-2S, FCV20G, FCV20G-2, FCV20G-2S, FCV20G-S, FCV21G, FCV21G-2, FCV21G-2S, FCV21G-S, FCV6G, FCV6G-2, FCV6G-2S, FCV6G-S, mCVM6G-2

OLIS Kitchen electric 74-02CTEE, 7TP-E800, 7TPF-EE800, 7TPV-E800, 7TPVP-E800

OLIS Solid top range 74-02CTE, 74-02TCTE

OZTIRYAKILER Boiling pan electric 7855.500LG.01 (OKTGID 500), 7855.N1.80908.04 (OTEI 100), 7855.N1.80908.05 (OTEI 150), 7855.N1.10908.07 (OTEI 250), 7855.N1.80708.01 (OTEI 60)

OZTIRYAKILER Boiling pan gas 7855.N1.80908.11 (OTGD 100), 7855.N1.80908.12 (OTGD 150), 7855.N1.10908.13 (OTGD 250), 7855.N1.80708.14 (OTGD 60), 7855.N1.80908.01 (OTGI 100), 7855.N1.80908.02 (OTGI 150), 7855.N1.10908.03 (OTGI 250), 7855.N1.80708.04 (OTGI 60)

OZTIRYAKILER Bratt pan 7867.N1.10908.05 (OTE 100), 7867.N1.12908.06 (OTE 130), 7867.N1.80708.01 (OTE 50), 7867.N1.80908.04 (OTE 80), 7867.N1.10908.02 (OTG 100), 7867.N1.12908.03 (OTG 130), 7867.N1.80708.04 (OTG 50), 7867.N1.80908.01 (OTG 80), 7867.N1.16908.14 (OTMG 205)

OZTIRYAKILER Convection oven 7890.10G11.01 (OKFE 101), 7890.10G21.01 (OKFE 102), 7890.20G21.01 (OKFE



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

202), 7890.95708.01 (OKFE 601), 7890.95701.03 (OKFG 101), 7890.10G21.03 (OKFG 102), 7890.20G21.03 (OKFG 202), 7890.6G110.03 (OKFG 601)

OZTIRYAKILER Fry top 7865.N1.40903.CS (OSC 4090)

OZTIRYAKILER Pasta cooker 7858.N1.40703.11 (OME 4070), 7858.N1.40908.11 (OME 4090), 7858.N1.80908.11 (OME 8090)

OZTIRYAKILER Pot stove glass-ceramics 7865.N1.40703.CS (OSC 4070), 7865.N1.80703.CS (OSC 8070), 7865.N1.80903.CS (OSC 8090)

SILKO Kitchen electric CCT7221V, CCT7246V

SILKO Pot stove electric CCT7241V

SILKO Pot stove glass-ceramics CCT7220V, CCT7222V, CCT7240V, CCT7242V

SMEG Display cabinet warm EP31BU, EP31R, EP31R1L, EP31R1LG, EP31RG, EP31RGS, EP41R, EP41R1L, EP41R1LG, EP41R3L, EP41R3LG, EP41RA, EP41RF, EP41RG, EP41RGS, EP41RR, EP41RS, EP42R3GS, EP42R3S, EP42RGS, EP42RS, EP91BU, EP91RL

SMEG Proving oven warm LEV101X, LEV135RU, LEV135X, LEV140XV, LEV141XV, LEV141XV-1, LEV143XV, LEV150XV, LEV31R, LEV31RU, LEV41XV, LEV41XV-1

UNOX Convection oven XF065-TG, XG310, XG410, XV202, XV301, XV401, XV501

UNOX Fry top XP200, XP300

WHIRLPOOL - INDESIT Convection oven F079662 (BIMS31KABIX), F080526 (BIMS31KABIXS), F079652 (BIMS53K.ABIX ), 25018 (FG10K(BK)GB), F025018 (FG10K(BK)GB), 25017 (FG10K(WH)GB), F025017 (FG10K(WH)GB), 14134 (FG1GB), 14135 (FG1GB), F014134 (FG1GB), F014135 (FG1GB), F034016 (FI31K.B(BK)GB), F034017 (FI31K.B(WH)GB), F034015 (FI31K.BIXGB), 02846 (FIE1UK), 02847 (FIE1UK), F002846 (FIE1UK), F002847 (FIE1UK), 06424 (FIE20GB), 06425 (FIE20GB), F006424 (FIE20GB), F006425 (FIE20GB), F034020 (FIE36K.B(BK)GB), F034019 (FIE36K.B(WH)GB), F034018 (FIE36K.BIXGB), F054255 (FIE36KBBKGB1), F054259 (FIE36KBIXGB1), F054258 (FIE36KBWHGB1), F079348 (FIM31K.ABKGB), F074217 (FIM31K.ABK-T), F079350 (FIM31K.AIXGB), F074218 (FIM31K.AIX-T), F074219 (FIM31K.AWH-T), F079349 (FIM31K.AWHGB), F079352 (FIM33K.ABKGB), F074221 (FIM33K.ABKT), F079351 (FIM33K.AIXGB), F074220 (FIM33K.AIX-T), F079353 (FIM33K.AWHGB), F074222 (FIM33K.AWHT), 02850 (FIM5UK), 02851 (FIM5UK), 08893 (FIM5UK), F002850 (FIM5UK), F002851 (FIM5UK), 02848 (FIV3UK), 02849 (FIV3UK), F002848 (FIV3UK), F002849 (FIV3UK), 28948 (FV10K.B(IX)GB), F028948 (FV10K.B(IX)GB), 28949 (FV20K.B(WH)GB), F028949 (FV20K.B(WH)GB)

WHIRLPOOL - INDESIT Kitchen electric F083508 (I6EVAWUK), F074372 (IS60EW), F081210 (IS60EWS), F075064 (IT50E1X), F081216 (IT50E1XXS), F081215 (IT50EMS), F075061 (IT50EW), F081213 (IT50EWS), F033171 (K6E32(W)-G), F033172 (K6E32(X)-G), F086903 (RIT50EWUK)

WHIRLPOOL - INDESIT Kitchen gas F088399 (IT50D1SUK), F081221 (IT50D1XXS), F081214 (IT50E(A)S), F023088 (K600V(W)-G), F029361 (K601V.C(W)-G), F028289 (K601VW-G), F025425 (K642RVS(X)-G), F024136 (K642V(G)-G), F023107 (K642VS(X)-G), F029359 (K645RV.C(X)-G), F028293 (K645RVX-G), F029360 (K645V.C(X)-G), F028291 (K645VX-G), F029358 (K647RV.C(X)-G), F028295 (K647RVX-G), F033166 (K6G32(W)-G), F033165 (K6G32(X)-G), F064077 (KD3G11S(X)-G), 00824 (KN6042WG), F000824 (KN6042WG), F005176 (KN6042WG-V), 00825 (KN6402WG), F000825 (KN6402WG), F005175 (KN6402WG-V), 01137

magazin online *HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

(KN6402WO), F001137 (KN6402WO), F004940 (KN6403WO-V), 00831 (KN6405WG), F000831 (KN6405WG), F005177 (KN6405WG-V), F004943 (KN6405XO-V)

WHIRLPOOL - INDESIT Kitchen glass-ceramics F083506 (I6VV2AWUK), F083807 (I6VV2AXEX), F083504 (I6VV2AXUK), F074367 (IS60C1W), F081207 (IS60C1WS), F074368 (IS60C1X), F081208 (IS60C1XXS), F088395 (IT50C1SUK), F081220 (IT50C1XXS), F081218 (IT50CAS), F088396 (IT50CKUK), F081219 (IT50CMS), F081217 (IT50CWS), F033168 (K6C32(W)-G), F033169 (K6C32(X)-G), F035976 (K6C320(W)-G), F062258 (K6C320(X)-AUS), F035977 (K6C320(X)-G), F054153 (KD3C1(A)-G), F078695 (KN6C320XAUS), F081255 (KN6C320XAUS)

