

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații

Automatizări / Materiale Electrice

Arzator pilot 3 flacari #3020011

Fara TVA: 58,82 Lei

Pret cu TVA: 70,00Lei

Arzator pilot 3 flacari #3020011

without sparking plug, gas jet
with pipe fitting and pilot pipe olive
with thermocouple connection
with sparking plug fitting

Compatibil cu:

ALPENINOX

ASCASO

ATA

BARON

EBERHARDT

ELECTROLUX PROFESSIONAL

EMMEPI

LINCAR INOX

OFFCAR

SILKO

TECNOINOX

WHIRLPOOL - INDESIT

ZANUSSI

EPMS

GEV 100051

EMMEPI Pasta cooker CP702B, CP704B

GIORIK Fry top FTG100, FTG46, FTG66L, GG626L, GG918

GIORIK Grill GG66

GIORIK Kitchen gas CG740F, CG760F, CG760H, CG940F, CG960F, CG960H, ECG740F, ECG760F, ECG760H,
TG720G, TG740E, TG740F, TG740G, TG76FTC, TG920G, TG920T, TG940E, TG940F, TG940G, TG940T

GIORIK Lava rock grill gas GG926

GIORIK Pasta cooker 22CPG, 23CPG, 2CPG, 3CPG, CPG1, CPG1BM, CPG22L, CPG23N, CPG2L, CPG66

OFFCAR Fry top FTG781

OFFCAR Pasta cooker 7CPG60, 8CPG90, 9CPG90, CPG730N, CPG945N

SILKO Fry top CRG7022, CRG9022, CRG9042

SILKO Lava rock grill gas CRG9022-S, CRG9042-S

ZANUSSI Bratt pan RMV/G1C (168038), RMV/G2C (168039), XMV/G1C (168438), XMV/G2C (168439), MMV/G1C

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(168838), MMV/G2C (168839), KMV/G2C (200313), KMV/E2C (200314), QMV/G2C (210313), QMV/E2C (210314), E9MFGHDIO0 (391142), E9MFEHDIO0 (391151), Z9MFGHDIO0 (392142), Z9MFEHDIO0 (392151), A9MFGHDIO0 (393142), A9MFEHDIO0 (393151)

ZANUSSI Convection oven NULL (240200), FCFG101/0 (240201), FCFG102-0 (240202), FCFG201-0 (240203), FCFG202-0 (240204), FCFG10160H (240221), NULL (240222), FCF102GMS (240224), FCF201GMS (240225), NULL (240260), FCF/G101/1 (240261), FCFG102-0T (240262), NULL (240263), FCFG101-1J (240264), FCFG102-1J (240265), FCFG101-60 (240269), FCFG20 (241200), FCFG20D (241205), FCFG20F (241210), PFCFG20 (241215), FCFG40 (241300), FCFG41 (241301), FCFG40D (241306), FCFG40F (241310), PFCFG40F (241315), FCFG20J (243210), FCFG20J (243212), FCFG40J (243218), FCFG40J (243220), FCFG20J (243234), FCFG20J (243236), FCFG41J (243238), FCFG40J (243240), ECFG201-T (260629), ECFG202-T (260644), NULL (260700), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), NULL (260722), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), FCFG201 (2FC04B), FCFG202 (2FC05B), FCF202 (2FC07B), NULL (697300), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), ACFG10160H (697311), JCF/G6-1 (697360), JCF/G101/1-1 (697361), JCF/G102/1-1 (697362), JCF/G6-2 (697390), JCF/G101/1-2 (697391), JCF/G102/1-2 (697392), NULL (697500), RCF101G (697502), RCF201G (697504), NULL (697506), RCF10GK (697508), RCFG202 (697516), FF/G20 (697730), FF/G40 (697740), NCF/G6-0 (724050), NCF/G101/1 (724051), NCF/G102/1 (724052), COCO20G (724212), 4236N (724236), ZOFCF/G20D (770347), ZCF/G6-0 (775100), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104)

ZANUSSI Fryer gas AFRG16 (169010), AFRG16W (169044), AFRG16 (169109), AFRG16W (169139)

ZANUSSI Grill ARG12FL (169012), ARG24FL (169013), ARG36FL (169014), ARG48FL (169015), ARG12FR (169016), ARG24FR (169017), ARG36FR (169018), ARG48FR (169019), ARG12FLCE (169050), ARG24FLCE (169051), ARG36FLCE (169052), ARG48FLCE (169053), ARG12FRCE (169054), ARG24FRCE (169055), ARG36FRCE (169056), ARG48FRCE (169057), ARG24FLCEP (169067), ARG36FLCEP (169068), ARG48FLCEP (169069), ARG24FRCEP (169070), ARG36FRCEP (169071), ARG48FRCEP (169072), ARG24RRCEP (169073), ARG36RRCEP (169074), ARG12FL (169111), ARG24FL (169112), ARG36FL (169113), ARG48FL (169114), ARG12FR (169115), ARG24FR (169116), ARG36FR (169117), ARG48FR (169118), ARG12FLCE (169140), ARG24FLCE (169141), ARG36FLCE (169142), ARG48FLCE (169143), ARG12FRCE (169144), ARG24FRCE (169145), ARG36FRCE (169146), ARG48FRCE (169147), ARG24FLCEP (169157), ARG36FLCEP (169158), ARG48FLCEP (169159), ARG24FRCEP (169160), ARG36FRCEP (169161), ARG48FRCEP (169162), ARG24RRCEP (169163), ARG36RRCEP (169164)

ZANUSSI Pasta cooker BCP/G1 (162320), RCP/G1S (168140), RCP/G2D (168141), XCP/G1S (168540), XCP/G2D (168541), JCP/G1S (168740), JCP/G2D (168741), MCP/G1S (168940), MCP/G2D (168941), ACPG25 (169024), ACPG25 (169123), PCP/G1S (178143), PCP/G2D (178144), OCP/G1S (178443), OCP/G2D (178444), TCP/G1S (178743), TCP/G2D (178744), NULL (200372), NULL (200373), KCP/G1 (200376), KCP/G1R (200377), KCP/G2 (200378), KCP/G2R (200379), NULL (200396), NULL (200397), QCP/G1 (210376), QCP/G1R (210377), QCP/G2 (210378), QCP/G2R (210379), WCP/G1 (220376), WCP/G1R (220377), WCP/G2 (220378), WCP/G2R (220379), DCP/G400 (224009), E7PCGD1KF0 (371090), E7PCGH2KF0 (371091), E7PCED1KF0 (371098), E7PCEH2KF0 (371099), Z7PCGD1KF0 (372090), Z7PCGH2KF0 (372091), Z7PCED1KF0 (372098), Z7PCEH2KF0 (372099),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

A7PCGD1KF0 (373090), A7PCGH2KF0 (373091), A7PCED1KF0 (373098), A7PCEH2KF0 (373099), E9PCGD1MF0 (391111), E9PCGH2MF0 (391112), E9PCED1MF0 (391126), E9PCEH2MF0 (391127), E9PCGD1MF2 (391201), E9PCGH2MF2 (391202), E9PCED1MF2 (391203), E9PCEH2MF2 (391204), Z9PCGD1MF0 (392111), Z9PCGH2MF0 (392112), Z9PCED1MF0 (392126), Z9PCEH2MF0 (392127), A9PCGD1MF0 (393111), A9PCGH2MF0 (393112), A9PCED1MF0 (393126), A9PCEH2MF0 (393127), A9PCGD1MFK (393212), A9PCGH2MFK (393213)

ZANUSSI Pot stove gas QP/G2 (210234)

ZANUSSI Solid top range KP/G2 (200234), E9GCGH3C00 (391024), Z9GCGH3C00 (392024)

