

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**
Automatizări / Materiale Electrice**Inel bicon ø12mm #3348082**

Fara TVA: 5,88 Lei

Pret cu TVA: 7,11Lei

Inel bicon ø12mm #3348082

øext.14mm h6mm

for model PEL 22-24-25

Compatibil cu:

ASCASO GAS.13, GAS353, MAC265

ATA MAC265

ATEL 10-117, 69CT005

BARON 69CT005

CAPIC 69CT005

COLGED 69CT005

COOKMAX 69CT005

DE VECCHI GIUSEPPE 8F42

DESCO 8F42

DEXION 8F42

DIHR 8F42

EBERHARDT 8F42

ELECTROLUX 8F42

ELETTROBAR 8F42

EMMEPI 8F42

EPMS 1510515

FAGOR 1510515

GEV 103435

GIORIK 103435

HOBART 103435

KROMO 103435

LAINOX 103435

LAMBER 103435

LASA 103435

LOTUS 103435, 533017900

LUXIA 103435

MACH 103435

MARENO 103435

MBM 103435



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

METOS 103435

MODULAR 103435

OLIS 103435

PALUX 103435

PEL 0906

RM GASTRO 00002836

ROSINOX 0906

SAGI 0906

SILKO 0906

SIT 0.957.007

TECNOINOX 0.957.007

ZANUSSI 0.957.007

ALPENINOX

AMBACH

AMBACH Kitchen Electric GKE-70, GPSE-80, SIE-105, SIEC-105

AMBACH Kitchen Gas GH-45-G, GH-80, GKG-70, GPSG-80, SIG-105, SIGC-105

AMBACH Lava Rock Grill GLG-70, GLG-80, GLG-90, GLG-90-BF, GRILL GAS GLG-40-CP

AMBACH Pasta Cooker CPG-40, GPK-40, GUK-45

AMBACH Pot Stove Gas GH-120, GH-40, GH-45, GH-45-H, GH-45-H-G, GH-90, GH-90-G, GH-90-H, GH-90-H-G,
GH-90IV-D, GHE-120, GHE-80, GHG-120, GHG-80, SI-105

AMBACH Solid Top GP-45, GP-90-D, GPS-80, RANGE GK-70

ANGELO PO

ANGELO PO Boiling Pan 1D1PI2VA, STEAM 1D1PI2V

ANGELO PO Boiling Pan Electric 1A1PI2EA, 1D1PI2E, 1D1PI2EA

ANGELO PO Boiling Pan Gas 1A1PD1G, 1A1PD2G, 1A1PI1G, 1A1PI1GA, 1A1PI2V, 1A1PI2VA, 1D1PD1G,
1D1PD2G, 1D1PI1G, 1D1PI1GA

ANGELO PO Bratt Pan 191BR1G, 191BR1GA, 191BR2GA, 1A1BR1E, 1A1BR1G, 1A1BR1GA, 1A1BR2E, 1A1BR2EA,
1A1BR2G, 1A1BR2GA, 1D1BR1E, 1D1BR1G, 1D1BR1GA, 1D1BR2E, 1D1BR2EA, 1D1BR2G, 1D1BR2GA,
1G1BR1G, 1N1BR2G, 1N1BR2GA, 1N1BR3G, 1N1BR3GA, 291BR1G, 291BR1GA, 291BR2G, 291BR2GA,
2A1BR1E, 2A1BR1G, 2A1BR1GA, 2A1BR2E, 2A1BR2EA, 2A1BR2G, 2A1BR2GA, 2D1BR1E, 2D1BR1G, 2D1BR1GA,
2D1BR2E, 2D1BR2EA, 2D1BR2G, 2D1BR2GA, 2N1BR2G, 2N1BR2GA, 2N1BR3G, 2N1BR3GA

ANGELO PO Convection Oven FC101, FC241G, FC61, FCV101, FCV101 CSA, FCV101DM, FCV101DM CSA,
FCV101DS, FCV101DS CSA, FCV141, FCV141 CSA, FCV141DM, FCV141DM CSA, FCV141DS, FCV141DS CSA,
FCV241G, FCV241G CSA, FCV241GDM, FCV241GDM CSA, FCV241GDS, FCV241GDS CSA, FCV401DM CSA,
FCV61, FCV61 CSA, FCV61DM, FCV61DM CSA, FCV61DS, FCV61DS CSA

ANGELO PO Fry Top 090FT1G, 090FT2G, 090FT4G, 090FT5G, 090FT7G, 0G0FT1G VERS 03-2008, 0G0FT2G
VERS 03-2008, 0G0FT4G VERS 03-2008, 0G0FT5G VERS 03-2008, 0G0FT7G, 0N0FT4G, 0N0FT5G, 0N0FT7G,
190FT15G, 190FT1G, 190FT2G, 190FT3G, 190FT42G, 190FT4G, 190FT6G, 190FT72G, 190FT7G, 1A0FT1G,
1A0FT2G, 1A0FT3G, 1A0FT4G, 1A0FT6G, 1D0FT1G, 1D0FT2G, 1D0FT3G, 1D0FT4G, 1D0FT6G, 1G0FT1G VERS



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

03-2008, 1G0FT2G VERS 03-2008, 1G0FT3G VERS 03-2008, 1G0FT4G VERS 03-2008, 1G0FT6G VERS 03-2008, 1G0FT7G, 1N0FT2G, 1N0FT4G, 1N0FT6G, 1N0FT7G, 2N0FT1G, 2N0FT7G, 6040560, 6042490, 6042500, 6043200

ANGELO PO Fryer Electric 091FR1I, 091FR1IA, 091FR1ID, 191FR2I, 191FR2ID

ANGELO PO Fryer Gas 091FR1G, 091FR1GD, 091FR1I VERS 03-2012, 091FR1ID VERS 05-2012, 091FR3G, 091FR3GD, 091FR7G, 091FR7G VERS 05-2012, 091FR7GD, 091FR7GS, 091FR7GX, 0A1FR1G VERS 2004, 0A1FR1GD VERS 2004, 0A1FR3G, 0A1FR3GD, 0B1FR1G, 0B1FR1GD, 0D1FR1G, 0D1FR1G VERS 2004, 0D1FR1GD, 0D1FR1GD VERS 2004, 0D1FR3G, 0D1FR3GD, 0G1FR3G, 0G1FR3GD, 0N1FR1G, 0N1FR1GD, 0N1FR1I, 0N1FR1IA, 0N1FR1ID, 0N1FR3G, 0N1FR3GD, 0N1FR7I, 0N1FR7IA, 0N1FR7ID, 0N1FR7IX, 191FR2G, 191FR2GD, 191FR2I VERS 03-2012, 191FR2ID VERS 09-2012, 191FR4G, 191FR4GD, 1A1FR2G, 1A1FR2G VERS 2004, 1A1FR2GD, 1A1FR2GD VERS 2004, 1A1FR4G, 1A1FR4GD, 1D1FR2G, 1D1FR2G VERS 2004, 1D1FR2GD, 1D1FR2GD VERS 2004, 1D1FR4G, 1D1FR4GD, 1G1FR4G, 1G1FR4GD, 1N1FR2G, 1N1FR2GD, 1N1FR2I, 1N1FR2ID, 1N1FR4G, 1N1FR4GD

ANGELO PO Grill 090GRG, 2N0GRG

ANGELO PO Kitchen Induction 1N1FAW

ANGELO PO Lava Rock Grill GRILL GAS 190GRG

ANGELO PO Pasta Cooker 0A1CP1E, 0A1CP1G, 0B1CP1G, 0D1CP1E, 0D1CP1G, 0N1CP1GH, 10CP1GA, 10CP1IA, 10NCP1IA, 12CP1GA, 12CP1IA, 18CP2GA, 18CP2IA, 1A1CP1G, 1A1CP2G, 1D1CP1G, 1D1CP2G, 1N1CP2GH

ANGELO PO Pot Stove Electric 1A1PI2E

ANGELO PO Pot Stove Gas 0A1FR1G, 0A1FR1GD

BARON Fryer Gas 7FRI-G415, 7FRI-G610, 7FRI-G815

BARON Kitchen Gas 7PC-G120, 7PC-G121, 7PC-G160, 7PC-G161, 7PC-G400, 7PC-G411, 7PC-G800, 7PC-G811, 7PCF-G120, 7PCF-G121, 7PCF-G160, 7PCF-G161, 7PCF-G800, 7PCF-G811, 7PCF-GE120, 7PCF-GE121, 7PCF-GE160, 7PCF-GE161, 7PCF-GE411, 7PCF-GE800, 7PCFL-G120, 7PCV-G120, 7PCV-G121, 7PCV-G160, 7PCV-G161, 7PCV-G400, 7PCV-G411, 7PCV-G800, 7PCV-G811

CAPIC Electric Oven W290251, W292966, W293061, W383061

CAPIC Grill W340912

CAPIC Pot Stove Electric W382966

CAPIC Pot Stove Gas W290211, W290215, W290225, W290235, W290245, W290255, W290511, W290515, W296513, W296523, W296533, W296543, W380111, W380112, W380121, W380122, W380131, W380132, W380141, W380142, W380151, W380152, W380161, W380162, W380211, W380221, W380231, W380241, W380251, W380261, W380511, W380521, W380531, W380541, W382511, W382551, W382552, W382561, W382562, W382611, W382651, W382652, W382661, W382662, W386513, W386523, W386533, W386543

CAPIC Solid Top RANGE W290111, W290112, W290115, W290116, W290121, W290122, W290125, W290135, W290136, W290141, W290142, W290411, W290413, W290415, W380411, W380413, W380421, W380423, W380431, W380433, W380441, W380443, W380451, W380461

DESCO Fryer Gas FRG63, FRG66

DEXION Bain-Marie Gas LX9GBM4T

DEXION Fry Top LX9GFT4, LX9GFT9, MG099-05-203, MG099-15-203



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

DEXION Fryer Gas LX9GC4SC, LX9GC4TSC, LX9GC9SC

DEXION Grill LX9GPL4P, LX9GPL9P

DEXION Kitchen Electric ME099-05-010, ME139-05-010

DEXION Kitchen Gas LX9G4SF, LX9G4SFE, LX9G6SFA, LX9GTF, LX9GTF2D, MG099-04-000, MG099-05-010, MG139-04-012, MG139-05-010, MG139-25-010

DEXION Lava Rock Grill GRILL GAS MG099-05-308

DEXION Pasta Cooker MG099-04-318, MG099-05-305, MG459-04-317, MG459-05-305

DEXION Pot Stove Gas LX9GT2DS, LX9GT2SS, LXGT9, MG099-03-200, MG099-05-200, MG139-05-200, MG459-05-200

DIHR Dishwasher 19ER (LP3 ELETTRONICA)

DIHR Dishwasher Conveyor 77 (CX), 77 (FX)

DIHR Dishwasher Pull-Through 22 (AX160), 23 (AX210), 24 (AX250), 25 (AX300), 25 (AX300LC), 26 (AX380), 26 (AX380LC), 26 (AX400), 27 (AX440), 27 (AX440LC), 28 (AX540), 28 (AX540LC), 34 (AX151), 34 (AX151HS), 34HS (AX151HS), 39 (BX280), 71 (BX230), 71G (BX230 CON SISTEMA GIRACESTE), 71G (BX230), 72 (BX300), 85 (UX220), 87 (TX1500)

DIHR Pan / Utensilwashing Machines 18ER (LP2 ELETTRONICA), 18U (LP2), 19U (LP3), 35ER (LP4/800 ELETTRONICA), 35U (LP4/800)

EMMEPI

EMMEPI Pasta Cooker ECP92EB, ECP94EB

FAGOR Bratt Pan PL-105, PL-105C, PL-105L, PL-110, PL-110C, PL-110L, PL-110L-R, PL-110R

FAGOR Convection Oven COG-061, COG-101, COG-102, COG-201, COG-202, HE9-00, HG9-00, HGP-10, HGV-10, HGV-10-21, HVG-10-11, HVG-10-11UL, HVG-10-21, HVG-10-21UL, HVG-1011, HVG-1021, HVG-10UL, HVG-2-20-11, HVG-2.10, HVG-2.10-11, HVG-2.20, HVG-20, HVG-20-11, HVG-20-21, HVG-2011, MFHVG-10, MFHVG-10-21, VG-101, VG-102, VG-201, VG-202, VGT-10, VGT-10-21, VGT-2-20-11, VGT-2.20, VGT-20, VGT-20-11, VGT-20-21, VPG-101, VPG-102, VPG-201, VPG-202

FAGOR Fry Top FTE-705, FTE-710, FTE9-05, FTE9-10, FTG-705, FTG-705V, FTG-710, FTG-710V, FTG-C9-05, FTG-C9-10, FTG9-00, FTG9-05, FTG9-05V, FTG9-10, FTG9-10A, FTG9-10V, FTG9-11, FTG9-11CL, FTG9-11CR, FTG9-11L, FTG9-11R

FAGOR Fryer Electric FTE9-00

FAGOR Grill BG710I

FAGOR Kitchen Gas CG-1002, CG-200, CG-2002, CG-200S, CG-210, CG-300, CG-300S, CG-310, CG-700, CG-711, CG-740, CG-741, CG-761, CG9-41, CG9-51CL, CG9-51CR, CG9-51L, CG9-51R, CG9-60, CG9-61, CG9-82, CGE741 (CGE-741), CGE9-41

FAGOR Lava Rock Grill BG705I, BG710, BG9-00, BG9-05, BG9-05I, BG9-10, BG9-10I, GRILL GAS BG705

FAGOR Oven Under CG-210G, CG-310G, CGB-761, COOKTOP GAS CG-1502, HG9-10, HG9-20

FAGOR Oven Under Cooktop Electric HE9-10, HE9-20

FAGOR Pasta Cooker CPG-705, CPG9-05, CPG9-10

FAGOR Pot Stove HP-G-15

FAGOR Pot Stove Gas CG-710, CG-720, CG9-10, CG9-11, CG9-20, CG9-40



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

FAGOR Stove Camp Gas HPG-15

GIORIK Pasta Cooker CP1, CP1BM, CP22L, CP23N, CP2L, CPE66, CPG1, CPG1BM, CPG22L, CPG23N, CPG2L, CPG66

HOBART Bain-Marie Gas BTGDBM, BTGSBM

HOBART Boiling Pan Gas HG50I7

HOBART Fry Top BTGDG, BTGDGC, BTGDGRG, BTGDGRGC, BTGDRG, BTGDRGC, BTGSG, BTGSLG, BTGSRG, BTGSRGC

HOBART Kitchen Gas BMG2B5TO, BMG4BO, BMG4BOE, BMG6B2O, BMG6BO, BMG6BOE, BMGSTO

HOBART Lava Rock Grill BTGDLGF, BTGSLG, BTGSLGF, GRILL GAS BTGDLG

HOBART Pasta Cooker BCGDPC, BCGSPC, BMGDPC, BMGSPC, HGC77

HOBART Pot Stove Gas BTG2B, BTG2BSTL, BTG2BSTR, BTG6B, BTGST

LAMBER Dishwasher 01F, 01F DEP, 040F, 040F DEP, 040F EK, 040F EK ADD, 040F EK DEP, 045F, 045F ADD, 045F DEP, 045F EK, 045F EK ADD, 045F EK DEP, 075F, 075F DEP, DSP4, F85, F85 DEP, F92, F92 DEP, GS350, GS581P, GS6, GS6 EK, GS800, GS900, L21 UL, L25 UL, LS415, NS455, NS455 DEP, NS456, NS456 DEP, PT1500M

LAMBER Dishwasher Conveyor A410

LAMBER Dishwasher Hood 015-24L, 015-24L DY, A240, A410 EK, DSP 5, DSP5, GS25, GS25 EK, L18, L20, L21, L21 EK, L21 EK ADD, L21 RGB, L21 RGB ADD, L24 DY PLUS, L24 EK, L25, L25 DY, L25 EK, L305 CV, L305 DY CV

LAMBER Glasswasher/Cupwasher DSP1, DSP2, DSP26, DSP26 ADD, DSP3, GS4 EK, GS400, GS45 EK, GS5 EK, GS581, MINIBAR, S200, S240, S260, S260 ADD, S260 DEP, S280, S280 ADD, S280 DEP, S280 UL, S400 EK, S400 EK ADD, S460 ADD, S460 EK, S460 EK ADD, S480 EK, S480 EK ADD, S510, S510 ADD, S510 DEP, S510 EK, S510 EK ADD, SL1, SL4, SUPER QS, SUPER QS ADD, SUPER QS DEP

LAMBER Pan / Utensilwashing Machines LP31 EK, LP31-L EK, LP38 EK, LP38-L EK, LP6 EK, LP6-L DY, LP6-L EK, LP6L, LP8 EK, LP8-L DY, LP8-L EK, P700, PT1500, PT1500 EK, PT1500-L EK, PT850, PT850 EK, PT850-L DY, PT850-L EK

LOTUS Bain-Marie Gas BM-74G, BM-78G, BM-94G, BM-98G, BMT-64G, BMT-66G, BMT-74G, BMT-78G, BMT-94G, BMT-98G

LOTUS Bratt Pan BRF-64G, BRF-74G, BRF-78G, BRF-94G, BRF-98G

LOTUS Fry Top FTTXX-610G, FTTXX-64G, FTTXX-66G, FTTXX-68G, FTTXX-712G, FTTXX-74G, FTTXX-76G, FTTXX-78G, FTTXX-94G, FTTXX-98G, FTXX-4G, FTXX-54G, FTXX-56G, FTXX-6G, FTXX-712G, FTXX-74G, FTXX-76G, FTXX-78G, FTXX-8G, FTXX-916G, FTXX-94G, FTXX-98G

LOTUS Fryer Electric FMPG-20

LOTUS Fryer Gas F11-54G, F13-64G, F13-74G, F13T-74G, F13T-94G, F18-74G, F2-13-78G, F2-13T-78G, F2-13T-98G, F2-18-78G, F2-8-74G, F2-8-94G, F2-8T-66G, F2-8T-74G, F2-8T-94G, F8T-63G, FMPG-30, FP-6G, FPG-20, FPG-30, FQ-4G, FQ-6G, FQM-4G

LOTUS Pasta Cooker CP-6G

LUXIA Dishwasher Pull-Through CT160

MACH Dishwasher MS350, MS450, MS450E, MS700, MS700E

MACH Dishwasher Hood MS1100, MS1100E, MS1100P, MS1100T, MS1300, MS1300E, MS1300P, MS1300T,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MS900, MS900E, MS900T, MS905

MACH Glasswasher/Cupwasher MB630

MACH Pan / Utensilwashing Machines MLP140, MLP60, MLP60E, MLP70, MLP80

MARENO Boiling Pan PI9-6G5

MARENO Boiling Pan Gas NPD78G8, NPD96G5, NPD98G10, NPD98G15, NPD98G15A, NPI76G5, NPI78G8, NPI96G5, NPI98G10, NPI98G14, NPI98G14A, PD7-6G5, PD9-6G5, PI7-6G5

MARENO Bratt Pan 94-10KBGI, NBR7-8EF, NBR7-8EI, NBR912EFM, NBR912GFM, NBR912GIM, NBR98GF, NBR98GFM, NBR98GI

MARENO Convection Oven NC7FE8G24, NC7FG12G44, NC7FG8G32, NC7FGM12G, NC9FG12G52, NC9FG16G72, NC9FG8G32, NC9FG8G36, NC9FG8G48

MARENO Electric Oven C7FE-12G

MARENO Fry Top FT12-9GLC, FT12-9GM, FT12C-9GL, FT12C-9GM, FT12C-9GTLC, FT12C-9GTMC, FT7-4GL, FT7-4GR, FT7-6GL, FT7-6GLC, FT7-6GM, FT7-6GMC, FT7-8GL, FT7-8GLC, FT7-8GLT, FT7-8GM, FT7-8GMC, FT7-8GMT, NFT11C9GTLC, NFT11C9GTMC, NFT74GTLC, NFT74GTLCO, NFT74GTLO, NFT74GTRC, NFT76GLC, NFT76GMC, NFT76GRC, NFT78GTL, NFT78GTLC, NFT78GTLCO, NFT78GTLO, NFT78GTM, NFT78GTMC, NFT78GTR, NFT78GTRC, NFT94GTLC, NFT94GTLO, NFT94GTRC, NFT98GTL, NFT98GTLC, NFT98GTLO, NFT98GTM, NFT98GTMC, NFT98GTR, PM12-9G

MARENO Fryer Gas F12C-4G15, F64G8, F66G8, F7-4G10, F7-4G15, F7-4G6, F7-6G10, F7-8G15, F9-4G10, F9-4G15, F9-4G6, F9-6G10, F9-8G15, F9S-4G15, F9S-8G15, FQC-61, FQG-41, NF11C4G10, NF11C9G10, NF74G10, NF74G15, NF74G8, NF76G10, NF76G8, NF78G15, NF78G15T, NF94G15, NF94G23, NF96G10, NF98G15, NF98G23, NFT74G15T, OFQG-41, OFQG-61

MARENO Grill NG94G, NG98G

MARENO Kitchen Gas C7-12G, C7-4G, C7FE-8G, C7FG-12G, C7FG-8G, C9-12G, C9-12GS, C9-4G, C9-4GP, C9-4GS, C9FE-12G, C9FE-12GS, C9FE-8G, C9FE-8GS, C9FG-12G, C9FG-12GS, C9FG-16G, C9FG-16GS, C9FG-8G, C9FG-8GP, C9FG-8GS, NC7FE12G36, NC9FG48, NS7FG12GS, NT7FG12G, NT9FG12G, T7FG-12G, T7FG-8G, T9F-4G, T9F-6GS, T9FG-12G, T9FG-8G

MARENO Oven Under BF9-12G, BF9-8G, C7FGM-12G, C9FGM-12G, COOKTOP GAS BF7-8G

MARENO Pasta Cooker NPC74G, NPC76G, NPC78G, NPC94G, NPC96G, NPC98G, PC12C-4G, PC12C-9G, PC7-4G, PC7-6G, PC7-8G, PC9-4G, PC9-6G, PC9-8G, PC9S-6G

MARENO Pot Stove Gas NC712G36, NC74G12, NC78G24, NC912G44, NC94G16, NC94G20, NC98G28, NC98G40

MARENO Solid Top NT7FG8, NT9FG8G, RANGE NS78GS, T12-9G, T7-8G, T9-8G, T9FE-4G, T9SB-4G, T9V-4G, T9V-6GS

MBM Bain-Marie Gas GBM45, GBM477, GBM49T, GBM90, GBM99T, GBMA477, GMB90

MBM Boiling Pan Gas G1008, G10098, G100I8, G100I98, G1508, G15098, G150I8, G150I98, G50I77

MBM Fry Top GFT45L, GFT45R, GFT45RC, GFT49L, GFT49R, GFT49RC, GFT90L, GFT90LR, GFT90LRC, GFT90R, GFT90RC, GFT99L, GFT99LC, GFT99LR, GFT99LRC, GFT99R, GFT99RC

MBM Kitchen Gas C4FV, C6FV, G2S, G2S9, G2SA11, G2SAP, G4S, G4SF, G4SF-1, G4SF11, G4SF9, G4SF9-2, G4SFE, G4SFE9, G4SFP, G4SFP2P, G6S, G6S9, G6SF2, G6SF29, G6SFA, G6SFA9, G6SFEA, G6SFEA9, G6SFM, G8S, G8SAP, G8SF2, G8SF2E, G8SF2P

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MBM Lava Rock Grill GPL49-P, GPL90-P, GPL99-P, GRILL GAS GPL45-P

MBM Oven Under Cooktop Electric GT2SFA, GT2SFEA

MBM Pasta Cooker GC411-SC, GC45, GC49, GC49T, GC902V, GC911-SC, GC992V, GC992VT

MBM Pot Stove Gas G4S9, G4S9-48, G4SA11, G4SAP

MBM Solid Top GT2SD, GT2SD9, GT2SDF, GT2SDFA9, GT2SS9, GT99, GTA911, GTF, GTF9, GTF911, RANGE GT

MBM-ITALIEN

MODULAR Bratt Pan 90-120-BRG, 90-120-BRGM, 90-80-BRG, 90-80-BRGM, 94 BRG M, 96 BRG M

MODULAR Convection Oven GCE10T, GCE6T, GME10T, GME10T-S, GME6T, GME6T-S

MODULAR Electric Oven 6CE6T, 6ME6T, 6ME6T-S

MODULAR Fryer Electric 90-80-FRG-22

MODULAR Fryer Gas 65-40FRG, 65-70-FRG, 90-40-FRG-13, 92-FRG-20, 92-FRG-20-S, 94-FRG-20, 94-FRG-20-S

OLIS Fry Top 110-90FTTG, 110-90FTTG1-2R, 110-90FTTGC, 110-90FTTGC1-2, 110-90FTTGCR, 110-90FTTGE, 110-90FTTGG, 110-90FTTGR, 110-90TFTTG, 110-90TFTTG1-2R, 110-90TFTTGC, 110-90TFTTGC1-2R, 110-90TFTTGCR, 110-90TFTTGR, 72-02FTG, 72-02FTG VAL, 72-02FTGC VAL, 72-02FTGR, 72-02FTGR VAL, 72-02TFTG, 72-02TFTG VAL, 72-02TFTGC VAL, 72-02TFTGR, 72-02TFTGR VAL, 74-02FTG, 74-02FTG VAL, 74-02FTG1-2R, 74-02FTG1-2R VAL, 74-02FTGC VAL, 74-02FTGR, 74-02FTGR VAL, 74-02TFTG, 74-02TFTG VAL, 74-02TFTG1-2R, 74-02TFTG1-2R VAL, 74-02TFTGC VAL, 74-02TFTGR, 74-02TFTGR VAL

OLIS Fryer Gas 55-45FRG, 55-90FRG, 72-02FRGM, 73-02FRGM, 74-02FRGM, 7FRI-G415, 7FRI-G610, 7FRI-G815

OLIS Kitchen Gas 2FX-PCF, 4FX, 4FX-PCF, 72-02CG, 72-02TCG, 74-02-2CTGG, 74-02CG, 74-02CGE, 74-02CGG, 74-02CTG, 74-02CTGE, 74-02CTGG, 74-02TCG, 74-02TCTG, 76-02-4CTGG, 76-02CG, 76-02CGE, 76-02CGEE, 76-02CGFL, 76-02CGG, 76-02CGGE, 76-02CTG, 76-02CTGG, 76-02CTGGE, 76-02TCG, 76-02TCTGG, 7PC-G120, 7PC-G121, 7PC-G160, 7PC-G161, 7PC-G400, 7PC-G411, 7PC-G800, 7PC-G811, 7PCF-G120, 7PCF-G121, 7PCF-G160, 7PCF-G161, 7PCF-G800, 7PCF-G811, 7PCF-GE120, 7PCF-GE121, 7PCF-GE160, 7PCF-GE161, 7PCF-GE411, 7PCF-GE800, 7PCFL-G120, 7PCV-G120, 7PCV-G121, 7PCV-G160, 7PCV-G161, 7PCV-G400, 7PCV-G411, 7PCV-G800, 7PCV-G811, KR

OLIS Lava Rock Grill 72-02TPLG, 74-02PLG, 74-02TPLG, 92-04PLG, 92-04TPLG, 94-04PLG, 94-04TPLG, GRILL GAS 72-02PLG

OLIS Pasta Cooker 92-04CPG, 94-04CPG, 94-10CPG, D92-10CPG

OLIS Solid Top 94-04CTGE, 94-04CTGG, 94-04CTGGSS, 94-04CTGSS, 94-04TCTG, 94-04TCTGSS, 96-04CTGDX, 96-04CTGEDX, 96-04CTGESX, 96-04CTGGDX, 96-04CTGGSX, 96-04CTGSX, 96-04TCTGDX, 96-04TCTGSX, 98-04CTG, 98-04CTGE, 98-04CTGG, 98-04TCTG, RANGE 94-04CTG

SILKO Bain-Marie Gas CMG9021, CMG9022, CMG9041, CMG9042

SILKO Bratt Pan SG74IRM, SG84CRM, SG84IRM, SG94CRM, SG94IRM

SILKO Fry Top BG82GLC, BG84GLC, BG84GMC, CGG6220, CGG6220C, CGG6220R, CGG6230, CGG6230C, CGG6230LR, CGG6240, CGG6240C, CGG6240LR, CGG9020-1, CGG9020-3, CGG9021-1, CGG9021-3, CGG9022-1, CGG9022-3, CGG9040-1, CGG9040-3, CGG9040-5, CGG9041-1, CGG9041-3, CGG9041-5, CGG9042-1, CGG9042-3, CGG9042-5

SILKO Fryer FG72115

SILKO Fryer Gas EFG92115A, FG74215

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SILKO Kitchen CTT7045L

SILKO Kitchen Gas CCG10652, CCG10652P, CCG10653, CCG10852, CCG9045-1, CCG90652-1, CCG90653-1, CCG9085-1, CCG90852-1, TG84FPS

SILKO Oven Under CCG7045, CCG7045P, CCG70652, CCG70652P, CCG90652, CCG90652P, CCG90653, COOKTOP GAS CCG7001P

SILKO Oven Under Cooktop Electric CCG70653, CCG9085, CCG90852

SILKO Pizza Oven Gas CFS9050, CFS9055

SILKO Pot Stove Gas CCG9045, CCG9045P, CG84FPS, CG86FPS, CG86HPS, CG88FPS, CTT70653, CTT70653L

SILKO Solid Top CTT7042R, CTT7045R, CTT70652, CTT70652L, CTT9045, CTT90652R, RANGE CTT1045

SIT

ZANUSSI Bain-Marie Gas 7BMG03T (172507), 7BMG07T (172508), CM/G700 (175517), HM/G400T (293100), HM/G800T (293105), HMA/G800 (293008), HMA/G800D (293043), HMA/G800NL (293064), HMS/G400 (293000), HMS/G400 (293041), HMS/G400NL (293062), HMS/G800 (293004), HMS/G800 (293063), HMS/G800D (293042), MM/G350 (162807), MM/G350F (162809), MM/G351 (162801), MM/G700 (162808), MM/G700E (162811), MM/G700F (162810), MM/G701 (162802), PMG600 (272100), PMG600D (272105), PMR/G300 (183021), PRM/G700 (183121), PRMV/G300 (193021), PRMV/G700 (193121), RM/G300 (2SM02B), RM/G300D (183010), RM/G300F (183020), RM/G300NL (183030), RM/G350D (172501), RM/G350F (172509), RM/G700 (183100), RM/G700 (2SM04B), RM/G700D (172502), RM/G700D (183110), RM/G700F (183120), RM/G700NL (183130), RMG300 (183000), RMV/G300 (193000), RMV/G300 (193010), RMV/G300 (193020), RMV/G300 (193030), RMV/G300 (2SM12B), RMV/G700 (193100), RMV/G700 (193110), RMV/G700 (193120), RMV/G700 (193130), RMV/G700 (2SM14B), T35GBM (175507), T70GBM (175508), XM/G350D (175501), XM/G350F (175509), XM/G700D (175502), XM/G700F (175510), ZHM/G400 (770536), ZHM/G400 (774200), ZHM/G800 (770537), ZHM/G800 (774201), ZHMA/G40 (770315), ZHMA/G400 (2KM01B), ZHMA/G80 (2KM03B), ZHMA/G80 (2KM05B), ZHMA/G80 (770317), ZHMA/G801D (770316), ZPM/G600 (2CM06B)

ZANUSSI Boiling Pan Gas JPD/G240 (168730), JPD/G260 (168731), JPI/G260 (168732), MPD/G240 (168930), MPD/G260 (168931), MPI/G260 (168932), RPD/G240 (168130), RPD/G260 (168131), RPI/G260 (168132), XPD/G240 (168530), XPD/G260 (168531), XPI/G260 (168532)

ZANUSSI Bratt Pan

A7BREHMNF0 (373107), A7BREHSNF0 (373108), A7BRGHDNF0 (373181), A7BRGHMNF0 (373103), A7BRGHMNF0 (373180), A7BRGHSNF0 (373104), ABR/E820 (221554), ABR/E825 (221555), ABR/G820 (221534), ABR/G825 (221535), E7BREHMNF0 (371107), E7BREHSNF0 (371108), E7BRGHDNF0 (371181), E7BRGHMNF0 (371103), E7BRGHMNF0 (371180), E7BRGHSNF0 (371104), HBR/E1003 (295033), HBR/E1003 (2KB57B), HBR/E1013 (295061), HBR/E1013 (2KB58B), HBR/E801 (295022), HBR/E801 (2KB53B), HBR/E803 (295025), HBR/E803 (2KB54B), HBR/E804 (295027), HBR/E804 (2KB55B), HBR/E805UK (295028), HBR/E820 (201554), HBR/E825 (201555), HBR/G1003 (295013), HBR/G1003 (295014), HBR/G1003 (2KB07B), HBR/G1004 (295018), HBR/G1004 (770213), HBR/G1013 (295057), HBR/G1013 (2KB08B), HBR/G803 (295003), HBR/G803 (295006), HBR/G803 (295009), HBR/G803 (295051), HBR/G803 (2KB03B), HBR/G804 (295004), HBR/G804 (295008), HBR/G804 (295052), HBR/G804 (2KB04B), HBR/G805 (295012), HBR/G820 (201534), HBR/G821UK (201574), HBR/G825 (201535), MMV/G1C (168838), MMV/G2C (168839), OBR/G2FM (178398), OBR/G2IM

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(178399), PBR/G2FM (178098), PBR/G2IM (178099), RMV/G1C (168038), RMV/G2C (168039), TBR/G2FM (178698), TBR/G2IM (178699), XMV/G1C (168438), XMV/G2C (168439), Z7BREHMNF0 (372107), Z7BREHSNF0 (372108), Z7BRGHDNF0 (372181), Z7BRGHMNF0 (372103), Z7BRGHMNF0 (372180), Z7BRGHSNF0 (372104), ZBR/E820 (211554), ZBR/E825 (211555), ZBR/G821 (211556), ZBR/G826 (211557)

ZANUSSI Convection Oven

4236N (724236), ACFG101-0 (697301), ACFG10160H (697311), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), AFCV/G101 (697621), AFCV/G103 (697631), AFCV/G201 (697641), AFCV/G203 (697651), AOS061EA (260450), AOS061EA0H (260510), AOS061EA2N (260462), AOS061EA3J (260456), AOS061EAA1 (267000), AOS061EAAQ (260600), AOS061EAB1 (267090), AOS061EABQ (260820), AOS061EABU (260165), AOS061EAC1 (267030), AOS061EACQ (260620), AOS061EAE1 (267040), AOS061EAF1 (267050), AOS061EAFU (260168), AOS061EAH1 (267010), AOS061EAHQ (260630), AOS061EAK1 (267100), AOS061EAM1 (267080), AOS061EAMQ (260810), AOS061EAN1 (267020), AOS061EANQ (260610), AOS061EAT1 (267110), AOS061EB (260451), AOS061EB0H (260511), AOS061EB2N (260463), AOS061EB3J (260457), AOS061EBA1 (268000), AOS061EBAQ (260601), AOS061EBC1 (268030), AOS061EBCQ (260621), AOS061EBE1 (268040), AOS061EBEQ (260641), AOS061EBF1 (268050), AOS061EBH1 (268010), AOS061EBHQ (260631), AOS061EBK1 (268100), AOS061EBN1 (268020), AOS061EBNQ (260611), AOS061ECA1 (269000), AOS061ECB1 (269090), AOS061ECC1 (269030), AOS061ECH1 (269010), AOS061ECM1 (269080), AOS061ECN1 (269020), AOS061GA (260550), AOS061GAU (260148), AOS061GAD1 (267510), AOS061GADL (260520), AOS061GADQ (260670), AOS061GAU (260095), AOS061GAG1 (267500), AOS061GAGQ (260660), AOS061GAI1 (267520), AOS061GAIQ (260680), AOS061GALQ (260690), AOS061GAP1 (267550), AOS061GAPQ (260870), AOS061GAU1 (267560), AOS061GB (260551), AOS061GBD1 (268510), AOS061GBDL (260521), AOS061GBDQ (260671), AOS061GBG1 (268500), AOS061GBGQ (260661), AOS061GBI1 (268520), AOS061GCD1 (269510), AOS061GCG1 (269500), AOS061GCP1 (269550), AOS062GAP1 (267551), AOS062GCP (269551), AOS101EA (260452), AOS101EA0H (260512), AOS101EA2N (260464), AOS101EA3J (260458), AOS101EAA1 (267002), AOS101EAAQ (260602), AOS101EAB1 (267092), AOS101EABQ (260822), AOS101EABU (260166), AOS101EAC1 (267032), AOS101EACQ (260622), AOS101EAE1 (267042), AOS101EAF1 (267052), AOS101EAFU (260169), AOS101EAH1 (267012), AOS101EAHQ (260632), AOS101EAK1 (267102), AOS101EAM1 (267082), AOS101EAMQ (260812), AOS101EAN1 (267022), AOS101EANQ (260612), AOS101EAQ1 (267072), AOS101EAT1 (267112), AOS101EB (260453), AOS101EB0H (260513), AOS101EB2N (260465), AOS101EB3J (260459), AOS101EBA1 (268002), AOS101EBAQ (260603), AOS101EBC1 (268032), AOS101EBCQ (260623), AOS101EBE1 (268042), AOS101EBF1 (268052), AOS101EBH1 (268012), AOS101EBHQ (260633), AOS101EBK1 (268102), AOS101EBN1 (268022), AOS101EBNQ (260613), AOS101ECA1 (269002), AOS101ECB1 (269092), AOS101ECC1 (269032), AOS101ECH1 (269012), AOS101ECM1 (269082), AOS101ECN1 (269022), AOS101GA (260552), AOS101GAU (260149), AOS101GAD1 (267512), AOS101GADL (260522), AOS101GADQ (260672), AOS101GAU (260096), AOS101GAG1 (267502), AOS101GAGQ (260662), AOS101GAI1 (267522), AOS101GAIQ (260682), AOS101GALQ (260692), AOS101GAP1 (267552), AOS101GAPQ (260872), AOS101GAU1 (267562), AOS101GB (260553), AOS101GBD1 (268512), AOS101GBDL (260523), AOS101GBDQ (260673), AOS101GBG1 (268502), AOS101GBGQ (260663), AOS101GBI1 (268522), AOS101GCD1 (269512), AOS101GCG1 (269502), AOS101GCP1 (269552), AOS102EA (260516), AOS102EA2N (260500), AOS102EAA1 (267003), AOS102EAAQ

(260604), AOS102EAB1 (267093), AOS102EABQ (260824), AOS102EAC1 (267033), AOS102EAK1 (267103), AOS102EAM1 (267083), AOS102EAMQ (260814), AOS102EANQ (260614), AOS102EAS1 (267063), AOS102EAT1 (267113), AOS102EB (260517), AOS102EB2N (260501), AOS102EBA1 (268003), AOS102EBAQ (260605), AOS102EBC1 (268033), AOS102EBK1 (268103), AOS102EBNQ (260615), AOS102ECA1 (269003), AOS102ECB1 (269093), AOS102ECM1 (269083), AOS102GA (260560), AOS102GAU (260150), AOS102GAD1 (267513), AOS102GADL (260530), AOS102GADQ (260674), AOS102GAEU (260097), AOS102GAG1 (267503), AOS102GAGQ (260664), AOS102GAP1 (267553), AOS102GAPQ (260874), AOS102GAU1 (267563), AOS102GB (260559), AOS102GBD1 (268513), AOS102GBDL (260529), AOS102GBDQ (260675), AOS102GBG1 (268503), AOS102GBGQ (260665), AOS102GCD1 (269513), AOS102GCG1 (269503), AOS102GCP1 (269553), AOS201EA (260454), AOS201EA0H (260514), AOS201EA2N (260466), AOS201EA3J (260460), AOS201EAA1 (267004), AOS201EAAQ (260606), AOS201EAB1 (267094), AOS201EABQ (260826), AOS201EABU (260167), AOS201EAC1 (267034), AOS201EACQ (260626), AOS201EAE1 (267044), AOS201EAF1 (267054), AOS201EAFU (260170), AOS201EAH1 (267014), AOS201EAHQ (260636), AOS201EAK1 (267104), AOS201EAM1 (267084), AOS201EAMQ (260816), AOS201EAN1 (267024), AOS201EANQ (260616), AOS201EAQ1 (267074), AOS201EAT1 (267114), AOS201EB (260455), AOS201EB0H (260515), AOS201EB2N (260467), AOS201EB3J (260461), AOS201EBA1 (268004), AOS201EBAQ (260607), AOS201EBC1 (268034), AOS201EBCQ (260627), AOS201EBE1 (268044), AOS201EBF1 (268054), AOS201EBH1 (268014), AOS201EBHQ (260637), AOS201EBK1 (268104), AOS201EBN1 (268024), AOS201EBNQ (260617), AOS201ECA1 (269004), AOS201ECB1 (269094), AOS201ECH1 (269014), AOS201ECM1 (269084), AOS201ECN1 (269024), AOS201GA (260554), AOS201GAU (260151), AOS201GAD1 (267514), AOS201GADQ (260676), AOS201GAEU (260098), AOS201GAG1 (267504), AOS201GAGQ (260666), AOS201GAIQ (260686), AOS201GALQ (260696), AOS201GAP1 (267554), AOS201GAPQ (260876), AOS201GAU1 (267564), AOS201GB (260555), AOS201GBD1 (268514), AOS201GBDQ (260677), AOS201GBG1 (268504), AOS201GBGQ (260667), AOS201GCD1 (269514), AOS201GCG1 (269504), AOS201GCP1 (269554), AOS202EA (260518), AOS202EA2N (260502), AOS202EAA1 (267005), AOS202EAAQ (260608), AOS202EAB1 (267095), AOS202EABU (260089), AOS202EAFU (260094), AOS202EAK1 (267105), AOS202EAM1 (267085), AOS202EANQ (260618), AOS202EAT1 (267115), AOS202EB (260519), AOS202EB2N (260503), AOS202EBA1 (268005), AOS202EBAQ (260609), AOS202EBK1 (268105), AOS202EBNQ (260619), AOS202ECA1 (269005), AOS202GA (260562), AOS202GAU (260152), AOS202GAD1 (267515), AOS202GADL (260532), AOS202GADQ (260678), AOS202GAEU (260099), AOS202GAG1 (267505), AOS202GAGQ (260668), AOS202GAP1 (267555), AOS202GAPQ (260878), AOS202GAU1 (267565), AOS202GB (260561), AOS202GBD1 (268515), AOS202GBDL (260531), AOS202GBDQ (260679), AOS202GBG1 (268505), AOS202GBGQ (260669), AOS202GCD1 (269515), AOS202GCG1 (269505), AOS202GCP1 (269555), AOW101EABU (260573), COCO20G (724212), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG201-T (260629), ECFG202-0 (260704), ECFG202-T (260644), EJJN102EAA (647003), EJJN102EBA (648003), EJJN102ECA (649003), FCF/G101/1 (240261), FCF102GMS (240224), FCF201GMS (240225), FCF202 (2FC07B), FCFG101-1J (240264), FCFG101-60 (240269), FCFG101/0 (240201), FCFG10160H (240221), FCFG102-0 (240202), FCFG102-0T (240262), FCFG102-1J (240265), FCFG20 (241200), FCFG201 (2FC04B), FCFG201-0 (240203), FCFG202 (2FC05B), FCFG202-0 (240204), FCFG20D (241205), FCFG20F (241210), FCFG20J (243210), FCFG20J (243212), FCFG20J (243234), FCFG20J (243236), FCFG40

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

(241300), FCFG40D (241306), FCFG40F (241310), FCFG40J (243218), FCFG40J (243220), FCFG40J (243240), FCFG41 (241301), FCFG41J (243238), FCVG10-2 (245402), FCVG10-2 (245412), FCVG10-2 (245482), FCVG10-2UK (245442), FCVG10-4 (245404), FCVG10-4 (245484), FCVG10-4D (245414), FCVG10-4UK (245444), FCVG10-ISG (245405), FCVG10-ISG (724350), FCVG10-P (256319), FCVG10PUK (257319), FCVG20-2 (246402), FCVG20-2 (246412), FCVG20-2UK (246442), FCVG20-4 (246404), FCVG20-4 (246482), FCVG20-4D (246414), FCVG20-4D (246484), FCVG20-4UK (246444), FCVG20-P (260319), FCVG20PUK (261319), FCVMG62 (247502), FCZ061EAA (237000), FCZ061EAH (237010), FCZ061EAN (237020), FCZ061EBA (238000), FCZ061EBC (238030), FCZ061EBH (238010), FCZ061EBN (238020), FCZ061ECA (239000), FCZ061ECH (239010), FCZ061ECN (239020), FCZ061GAD (237510), FCZ061GAG (237500), FCZ061GBD (238510), FCZ061GBG (238500), FCZ061GBI (238520), FCZ061GCD (239510), FCZ061GCG (239500), FCZ101EAA (237002), FCZ101EAH (237012), FCZ101EAN (237022), FCZ101EBA (238002), FCZ101EBC (238032), FCZ101EBH (238012), FCZ101EBN (238022), FCZ101ECA (239002), FCZ101ECH (239012), FCZ101ECN (239022), FCZ101GAD (237512), FCZ101GAG (237502), FCZ101GBD (238512), FCZ101GBG (238502), FCZ101GBI (238522), FCZ101GCD (239512), FCZ101GCG (239502), FCZ102EAA (237003), FCZ102EBA (238003), FCZ102ECA (239003), FCZ102GAD (237513), FCZ102GAG (237503), FCZ102GBD (238513), FCZ102GBG (238503), FCZ102GCD (239513), FCZ102GCG (239503), FCZ201EAA (237004), FCZ201EAH (237014), FCZ201EAN (237024), FCZ201EBA (238004), FCZ201EBC (238034), FCZ201EBH (238014), FCZ201EBN (238024), FCZ201ECA (239004), FCZ201ECH (239014), FCZ201ECN (239024), FCZ201GAD (237514), FCZ201GAG (237504), FCZ201GBD (238514), FCZ201GBG (238504), FCZ201GBI (238524), FCZ201GCD (239514), FCZ201GCG (239504), FCZ202EAA (237005), FCZ202EBA (238005), FCZ202ECA (239005), FCZ202GAD (237515), FCZ202GAG (237505), FCZ202GBD (238515), FCZ202GBG (238505), FCZ202GCD (239515), FCZ202GCG (239505), FF/G20 (697730), FF/G40 (697740), JCF/G101/1-1 (697361), JCF/G101/1-2 (697391), JCF/G102/1-1 (697362), JCF/G102/1-2 (697392), NCF/G101/1 (724051), NCF/G102/1 (724052), PFCFG20 (241215), PFCFG40F (241315), RCF101G (697502), RCF10GK (697508), RCF201G (697504), RCFG202 (697516), SCO/G10-3 (697635), SCO/G20-3 (697655), XFV/G700 (176502), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104), ZOFCF/G20D (770347), ZOFCV/G102 (2FM16B), ZOFCV/G104 (2FM18B), ZOFCV/G202 (2FM26B), ZOFCV/G204 (2FM28B)

ZANUSSI Dishwasher 652120Z (5CF10B), ALLS520 (690210), ALLS521 (690208), ALS510 (690212), ALS540 (690206), C51 (727116), C52 (727120), LS360 (500120), LS360 (5CF05B), LS360/63 (500130), LS360D (500110), LS360DK (500043), LS360F (500042), LS365 (500053), LS365 (500121), LS365/63 (500131), LS365D (500111), LS365F (500052), LS365F (5CF06B), LS365PH (500054), LS367 (500145), LS510 (501010), LS510MZ (777202), LS520 (501020), LS520D (501021), LS520F (501022), LS520K (501029), LS520M (501028), LS520MZ (777203), LS520ZD (770400), LS521 (501030), LS521 (501045), LS521D (501031), LS521F (501032), LS521K (501039), LS521M (501038), LS521MZ (777204), LS521ZD (770401), LS540 (500484), LS540 (5CF09B), LS540/63 (500635), LS540D (500615), LS540DK (500083), LS540F (500082), LS541 (500800), LS541F (500092), LS720N (727122), LSDS51 (500585), LSDS5V (500590), LSE720Z (770403), ZA/E71DXUK (523141), ZA/E71SXUK (523144), ZA/V71DX (523146), ZA/V71SX (523148), ZAE71D (523140), ZAE71S (523143), ZLS510 (5CF50B), ZLS520 (5CF51B), ZLS521 (5CF52B)

ZANUSSI Dishwasher Hood HT1000ELM (698021), HT1200ELM (698020), HYDRA1000 (727021), HYDRA1200

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

(727020), LC100 (504003), LC120 (504023), LS10 (504001), LS1080 (500488), LS1080 (5CF12B), LS1080 (770405), LS1080 (777408), LS1080/63 (500493), LS1080D (500489), LS1080F (500342), LS1080M (500487), LS1080PH (500344), LS1080UK (500343), LS1080UK (500492), LS10D (504000), LS10F (504008), LS10UKRP (504002), LS12 (504021), LS12D (504020), LS12F (504028), LS12UK/RP (504022), LS720 (500706), LS720F (500322), LS721UK (500711), LS860 (500847), LS860 (500848), LS860 (5CF11B), LS860 (770404), LS860 (777407), LS860/63 (500854), LS860D (500849), LS860DK (500333), LS860F (500332), LS860PH (500334), LS860UK (500852), LS861 (500855), LS861F (500362), LS861UK (500853), LSCE10 (777410), LSCE12 (777420), LSE720D (500715), LSE720DK (500323), LSE720PH (500324), LSE720UK (500710), LSE721 (500705), LSE721F (500352)

ZANUSSI Dishwasher Pull-Through CT140EDX (504181), CT140EDXUK (504184), CT140EDXZ (5CT10B), CT140ESX (504182), CT140ESXZ (5CT11B), CT140SXEU (504185), CT140VDX (504281), CT140VDXZ (5CT12B), CT140VSX (504282), CT141EDUK (505184), CT141EDX (505181), CT141EDXZ (5CT14B), CT141ESUK (505185), CT141ESX (505182), CT141ESXZ (5CT15B), CT141VDX (505281), CT141VDXZ (5CT16B), CT141VSX (505282), CT141VSXZ (5CT13B), CT141VSXZ (5CT17B), CT142DXE (506181), CT142DXEU (506184), CT142DXEZ (5CT21B), CT142DXV (506281), CT142DXVZ (5CT23B), CT142SXE (506182), CT142SXEU (506185), CT142SXEZ (5CT22B), CT142SXV (506282), CT142SXVZ (5CT24B), CT190DXE (507181), CT190DXEU (507184), CT190DXEZ (5CT25B), CT190DXV (507281), CT190DXV (5CT27B), CT190SXE (507182), CT190SXEU (507185), CT190SXEZ (5CT26B), CT190SXV (507282), CT190SXV (5CT28B), CT191DXE (508181), CT191DXE (508184), CT191DXE (5CT29B), CT191DXV (508281), CT191DXV (5CT31B), CT191SXE (508182), CT191SXE (5CT30B), CT191SXEU (508185), CT191SXV (508282), CT191SXV (5CT32B), CT192DXE (509181), CT192DXE (5CT41B), CT192DXEU (509184), CT192DXV (509281), CT192DXV (5CT43B), CT192SXE (509182), CT192SXE (5CT42B), CT192SXEU (509185), CT192SXV (509282), CT192SXV (5CT44B), CT240DXE (510181), CT240DXE (5CT45B), CT240DXEU (510184), CT240DXV (510281), CT240DXV (5CT47B), CT240SX (510185), CT240SXE (510182), CT240SXE (5CT46B), CT240SXV (5CT48B), CT240SXVUK (510282), CT241DXE (511181), CT241DXE (5CT49B), CT241DXEU (511184), CT241DXV (511281), CT241DXV (5CT51B), CT241SXE (511182), CT241SXE (5CT50B), CT241SXEU (511185), CT241SXV (511282), CT241SXV (5CT52B), CT92DXE (503181), CT92DXEU (503184), CT92DXV (503281), CT92DXVUK (503284), CT92EDXZ (5CT01B), CT92ESXZ (5CT02B), CT92SXE (503182), CT92SXEU (503185), CT92SXV (503282), CT92SXVUK (503285), CT92VDXZ (5CT03B), CT92VSXZ (5CT04B)

ZANUSSI Fry Top 7FTGF3L (171262), 7FTGF3R (171265), 7FTGF7L (171267), CR/G720 (174290), HR/G401T (292480), HR/G411T (292481), HR/G801T (292482), HR/G811T (292483), HRA/G401D (770321), HRA/G411D (770322), HRA/G801D (770323), HRA/G811D (770324), HRS/G401 (292200), HRS/G401 (292202), HRS/G401F (292203), HRS/G411 (292220), HRS/G411 (292222), HRS/G411 (292223), HRS/G801 (292240), HRS/G801 (292242), HRS/G801 (292245), HRS/G811 (292260), HRS/G811 (292262), KRF/GT2R (200201), KRF/GT2RP (200224), MBHAGBDDPO (588667), MBHBGBHDPO (588668), MBHCBDDPO (588671), MBHDBGBHDPO (588672), MBHFBGBHDPO (588676), MBHMBBDDPO (588532), MBHMBBHOPO (588533), MBHNBDDPO (588536), MBHNBBOPO (588537), MBHOBBOPO (588541), MCHAEADDPO (589536), MCHAEADDPO (589537), MCHAFADDPO (589556), MCHAFBDDPO (589557), MCHBEADDPO (589538), MCHBEBDDPO (589539), MCHBFAHDPO (589558), MCHBFBHDPO (589559), MCHCEADDPO (589544), MCHCEBDDPO (589545),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MCHCFADDPO (589564), MCHCFBDDPO (589565), MCHDEAHDPO (589546), MCHDEBHDPO (589547), MCHDFAHDPO (589566), MCHDFBHDPO (589567), MCHFEAHDPO (589550), MCHFEBHDPO (589551), MCHFFAHDPO (589570), MCHFFBHDPO (589571), MCHMAADOPO (589092), MCHMAAHOPO (589094), MCHMABDOPO (589093), MCHMABHOPO (589095), MCHNAADOPO (589100), MCHNAAHOPO (589102), MCHNABDOPO (589101), MCHNABHOPO (589103), MCHOAAHOPO (589110), MCHOABHOPO (589111), MR/G350 (161312), MR/G350E (161315), MR/G350F (161313), MR/G350NL (161314), MR/G351 (161308), MR/G360 (161316), MR/G360F (161317), MR/G361 (161334), MR/G700 (161318), MR/G700E (161321), MR/G700F (161319), MR/G700NL (161320), MR/G701 (161309), MR/G710 (161322), MR/G710F (161323), MR/G711 (161335), MR/G715 (161326), MR/G716 (161336), QRF/GT2R (210201), QRF/GT2RP (210224), RR/G350D (171260), RR/G350F (171275), RR/G360F (171266), RR/G700D (171261), RR/G700F (171276), RR/G710 (171269), RR/G710F (171270), RR/G716 (171281), RRV/G300 (191000), RRV/G300 (191030), RRV/G300 (2ST12B), RRV/G300 (2ST13B), RRV/G300D (191010), RRV/G311 (191300), RRV/G700 (191200), RRV/G700 (191210), RRV/G700 (191230), RRV/G700 (2ST14B), RRV/G700 (2ST15B), RRV/G711 (191400), T35GFT (174262), T36GFT (174264), T70GFT (174266), T70GFT (174268), WRF/GT2R (220201), WRF/GT2RP (220224), XR/G350D (174258), XR/G350F (174263), XR/G350NL (174274), XR/G360F (174265), XR/G700D (174259), XR/G700F (174267), XR/G700NL (174275), XR/G710F (174269), ZHR/G401T (770540), ZHR/G401T (770541), ZHR/G801D (774101), ZHR/G801T (770542), ZHR/G811T (770543), ZHRA/G411 (2KT02B), ZHRA/G801 (2KT03B), ZHRA/G811 (2KT04B), ZHRS/G401 (2KT01B)

ZANUSSI Fryer A7FRGD1GFK (373229), A7FRGH2GFK (373230), E9FRGD1J4E (391287), E9FRGD1J4O (391288), E9FRGD1J4P (391289)

ZANUSSI Fryer Electric A9FRED1JFE (393091), A9FRED1JFO (393092), A9FRED1JFP (393093), AFH/E435 (221051), E9FRED1JFE (391091), E9FRED1JFO (391092), E9FRED1JFP (391093), HFH/E430 (201039), HFH/G435 (201051), KFH/E1 (200352), KFH/E1EH (200356), KFH/E1ELH (200354), MBFGGBDDAO (588685), QFH/E1 (210352), QFH/E1ELH (210354), QFH/E1H (210356), WFH/E1 (220352), WFH/E1EH (220356), WFH/E1ELH (220354), Z9FRED1JFE (392091), Z9FRED1JFO (392092), Z9FRED1JFP (392093), ZFH/E430 (211039), ZFH/G435 (211051)

ZANUSSI Fryer Gas 7FRG03T (171540), A7FRGD1B00 (373066), A7FRGD1GF0 (373070), A7FRGH2B00 (373067), A7FRGH2GF0 (373071), A9FRGD1GF0 (393077), A9FRGD1JF0 (393079), A9FRGD1JFE (393081), A9FRGD1JFK (393210), A9FRGD1JFO (393082), A9FRGD1JFP (393083), A9FRGD1JFT (393084), A9FRGH2GF0 (393078), A9FRGH2JF0 (393080), A9FRGH2JFK (393211), AFH/G435 (221050), AFR/G430 (221040), AFR/G830 (221041), AFRS/G430 (221052), BF/G1S07 (162304), BFR/G1S14 (162305), CFR/G351 (174931), CFR/G381 (174539), CFR/G700 (174933), E7FRGD1B00 (371066), E7FRGD1BF0 (371068), E7FRGD1GF0 (371070), E7FRGH2B00 (371067), E7FRGH2BF0 (371069), E7FRGH2GF0 (371071), E9FRGD1GF0 (391077), E9FRGD1JF0 (391079), E9FRGD1JFE (391081), E9FRGD1JFO (391082), E9FRGD1JFP (391083), E9FRGD1JFT (391084), E9FRGH2GF0 (391078), E9FRGH2JF0 (391080), HFH/G400U (201046), HFH/G401U (201047), HFH/G430 (201038), HFH/G435 (201050), HFR/G430 (201040), HFR/G830 (201041), HFRS/G430 (201052), JF/G1S07 (168645), JF/G1S07 (168786), JF/G2D07 (168646), JF/G2D07 (168787), JFR/G1S07 (168647), JFR/G1S14 (168662), JFR/G2D07 (168648), JFR/G2D07 (168788), JFR/G2D07 (168789), JFR/G2D14 (168663), KFH/G1 (200351), KFH/G1EH (200355), KFH/G1ELH (200353), KFR/G1A (200336), KFR/G1E (200340), KFR/G1T

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**
Automatizări / Materiale Electrice

(200361), KFR/G2B (200337), KFR/G2F (200341), M35GFR (174501), M70GFR (174502), MBFDGBEDPO (588632), MBFHGBDDPO (588687), MCFDEAEDPO (589302), MCFDEBEDPO (589303), MCFDFAEDPO (589459), MCFDFBEDPO (589460), MCFHEADDPO (589504), MCFHEBDDPO (589505), MCFHFADDPO (589506), MCFHFBDDPO (589507), MF/G1S07 (168845), MF/G1S07 (168986), MF/G2D07 (168846), MF/G2D07 (168987), MFR/G1S07 (168847), MFR/G1S07 (168988), MFR/G1S14 (168862), MFR/G2D07 (168848), MFR/G2D07 (168989), MFR/G2D14 (168863), MFR/G350 (161901), MFR/G350D (161906), MFR/G350E (161914), MFR/G350F (161912), MFR/G380 (161939), MFR/G381 (161940), MFR/G700 (161902), MFR/G700D (161907), MFR/G700E (161915), MFR/G700F (161913), OF/G1S07 (178410), OFR/G1S07 (178412), OFR/G1S14 (178414), OFR/G2D07 (178413), OFR/G2D14 (178415), PF/G1S07 (178110), PF/G2D07 (178111), PFR/G1S07 (178112), PFR/G1S14 (178114), PFR/G2D07 (178113), PFR/G2D14 (178115), PFRG1S14HV (178198), PFRG2D14HV (178191), QFH/G1 (210351), QFH/G1EH (210355), QFH/G1ELH (210353), QFR/G1A (210336), QFR/G1E (210340), QFR/G1T (210361), QFR/G2B (210337), QFR/G2F (210341), RF/G1S07 (168045), RF/G1S07 (168186), RF/G2D07 (168046), RF/G2D07 (168187), RFR/G1S07 (168047), RFR/G1S07 (168188), RFR/G1S14 (168062), RFR/G2D07 (168048), RFR/G2D07 (168189), RFR/G2D14 (168063), RFR/G301 (196001), RFR/G301 (196022), RFR/G301 (2SF12B), RFR/G350 (171501), RFR/G350D (171506), RFR/G350F (171512), RFR/G700 (171502), RFR/G700D (171507), RFR/G700F (171513), RFR/G701 (196101), RFR/G701 (2SF14B), RFR/G701F (196122), T35GFR (174540), TF/G1S07 (178710), TF/G2D07 (178711), TFR/G1S07 (178712), TFR/G1S14 (178714), TFR/G2D07 (178713), TFR/G2D14 (178715), WFH/G1 (220351), WFH/G1EH (220355), WFH/G1ELH (220353), WFR/G1A (220336), WFR/G1E (220340), WFR/G1T (220361), WFR/G2B (220337), WFR/G2F (220341), XF/G1S07 (168445), XF/G1S07 (168586), XF/G2D07 (168587), XFR/G1S07 (168447), XFR/G1S07 (168588), XFR/G1S14 (168462), XFR/G2D07 (168448), XFR/G2D14 (168463), XFR/G2D07 (168589), XFR/G350D (174506), XFR/G350F (174512), XFR/G351 (174517), XFR/G700D (174507), XFR/G700F (174513), XFR/G2D07 (168446), Z7FRGD1B00 (372066), Z7FRGD1BF0 (372068), Z7FRGD1GF0 (372070), Z7FRGH2B00 (372067), Z7FRGH2BF0 (372069), Z7FRGH2GF0 (372071), Z7FRGH2GFH (372159), Z9FRGD1GF0 (392077), Z9FRGD1JF0 (392079), Z9FRGD1JFE (392081), Z9FRGD1JFO (392082), Z9FRGD1JFP (392083), Z9FRGD1JFT (392084), Z9FRGH2GF0 (392078), Z9FRGH2JF0 (392080), ZFH/G430 (211038), ZFH/G435 (211050), ZFR/G430 (211040), ZFR/G830 (211041), ZFRS/G430 (211052)

ZANUSSI Grill 7GLG03 (173257), 7GLG07 (173261), 7GLG10 (173265), A9GREDGCF0 (393075), A9GREHGCFO (393076), A9GRGDGCF0 (393063), A9GRGHGCF0 (393064), AGG12 (169020), AGG12 (169119), AGG12CE (169058), AGG12CE (169148), AGG24 (169021), AGG24 (169120), AGG24CE (169059), AGG24CE (169149), AGG36 (169022), AGG36 (169121), AGG36CE (169060), AGG36CE (169150), AGG48 (169023), AGG48 (169122), AGG48CE (169061), AGG48CE (169151), E7GRGDGCOP (371042), E7GRGHGCOP (371043), E9GREDGCF0 (391075), E9GREHGCFO (391076), E9GRGDGCOP (391219), E9GRGDGCFO (391063), E9GRGHGCOP (391065), E9GRGHGCFO (391064), E9GRGLGCOP (391066), E9GRTDGCOP (391186), E9GRTDGCFO (391197), E9GRTHGCOP (391187), E9GRTHGCFO (391198), E9GRTLGCOP (391188), KGR/E1 (200243), KGR/E2 (200244), KGR/G1 (200241), KGR/G2 (200242), KGR/T1 (200249), KGR/T2 (200250), MG/G1050 (163715), MG/G1050F (163716), MG/G1051 (163721), MG/G350 (163707), MG/G350D (163705), MG/G350E (163708), MG/G350F (163709), MG/G350NL (163710), MG/G700 (163711), MG/G700D (163706), MG/G700E (163712), MG/G700F (163713), MG/G700NL (163714), PRG/G1000 (182221), PRG/G300 (182021),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

PRG/G700 (182121), PRGV/G100 (192221), PRGV/G300 (192021), PRGV/G700 (192121), QGR/E1 (210243), QGR/E2 (210244), QGR/G1 (210241), QGR/G2 (210242), QGR/T1 (210249), QGR/T2 (210250), RG/G1000 (182220), RG/G1000 (2SG06B), RG/G300 (182000), RG/G300 (2SG02B), RG/G300F (182020), RG/G300N (182031), RG/G310D (182011), RG/G350D (173255), RG/G700 (182100), RG/G700 (2SG04B), RG/G700D (173256), RG/G700F (182120), RG/G700N (182131), RG/G710D (182111), RGG1000 (182200), RGV/G1000 (192200), RGV/G1000 (192220), RGV/G1000 (2SG16B), RGV/G300 (192000), RGV/G300 (192020), RGV/G300 (192031), RGV/G300 (2SG12B), RGV/G310 (192011), RGV/G700 (192100), RGV/G700 (192120), RGV/G700 (192131), RGV/G700 (2SG14B), RGV/G701D (192111), WGR/E1 (220243), WGR/E2 (220244), WGR/G1 (220241), WGR/G2 (220242), Z7GRGDGC0P (372042), Z7GRGHGC0P (372043), Z9GREDGCF0 (392075), Z9GREHGC0P (392076), Z9GRGDGC0P (392219), Z9GRGDGC0P (392063), Z9GRGHGC0P (392065), Z9GRGHGC0P (392064), Z9GRGLGC0P (392066), Z9GRTDGC0P (392186), Z9GRTDGC0P (392197), Z9GRTHGC0P (392187), Z9GRTHGC0P (392198)

ZANUSSI Hot Cupboard Gas HTF/G1210 (298101), HTF/G1210 (298102), HTF/G1210 (770320), ZHTF/G121 (2KS08B)

ZANUSSI Kitchen A7GCGI6CLA (373216), A7GCGI6CLG (373173), E9GCGHTCEA (391261), E9GCGHTCGA (391259), E9GCGHTCGB (391260), E9GCGLTC1A (391262), E9GCGLTC1B (391263), E9GCGP8CGA (391272), O7GCGH4CG0 (373219), Z7GCGI6CLA (372216), Z9GCGHTCEA (392261), Z9GCGHTCGA (392259), Z9GCGHTCGB (392260), Z9GCGLTC1A (392262), Z9GCGLTC1B (392263), Z9GCGP8SGA (392272)

ZANUSSI Kitchen Electric E7GCGH4CEA (371169), E7GCGH4CGA (371168), E7GCGI6CLA (371216), E7GCGI6CLG (371173), E7GCGL6C1A (371171), E7GCGL6C2A (371172)

ZANUSSI Kitchen Gas A7GCGH4CE0 (373003), A7GCGH4CEN (373125), A7GCGH4CG0 (373002), A7GCGL6C10 (373005), A9GCGH4CE0 (393010), A9GCGH4CG0 (393005), A9GCGH4CGM (393006), A9GCGL6C10 (393013), A9GCGP8CG0 (393017), ACF/G1210 (220031), ACF/G1610 (220033), ACF/G810 (220002), ACF/G810D (220008), ACF/G810NL (220013), BCF/G2 (162301), E7GCGH4CE0 (371003), E7GCGH4CEN (371125), E7GCGH4CG0 (371002), E7GCGI6CL0 (371215), E7GCGL6C10 (371005), E7GCGL6C20 (371006), E9GCGH4CE0 (391010), E9GCGH4CEN (391164), E9GCGH4CG0 (391005), E9GCGH4CGL (391004), E9GCGH4CGM (391006), E9GCGL6C10 (391013), E9GCGL6C1M (391014), E9GCGL6CL0 (391015), E9GCGL6CLM (391016), E9GCGP8CG0 (391017), E9GCTH4CEM (391195), HCF/G1200U (200078), HCF/G1210 (200031), HCF/G1210 (200068), HCF/G1210D (200009), HCF/G1600U (200079), HCF/G1610 (200033), HCF/G1610 (200069), HCF/G1610D (200010), HCF/G800F (290013), HCF/G800U (200077), HCF/G810 (200002), HCF/G810 (200067), HCF/G810D (200008), HCF/G810D (290127), HCF/G810NL (200013), HCF/G811 (200070), HCF/G810 (290120), KCF/G2 (200102), KCF/G2G (200152), KCF/G2H (200121), KCF/G2HG (200157), KCF/G2L (200148), KCF/G2LG (200164), KCF/G3 (200104), KCF/G3A (200143), KCF/G3AG (200161), KCF/G3G (200154), KCF/G3H (200145), KCF/G3HG (200162), KCF/G4 (200105), KCF/G4G (200155), KCF/T2 (200116), KCF/T3 (200117), KCF/T4 (200118), MCF/G1090 (161059), MCF/G1095 (161071), OCF/G1210 (220061), OCF/G1610 (220060), OCF/G2 (178304), OCF/G3 (178305), OCF/G840 (220055), OCF/G9UK (178309), OCV/G2 (178302), PCF/G2 (178004), PCF/G2A (178209), PCF/G2HV (178195), PCF/G3 (178005), PCF/G3A (178210), PCF/G3HV (178192), PCF/G9 (178006), PCG1200NL (272065), PCG1210 (272041), PCG1210D (272061), PCG1210F (272044), PCG1600NL (272066), PCG1610 (272042), PCG1610D (272062), PCG1610F (272045), PCG800NL (272064), PCG810 (272040),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

PCG810D (272060), PCG810F (272043), PCSG1210 (272141), PCSG1610 (272142), PCSG810 (272140), PCV/G2 (178002), PCV/G2A (178207), PCV/G2HV (178190), PCV/G3 (178003), PCV/G3A (178208), PCV/G3HV (178194), PHCF/G800 (290014), QCF/G2 (210102), QCF/G2H (210121), QCF/G3 (210104), QCF/G4 (210105), QCF/T2 (210116), QCF/T3 (210117), QCF/T4 (210118), TCF/G2 (178604), TCF/G2A (178809), TCF/G3 (178605), TCF/G3A (178810), TCF/G9 (178606), TCF/G9UK (178609), TCV/G2 (178602), TCV/G2A (178807), TCV/G3 (178603), TCV/G3A (178808), WCF/G2 (220102), WCF/G2H (220121), WCF/G3 (220104), WCF/G4 (220105), Z7GCGH4CE0 (372003), Z7GCGH4CEA (372149), Z7GCGH4CEN (372125), Z7GCGH4CG0 (372002), Z7GCGH4CGA (372148), Z7GCGH4CGH (372155), Z7GCGI6CLG (372173), Z7GCGL6C10 (372005), Z7GCGL6C1A (372151), Z7GCGL6C1H (372157), Z7GCGL6C20 (372006), Z7GCGL6C2A (372152), Z9GCGH4CE0 (392032), Z9GCGH4CEN (392164), Z9GCGH4CG0 (392030), Z9GCGH4CGL (392029), Z9GCGH4CGM (392031), Z9GCGH4SE0 (392010), Z9GCGH4SG0 (392005), Z9GCGH4SGL (392004), Z9GCGH4SGM (392006), Z9GCGL6C10 (392035), Z9GCGL6C1M (392036), Z9GCGL6CL0 (392037), Z9GCGL6S10 (392013), Z9GCGL6S1M (392014), Z9GCGL6SL0 (392015), Z9GCGP8CG0 (392038), Z9GCGP8SG0 (392017), Z9GCTH4YEM (392195), ZCF/G1210 (210031), ZCF/G1210 (210068), ZCF/G1210D (210009), ZCF/G1610 (210033), ZCF/G1610 (210069), ZCF/G810 (210002), ZCF/G810 (210067), ZCF/G810D (210008), ZCF/G811 (210070), ZHCFG1610D (210010), ZPC/G1210 (2CC04B), ZPC/G1610 (2CC06B), ZPC/G810 (2CC02B) ZANUSSI Lava Rock Grill AG/G400 (224501), AG/G800 (224502), CG/G701 (176272), GRILL GAS RG/G350F (173259), HG/G400 (204501), HG/G800 (204502), RG/G1050 (173266), RG/G700F (173263), T105GCG (176265), T35GCG (176257), T70GCG (176261), XG/G1050F (176266), XG/G350D (176255), XG/G350E (176258), XG/G350F (176259), XG/G350NL (176260), XG/G700D (176256), XG/G700E (176262), XG/G700F (176263), XG/G700NL (176264), ZG/G400 (214501), ZG/G800 (214502)

ZANUSSI Microwave Oven AOW101EA (260153)

ZANUSSI Neutral Counter AFS/G800 (225001), HFS/G800 (205001), ZFS/G800 (215001)

ZANUSSI Oven Under COOKTOP GAS HCF/G1610 (770310)

ZANUSSI Pan / Utensilwashing Machines LO/E250 (557100), LO/E250UK (557125), LO/E480 (556100), LO250E/63 (557130), LO480E/63 (556130), LO480EUK (556125), LO480V/63-60HZ (556230), LO480VAPORESTD (556200), LO480Z-VAPORE (5LP06B), LOPE25 (5LP02B), LOPE48 (5LP04B), PLO250E (557115), PLO480/E (556115), PLO480V (556215)

ZANUSSI Pasta Cooker 7CPE07P (173001), 7CPG07P (173002), ACP/E400 (224013), ACP/E410 (224014), ACP/E800 (224015), ACP/E810 (224016), ACP/G400 (224005), ACP/G410 (224006), ACP/G800 (224007), ACP/G810 (224008), ACPS/E400 (224027), ACPS/E410 (224028), ACPS/G400 (224025), AKAROA0000 (582379), AKAROA000C (599612), AKAROF0000 (582380), AKAROFU00C (599611), CCP/E700 (176010), CCP/G700 (176009), CPG2000Z (163999), DKAROE0000 (591501), EKAROE0000 (591511), EKAROM0000 (580512), HCP/E400 (204013), HCP/E400 (295564), HCP/E401 (295565), HCP/E410 (204014), HCP/E800 (204015), HCP/E800 (295554), HCP/E800 (774440), HCP/E801 (295555), HCP/E810 (204016), HCP/G400 (204005), HCP/G400 (291514), HCP/G400U (204032), HCP/G401 (291515), HCP/G410 (204006), HCP/G410D (204002), HCP/G800 (204007), HCP/G800 (291504), HCP/G800U (204033), HCP/G801 (291505), HCP/G810 (204008), HCPS/E400 (204027), HCPS/E410 (204028), HCPS/G400 (204025), JCP/G1S (168740), JCP/G2D (168741), M70EPC (176001), M70GPC (176002), M70GPC (176003), MBKDG BDDPO (588626), MBKDG BDDVO

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

(593117), MCKDEADDPO (589473), MCKDEBDDPO (589474), MCKDFADDPO (589477), MCKDFBDDPO (589478), MCKFEADDPO (589294), MCKFEADDVO (593340), MCKFEBDDPO (589295), MCKFEBDDVO (593341), MCKFFADDPO (589451), MCKFFBDDPO (589452), MCP/E700 (163401), MCP/E700D (163403), MCP/G1S (168940), MCP/G2D (168941), MCP/G700 (163402), MCP/G701 (163404), MCP/G705 (163407), MCP/G706 (163408), MCP/G710 (163405), MCP/G711 (163406), RCP/E700 (775220), RCP/G1S (168140), RCP/G2D (168141), RCP/G700 (195500), RCP/G700 (775200), RCP/G701 (173003), RCP/G706 (173004), RCPE700 (195550), UKDROEOOOO (580936), UKDROEOOOQ (580938), XCP/G1S (168540), XCP/G2D (168541), XCP/G706 (176004), ZCP/E400 (214013), ZCP/E410 (214014), ZCP/E800 (214015), ZCP/E810 (214016), ZCP/G400 (214005), ZCP/G410 (214006), ZCP/G800 (214007), ZCP/G810 (214008), ZCPS/E400 (214027), ZCPS/E410 (214028), ZCPS/G400 (214025), ZHCP/E400 (774430), ZHCP/E401 (774435), ZHCP/E800 (770440), ZHCP/E801 (774445), ZHCP/G400 (774400), ZHCP/G401 (774405), ZHCP/G800 (774410), ZHCP/G801 (774415)

ZANUSSI Pot Stove Gas E9STGH10GA (391264), E9STGLT01A (391265), HC/G1211 (200073), HC/G1211 (210073), HC/G400 (770530), HC/G410 (290350), HC/G411 (200071), HC/G800 (770531), HC/G810 (290355), HC/G811 (200072), HCA/G410 (2KC02B), HCA/G410 (774000), HCA/G410D (770306), HCA/G810 (2KC04B), HCA/G810 (2KC06B), HCA/G810 (770307), HCA/G810 (770308), HCA/G810 (774001), HCF/G1200 (290230), HCF/G1200D (290238), HCF/G1200F (290232), HCF/G1200N (290235), HCF/G1210 (2KC08B), HCF/G1210 (770309), HCF/G1210D (290227), HCF/G1600 (290330), HCF/G1600D (290338), HCF/G1600F (290332), HCF/G1600N (290335), HCF/G1610D (290327), HCF/G800 (290140), HCF/G800DK (290148), HCF/G800NL (290145), HCF/GE80 (290150), HCF/GE80 (290152), HCF/GE81 (290130), HCF/GE81 (290136), HCF/GE81 (290137), HCF/GE81 (2KC12B), HCF/GE81 (770211), HCF/GE81 (774010), HCFG1210 (290220), HCFG1610 (290320), HCS/G400 (290010), HCS/G400DK (290018), HCS/G400F (290012), HCS/G400NL (290015), HCS/G410D (290007), HCS/G800 (290110), HCS/G800 (290113), HCS/G800DK (290118), HCS/G800F (290112), HCS/G800NL (290115), HCS/G810D (290107), HCSG410 (290000), HCSG810 (290100), HI/G400 (200047), HI/G400N (200056), HI/G800 (200048), HI/G800N (200057), KCF/G3HA (200149), PHCF/G1200 (290233), PHCF/G1600 (290333), PHCF/GE8 (290153), PHCS/G400 (290011), QCF/G2L (210148), QCF/G3A (210143), QCF/G3H (210145), QCF/G3HA (210149), Z7GCGI6CL0 (372215), Z9GCGI6SLM (392016), Z9STGLT01A (392265), ZC/G411 (210071), ZC/G811 (210072), ZHCF/G161 (2KC10B)

ZANUSSI Potato Heater RM/G700F (172510)

ZANUSSI Solid Top 7TPG07F (172255), 7TPG07T (172254), 7TPG10F (172257), A7STGH1000 (373007), A7STGH10G0 (373008), A7STGH3000 (373011), A7STGH30G0 (373009), A7STGL3010 (373010), A9STGH1000 (393018), A9STGH10G0 (393019), A9STGL3010 (393021), AT/G800 (222502), AT/G800D (222517), AT/G800NL (222524), ATF/G1210 (222522), ATF/G1210D (222523), ATF/G800D (222519), ATF/G800NL (222525), ATF/G810 (222518), ATFG1210NL (222526), CT/G700 (175269), CTFGA702 (175264), E7STGH1000 (371007), E7STGH10G0 (371008), E7STGH10GA (371217), E7STGH3000 (371011), E7STGH30G0 (371009), E7STGL3010 (371010), E7STGL301A (371218), E7STGL5000 (371012), E9STGH1000 (391018), E9STGH10G0 (391019), E9STGH10V0 (391214), E9STGH30G0 (391020), E9STGL3010 (391021), E9STGL3C30 (391215), HT/G800 (202502), HT/G800 (298110), HT/G800D (202517), HT/G800F (298013), HT/G800NL (202524), HT/GE800 (298023), HTF/G1200 (298103), HTF/G1200 (298105), HTF/G1210 (202522), HTF/G1210D (202523), HTF/G800 (298012), HTF/G800 (298016), HTF/G800D (202519), HTF/G800NL (202525), HTF/G810 (202518), HTFG1210NL

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(202526), HTFG800 (298011), HTS/G800 (298001), HTS/G800 (298002), HTS/G800 (298003), HTS/G800NL (298005), KS/G2 (200230), KSCF/G3 (200232), KSF/G2 (200231), M105GST/GA (175257), M70GST/G (175255), MT/G350 (162514), MT/G352 (162515), MT/G700 (162504), MT/G700F (162509), MTF/G1050 (162507), MTF/G1050D (162503), MTF/G1055F (162512), MTF/G700 (162505), MTF/G700D (162502), MTF/G700F (162510), MTF/GE1050 (162508), MTFGE1055F (162513), OSF/G2 (178383), OSV/G2 (178384), OT/G800 (222543), OTF/G1210 (222544), OTF/G2 (178382), OTF/G840 (222540), OTV/G2 (178381), PSF/G2 (178083), PSF/G3 (178085), PSV/G2 (178084), PTF/G2 (178082), PTFG810 (272180), PTSG810 (272170), PTV/G2 (178081), PTV/G2N (178201), QS/G2 (210230), QSCF/G3 (210232), QSF/G2 (210231), RANGE MT/G700D (162501), RT/G351 (172266), RT/G352 (172263), RT/G700D (172251), RT/G700F (172259), RTF/G1020 (177302), RTF/G1020 (2SS17B), RTF/G1020F (177322), RTF/G1030 (177307), RTF/G1030 (2SS18B), RTF/G1050 (172262), RTF/G1050D (172253), RTF/G700 (172260), RTF/G700D (172252), RTF/G720 (2SS16B), RTF/G720F (177122), RTFG720 (177102), RTV/G720 (177002), RTV/G720 (177022), RTV/G720 (2SS14B), T70GST (175254), TSF/G2 (178683), TSF/G3 (178685), TSV/G2 (178684), TTF/G2 (178682), TTV/G2 (178681), WS/G2 (220230), WSCF/G3 (220232), WSF/G2 (220231), XT/G352 (175263), XT/G700D (175251), XT/G700F (175259), XTF/G1050D (175253), XTF/G1050F (175262), XTF/G700D (175252), XTF/G700F (175260), Z7STGH1000 (372007), Z7STGH100H (372160), Z7STGH10G0 (372008), Z7STGH3000 (372011), Z7STGH30G0 (372009), Z7STGL3010 (372010), Z7STGL5000 (372012), Z9STGH1000 (392018), Z9STGH10G0 (392019), Z9STGH10GA (392264), Z9STGH10V0 (392214), Z9STGH30G0 (392020), Z9STGL3010 (392021), Z9STGL3C30 (392215), ZHT/G800 (770538), ZHT/G800 (774600), ZHTA/G800 (770318), ZHTF/G800 (2KS06B), ZHTF/G800 (770319), ZHTS/G800 (2KS04B), ZPTF/G1000 (2CS04B), ZPTS/G1000 (2CS14B), ZT/G800 (212502), ZT/G800D (212517), ZTF/G1210 (212522), ZTF/G1210D (212523), ZTF/G800D (212519), ZTF/G810 (212518)
ZANUSSI Stove Camp Gas FT/G2 (774100)

