

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații

Automatizări / Materiale Electrice

Regulator energie 230V 13A 23mm #COK356UN

Fara TVA: 63,03 Lei

Pret cu TVA: 75,01Lei

Regulator energie 230V 13A 23mm #COK356UN

Tensiune de alimentare: 230V

Capacitate de comutare: 13A

Diametru arbore 6x4.6mm

Filet de montare: M4

Functionare: cu un singur circuit

Lungime arbore: 23 mm

Producator: EGO

Numar: 50.57021.010

Eliberare de putere: 6-100%

Compatibil cu:

ALBA 405611100089

ALIBERINOX 699801001

ALPENINOX 005270, 026861, 055016, 0A2482, 0C1605, 0K8611

AMATIS 05057021010, 5057021010

AMBACH 5061616087, 6205406501

ANGELO PO 32Z0170, 32Z0171

ARCELIK BEKO 163900005

ARISTON 482000022605, C00037056

ARRIS PR001

ASCASO BA..54, BA.262, CM.147, OL.178, V.2914

ASCOBLOC 8183150, V.2914

ATEL 05CT001, 40CU137

BARON 40CU137, 41826630141, 41853400180, 65080250, 6A049320, 826630140, 853310063, 853400010, LA65080250, LAR65080250

BARTSCHER 05057021010, 40CU137

BAUKNECHT 40CU137, 481927328279

BEKO 40CU137

BERNER 800400

BERTO'S 800400

BERTOS 24114800, 27114900, 27115100

BOMPANI 800400, M00317558

BONNET 1800602, 301200, 70486, 70486E, 72113E, 800400, BAAN167036, BAAN304497



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

CANDY 800400
CAPITO 63867
CB 09020004
CF CENEDESE 63.7.0601
CHARVET 09099A, 800400, 9099
COOKING-SYSTEMS C5322489
COOKMAX 01201450, 05057021010, 09099A, 402520000, 637060100, 699801001, 6A049320, 800400,
A0AT93616, LA65080250
COVEN 800400, EMPUAH00
DE DIETRICH 75X1764, 77X3797, 800400
DE LONGHT 800400
DESCO 800400, C2192-00
DEXION RTCU800066
DIHR 009107, 30102, 800400, 9107, DW9107
DOSILET 400007050, 800400, 91031
EBERHARDT 800400
EDESA K002B42045
EFFICOLD 800400
EGO 5017011000, 5017021000, 5037011000, 5037021000, 5057011000, 5057021010
ELECTROLUX
003030, 003031, 003529, 005270, 026861, 055016, 058406, 06501, 0A2482, 0C1605, 0C4929, 0F0089,
0G0652, 0G2652, 0H6103, 0H6137, 0H7480, 0HB171, 0K0502, 0K2964, 0K3459, 0K3763, 0K3874, 0K5029,
0K7769, 0K8611, 0K9374, 0K9741, 0K9775, 0K9784, 0KB064, 0KE181, 0KJ148, 0KJ210, 0KS980, 0KW347,
10063, 18015440, 203160, 26861, 30001227, 3016217, 3030, 3031, 315078803, 3150788234, 3529,
50281418009, 5057021010, 5270, 53701330, 55016, 58406, 6501, 750011
ELOMA
314544, E0180, E344009, EL0314544, ELE344009
EMAINOX
3700010
EMMEPI
5057021010, 808020, 809397, 8C0297, E11110001
EPMS
1150011, 163900005, 235011, 3150788234, 481227328267, 705005, 705010, 705013, 816810066,
LF3350026
ERRE 2
539205, 816810066
EURAST
6031023, 816810066, 96031023, C5322489
FAGOR



magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

12024522, 12029890, 71X7083, 816810066, K002B42045, S333001, S333001000

FAGOR BRANDT

71X7083, 75X1764, 77X3797, 816810066

FALCON

530314544

FIAMMA RST

4.0.130.0009, 816810066

FIMAR

CO1953, CO4875

FOEM

05050204750

FOEMM

816810066

FRANKE

962529

GEV

380015, H380015

GICO

539205, 539206, 539209, H380015

GIERRE

H380015, SIM123

GIGA

073010, 5010063, H380015, X44400, Y12206, Y12406, Y44400

GIORIK

6031020, 6031023, 6031024, H380015

HAKA

6031024, H380015

HEIDEBRENNER

94707

HENDI

3350024, 3350026

HOBART

301200, H380015

HORECAPARTS

3350024, 3350026

HOTPOINT

482000022605, C00037056, H380015

ICOS

07931, H380015



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

IKEA

481927328279, H380015

ILSA

61137

ILVE

A45600, H380015

INDESIT

481927328279, 482000022605, C00037056, C00314627, C00492938, H380015

INOKSAN

10091000

INOXTREND

C2192, C2192-00, H380015

JUNO

0C1605

KELVIN

0101250, H380015

KING

0101250, 0C1605, H380015

KREFFT

0101250, H380015

KROMET

50.57021.010

KROMO

009107, 30102, 9107, DW9107, H380015

KÜPPERSBUSCH

183149, 183150, 183236, 540548, H380015

LAINOX

50304011, 65080250, H380015, LA65080250, LAR50304011, LAR65080250, MACM293900, R50304011,
R65080250

LOHBERGER

51440126, H380015, R65080250

LOTUS

07931, 537013300, 537020100, 537021500, H380015, _02390, _07931

MACFRIN

C5322489

MARENO

1037035310, 1037108713, 1037110113, 426710, CM189600, H380015, LA65080250, MA1037110113,
MACM189600

MASBAGA



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

C5322489

MASTRO

1037035310, 1037110113, 426710, MA1037110113

MBM

RTCU800066

METOS

30102, 3016217, 6A049320, 9107, H380015

MKN

203160, H380015

MODULAR

661.101.00, 66105800, H380015, M564010400, RRC2192-00

MODULINE

34100700, A34100700, H380015

MORICE

DE0952

MULTINOX

564010400

NAYATI

H380015, PD412J

NORTH

HS0003, HWG002

OLIS

0111641820, 6A049320, BN0111641820, H380015

PALUX

314544, H380015

RIEBER

33063301, H380015

RINALDI SUPERFORNI

33063301, H380015

RM GASTRO

00002396, 00002974, 00003306

ROKA

8900215, H380015

ROLLER GRILL

A04006, H380015

ROSINOX

94812641, H380015, RX94812641

SAGI

32Z0170, 32Z0171, H380015



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SALVIS

1G962529, 314544

SAMMIC

4.0.130.0009, 6503625, H380015

SCH

402520000, 637060100

SILKO

0105171, 0108203, 0108231, 1037108713, 426710, 65080250, CM189600, CM293900, H380015,
LA65080250, LAR6508025, LAR65080250, MACM293900, SI0108203, SIR0105171, SIR0108203, SIR0108231

SILTAL-IAR

3.11260060130, H380015

SIRMAN

ATHD073010, H380015, IB5256500, IGS445SF, RCSG230

SMEG

23921, 816810066, 818731068, H380015

SOFRACA

H380015, SAEREG01

SOLYMAC

H380015, P82

STAHL

167115

STAR 10

H380015

STAR10

073010, Y12206

TECNOEKA

01201450, 11950017000, H380015

TECNOGAS

H380015

TECNOINOX

00012, 00937, 06501, H380015, RC00006501, RC00012000, RC00937000, RCK6031023

TELLIER

H380015

THERMA

0C1605

THERMOR

71X7083, 75X1764, H380015

THIRODE

1800602, 301200, 72113E, H380015



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

UBERT

341141, H380015

UNIVERSAL

07160001, H380015

VEDETTE

71X7083, 75X1764, H380015

VEGA

93087, 93087G

VOSS

75X1764, H380015

WHIRLPOOL

202482, 248611, 271605, 481227328267, 481227338086, 481927328279, 481927338086, 482000022605,
483286000399, 483286008224, 771985003070, C00314627, H380015

ZANOLLI

H380015, TERM0014, TERM0050

ZANUSSI

005270, 026861, 055016, 0A2482, 0C1605, 0K8611, H380015

SUITABLE FOR MODEL

manufacturerdevice typemachine model

ALBA

ALIBERINOX

ALPENINOX

AMATIS

AMBACH

7CH-50, 7CH-80, CH-70, EKK-100, EKK-100-BF, EKK-150, EKK-150-BF, EKK-40, EKK-40-BF

ANGELO PO

06WBR3E, 08WGREV, 090SPE, 0G0SPE, 0G1BR3E, 190GRE, 191BR1E, 191BR2E, 191BR2EA, 1A1BR1E,
1A1BR2E, 1A1BR2EA, 1D1BR1E, 1D1BR2E, 1D1BR2EA, 1G0GRE, 1G1BR3E, 291BR1E, 291BR2E, 291BR2EA,
291PI3E, 2A1BR1E, 2A1BR2E, 2A1BR2EA, 2A1PI3E, 2D1BR1E, 2D1BR2E, 2D1BR2EA, FC1011E, FC1011G,
FC1221E, FC1221G, FC611E, FC611G, FMS, FMSX

ANGELO PO

Boiling Pan Electric

291PI3E, 2A1PI3E

ANGELO PO

Bratt Pan

06WBR3E, 0G1BR3E, 191BR1E, 191BR2E, 191BR2EA, 1A1BR1E, 1A1BR2E, 1A1BR2EA, 1D1BR1E, 1D1BR2E,
1D1BR2EA, 1G1BR3E, 1N1BR2E, 1N1BR2EA, 1N1BR3E, 1N1BR3EA, 1N1BR3EF, 291BR1E, 291BR2E, 291BR2EA,
2A1BR1E, 2A1BR2E, 2A1BR2EA, 2D1BR1E, 2D1BR2E, 2D1BR2EA, 2N1BR2E, 2N1BR2EA, 2N1BR3E, 2N1BR3EA

ANGELO PO



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Bratt Pan Electric

06WBR3E, 0G1BR3E, 191BR1E, 191BR2E, 191BR2EA, 1A1BR1E, 1A1BR2E, 1A1BR2EA, 1D1BR1E, 1D1BR2E, 1D1BR2EA, 1G1BR3E, 1N1BR2E, 1N1BR2EA, 1N1BR3E, 1N1BR3EA, 1N1BR3EF, 291BR1E, 291BR2E, 291BR2EA, 2A1BR1E, 2A1BR2E, 2D1BR1E, 2D1BR2E, 2D1BR2EA, 2N1BR2E, 2N1BR2EA, 2N1BR3E, 2N1BR3EA

ANGELO PO

Bratt Pan Gas

2A1BR2EA

ANGELO PO

Convection Oven

FC1011E, FC1011G, FC1221E, FC1221G, FC611E, FC611G

ANGELO PO

Convection Oven Electric

FC1011E, FC1221E, FC611E

ANGELO PO

Convection Oven Gas

FC1011G, FC1221G, FC611G

ANGELO PO

Fry Top

0G0PEVTR

ANGELO PO

Grill

08WGREV, 0N0GRE, 190GRE, 1G0GRE, 1N0GRE, 2N0GRE

ANGELO PO

Grill Electric

08WGREV, 0N0GRE, 190GRE, 1G0GRE, 1N0GRE, 2N0GRE

ANGELO PO

Hot Plate Glass-Ceramics

0G0PEVTR

ANGELO PO

Pot Stove Glass-Ceramics

1G0PEVTR

ANGELO PO

Potato Heater

090SPE, 0G0SPE, 0N0SPE

ANGELO PO

Potato Heater Electric

090SPE, 0G0SPE, 0N0SPE

APACH

APACH

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Convection Oven

AB10M, AP10M

ARISTON

ARISTON

Convection Oven

05479 (HM27V), 05480 (HM27V), 05481 (HM27V), 06267 (HM37V), 06268 (HM37V), 13552 (HM27M), 13553 (HM27M), 16567 (HM87V), 16568 (HM87V), 16569 (HM87V), 18191 (HD87C(WH)), 18194 (HD87C(BK)), 18194 (HD87C(WH)), 22221 (HM55R(WH)), 22222 (HM55R(BK)), 22223 (HM55RIX), 22224 (HD50(BK)), 22225 (HD50(MR)), 22226 (HD87C(MR)), 24020 (HD50(ICE)), 24021 (HD50IX), 26506 (HB50ER(IX)), 26507 (HB50ER(ALU)), 26508 (HO10(IX)), 26509 (HO10(ALU)), 26510 (HO10(BM)), 26511 (HO50(IX)), 26512 (HO50(ALU)), 26513 (HO50(BM)), 26514 (HO87EF(IX)), 26515 (HO87EF(ALU)), 26516 (HO87EF(BM)), 26976 (HB20AC(WH)), 26977 (HB22AC(IX)), 26978 (HB22AC(WH)), 26985 (HB52C(IX)), 26986 (HB52AC(WH)), 26987 (HB52AC(BK)), 26994 (HB56C(IX)), 26995 (HB56C(WH)), 26996 (HB56C(BK)), 26997 (HO87EC(IX)), 27438 (HB86CIX), 28352 (FD98P.1 ICE), 28353 (FD98P.1 MR), 28368 (FD97P CH), 28369 (FD97P SL), 28370 (FD97P GC), 28394 (HD870C(ICE)), 28395 (HD870C(MR)), 28396 (HD870C(SL)), 29104 (HD870C.2(ICE)), 29105 (HD870C.2(MR)), 29106 (HD870C.2(SL)), 29108 (HO87EF.1(ALU)), 29109 (HO87EF.1(BM)), 29111 (HO50.2(ALU)), 29112 (HO50.2(BM)), 29113 (HO50.2IX), 29115 (HO10.2IX), 29118 (HB86C.2IX), 29119 (HB56C.2IX), 29120 (HB52C.2IX), 29121 (HB52AC.1(BK)), 29122 (HB52AC.1(WH)), 29123 (HB22AC.1IX), 29126 (HB50ER.2(ALU)), 29127 (HB50ER.2IX), 29829 (HB22AC.1(WH)), FC97P.1-E AN (T), FC97P.1-E IX (T), FC98P.1 IX, FD77P IX, FD960P.2-E BK (T), FD960P.2-E WH (T), FO97P.1-E AN (T), FO97P.1-E IX (T), FO97P.1-E WH (T), FO98P.1 IX, FO98P.1 IX DIGITAL, H10.1IX, H101.1IX, H60.1(ALU), H60.1IX, H60VP.1IX, H60VP.1IX-Y, H61.1(BK), H61.1(WH), H61.1IX, H622.1IX, H62C.1IX, H66.1IX, H66V.1IX, H87V.1(ALU), H87V.1IX, H87VP.1(ALU), H87VP.1IX, H89V.1IX, H89VP.1IX, HB20AC(WH), HB22AC(IX), HB22AC(WH), HB22AC.1(WH), HB22AC.1IX, HB50ER(ALU), HB50ER(IX), HB50ER.2(ALU), HB50ER.2IX, HB52AC(BK), HB52AC(WH), HB52AC.1(BK), HB52AC.1(WH), HB52C(IX), HB52C.2IX, HB56C(BK), HB56C(IX), HB56C(WH), HB56C.2IX, HB86C.2IX, HB86CIX, HD50(BK), HD50(ICE), HD50(MR), HD50IX, HD870C(ICE), HD870C(MR), HD870C(SL), HD870C.2(ICE), HD870C.2(MR), HD870C.2(SL), HD87C(BK), HD87C(MR), HD87C(WH), HM27M, HM27V, HM37V, HM55R(BK), HM55R(WH), HM55RIX, HM87V, HO10(ALU), HO10(BM), HO10(IX), HO10.2IX, HO50(ALU), HO50(BM), HO50(IX), HO50.2(ALU), HO50.2(BM), HO50.2IX, HO50.2TIX, HO87EC(IX), HO87EC.2-EIX, HO87EC.2IX, HO87EF(ALU), HO87EF(BM), HO87EF(IX), HO87EF.1(ALU), HO87EF.1(BM), HO87EF.1-E(ALU), HO87EF.1-E(BM), HO87EF.1-EIX, HR10.1IX, HR50.2IX, HR50.2TIX, HR86T.1IX, HR87.1IX, HR87.1TIX, HR87P.1IX

ARISTON

Convection Oven Electric

FC97P.1-E AN (T), FC97P.1-E IX (T), FC98P.1 IX, FD77P IX, FD960P.2-E BK (T), FD960P.2-E WH (T), FD97P CH, FD97P GC, FD97P SL, FD98P.1 ICE, FD98P.1 MR, FO97P.1-E AN (T), FO97P.1-E IX (T), FO97P.1-E WH (T), FO98P.1 IX, FO98P.1 IX DIGITAL, H10.1IX, H101.1IX, H60.1(ALU), H60.1IX, H60VP.1IX, H60VP.1IX-Y, H61.1(BK), H61.1(WH), H61.1IX, H622.1IX, H62C.1IX, H66.1IX, H66V.1IX, H87V.1(ALU), H87V.1IX, H87VP.1(ALU), H87VP.1IX, H89V.1IX, H89VP.1IX, HB20AC(WH), HB22AC(IX), HB22AC(WH), HB22AC.1(WH), HB22AC.1IX, HB50ER(ALU), HB50ER(IX), HB50ER.2(ALU), HB50ER.2IX, HB52AC(BK), HB52AC(WH), HB52AC.1(BK), HB52AC.1(WH), HB52C(IX), HB52C.2IX, HB56C(BK), HB56C(IX), HB56C(WH), HB56C.2IX, HB86C.2IX, HB86CIX, HD50(BK), HD50(ICE), HD50(MR), HD50IX, HD870C(ICE), HD870C(MR), HD870C(SL), HD870C.2(ICE), HD870C.2(MR), HD870C.2(SL), HD87C(BK), HD87C(MR), HD87C(WH), HM27M, HM27V, HM37V, HM55R(BK), HM55R(WH), HM55RIX, HM87V, HO10(ALU), HO10(BM), HO10(IX), HO10.2IX, HO50(ALU), HO50(BM), HO50(IX), HO50.2(ALU), HO50.2(BM), HO50.2IX, HO50.2TIX, HO87EC(IX), HO87EC.2-EIX, HO87EC.2IX, HO87EF(ALU), HO87EF(BM), HO87EF(IX), HO87EF.1(ALU), HO87EF.1(BM), HO87EF.1-E(ALU), HO87EF.1-E(BM), HO87EF.1-EIX,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

HO87EF.1IX, HO87EF.2-ETDIX, HO97P.1-E IX (T), HO97P.1-EIX, HR10.1IX, HR50.2IX, HR50.2TIX, HR86T.1IX, HR87.1IX, HR87.1TIX, HR87P.1IX

ARISTON

Kitchen Electric

06995 (C504VE3), C504VE3

ARISTON

Kitchen Gas

04858 (G1MCGR), 05466 (G2VCGR), 13710 (G650MC), 14689 (G1MCR), A6V530WEX, A6V530XEX, CE6VP6(W)EU, CE6VP6(W)EU, CP65S F8, G1MCGR, G1MCR, G2VCGR, G650MC

ARISTON

Kitchen Glass-Ceramics

21694 (C6V9P(W)F), 22095 (C6V9P(W)R), 22096 (C6V9PAR), 24490 (XC95MK(IX)), 24491 (XC95MK(AN)), 26051 (C3V9P(W)U), 26053 (C3V9PWR), 27642 (C3V9EWF), C3V7M(B)R, C3V7M(B)R, C3V7M(X)R, C3V7M(X)R, C3V7M.3(W)R, C3V7M.3(W)R, C3V7MW-R, C3V8P(W)U, C3V8P(W)U, C3V8P(X)U, C3V8P(X)U, C3V8P.2(W)U, C3V8P.2(W)U, C3V8P.2(X)U, C3V8P.2(X)U, C3V9EWF, C3V9P(W)U, C3V9P.2(W)U, C3V9P.2(W)U, C3V9PWR, C3VM5(W)R, C3VM5(W)R, C3VM5(X)R, C3VM5(X)R, C3VM6(W)F, C3VM6(W)F, C3VM6(X)F, C3VM6(X)F, C3VP6(W)R, C3VP6(W)R, C3VP6(X)R, C3VP6(X)R, C6V9P(W)F, C6V9P(W)R, C6V9P(W)U, C6V9P(W)U, C6V9P.3(W)U, C6V9P.3(W)U, C6V9P.5(W)R, C6V9P.5(W)R, C6V9PAR, C6V9PW-SK230, C6V9PW-SK400, C6V9PX-SK230, C6V9PX-SK400, C6VF7(X)R, C6VF7(X)R, C6VF8(X)R, C6VF8(X)R, C6VF8XU, C6VP1(W)SK230, C6VP1(W)SK230, C6VP1(X)SK230, C6VP1(X)SK230, C6VP4(W)R, C6VP4(W)R, C6VP4(X)R, C6VP4(X)R, CE6VP4(X)R, CE6VP4(X)R, CE6VP5(W)GR, CE6VP5(W)GR, CE6VP5(X)GR, CE6VP5(X)GR, CP0V9M(X)AUS, CP0V9M(X)AUS, CP0V9M(X)DE, CP0V9M(X)DE, CP0V9MXDES, XC95MK(AN), XC95MK(IX)

ARISTON

Pot Stove Gas

15638 (PH941MSTB), 15639 (PH941MSTB), 18676 (PH941MSTBUIX), 21661 (PH941MSTB(IX)NG), 24917 (PH941MSTB(GH)), 27732 (XP90K), 29500 (PH723RQOGH), PH723RQOGH, PH723RQOGHAUS, PH941MSTB, PH941MSTB(GH), PH941MSTB(IX), PH941MSTB(IX)NG, PH941MSTBGH, PH941MSTBUIX, XP90K

ARISTON

Pot Stove Glass-Ceramics

05672 (VL04S), 05673 (VL04S), 05674 (VL22S), 05675 (VL22S), 05884 (VL13S), 05885 (VL13S), 06348 (VL04S), 06565 (VL22S), 09856 (VL04S), 09857 (VL04S), 09858 (VL13S), 11564 (VL04S.1), 11564 (VL04S.2), 11565 (VL04S.1), 11565 (VL04S.2), 11566 (VL04S.1), 11566 (VL04S.2), 11567 (VL13S.1), 11567 (VL13S.H), 11568 (VL13S.1), 11568 (VL13S.H), 11569 (VL13S.1), 11569 (VL13S.H), 11570 (VL22S.1), 11570 (VL22S.H), 11571 (VL22S.1), 11571 (VL22S.H), 11572 (VL22S.1), 11572 (VL22S.H), 11591 (VL04S.1), 11591 (VL04S.2), 11592 (VL22S.1), 11592 (VL22S.H), 12543 (VP13), 12544 (VP13), 12545 (VP13), 12546 (VP13), 12597 (VP04), 12598 (VP04), 12599 (VP04), 12600 (VP042), 12601 (VP042), 12602 (VP042), 14639 (VP13.1), 14640 (VP13.1), 14641 (VP13.1), 14645 (VP042.1), 14646 (VP042.1), 14647 (VP042.1), 17234 (VL13S.1), 17234 (VL13S.H), 17235 (VL13S.1), 17235 (VL13S.H), 17236 (VL13S.1), 17236 (VL13S.H), 17237 (VL22S.1), 17237 (VL22S.H), 17238 (VL22S.1), 17238 (VL22S.H), 17239 (VL22S.1), 17239 (VL22S.H), 17240 (VL22S.1), 17240 (VL22S.H), 17771



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(VL04S.1), 17771 (VL04S.2), 17772 (VL04S.1), 17772 (VL04S.2), 17962 (KM600), 17963 (KM600), 17964 (KM600), 17965 (KM600), 17970 (KM6000Q), 17971 (KM6000Q), 17972 (KM6000Q), 17973 (KM6000Q), 17974 (KM6001H), 17975 (KM6001H), 17976 (KM6001H), 17977 (KM6001H), 17978 (KM6002H), 17979 (KM6002H), 17980 (KM6002H), 17981 (KM6002H), 18193 (XP90K.1), 18209 (KP600Q), 18210 (KP600Q), 18211 (KP601H), 18212 (KP601H), 22249 (KM6002HGB), 22250 (KM6002HGB), 22251 (KM6002HGB), 22252 (KM6002HGB), 27456 (XBC901K), A2032-2, A2033-2, KBM6002DHCL, KBM6004 IX, KBM6004CL, KBM6011DH IX, KBM6014D IX, KBT6003I BI, KBT6003I IX, KBT6004I BI, KBT6004I IX, KBT6011DH IX, KBT6013T BI, KBT6013T IX, KBT6013T-C IX, KBT6114ID-C IX, KBT6412I-C IX, KBT8134DO IX, KM600, KM6000Q, KM6001H, KM6002H, KM6002HGB, KOT7424IO BI, KP600Q, KP601H, NRM640X, VL04S, VL04S.1, VL04S.2, VL13S, VL13S.1, VL13S.H, VL22S, VL22S.1, VL22S.H, VP04, VP04.1-04.2, VP042, VP042.1, VP13, VP13.1, XBC901K, XP90K.1

ARRIS

ARRIS CATERING EQUIPMENT SRL

ASCASO

ASCOBLOC

AES060, AES080

BARON

SERIE700

BARON

Boiling Pan Electric

7NP-E150

BARON

Bratt Pan

9BR-E100, 9BR-E105, 9BRS-E100, 9BRS-E105

BARON

Bratt Pan Electric

9BR-E100, 9BR-E105, 9BRS-E100, 9BRS-E105

BARON

Convection Oven

CVE, CVE-2, CVE-S, CVE-S2, CVG, CVG-2, CVG-S, CVG-S2, CVME, CVME-2, CVME-S, CVME-S2, CVMG, CVMG-2, CVMG-S, CVMG-S2, CVPE, CVPE-2, CVPE-S, CVPE-S2, CVPG, CVPG-2, CVPG-S, CVPG-S2, FC21E, FC21E-2, FC21E-2S, FC21E-S, FCE, FCE-2, FCE-2S, FCE-S, FCG, FCG-2, FCG-2S, FCG-S, FCME, FCME-2, FCME-2S, FCME-S, FCMG, FCMG-2, FCMG-2S, FCMG-S, FCV21E, FCV21E-2, FCV21E-2S, FCV21E-S, FCVE, FCVE-2, FCVE-2S, FCVE-S, FCVG, FCVG-2, FCVG-2S, FCVG-S

BARON

Convection Oven Electric

CVE, CVE-2, CVE-S, CVE-S2, CVME, CVME-2, CVME-S, CVME-S2, CVPE, CVPE-2, CVPE-S, CVPE-S2, FC21E, FC21E-2, FC21E-2S, FC21E-S, FCE, FCE-2, FCE-2S, FCE-S, FCME, FCME-2, FCME-2S, FCME-S, FCV21E, FCV21E-2, FCV21E-2S, FCV21E-S, FCVE, FCVE-2, FCVE-2S, FCVE-S

BARON



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Convection Oven Gas

CVG, CVG-2, CVG-S, CVG-S2, CVMG, CVMG-2, CVMG-S, CVMG-S2, CVPG, CVPG-2, CVPG-S, CVPG-S2, FCG, FCG-2, FCG-2S, FCG-S, FCMG, FCMG-2, FCMG-2S, FCMG-S, FCVG, FCVG-2, FCVG-2S, FCVG-S

BARON

Kitchen Electric

7TP-E800, 7TPF-EE800, 7TPV-E800, 7TPVP-E800

BARTSCHER

100054 KOCIOŁEK PARTY 9L, 100058 GARNEK DO ZUPY DE LUXE 9L, 100061 GARNEK DO ZUPY ECONOMIC 9L, CZARNY, 100062 KOCIOŁEK NA ZUPĘ 5,4L, 100524 SALAMANDER 400-1Z, 100528 SALAMANDER 600-2Z, 115138 WARNIK DO MAKARONU 650, B600, 28L, 3K, 115139 GRILL 650, SZER. 800, US, 115141 GRILL ELEKTRYCZNY 650, B800, TG, 116621 PIEC KONWEKCYJNO-PAROWY M10110, 10X1/1GN, 1166281 PIEC KONWEKCYJNO-PAROWY M71110G, GAZ, 7X1/1GN, 151510 SALAMANDER Z WINDĄ 500-1Z, 215037 ROŻEN DO KURCZAKÓW P12N, 287410 KUCHNIA CERAMICZNA 700, 2 POLA, PO, 296431 4-PALN. KUCHNIA CER., PIEK.EL.2/1GN

BAUKNECHT

Pot Stove

SLE348001BW

BERNER

BERTOS

E6BM3B, E6BM3M, E6BM6B, E6BM6M, E6PL60B, E6PL60M, E9BM4M, E9BM8M, E9P2MP-VTR, E9P4MP-VTR, E9P4P-VTR+FE, E9P4P-VTR+FE1, E9PL40M, E9PL80M, EGRM4, EGRS4, FME06M, FME10M, FME20M, FMG10M, FMG20M, FMG6, FMG6M, FPE12TURBO, FPE6TURBO, FPG12, FPG5A, FPG5B, FPG6, LXE9P2P-VTR, LXE9P4P-VTR, PLE40BE, PLE40ME, PLE80BE, PLE80ME, SA-E48, SA-E60, SA-E60-E, SA-E68, SA-E68M, SA-E68M-E, SE9BM4M, SE9BM8M, SE9P2MP-VTR, SE9P4MP-VTR, SE9P4P-VTR+FE, SE9PL40M, SE9PL80M, WAV-E12, WAV-E12T...(OTHER

BONNET

BONNET

Pasta Cooker

B-B909.CP400 P075756, B107CP4PE

BONNET

Pasta Cooker Electric

B-B909.CP400 P075756, B107CP4PE

CAPITO

CB

CB

Sausage Grill

2P, 4P, SW1, W12-5, W18-7, W24-5, W24-7, W32-9, W32-9S

CB

Vacuum Packer



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

DIPA, DIPA50

CF CENEDESE

CW6, CW8, HD20, HD40, SE1, SE1M, SEP, SEPC

CF CENEDESE

Toaster

TN30PLUS

COOKING-SYSTEMS

5305, 53054, 5310, 53104, 5315, 53154, 5320, 53204, 5330, 53304, 5340, 53404, 5355, 5360, 53604, 5375, 5380, 53804

COOKMAX

122105, 122106, 122110, 123118, 123119, 126101, 126103, 132207, 132208, 132209, 132210, 211045, 211046, 212034, 212036, 212038, 212040, 221001, 221002, 221003, 221004, 221017, 221018, 248001, 248002, 248003, 262001

COVEN

Electric Oven

TEC 10, TEC 3, TEC 5P MEC, TEC 6

COVEN

Gas Oven

TEC 10G, TEC 10GP MEC, TEC 20G, TEC 20GMD, TEC 5GP MEC, TEC 6G

COVEN

Proving Oven

LIEVITATORE 10P

CPE

015-D4S, 051-C

DE DIETRICH

Electric Oven

7DF0194 (FW4427E1), 7DF0303 (FW4821E1), 7DF0350 (FM1648D1), 7DF0351 (FW1648D1), 7DF0362 (FM2642D1), 7DF0364 (FW2642D1), 7DF0372 (FM5642D1), 7DF0374 (FW4427E3), 7DF0379 (FX4427E3), 7DF0400 (FW2642D1), 7DF0417 (FW1648D1), 7DF0421 (FM2642D1), FM1648D21 (FM1648D2), FX5847E31 (FX5847E3), FX5847E32 (FX5847E3), REP-005321 (FW4427E2), REP-005322 (FW4427E3), REP-005323 (FX4427E1), REP-005324 (FX4427E2), REP-005325 (FX4427E3), REP-005382 (FW4821E3), REP-005383 (FX4821E1), REP-005385 (FX4821E3), REP-005413 (FX1648D1), REP-005417 (FX2642D1), REP-005436 (FX2642D12), REP-005449 (FX1648D1)

DE DIETRICH

Pot Stove

1241A, 7DT0254 (WM1349E1), 7DT0255 (WM1379E1), 7DT0256 (WM1339E1), 7DT0318 (DTV304XE1), 7DT0377 (WM1536E1), 7DT0408 (WM1578U1), 7DT0449 (WM1049E2), 7DT0450 (WM1079E2), 7DT0903 (DTV303JE1), DTV103XE11 (DTV103XE1), INDUCTION 8X0264 (DTV301XD1)

DE DIETRICH



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Pot Stove Electric

REP-006321 (WN1349E1)

DE DIETRICH

Pot Stove Gas

7DT0271 (DTG115BE1), 7DT0861 (DTG315XL1), 7DT0877 (DTG315XL1)

DE DIETRICH

Pot Stove Glass-Ceramics

7DT0252 (WN1438E1), 7DT0374 (WN1577E1), 7DT0375 (WN1578E1), 7DT0378 (WN1537E1), REP-006322 (WN1379E1), REP-006323 (WN1339E1), REP-006351 (WN1536E1), REP-006352 (WW1536E1), REP-006387 (WW1578U1), WN1537E11 (WN1537E1)

DESCO

Convection Oven

E2CDA107GCG, FCA6E

DESCO

Convection Oven Electric

FCA6E

DESCO

Convection Oven Gas

E2CDA107GCG

DEXION

DIAMOND

DIHR

S2, SALAMANDRA-S1, SALAMANDRA-S2

DIHR

Salamander

S1

DIHR

Salamander Electric

S1

DOSILET

Toaster Electric

GG4000, TT6000

EGO

ELECTROLUX

7PIE06, BCP/E1, JMV/E1C, JMV/E2C, M70EIKE, MCP/E1SH, MCP/E1SUH, MCP/E2S, MCP/E2SH, MCP/E2SHB, MCP/E2SUH, MCP/E2SUHS, MCP/E2SUT, MMV/E1C, MMV/E2C, MPI/G260P, MPN/EI760, MPN/EI760D, MPNEI760UK, OCP/E1SH, OCP/E2S, OCP/E2SH, OMV/E1C, OMV/E2C, OPD/G260, OPI/E260P, OPI/G260P, PCP/E1SH, PCP/E2SH, PCP/E2SH3B, PCP/E2SHP, PMV/E1C, PMV/E2C, PPD/G260, PPI/E260P, PPI/G260P, RCP/E2S, RMV/E1C, RMV/E2C, RPI/G260P, RPN/EI760D, RPN/EI760UK, TMV/E1C, TMV/E2C, XMV/E1C, XMV/E2C, XPI/G260P,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

XPN/EI760D, XPN/EI760UK

ELECTROLUX

Dishwasher

AHE4062UB (94972024600), AKE4123IW (92344101400), AME3039NN (94960021200), AME3051NN (94960031000), ASU4040IB (91182300800), ASU4040IN (91182301000), ASU4040IS (91182300900), ASU4040IW (91182300700), ASU4050I (91182500300), ASU4060I (91172502000)

ELECTROLUX

Electric Oven

5020E-B (94031602300), E57415-4-M R05 (94032015300), FMT45N (94772702100), FMT45N (94772703200)

ELECTROLUX

Fryer Electric

AME3040NN (94960061800), EHB334X (94960064500), ZKM3040XX (94960068300)

ELECTROLUX

Hood

AEF3100N (90000005400)

ELECTROLUX

Kitchen

30006VE-W (94031310700), AHE4062US (94972024800), C6033V-A EURO (94031307600), CE1100-2-B EURO (94031679500), CE1100-2-M EURO (94031679600), CE1100-2-W EURO (94031679400), CE4100-1-A EURO (94031667900), CE4100-1-B EURO (94031667700), CE4100-1-D EURO (94031667500), CE4100-1-M EURO (94031667800), CE4100-1-W EURO (94031667600), E 1000-B EURO (94031644900), E 1000-EW EURO (94031644800), E 1000-M1 EURO (94031645000), E 4100-B EURO (94031645700), E 4100-D EURO (94031645500), E 4100-EW EURO (94031645600), E 4100-M EURO (94031645800), E4101-4-M EU R05 (94032028700), E4101-5-M DE R08 (94032039801), E4101-5-M EU R08 (94032039901)

ELECTROLUX

Pot Stove

ASK4022D (94166808600)

ELECTROLUX

Pot Stove Electric

AME2200KB (9413262500), AME2200KW (94132626600), AME2250KB (94168364100), AME2250KW (94168364200), AME3011NN (94960000500), AME3024KN (94960010800), AME3040NN (94960060500), AME3064KN (94960042000), AME3079NN (94960051300), DGF310X (94960060900), DGF310X (94960062100), DGF310X (94960063000), DGF310X (94960064300), EHB334X (94960060200), EHB334X (94960061500), EHB334X (94960063500), ZH2SGF (94960060800)

ELECTROLUX

Pot Stove Glass-Ceramics

130FG-M (94117742300), 130FG-M (94960068000), 94159265600 (EHO600), 94159265700 (EHO600K), 94159265800 (EHO601), 94159265900 (EHO601K), AME2222KB (94168363100), AME2222KJ (94168363400), AME2222KN (94168363500), AME2222KS (94168363300), AME2222KW (94168363200), EHB334X



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(94117764100), EHO602K (94959071000), EHO602W (94959070900), EHO603B (94959071800), EHO603K (94959071600), EHO603W (94959071700), EHP663X 30S (94959296501), EHP663X 75L (94959200100), K641X X50 (94959117500), K641X (94959097000), K641X 63C (94959223700), K641X 63D (94959162600)

ELOMA

EMAINOX

EMMEPI

EURAST

105, 105E, 1155, 1260, 1260E, 1575, 1680, 1680E, 210, 210E, 315, 315E, 420, 420E, 630, 630E, 840, 840E

FAGOR

CPE9-05AD-S, CPE9-05NC, CPE9-05PLUS-S, CPE9-05S, CPE9-05SNC, HGV-10-11, HGV-20-11, HVG-2-10-11, HVG-2-20-21, ME9-10PLUS-BM, ME9-10PLUS-BMS, ME9-15BM-AD, ME9-15PLUS-BM, ME9-15PLUS-BMS, MFHVG-10-11, MG9-10BMSAD, MG9-10PLUS-BM, MG9-10PLUS-BMS, MG9-10PLUS-S, MG9-10S-AD, MG9-15BMSAD

FAGOR

Boiling Pan Electric

ME7-10BM, ME9-00BM, ME9-10BM, ME9-10BM316, ME9-10BMS, ME9-10PLUSBM, ME9-15BM, ME9-15BM316, ME9-15BMAD, ME9-15BMS, MPE9-00BM, MPE9-10BM, MPE9-10BMS, MPE9-15BM, MPE9-15BMS

FAGOR

Boiling Pan Gas

MG9-10AD, MG9-10BMAD, MG9-10PLUS, MG9-10PLUSBM, MG9-15AD, MG9-15BMAD, MG9-15PLUS, MG9-15PLUSBM, MG9-20AD, MG9-20PLUS

FAGOR

Convection Oven

HVG-10-11, HVG-10-11UL, HVG-10-21, HVG-10-21UL, HVG-1011, HVG-1021, HVG-10UL, HVG-2-20-11, HVG-2.10, HVG-2.10-11, HVG-2.20, HVG-20, HVG-20-11, HVG-20-21, HVG-2011, MFHVG-10, MFHVG-10-21, VGT-10, VGT-10-21, VGT-2-20-11, VGT-2.20, VGT-20, VGT-20-11, VGT-20-21

FAGOR

Convection Oven Electric

HVG-20-11

FAGOR

Convection Oven Gas

HVG-10-11, HVG-10-11UL, HVG-10-21, HVG-10-21UL, HVG-1011, HVG-1021, HVG-10UL, HVG-2-20-11, HVG-2.10, HVG-2.10-11, HVG-2.20, HVG-20, HVG-20-21, HVG-2011, MFHVG-10, MFHVG-10-21, VGT-10, VGT-10-21, VGT-2-20-11, VGT-2.20, VGT-20, VGT-20-11, VGT-20-21

FAGOR

Kitchen Glass-Ceramics

CV6-20, CV6-40

FAGOR

Pasta Cooker



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

CPE6-05, CPE7-05, CPE7-05NC, CPE9-05, CPE9-05AD, CPE9-05ADS, CPE9-05PLUS, CPE9-05PLUSS, CPG7-05,
CPG7-05NC, CPG9-05, CPG9-05AD, CPG9-05ADS, CPG9-05PLUS, CPG9-05PLUSS, EPC-350, GPC-350

FAGOR

Pasta Cooker Electric

CPE6-05, CPE7-05, CPE7-05NC, CPE9-05, CPE9-05AD, CPE9-05ADS, CPE9-05PLUS, CPE9-05PLUSS

FAGOR

Pasta Cooker Gas

CPG7-05, CPG7-05NC, CPG9-05, CPG9-05AD, CPG9-05ADS, CPG9-05PLUS, CPG9-05PLUSS, EPC-350, GPC-350

FAGOR

Salamander

SE-60-0, SE-60-4

FAGOR BRANDT

CPE6-05, CPE7-05, CPE7-05NC, CPE9-05, CPE9-05AD, CPE9-05AD-S, CPE9-05NC, CPE9-05PLUS, CPE9-05PLUS-S,
CPE9-05S, CPE9-05SNC, CV6-20, CV6-40, EPC-350, FAGOR, HGV-10-11, HGV-20-11, HVG-10-11, HVG-10-11UL,
HVG-10-21, HVG-10-21UL, HVG-2-10-, HVG-20-11, HVG-20-21

FAGOR BRANDT

Electric Oven

MP4330EX1 (MP4330EX), MP4330EX2 (MP4330EX), MP4330EX3 (MP4330EX)

FAGOR BRANDT

Kitchen

EN626-1 (EN626), EN626-2 (EN626), EN634-1 (EN634), K5026-1 (K5026), K5026-2 (K5026), K5026-2 (K5026B),
K5026-2 (K5026N), K522-1 (K522), K522-2 (K522), K534-1 (K534), K534-1 (K534N), K626-1 (K626), K626-2
(K626), K626-2 (K626B), K626-2 (K626N), K626C2 (K626C), K626C2 (K626CN), K634-1 (K634), K634-2 (K634),
K634-3 (K634), K634-3 (K634B), K634-3 (K634N), K634C1 (K634C), KB522-1 (KB522), KB622-1 (KB622),
KB622-2 (KB622), KB622-2 (KB622N), KB624-1 (KB624), KB624-2 (KB624), KB624-2 (KB624B), KB624-2
(KB624N), KB624-5 (KB624), KB626-1 (KB626), KB634-1 (KB634), KB634/1 (KB634), KBN624-1 (KBN624),
KBN624-2 (KBN624), KF625-1 (KF625), KF625-1 (KF625B), KF625-1 (KF625N), KF639-1 (KF639), KF639-2
(KF639), KF639-2 (KF639N), KFB628-1 (KFB628), KFB628-2 (KFB628), KFB630-1 (KFB630), KFB630-2 (KFB630),
KFBN628-1 (KFBN628), KFBN630-1 (KFBN630), KN626C1 (KN626C)

FAGOR BRANDT

Kitchen Electric

E626-1 (E626), E626-2 (E626), E626C1 (E626C), E626C2 (E626C), E634-1 (E634), E634-2 (E634), E634-3
(E634), EN626C-2 (EN626C), EN626C1 (EN626C)

FAGOR BRANDT

Kitchen Glass-Ceramics

KD173W1G1 (KD173W1G), KD173W1G2 (KD173W1G), KN173W1G1 (KN173W1G), KN173W1G2 (KN173W1G),
KNA13W1N1 (KNA13W1N), KNA43W1N1 (KNA43W1N), KNA84W1N1 (KNA84W1N), KNA85W1N1 (KNA85W1N),
KNW95W1N1 (KNW95W1N), KV372WE11 (KV372WE1), KV571WN11 (KV571WN1), KV571WN12 (KV571WN1),
KV571XN11 (KV571XN1), KV571XN12 (KV571XN1), KV600WN11 (KV600WN1), VBM51BW-1 (VBM51BW)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FAGOR BRANDT

Pot Stove

HFD53B1F1 (HFD53B1F), HFD53B1F2 (HFD53B1F), HFD53F1F1 (HFD53B1F), HFD53F1F2 (HFD53F1F),
HFD53W1F1 (HFD53W1F), HFD53W1F2 (HFD53W1F), HFL12B1E1 (HFL12B1E), HFL12B1E2 (HFL12B1E),
HMT51F1F1 (HMT51F1F), HMT51W1F1 (HMT51W1F), HMT51X1F1 (HMT51X1F), HMT51X1F2 (HMT51X1F),
INDUCTION VI-390R1 (VI-390R), T106RV2 (T106RV), TLE40H2 (TLE40H), TLK31B4 (TLK31B), TLK31C2 (TLK31C),
TLK31C4 (TLK31C)

FAGOR BRANDT

Pot Stove Electric

DE89B1 (DE89B), DE89H1 (DE89H), TLK31H4 (TLK31H)

FAGOR BRANDT

Pot Stove Gas

SD882C3 (SD882C), SD882C4 (SD882C), SD882H3 (SD882H), SD882H4 (SD882H), SE884B2 (SE884B),
SE884B3 (SE884B), SE884C2 (SE884C), SE884C3 (SE884C), SE884H2 (SE884H), SE884H3 (SE884H), SK883B3
(SK883B), SK883B4 (SK883B), SK883B5 (SK883B), SK883C3 (SK883C), SK883C4 (SK883C), SK883C5 (SK883C),
SK883H3 (SK883H), SK883H4 (SK883H), TLE40B2 (TLE40B)

FAGOR BRANDT

Pot Stove Glass-Ceramics

BV60B-1 (BV60B), BV60W-1 (BV60W), BV60X-1 (BV60X), BV60X-2 (BV60X), HFJ15B1E1 (HFJ15B1E), HFT15B1E1
(HFT15B1E), TRH622N1 (TRH622N), TRH631N1 (TRH631N), TV610BT11 (TV610BT1), TV611BT11 (TV611BT1)

FIAMMA RST

Salamander

SEF 450, SEF 450I, SEF 650, SEF 650I

FIAMMA RST

Salamander Electric

SEF 450, SEF 450I, SEF 650, SEF 650I

FIMAR

FIMAR

Panini Grill Electric

RW8

FIMAR

Salamander

RS40, RS70, SAL600

FIMAR

Salamander Electric

RS40, RS70, SAL600

FOINOX

FC05E, FC05EU, FC05G, FC05GU, FC06E, FC06EA, FC06EDG, FC06G, FC06GA, FC06GDG, FC06SE, FC06SEA,
FC06SEDG, FC12E, FC12EA, FC12EDG, FC12G, FC12GA, FC12GDG, FC12SE, FC12SEA, FC12SEDG, FC200EB,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FC200GB, FC201EB, FC20E, FC20EA, FC20EDG, FC20G, FC20GA, FC20GDG, FC401EB, FDE10, FDE155, FDE55, FDG10, FDG155, FDG55, FM06EB, FM06GB, FM10EB, FM10GB, FM20EB, FM20GB, FP05E, FP05EDG, FP05G, FP05GDG, FP10E

FRANKE

GICO

GICO

Kitchen Electric

CE7N037C, CE7N037T, CE7N057C, CE7N057FEB, CE7N057T

GIERRE

GIERRE

Convection Oven

FEV-106M, FEV-107M, FEV-166E, FEV-166M, FEV-166P, FEV-167E, FEV-167M, FEV-167P, FEV-168E, FEV-168M, FEV-56M, FEV-57M

GIERRE

Convection Oven Electric

FEV-106M, FEV-166E, FEV-166M, FEV-166P, FEV-168E, FEV-168M, FEV-56M

GIERRE

Convection Oven Gas

FEV-107M, FEV-167E, FEV-167M, FEV-167P, FEV-57M

GIGA

C4V, CCV80E, CCV81E, K2V, K4V, K4VFCE, K4VFE, OP2V, OP4V, S110E, S300E, TCV80E

GIGA

Bain-Marie Electric

CBE4, CBE6, CBE8, SKB40E, SKB60E, SKB80E, TB40E, TB60E, TB80E

GIGA

Grill

CR4E, CR6E, CRE4, CRE6, IRE4, IRE6, SKR40E, SKR60E, TR40E, TR60E

GIGA

Grill Electric

CR4E, CR6E, CRE4, CRE6, IRE4, IRE6, SKR40E, SKR60E, TR40E, TR60E

GIGA

Kitchen Electric

C4VFCE, C4VFE

GIGA

Kitchen Glass-Ceramics

SK4VFCE

GIGA

Pot Stove Glass-Ceramics

SKCV40E, SKCV80E



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

GIGA

Salamander

S600E, S680E

GIGA

Salamander Electric

S600E, S680E

GIORIK

GIORIK

Boiling Pan Electric

PEI705, PEI915

GIORIK

Convection Oven

CG06ES, DE06ES, DE06MX, DE102ES, DE102MX, DE10ES, DE10MX, DG06ES, DG06MX, DG102MX, DG10ES, DG10MX, EF10GM, EF4PM, EF5GM, EF6PM, EF7GM, EF8PM, EG423, EGE05, EGE10, EGG05, EGG10, EGG10M, EN10MX, EN10VEMC, EN20MX, EN6MX, EN6VEMC, EPE04, EPE04R, EPE05, EPE10, G10VEMX, G10VGMX, G20VEMX, G6VGMX, GF10GM, GF4PM, GF5GM, GF6PM, GF7GM, GF8PM, GN10VGMX, GN6MX, ME102, ME102X, ME42, ME4232, ME52, ME5232, ME5232X, ME52X, ME72, ME72X, MG102, MG52, MG72, MME102, MME102S, MME52, MME523, MME523S, MME52S, MME72, MME72S, MMG102, MMG102S, MMG52, MMG52S, MMG72, MMG72S, MR32, MR321, MR42, VE06MX, VE102MX, VE10MX, VE20MX, VG06MX, VG102MX, VG10MX, VG20MX

GIORIK

Convection Oven Electric

DE06ES, DE06MX, DE102ES, DE102MX, DE10ES, DE10MX, EF10GM, EF4PM, EF5GM, EF6PM, EF7GM, EF8PM, EG423, EGE05, EGE10, EN10MX, EN10VEMC, EN20MX, EN6MX, EN6VEMC, EPE04, EPE04R, EPE05, EPE10, ME102, ME102X, ME42, ME4232, ME52, ME5232, ME5232X, ME52X, ME72, ME72X, MME102, MME102S, MME52, MME523, MME523S, MME52S, MME72, MME72S, MR32, MR321, MR42, VE06MX, VE102MX, VE10MX, VE20MX

GIORIK

Convection Oven Gas

CG06ES, DG06ES, DG06MX, DG102MX, DG10ES, DG10MX, EGG05, EGG10, EGG10M, G10VEMX, G10VGMX, G20VEMX, G6VGMX, GF10GM, GF4PM, GF5GM, GF6PM, GF7GM, GF8PM, GN10VGMX, GN6MX, MG102, MG52, MG72, MMG102, MMG102S, MMG52, MMG52S, MMG72, MMG72S, VG06MX, VG102MX, VG10MX, VG20MX

GIORIK

Grill

GL72GE

GIORIK

Grill Electric

GL72GE

GIORIK

Salamander



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

S505, S505R, S510, S510S, S511, S511S, SE520, SR512R

GIORIK

Salamander Electric

S505, S505R, S510, S510S, S511, S511S, SE520, SR512R

GORT

50.57021.010

HAKA

HEIDEBRENNER

HOTPOINT

Electric Oven Electric

HH831ERJIX-HA

HOTPOINT

Kitchen Electric

EW12P

HOTPOINT

Kitchen Gas

CI6VE9(W)R-HA, CI6VE9(W)R-HA), CI6VE97(W)RU-HA, CI6VE97(W)RU-HA), CI6VE97A1XHA, CI6VE97A1XHA.0,
CI6VE97XRUA, CP9VP6DE-HAS, EW12C

HOTPOINT

Kitchen Glass-Ceramics

C3BM6(W)F-HA, C3BM6(W)F-HA), C3BM6(X)F-HA, C3BM6(X)F-HA), C3VM5(W)R-HA, C3VM5(W)R-HA),
C3VM5(W)UA-HA, C3VM5(W)UA-HA), C3VM5(X)R-HA, C3VM5(X)R-HA), C3VM57(W)RU-HA, C3VM57(W)RU-HA),
C3VM57(X)RU-HA, C3VM57(X)RU-HA), C3VP6(W)R-HA, C3VP6(W)R-HA), C3VP6(X)R-HA, C3VP6(X)R-HA),
C3VP6WRHAS, C3VP6XRHAS, CE6VP4(X)R-HA, CE6VP4(X)R-HA), CE6VP5(W)GR-HA, CE6VP5(W)GR-HA),
CE6VP5(X)GR-HA, CE6VP5(X)GR-HA), CE6VP5XGRHAS, CE6VP6(W)EU-HA, CE6VP6(W)EU-HA), CI3VP6(X)R-HA,
CI3VP6(X)R-HA), CI3VP67(X)RU-HA, CI3VP67(X)RU-HA), H5V56WRU, H5V56XRU, H5VMC6AXRU, H5VMH5AW,
H5VMH5AX, H5VMH6AXEA, H5VMH6AXPL, H6V530ARU, H6V560WRU, H6V560XRU, H6V5D60WRU,
H6V5D60XRU, H6V9CA1WFR, H6VMC2AWFR, H6VMC6A.B(X)FR, H6VMC6A.B(X)FR), H6VMC6AWFR,
H6VMH6A.BXGR, HT5VM4AANE, HT5VM4AOWEA

HOTPOINT

Pot Stove Gas

GF941BX, PH941MSTB(IX)-HA, PH941MSTB(IX)-HA), PH941MSTBGH-HA

HOTPOINT

Pot Stove Glass-Ceramics

7HKRM641DXRU-HA, 7HKRM641DXRUHA, CEM645DX, CRM641DC, CRM641DX, E6011, E6011X, E6014,
E6014X, EC6011, EC6014, EX901X, KBM6001HIX-HA, KBM6004CL-HA, KBM6004IX-HA, KBM6014DIX-HA,
KRM630C, KRM640C, KRM641DX, XBC901K-HA

ICOS

IKEA

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Pot Stove Electric

CKH422, CKH432, HB42000126580, HBD40S00123505, HBD50S60123507, HOBD40S10095168

ILSA

INDESIT

Convection Oven

24040 (HGM10K(IX)), F023549 (FDE1RG), F024040 (HGM10K(IX)), F030155 (HGM300K.CIX), F030156 (HGM300K.C(WH)), F030157 (HGM300K.C(BR)), F030160 (HGM30K.CIX), F030161 (HGM30K.C(WH)), F030162 (HGM30K.C(BR)), F036797 (HI50EK.B(WH)), F036798 (HI50EK.BIX), F036799 (HI56EK.BIX), F038108 (HI56EK.BIXGR), F058894 (HI53EK.BIXGR), F060836 (IH51K.AIX), F060837 (IH63K.AIX), F068272 (HI50EK.AIX), F074485 (HIM506EK.AIX), F074486 (HIM506EK.AWH), F074487 (HIM531EK.AIX), F074488 (HIM537EKAIX), F078287 (HIM50EK.AIX2), F078293 (HIM506EK.AIX-2), F078298 (HIM506EK.AWH2), F078301 (HIM531EK.AIX-2), F078304 (IH51K.AIX2), F081390 (HIM 20K.A(BK)-2)

INDESIT

Convection Oven Electric

F023549 (FDE1RG), F024040 (HGM10K(IX)), F030155 (HGM300K.CIX), F030156 (HGM300K.C(WH)), F030157 (HGM300K.C(BR)), F030160 (HGM30K.CIX), F030161 (HGM30K.C(WH)), F030162 (HGM30K.C(BR)), F036797 (HI50EK.B(WH)), F036798 (HI50EK.BIX), F036799 (HI56EK.BIX), F038108 (HI56EK.BIXGR), F058894 (HI53EK.BIXGR), F060836 (IH51K.AIX), F060837 (IH63K.AIX), F068272 (HI50EK.AIX), F074485 (HIM506EK.AIX), F074486 (HIM506EK.AWH), F074487 (HIM531EK.AIX), F074488 (HIM537EKAIX), F078287 (HIM50EK.AIX2), F078293 (HIM506EK.AIX-2), F078298 (HIM506EK.AWH2), F078301 (HIM531EK.AIX-2), F078304 (IH51K.AIX2), F081390 (HIM 20K.A(BK)-2)

INDESIT

Kitchen Electric

F033171 (K6E32(W)-G), F033172 (K6E32(X)-G)

INDESIT

Kitchen Gas

F011600 (KG6405WV-O), F011601 (KG6405XV-O), F014037 (KG6408WV-G), F014038 (KG6044WV-G), F017491 (KG6407GV-G), F017990 (KG6408XV-G), F017991 (KG6407AV-G), F022215 (KG6408XV-O), F022260 (KG6407LV-G), F023079 (K647VS(W)-O), F023080 (K647VSX-O), F027593 (K648VX-O), F027594 (K648VW-O), F029288 (K648V.C(W)-O), F029289 (K648V.CX-O), F033165 (K6G32(X)-G), F033166 (K6G32(W)-G), F088436 (EI6V6C6AWFR)

INDESIT

Kitchen Glass-Ceramics

F026823 (K3C8VW-G), F026824 (K3C8VX-G), F028467 (K3C8VA-G), F029364 (K3C8V.BA-G), F029365 (K3C8V.B(X)-G), F033168 (K6C32(W)-G), F033169 (K6C32(X)-G), F033973 (K6C7(W)-SK), F033974 (K6C7(X)-SK), F035942 (K3C36(X)-G), F057476 (KP900CX), F057477 (KP9508CXG), F057876 (K6C7(W)-NO), F060903 (K6C7(IX)-SK), F063012 (KP902CX), F068721 (KP9C11S(K)-G), F073913 (KN6C72A(X)-GR), F073925 (KN3C76A(W)BG), F081167 (KN6C72AXGRS), F081172 (KN3C76AWBGS), F083518 (I6V6C1A.HWFR), F083520 (I6V66AWFR), F083520 (I6V6C6AWFR), F083805 (I6VSH2WEX), F083807 (I6VV2AXEX), F083812 (I6V6H1AWFR),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

F084285 (I6VMH2ABXGR), F088232 (I5VM6HAWBG), F088424 (I6V6C5AXHU), F088426 (I6V6C5AWHU)

INDESIT

Pot Stove Gas

F033889 (PI 640 AS(IX) IR)

INDESIT

Pot Stove Glass-Ceramics

06447 (PVI13), 06451 (PVI13), 12312 (EPI04.1), 12313 (EPI04.1), 12314 (EPI04.1), 12315 (EPI13.1), 12316 (EPI13.1), 12317 (EPI13.1), 12547 (PVI13.1), 12548 (PVI13.1), 12549 (PVI13.1), 12810 (PVI04.1), 12811 (PVI04.1), 12812 (PVI22.1), 12813 (PVI22.1), 13692 (PV22), 13693 (PV22), 13957 (EPV04), 13958 (EPV04), 13959 (EPV04), 13963 (EPV04D), 13964 (EPV04D), 13965 (EPV04D), 23933 (PV604IX), 25321 (PV604BK), F006447 (PVI13), F006451 (PVI13), F012312 (EPI04.1), F012313 (EPI04.1), F012314 (EPI04.1), F012315 (EPI13.1), F012316 (EPI13.1), F012317 (EPI13.1), F012547 (PVI13.1), F012548 (PVI13.1), F012549 (PVI13.1), F012810 (PVI04.1), F012811 (PVI04.1), F012812 (PVI22.1), F012813 (PVI22.1), F013692 (PV22), F013693 (PV22), F013957 (EPV04), F013958 (EPV04), F013959 (EPV04), F013960 (EPV13-13.1), F013961 (EPV13-13.1), F013962 (EPV13-13.1), F013963 (EPV04D), F013964 (EPV04D), F013965 (EPV04D), F013966 (PV04), F013967 (PV04), F013968 (PV04), F013969 (PV13-PV13H), F013970 (PV13-PV13H), F013971 (PV13-PV13H), F017241 (PV13-PV13H), F017243 (PV13-PV13H), F017244 (PV13-PV13H), F023933 (PV604IX), F025321 (PV604BK), F038966 (MK64RCL), F053074 (VRM640X), F068819 (VRM630C), F074065 (VRM640MIX), F074066 (VRM640MC), F074067 (VRM641MDIX), F074068 (VRM641MDC), F075810 (VRM630MC)

INOKSAN

INOXTREND

INOXTREND

Convection Oven

AUA-606E, AUA-606G, AUA-610E, AUA-610G, BUA-606E, BUA-606G, BUA-610G, CBA-107E, CBA-111E, CBA-220E, CDA-107E, CDA-107G, CDA-111E, CDA-111G, CDA-120E, CDA-120G, CDA-207E, CDA-207G, CDA-211E, CDA-211G, CDA-220E, CDA-305E, CRUA-107E, CRUA-110E, CUA-107E, CUA-107G, CUA-111E, CUA-111G, CUA-120E, CUA-207E, CUA-211E, CUA-211G, CUA-220E, FBA-106E, FBA-106G, FBA-110E, FBA-110G, FBA-120E, FBA-120G, FBA-210E, FBA-210G, FBA-220E, FBA-220G, FDA-106E, FDA-106G, FDA-110E, FDA-110G, FDA-120G, FDA-210E, FDA-210G, FDA-220E, FDA-220G, FUA-106E, FUA-106G, FUA-110E, FUA-110G, FUA-120E, FUA-120G, FUA-210E, FUA-210G, FUA-220E, FUA-220G, MB1A-10E, MB1A-10G, MB1E-10E, MB1E-10G, MBE-6E, MBE-6G, MDA-10E, MDA-10G, MDA-6E, MDA-6G, MDE-10E, MDE-10G, MDE-6E, MDE-6G, RDA-105E, RDA-110E, RDA-115E, RDA-305E, RUA-105E, RUA-110E, RUA-115E, RUA-305E, RUA-605E, SDA-4E, SDA-4EM, SDA-5E, SDA-5EM, TAUA-606E, TAUA-610E, TAUA-610G, VB1E-210E, VB1E-210G

INOXTREND

Convection Oven Electric

AUA-606E, AUA-610E, BUA-606E, CBA-107E, CBA-111E, CBA-220E, CDA-107E, CDA-111E, CDA-120E, CDA-207E, CDA-211E, CDA-220E, CDA-305E, CRUA-107E, CRUA-110E, CUA-107E, CUA-111E, CUA-120E, CUA-207E, CUA-211E, CUA-220E, FBA-106E, FBA-110E, FBA-120E, FBA-210E, FBA-220E, FDA-106E, FDA-110E, FDA-210E, FDA-220E, FUA-106E, FUA-110E, FUA-120E, FUA-210E, FUA-220E, MB1A-10E, MB1E-10E, MBE-6E,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MDA-10E, MDA-6E, MDE-10E, MDE-6E, RDA-105E, RDA-110E, RDA-115E, RDA-305E, RRU-105E, RRU-110E, RRU-305E, RUA-105E, RUA-110E, RUA-115E, RUA-305E, RUA-605E, SDA-4E, SDA-4EM, SDA-5E, SDA-5EM, TAUA-606E, TAUA-610E, VB1E-210E

INOXTREND

Convection Oven Gas

AUA-606G, AUA-610G, BUA-606G, BUA-610G, CDA-107G, CDA-111G, CDA-120G, CDA-207G, CDA-211G, CUA-107G, CUA-111G, CUA-211G, FBA-106G, FBA-110G, FBA-120G, FBA-210G, FBA-220G, FDA-106G, FDA-110G, FDA-120G, FDA-210G, FDA-220G, FUA-106G, FUA-110G, FUA-120G, FUA-210G, FUA-220G, MB1A-10G, MB1E-10G, MBE-6G, MDA-10G, MDA-6G, MDE-10G, MDE-6G, TAUA-610G, VB1E-210G

JUNO-RÖDER-SENKING

KING

KOMAT

50.57021.010

KREFFT

KROMET

000.BEK-150.1, 000.BEK-200.W, 000.BEK-80.2, 700.BEK-80.2, 900.BEK-150.2, 900.BEK-200, KOCIOŁ WARZELNY ELEKTRYCZNY 700.BEK-80, KOCIOŁ WARZELNY ELEKTRYCZNY 900.BEK-200, KOCIOŁ WARZELNY GAZOWY 900.BEK-150

KROMO

BK21, S1, S2

KÜPPERSBUSCH

KÜPPERSBUSCH

Boiling Pan Electric

EES060, EES080, NEK040, NEK060, NEK080, NEK100, NEK150, NEM100, NER500, NES040, NES060, NES080, NES100, NES150, OES060, OES080, OES100

KÜPPERSBUSCH

Fry Top

LEB231, LEB431, LEB631, NEB431, NEB631, NEB831, SEB231, SEB431, SEB631

KÜPPERSBUSCH

Fry Top Electric

SEB231, SEB431, SEB631

KÜPPERSBUSCH

Fry Top Glass-Ceramics

LEB231, LEB431, LEB631, NEB431, NEB631, NEB831

KÜPPERSBUSCH

Fryer Electric

EEF040, FEF040, LEF040, NEF040, SEF400, TEF400

KÜPPERSBUSCH

Grill



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SER400, SER600

KÜPPERSBUSCH

Grill Electric

SER400, SER600

KÜPPERSBUSCH

Hot Plate Electric

FEH230, FEH430, FEH433, FEH435, FEH630, FEH633, FEH635, OEH230, OEH430, OEH433, OEH435, OEH630,
OEH633, OEH635

KÜPPERSBUSCH

Kitchen Electric

EEH210, EEH410, EEH413, EEH610, EEH613, OEH410 3X440V, OEH610 3X440V

KÜPPERSBUSCH

Kitchen Glass-Ceramics

EEH300, EEH500, EEH503, EEH700, EEH703, FEH300, FEH310, FEH500, FEH503, FEH505, FEH510, FEH513,
FEH515, FEH700, FEH703, FEH705, FEH710, FEH713, FEH715, LEH500, LEH503, LEH505, LEH700, LEH703,
LEH705, NEH500, NEH505, NEH510, NEH515, NEH700, NEH705, NEH710, NEH715, OEH300, OEH310, OEH500,
OEH503, OEH505, OEH510, OEH513, OEH515, OEH700, OEH703, OEH705, OEH710, OEH713, OEH715, PEH508,
PEH518, PEH708, PEH718, SEH300, TEH300

KÜPPERSBUSCH

Solid Top

FEH433, FEH435, FEH630, FEH633, FEH635, OEH433, RANGE FEH230

LAINOX

FE05, FG05, PE08, PE12, PG04, PG08, PG12, RE05, RE07, RE10, RE20, RE24, RG05, RG07, RG10, RG20, RG24,
RG40

LAINOX

Convection Oven

CE106M, CE110M, CE210M, CEC24M, CEC40M, CES24M, CG106M, CG110M, CG210M, CGC40M, CGS24M,
CGS40M, REC023M, REC101M, REP064M, REP074M, RGC071M, SCE042M, SCE051M, SCE071M, SCE101M,
SCE201M, SCE202M, SCEA20M, SCG051M, SCG071M, SCG101M, SCG201M, SCG202M, SCGA20M

LAINOX

Convection Oven Electric

CE106M, CE110M, CE210M, CEC24M, CEC40M, CES24M, REC023M, REC101M, REP064M, REP074M, SCE042M,
SCE071M, SCE101M, SCE201M, SCE202M, SCEA20M

LAINOX

Convection Oven Gas

CG106M, CG110M, CG210M, CGC40M, CGS24M, CGS40M, RGC071M, SCG051M, SCG071M, SCG101M,
SCG201M, SCG202M, SCGA20M

LOHBERGER

LOTUS



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

CFC-62EM, CFC-62ET, CFMC4-66ET, CWK-74ET, CWK-78ET, CWK-94ET, CWK-98ET, CWKT-64ET, CWKT-68ET, CWKT-74ET, CWKT-78ET, CWKT-94ET, CWKT-98ET, FTC-61EM, FTC-61ET, FTC-62EM, FTC-62ET, PC-CT-63ET, PCC-61EM, PCC-62EM, PCC-62ET

LOTUS

Fry Top

FTC-4EM, FTC-4EMX, FTC-6EM, FTC-6EMX, FTC-6ET, FTC-74ET, FTC-78ET, FTC-8EMX, FTC-8ET, FTC-94ET, FTC-98ET, FTCD-64EM, FTCD-66ET, FTCT-64ET, FTCT-66ET, FTCT-74ET, FTCT-78ET, FTCT-94ET, FTCT-98ET

LOTUS

Fry Top Glass-Ceramics

FTC-4EM, FTC-4EMX, FTC-6EM, FTC-6EMX, FTC-6ET, FTC-74ET, FTC-78ET, FTC-8EMX, FTC-8ET, FTC-94ET, FTC-98ET, FTCD-64EM, FTCD-66ET, FTCT-64ET, FTCT-66ET, FTCT-74ET, FTCT-78ET, FTCT-94ET, FTCT-98ET

LOTUS

Kitchen Glass-Ceramics

CFC4-8ET

LOTUS

Pot Stove Glass-Ceramics

PCC-4EM, PCC-4EMX, PCC-4ET, PCC-6EM, PCC-6EMX, PCC-6ET, PCC-8EMX, PCC-8ET

LOTUS

Salamander

SA-400EM, SA-400EMX, SA-600EM, SA-600EMX, SA-600ET, SA-600ETX, SL-600EM, SL-600EMX, SL-600ET, SL-600ETX, SLC-600EM, SLC-600ET

MACFRIN

5305, 53054, 5310, 53104, 5315, 53154, 5320, 53204, 5330, 53304, 5340, 53404, 5355, 5360, 53604, 5375, 5380, 53804

MARENO

CFVE60, CON102E, CON102EP, CON102G, CON102GP, CON10E, CON10EP, CON10G, CON10GP, CON201E, CON201EP, CON201G, CON201GP, CON202E, CON202EP, CON202G, CON202GP, CON6E, CON6EP, CON6G, CON6GP, CP704E, CP92E, CP92E2, CP94E, CP94E2, CP9SB2E, CP9SB2E2, CP9SB4E, CP9SB4E2, CPE60, CRE6220, CRE6230, CRE6320, CRE6330, CS102E, CS102EP, CS102G, CS102GP, CS10E, CS10EP, CS10G, CS6E, CS6EP, CS6G, CWE42, CWE62, FC10E, FC10G

MARENO

Glass-Ceramic Plate Electric

V9-4E, V9-8E

MARENO

Grill

NG74EP, NG78EP

MARENO

Grill Electric

NG74EP, NG78EP

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MARENO

Pasta Cooker

NPC74E, NPC74G, NPC76E, NPC76G, NPC78E, NPC78G, NPC94G, NPC96E, NPC96G, NPC98G, PC12C-4E,
PC12C-9E, PC7-4E, PC7-6E, PC7-8E, PC9-4E, PC9-6E, PC9-8E, PC9S-6E, PC9S-8E

MARENO

Pasta Cooker Electric

NPC74E, NPC76E, NPC78E, NPC96E, PC12C-4E, PC12C-9E, PC7-4E, PC7-6E, PC7-8E, PC9-4E, PC9-6E, PC9-8E,
PC9S-6E, PC9S-8E

MARENO

Pasta Cooker Gas

NPC74G, NPC76G, NPC78G, NPC94G, NPC96G, NPC98G

MARENO

Pot Stove Glass-Ceramics

V64E, V64EP, V67E, V7-4EC, V7-6EC

MARENO

Sausage Grill Electric

CRE-6220, CRE-6230, CRE-6320, CRE-6330

MARENO

Solid Top

RANGE V67EP, RANGE GLASS-CERAMICS V67EP

MASBAGA

AP10E, AP10G, AP15E, AP15G, AP20E, AP20G, AP30E, AP30G, AP40E, AP40G, AP55G, AP5E, AP5G, AP60E,
AP60G, AP75G, AP80E, AP80G

MASTRO

CFVE60, CON102E, CON102EP, CON102G, CON102GP, CON10E, CON10EP, CON10G, CON10GP, CON201E,
CON201EP, CON201G, CON201GP, CON202E, CON202EP, CON202G, CON202GP, CON6E, CON6EP, CON6G,
CON6GP, CP704E, CP92E, CP92E2, CP94E, CP94E2, CP9SB2E, CP9SB2E2, CP9SB4E, CP9SB4E2, CPE60,
CRE6220, CRE6230, CRE6320, CRE6330, CS102E, CS102EP, CS102G, CS102GP, CS10E, CS10EP, CS10G, CS6E,
CS6EP, CS6G, CWE42, CWE62, FC10E, FC10G

MBM

ECC46, EPL46, EPL66, FCE10, FCE108, FCE20, FCE6, FCE68, FCG10, FCG108, FCG20, FCG6, FCG68, FEC060,
FEC065, FEC100, FEC200, FEM060, FEM061, FEM100, FEM101, FEM200, FEM201, FEMD023, FEMD060,
FEMD061, FEMD065, FEMD066, FEMD100, FEMD101, FEMD200, FEMD201, FEP050, FEP080, FEP160, FGC060,
FGC065, FGC100, FGC200, FGM060, FGM061, FGM100, FGM101, FGM200, FGM201, FGMD060, FGMD061,
FGMD065, FGMD066, FGMD100...

METOS

74-02CTE, 74-02CTEE, 74-02NPEI, 74-02TCTE, CVP6E

MKN

00217022-0, 0221001H00, 0221202-00, 0221501-00, 0221502-00, 0521701-00, 0521702-00, 0521702-02,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

0521702-03, 0521702-04, 0521702B03, 0521702B04, 0521702C04, 0521704-04, 0521704-05, 0521705-00,
0521705-01, 1221501-00, 1221501-01, 1221501-02, 1223202A00, 1223209-00, 1321501-00, 1321501-01,
1321501-02, 1323202A00...

MKN

Bain-Marie Electric

1022603-00, 1222603-00, 1322603-00, 1422603-00, 2022603-00, 2122603-00

MKN

Fry Top

1321501-03

MKN

Fry Top Electric

1321501-03

MKN

Pasta Cooker

1220402-00, 1220402-01, 1320402-00, 1320402-01, 1520402-00, 1520402-01, 2020402-00, 2020402-01,
2120402-00, 2120402-01, 2120406A00, 3020402-00, 3020402-01, 4228801-00, 4228801-01

MKN

Pasta Cooker Electric

1220402-00, 1220402-01, 1320402-00, 1320402-01, 1520402-00, 1520402-01, 2020402-00, 2020402-01,
2120402-00, 2120402-01, 2120406A00, 3020402-00, 3020402-01, 4228801-00, 4228801-01

MKN

Pot Stove Glass-Ceramics

1023401-00, 1023401K00, 1223202A01, 1223202J00, 1223202J01, 1223209-01, 1223401-00, 1223401J00,
1223401K00, 1223401L00, 1223402-00, 1223402K00, 1323202A01, 1323202A02, 1323209-02, 1323209-03,
1323210-02, 1323210-03, 1323210-04, 1323401-00, 1323401K00, 1323402-00, 1323402K00, 1323403-00,
1323403K00, 1423402-00, 1424818A00, 1424824-01, 1424825-00, 1523401K00, 1523402K00, 2023212-00,
2023401-00, 2123207A01, 2123208A02, 2123208A03, 2123210-00, 2123401-00, 2123401K00, 2123402-00,
2123402K00, 2123403-00, 2123403K00, 3023401-00

MKN

Salamander

0521701-01, 0521702-01, 0521704-06, 0521704-07

MKN

Salamander Electric

0521701-01, 0521702-01, 0521704-06, 0521704-07

MODULAR

MODULAR

Convection Oven

NWM-6E-AV, NWW-10G, NWW-6G

MODULAR



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Convection Oven Gas

NWM-6E-AV, NWW-10G, NWW-6G

MODULAR

Electric Oven

NWM-10E-AV

MODULINE

MODULINE

Convection Oven

RB056M, RB142M, RC101M, RC153M, RC162M, RM112M, RMC20M, RRT153M

MODULINE

Convection Oven Electric

RB056M, RB142M, RC101M, RC153M, RC162M, RM112M, RMC20M, RRT153M

MORICE

MULTINOX

NAOMI-GRILLS

NAYATI

NORTH

OLIS

40SEW, 40SEW-1825190, 74-02CTE, 74-02CTE-12701170, 74-02CTEE-12701180, 74-02NPEI-12701755,
74-02TCTE-12731170, 7PN-EI50, 911PEB-1192805, 911RPEB-1392890, 915PEB-1192800,
96-04KBEC-12901105, CV10E-1320100, CV10E2-1320140, CV10EB-1321100, CV10ES-1320150,
CV10ES2-1320190, CV10G-1310100, CV10G2-1310140, CV10GB-1311100, CV10GS-1310150,
CV10GS2-1310190, CV20E-1320200, CV20E2-1320240, CV20EB-1321200, CV20ES-1320250,
CV20ES2-1320290...(OTHER

OLIS

Boiling Pan Electric

74-02NPEI, 7NP-EI50

OLIS

Boiling Pan Gas

74-10 PGD08, 94-10PGI10

OLIS

Bratt Pan

9BR-E100, 9BR-E105, 9BRS-E100, 9BRS-E105

OLIS

Bratt Pan Electric

9BR-E100, 9BR-E105, 9BRS-E105

OLIS

Bratt Pan Gas

9BRS-E100

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

OLIS

Electric Oven

CV10E, CV10E-2, CV10E-S, CV10E-S2, CV20E, CV20E-2, CV20E-S, CV20E-S2, CV21E, CV21E-2, CV21E-S, CV21E-S2, CV6E, CV6E-2, CV6E-S, CV6E-S2, CVM10E, CVM10E-2, CVM10E-S, CVM10E-S2, CVM20E, CVM20E-2, CVM20E-S, CVM20E-S2, CVM21E, CVM21E-2, CVM21E-S, CVM21E-S2, CVM6E, CVM6E-2, CVM6E-S, CVM6E-S2, CVP10E, CVP10E-2, CVP10E-S, CVP10E-S2, CVP20E, CVP20E-2, CVP20E-S, CVP20E-S2, CVP21E, CVP21E-2, CVP21E-S, CVP21E-S2, CVP6E, CVP6E-2, CVP6E-S, CVP6E-S2, FC10E, FC10E-2, FC10E-2S, FC10E-S, FC20E, FC20E-2, FC20E-2S, FC20E-S, FC21E, FC21E-2, FC21E-2S, FC21E-S, FC6E, FC6E-2, FC6E-2S, FC6E-S, FCM10E, FCM10E-2, FCM10E-2S, FCM10E-S, FCM10E-S2, FCM20E, FCM20E-2, FCM20E-2S, FCM20E-S, FCM21E, FCM21E-2, FCM21E-2S, FCM21E-S, FCM6E, FCM6E-2, FCM6E-2S, FCM6E-S, FCV10E, FCV10E-2, FCV10E-2S, FCV10E-S, FCV20E, FCV20E-2, FCV20E-S, FCV21E, FCV21E-2, FCV21E-2S, FCV21E-S, FCV6E, FCV6E-2, FCV6E-2S, FCV6E-S

OLIS

Gas Oven

CV10G, CV10G-2, CV10G-S, CV10G-S2, CV20G, CV20G-2, CV20G-S, CV20G-S2, CV21G, CV21G-2, CV21G-S, CV21G-S2, CV6G, CV6G-2, CV6G-S, CV6G-S2, CVM10G, CVM10G-2, CVM10G-S, CVM10G-S2, CVM20G, CVM20G-2, CVM20G-S, CVM20G-S2, CVM21G, CVM21G-2, CVM21G-S, CVM21G-S2, CVM6G, CVM6G-2, CVM6G-S, CVM6G-S2, CVP10G, CVP10G-2, CVP10G-S, CVP10G-S2, CVP20G, CVP20G-2, CVP20G-S, CVP20G-S2, CVP21G, CVP21G-2, CVP21G-S, CVP21G-S2, CVP6G, CVP6G-2, CVP6G-S, CVP6G-S2, FC10G, FC10G-2, FC10G-2S, FC10G-S, FC20G, FC20G-2, FC20G-2S, FC20G-S, FC21G, FC21G-2, FC21G-2S, FC21G-S, FC6G, FC6G-2, FC6G-2S, FC6G-S, FCM10G, FCM10G-2, FCM10G-2S, FCM10G-S, FCM20G, FCM20G-2, FCM20G-2S, FCM20G-S, FCM21G, FCM21G-2, FCM21G-2S, FCM21G-S, FCM6G, FCM6G-2, FCM6G-2S, FCM6G-S, FCV10G, FCV10G-2, FCV10G-2S, FCV10G-S, FCV20E-2S, FCV20G, FCV20G-2, FCV20G-2S, FCV20G-S, FCV21G, FCV21G-2, FCV21G-2S, FCV21G-S, FCV6G, FCV6G-2, FCV6G-2S, FCV6G-S, MCVM6G-2

OLIS

Kitchen Electric

74-02CTEE, 7TP-E800, 7TPF-EE800, 7TPV-E800, 7TPVP-E800

OLIS

Pasta Cooker

72-10CPG, 73-10CPE, 73-10CPG, 74-10CPG, 94-10CPG, D92-10CPG

OLIS

Solid Top

74-02TCTE, RANGE 74-02CTE, RANGE ELECTRIC 74-02CTE

PALUX

503010, 503150, 517887, 574961, 610038, 61030X, 610402, 610429, 620203, 620300, 620408, 620424, 637564, 657735, 659002, 685003, 686018, 686026, 686034, 686298, 688428, 700673, 702560, 706000, FOEM-KIPPBRATPFANNE-ELEKTRO, ODWB-1040-WAERMEBRUECKEN, ODWB-1240-WAERMEBRUECKEN, ODWB-1440-WAERMEBRUECKEN, ODWB-1640-WAERMEBRUECKEN, ODWB-1840-WAERMEBRUECKEN, ODWB-2040-WAERMEBRUECKEN, OEWB-1040-WAND-WAERMEBORDE, OEWB-1240-WAND-WAERMEBORDE,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

OEWB-1440-WAND-WAERMEBORDE, OEWB-1640-WAND-WAERMEBORDE, OEWB-1840-WAND-WAERMEBORDE,
OEWB-2040-WAND-WAERMEBORDE, STEAKGRILL-61030, STEAKGRILL-62030

PALUX

Fryer Electric

ELECTRIC-APPLIANCES-614-TO-629

PALUX

Grill

BISTROLINE-STEAK-GRILL

PALUX

Grill Electric

BISTROLINE-STEAK-GRILL

PALUX

Pot Stove Electric

FUNCTIONLINE-COOKER, TOPLINE-VARIO-COOKER

PALUX

Pot Stove Glass-Ceramics

BISTROLINE-CERAMIC-RANGE

PALUX

Potato Heater

BISTROLINE-CHIP-SCUTTLE, COMPACT-ELECTRIC-CHIP-SCUTTLE, FUNCTIONLINE-CHIP-SCUTTLE,
TOPLINE-CHIP-SCUTTLE

PALUX

Potato Heater Electric

BISTROLINE-CHIP-SCUTTLE, COMPACT-ELECTRIC-CHIP-SCUTTLE, FUNCTIONLINE-CHIP-SCUTTLE,
TOPLINE-CHIP-SCUTTLE

PALUX

Salamander

SALAMANDER

PALUX

Salamander Electric

SALAMANDER

RIEBER

Chaffing Dish

ROLLITO RO-WT-2

RIEBER

Chaffing Dish Electric

ROLLITO RO-WT-2

RIEBER

Food-Service Trolley



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

BUFFETTO WARM TOP

RIEBER

Pot Stove Electric

VARITHEK CK 3,4

RINALDI SUPERFORNI

RM-GASTRO

ROLLER GRILL

ROLLER GRILL

Lava Rock Grill

140D, GRILL ELECTRIC 140

ROLLER GRILL

Pizza Oven

PZ 430 2D, PZ 430 S, PZ 430D, PZ 430S

ROLLER GRILL

Pizza Oven Electric

PZ 430 2D, PZ 430 S, PZ 430D, PZ 430S

ROLLER GRILL

Sausage Grill

CS2004, RG5

ROLLER GRILL

Sausage Grill Electric

CS0E, CS2E, CS3E, CS4E, HD4, RG11, RG7, RG9

ROSINOX

SALVIS

SAMMIC

SAMMIC

Salamander

SGF-450, SGF-650

SAMMIC

Salamander Electric

SGF-450, SGF-650

SILKO

BER12, BER14, BER16, BER18, BER20, CBE6030, CCQ9020, CCQ9020-V, CCQ9021, CCQ9021-V, CCQ9022, CCQ9022-V, CCQ9040, CCQ9040-V, CCQ9041, CCQ9041-V, CCQ9042, CCQ9042-V, CCQ9046, CCQ9046-V, CCT6020V, CCT6040V, CCT7020-V, CCT7021-V, CCT7022-V, CCT7040-V, CCT7041-V, CCT7042-V, CCT7046-V, CCT7220V, CCT7221V, CCT7222V, CCT7240V, CCT7241V, CCT7242V, CCT7246V, CNE6230, CPD90100, CPD90100A, CPD90150, CPD90150A, CRE6-20, CRE6-30, CRE6220, CRE6230, CSE-045, CSE-048, CSE-050, CSE-053, CSE-060...(OTHER

SILKO



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Fry Top

ECV74

SILKO

Glass-Ceramic Plate

CV64TPS, ECV74

SILKO

Pasta Cooker

DE72128, DE74228, DE82140, DE84240, DE92142, DE94242, DEY2142, DEY4242

SILKO

Pasta Cooker Electric

DE74228, DE82140, DE84240, DE92142, DE94242, DEY2142, DEY4242

SILKO

Pot Stove Glass-Ceramics

CV62TPS, CV64TPS, CV72, CV74, CV82, CV84

SIRMAN

SIRMAN

Panini Grill Electric

HOTDOG, HOTDOG 3 Y06, HOTDOG 4 Y06

SIRMAN

Pasta Cooker

GW 5 CE, GW 7 CE

SIRMAN

Pasta Cooker Electric

GW 5 CE, GW 7 CE

SIRMAN

Salamander

SALAMANDRA BASIC, SALAMANDRA FISSA, SALAMANDRA PRO, SALAMANDRA PRO 1/1 G CE, SALAMANDRA PRO
1/2 G CE

SIRMAN

Salamander Electric

SALAMANDRA BASIC, SALAMANDRA FISSA, SALAMANDRA PRO, SALAMANDRA PRO 1/1 G CE, SALAMANDRA PRO
1/2 G CE

SIRMAN

Sausage Grill Electric

GW 9 CE

SMEG

SMEG

Electric Oven

ALFA30V, ALFA31V, S101X-5, S104X-5, S106X-5, S106X-6, S108X-5, S108X-6, S200, S200-1, S200EB,



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

S200EB-1, S200X, S200X-1, S201X, S300, S300EB, S300X, S300X-5, S301X-5, S302X, SC041MFX, SC0468X-8, SC0485X-8, SC04MFX, SC0521X-8, SC0578X-8, SC061MFX, SC061X-8, SC06MFX, SC081MFX, SC081X-8, SC08MFX, SC51X, SC54X, SC63MFX, SC64MFX, SC73MFX, SC74MFX, SE101EB, SE101NE, SE101X, SE105EB, SE105EB-1, SE105NE, SE105NE-1, SE105X, SE105X-1, SE106EB, SE106EB-1, SE106NE, SE106NE-1, SE106X, SE106X-1, SE106X-5, SE108X-1, SE286X, SE286X-5, SE50X-5, SE51X-5, SE62MFX-5, SE63MFX-5, SE72MFX-5, SE73MFX-5, SE820MF, SE820MF-1, SE820MFB1, SE820MFEB, SE90, SE90-1, SE90EB, SE90EB-1, SE90MB, SE90MB-1, SE90X, SE90X-1, SE92, SE92EB, SE96, SE96-1, SE96EB, SE96EB-1, SE96MB, SE96MB-1, SE96X, SE96X-1, SF0351X, WE200, WE200-1, WE200EB, WE200EB-1, WE200X, WE200X-1, WI200, WI200EB, WI200X, WI300, WI300EB, WI300X

SMEG

Kitchen Electric

CE6CMX, CE92CMX, CE9CMX, CE9CMXA, CIE66MDK3, SUK60CMFA, SUK60CMFX, UK60CMFA, UK60CMFA1, UK60CMFX, UK60CMFX1

SMEG

Kitchen Gas

S854XQV-A, SUK60GA, SUK60GX, SUK60MFA, SUK60MFX, SUK80GA, SUK80GX, SUK80MFA, SUK80MFX, UK60MFA, UK60MFA1, UK60MFX, UK60MFX1, UK80MFA, UK80MFA1, UK80MFX, UK80MFX1

SMEG

Pot Stove

PDX12RUSB

SMEG

Pot Stove Electric

P652, P752, P764AO, P764PO, P775AO, P775PO, P864A, P864A-9, P864P, P864P-9, P875A, P875P, PDX30B-1, PDX30BBR2, PDX30C-1, PDX30CBR2, PDXF30B, PDXF30B-1, PDXF30C, PDXF30C-1, PDXK30B, PDXS30B, PDXS30B-1, PDXS30C, PDXS30C-1, PGA32C, PGF30B, PGF32C, S264C, SA661X1, SE641X, SE660, SE660-1, SE660X, SE660X1, SE661X, SE661X1

SMEG

Pot Stove



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

