



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta 9000W 230V 470mm #3355480

Fara TVA: 512,61 Lei

Pret cu TVA: 610,01Lei

Rezistenta 9000W 230V 470mm #3355480

power 9000W

voltage 230V

length 470mm

mounting round flange

connection M5

tube diameter 8.5mm

heating circuits 3

height 41mm

mounting diameter 57.5mm

width 35mm

diameter thermostat sleeves 7.5mm

number of thermostat sleeves 1

length thermostat sleeves 295mm

connection length upper centre not clinging mm

application immersion heater

Compatibil cu:

ALBA 30001011

ANGELO PO 32G3410

ATEL 27LS007

BOBECK 27LS007, E30001011

DIHR 0016303, 0030001011, 16303, 27LS007, 30001011, DW16303, DW30001011

EPMS 27LS007, LF3355480

GEV 415265

HENDI 3355480

HORECAPARTS 3355480

IRCA 1GEL7E489002, 1GEL7R677002

KROMO 0016303, 0030001011, 1GEL7R677002, 30001011, DW16303, DW30001011

LANDOT 1GEL7R677002, 4798

LUXIA 1GEL7R677002, 30001011

METOS 1GEL7R677002, 30001011



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MULTI 130011

OLIS 1GEL7R677002, 30001011, BN011DWM30001011

RHIMA 1GEL7R677002, 50300043

ROSINOX 1GEL7R677002, RX94807963

SAGI 1GEL7R677002, 32G3410

ALBA

ANGELO PO KD100, KD100A, KD100PSD, KD130, KD130A, KD130E, KD130EAT, LP202, LP202HC, LP302, LP302HC, LP402, LP402HC, LP402V, LPG300, N100D, N100S, N100VD, N100VS, N38D, N38S, N42D, N42S, N42VD, N42VS, N50D, N50S, N50VD, N50VS, N66D, N66S, N66VD, N66VS, N70D, N70S, N70VD, N70VS, N85D, N85S, N85VD, N85VS

ANGELO PO Dishwasher KD130E, KD130EAT

ANGELO PO Dishwasher Conveyor N100D, N100S, N100VD, N100VS, N38D, N38S, N42D, N42S, N42VD, N42VS, N50D, N50S, N50VD, N50VS, N66D, N66S, N66VD, N66VS, N70D, N70S, N70VD, N70VS, N85D, N85S, N85VD, N85VS

ANGELO PO Dishwasher Hood KD100, KD100A, KD100PSD, KD130, KD130A

ANGELO PO Pan / Utensilwashing Machines LP202, LP202HC, LP302, LP302HC, LP402, LP402HC, LP402V, LPG300

ASCASO

DIHR AX151, AX151-HIGHSPEED, AX160, AX161, AX210, AX220, AX230, AX240, AX250, AX290, AX300, AX300LC, AX310, AX310LC, AX320, AX330, AX380, AX380LC, AX400, AX440, AX440LC, AX510, AX510LC, AX540, AX540LC, BX230, BX230SPECIAL, BX280, BX300, CX, FX, GASTRO-11-S, GASTRO-11-S-ISOLATA, GASTRO-11S, GASTRO-1200-S, GASTRO-1200-S-ISOLA-TA, GASTRO-1200S, GASTRO11S, GASTRO1200, GASTRO12S, GRANUL1000, GRANUL900, H600, H600ELECTRONIC, HT11

DIHR Dishwasher 111EN (HT12E), 111EU (HT12E), 115U (OPTIMHR), 123EU (ELECTRON1000 PLUS), 19ER (LP3 ELETTRONICA), 81E (LP3S PLUS), 81E (LP3STR PLUS), 92 (AX290), H63E (H600 ELETTRONICA)

DIHR Dishwasher Conveyor 77 (CX), 77 (FX)

DIHR Dishwasher Hood 112E600U (H600E PLUS), 112EU (HT12E PLUS), 144R (GASTRO11S), 144S (HT111E), 144T (HT11T TOUCHE), 144U (HT11), 14R (HT11), 14U (GASTRO11S), 373E (GASTRO12S ELETTRONICA), 373R (GASTRO12S), 373U (GASTRO12S), 373U (HT12), 37U (HT12), G12D, G12S, H63R (H600)

DIHR Dishwasher Pull-Through 22 (AX160), 23 (AX210), 24 (AX250), 25 (AX300), 25 (AX300LC), 25 (AX310), 25 (AX310LC), 25 (AX330), 26 (AX380), 26 (AX380LC), 26 (AX400), 27 (AX440), 27 (AX440LC), 28 (AX540), 28 (AX540LC), 34 (AX151), 34 (AX151HS), 34HS (AX151HS), 39 (BX280), 71 (BX230), 71G (BX230 CON SISTEMA GIRACESTE), 71G (BX230), 72 (BX300), 85 (UX220), 85EG (EVENT MASTER), 85EG (GLASS MASTER), 87 (TX1500), 91 (AX161)

DIHR Pan / Utensilwashing Machines

109E (GRANUL1000), 110EU (GRANUL900), 116EU (LP1/800), 117EU (LP1S8 PLUS), 118EU (LP2 PLUS), 119EU (LP3 PLUS), 120EU (LP4S8 PLUS), 123E55U (LP1S5 PLUS), 123E55U (LP1S5), 16R (LP1), 17R (LP1/800), 17U (LP1/800), 18ER (LP2 ELETTRONICA), 18U (LP2), 19U (LP3), 35ER (LP4/800 ELETTRONICA), 35U (LP4/800), 68E (GRANUL900), 69R (LPZERO), 69U (LPZERO), 70R (LP1S8), 70U (LP1S8), 82E (LP4S8 PLUS), 82E (LP4S8TR

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

PLUS)

KROMO BB-2500, F, FP, GR300, GR800, HOOD-110, HOOD-110-E, HOOD-130, HOOD-130-ELETTRONICA, HOOD800SP-3D-GOGGLES-IMAX, K1600, K1600-ALTA-VELOCITA, K1700, K1800, K2100, K2200, K2500, K2700, K3000, K3000+K10, K3100, K3100+K10, K3300, K3800, K3800+K10, K4000, K4400, K4400+K10, K5400, K5400+K10, KP130-ELETTRONICA, KP149, KP150, KP151, KP151-E, KP200, KP200-ELETTRONICA, KP202-E, KP2300, KP2300+KP23, KP2800, KP300, KP300-ELETTRONICA, KP3000, KP302-E, KP400, KP4000

KROMO Dishwasher Hood K100, K120

LUXIA Dishwasher Pull-Through CT160

METOS

MULTI

OLIS G12S, OLAX151, OLAX151-HIGHSPEED, OLAX151EDX-1080725, OLAX151ELEFT-1080727, OLAX160, OLAX160E-1080750, OLAX160E-1080751, OLAX160V-1080755, OLAX160V-1080756, OLAX160V-1081031, OLAX160V-1081032, OLAX210, OLAX210E-1081029, OLAX210E-1081030, OLAX220, OLAX220E-1080787, OLAX220E-1080788, OLAX220V-1080789, OLAX220V-1080790, OLAX230, OLAX230E-1080791, OLAX230E-1080792, OLAX230V-1080793, OLAX230V-1080794, OLAX240, OLAX240E-1080795, OLAX240E-1080796, OLAX240V-1080797, OLAX240V-1080798, OLAX250, OLAX250E-1080760, OLAX250E-1080761, OLAX250V-1080765, OLAX250V-1080766, OLAX300, OLAX300E-1080770, OLAX300E-1080771, OLAX300E-1081033, OLAX300E-1081035, OLAX300E-1081036, OLAX300LC, OLAX300LCE-1081034, OLAX300V-1080775, OLAX300V-1080776, OLAX310, OLAX310E-1081110, OLAX310E-1081111, OLAX310LC

RHIMA

ROSINOX

