

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rulment ø22x8x7mm 608-2Z SKF #D063082

Fara TVA: 16,81 Lei

Pret cu TVA: 20,00Lei

Rulment ø22x8x7mm 608-2Z SKF #D063082

material otel inoxidabil
diametru exterior 22mm
latime 7mm
aplicatie universal
tip 608-2Z
producator SKF
standard DIN 625-1
diametru ax 8mm

Compatibil cu:

ATEL 13AG122

ARISTON

BAUKNECHT - INDESIT

CANDY

CANDY Dishwasher 32000018 (LSCD570D), 32000022 (LSCD710M), 32000029 (LSCD711S-1), 32000030 (LSCD601A-1), 32000032 (CD711SX-1IT), 32000038 (LSCD265AXFR), 32000039 (LSCD265AFR), 32000040 (LSCDE705AFR), 32000041 (LSCD622XUK), 32000042 (LSCDE700AFR), 32000043 (LSCD245AFR), 32000044 (CD700SY), 32000045 (CD700ES), 32000046 (LSCD650UK), 32000050 (LSCD711-1ES), 32000051 (LSCDW478-1), 32000052 (LSCD372-1), 32000053 (LSCD800-1ES), 32000054 (LSCDW374-1ES), 32000060 (LSCD623UK), 32000061 (CD623XUK), 32000062 (LSCDW479-1E), 32000063 (LSCD571-1E), 32000064 (LSCDW480-1E), 32000065 (LSCD700IT), 32000066 (CD711-1XES), 32000069 (LSCD6100), 32000071 (LSCD801TX), 32000073 (LSCD255FR), 32000074 (CDF312P01), 32000075 (CDF315P01), 32000076 (CDF615A01), 32000077 (CDF615AX01), 32000078 (CDF615AN01), 32000079 (CDF715T01), 32000080 (CDF715TX01), 32000085 (CD31280), 32000086 (CD112S80), 32000087 (CD11280), 32000090 (LSCDF62247), 32000091 (LSCDF51247), 32000092 (LSCDF512X47), 32000104 (CD212A-40S), 32000105 (CD1120-40S), 32000106 (CD112-01), 32000107 (CDF715T-37), 32000108 (CDF6150CORTE), 32000110 (CFD6151MIRO), 32000111 (CDF6152MAST), 32000112 (CDF3154XIDE), 32000114 (CDF615A-37), 32000116 (CDF312P-37), 32000117 (CD1120CORTE), 32000118 (CD112-85S), 32000120 (CDF312-80), 32000121 (CDF715T-16S), 32000122 (CD112-41S), 32000123 (CDF312A-85S), 32000124 (CDF312AX-41S), 32000125 (CDF615A-39S), 32000126 (CDF615A-85S), 32000127 (CDF615AX-84S), 32000141 (CD112-04ARG), 32000142 (CDF622X47), 32000149 (CDF315A-39S), 32000150 (CDF615T-86S), 32000151 (CDF312T-86S), 32000154 (CDF615TX-86S), 32000165 (CKDCD115), 32000171 (CDF622-80), 32000172 (CDF622X-80), 32000173 (CDF322-80), 32000182



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(CDF722-47), 32000183 (CDF513X-47), 32000184 (CDF513-47), 32000185 (CDF312X-47), 32000186 (CDF312-47), 32000188 (CD122-39S), 32000203 (CD112-86S), 32000247 (CDF732X-47), 32000248 (CDF732-47), 32000250 (CDF765-47), 32000256 (CDF735HX-01), 32000257 (CDF735H-01), 32000286 (CDF735P-16S), 32000317 (CD488-47), 32000318 (CD488L-47), 32000321 (CDF772-47), 32000322 (CDF772X-47), 32000323 (CDF872-47), 32000351 (CDF735X-S), 32000377 (CDF8715-01), 32000380 (CDF8715X-01), 32000381 (CDF8815X-S), 32000382 (CDF8825-S), 32000393 (CPPX5000-S), 32000396 (CDF8846), 32000396 (CDF8846-47), 32000398 (CDF8646X-47), 32000399 (CDF8646-47), 32000412 (CDF8712-01), 32000413 (CDF8712L-01), 32000415 (CDF8712-S), 32000416 (CDF8712L-S), 32000422 (CDF8712-1-01), 32000426 (CDF8322-60), 32000427 (CDF8615X-60), 32000429 (CDF872E10L-S), 32000430 (CDF872E10-S), 32000467 (CDF885E10-S), 32000468 (CDF885E10X-S), 32000469 (CDF875E10-01), 32000470 (CDF875E10X-01), 32000472 (CDF860E10-S), 32000473 (CDF860E10X-S), 32000474 (CDF865E10-S), 32000477 (CDF8712L-1-01), 32000479 (CDF8647), 32000479 (CDF8647-47), 32000480 (CDF8647X-47), 32042624 (LSB4001WFR), 32043648 (LSEXCL.651), 32044000 (LSCI6600W), 32044604 (LSCI6600N), 32044612 (LSCI6600M), 32044620 (LSCI6600XN), 32045007 (LSCI6100W), 32045015 (LSCI7100W), 32045106 (LSCI7100X), 32045114 (LSCI7100NITA), 32045502 (LSCI6100WUK), 32045510 (LSCI6100MUK), 32045601 (LSCI6100N), 32045619 (LSCI6100M), 32045627 (LSCI6100NIT), 32061012 (LSCDW965S), 32066003 (LSECO2061UK), 32068009 (LSCI6800W), 32068603 (LSCI6800M), 32068611 (LSCI6800N), 32068629 (LSCI6800X), 32069007 (LSCI6300W), 32069015 (LSCI7300W), 32069106 (LSCI7300X), 32069114 (LSCI7300N), 32069130 (LSCI7300XOS), 32069601 (LSCI6300N), 32069619 (LSCI6300X), 32069627 (LSCI6300XA), 32083008 (LSCI6850W), 32083602 (LSCI6850N), 32083610 (LSCI6850X), 32088007 (LSCDW250UNI), 32088015 (LSCD351S), 32088114 (LSCD373SK), 32088122 (LSCD373C), 32088205 (LSCDW255SCE), 32088502 (LSCDW250UK), 32088601 (LSCDW250S), 32088619 (LSCDW250NX), 32088627 (LSCDW250SNX), 32088643 (LSCDW250ARG), 32088650 (LSCHIARA258S), 32088668 (LSCDW252), 32088676 (LSCDW250SKOR), 32088684 (LSCDW250-D), 32088692 (LSCDW250-CBR), 32089005 (LSCDW363ITES), 32089609 (LSCDW365ITES), 32089617 (LSCDW365SUNI), 32089625 (LSCDW35), 32091001 (LSCDW470UNI), 32091019 (LSCD571S), 32091308 (LSCDW471S), 32091506 (LSCDW470UK), 32091605 (LSCDW470SUNI), 32091613 (LSCDW470SARG), 32091621 (LSCHIARA488S), 32091639 (LSCDW470SKOR), 32091647 (LSCDW675S), 32092603 (LSCDW575S), 32092611 (LSCDW575SNX), 32092629 (LSCDW575SXX), 32114001 (LSCDW484UNI), 32114506 (LSCDW587UK), 32114514 (LSCDW587XUK), 32114605 (LSCDW484S), 32114613 (LSCDW484XX), 32114621 (LSCDW485), 32116006 (LSCDW254UNI), 32116501 (LSCDW254), 32116600 (LSCDW254NX), 32116618 (LSCDW254S), 32116626 (LSCDW254SNX), 32116634 (LSCDW254E), 32116642 (LSCDW144), 32116659 (LSCDW258S), 32116667 (LSCDW254I), 32116675 (LSCDW256), 32117004 (LSCHIARA259S), 32118002 (LSCDW686S), 32119000 (LSCHIARA489S), 32121006 (LSCDW374ITES), 32122004 (LSCDW376), 32122608 (LSCDW376S), 32122624 (LSCDW36), 32122632 (LSCDW376SR), 32122640 (LSCDW376SY), 32122657 (LSCDW376SB), 32122665 (LSCDW376SSEE), 32124000 (LSCDW586S), 32124604 (LSCDW586SNX), 32124612 (LSCDW586SXX), 32125007 (LSCDW966S), 32125601 (LSCDW966SXX), 32129009 (LSCDW464), 32129108 (LSCD474XUK), 32143000 (LSCDW254E-1), 32143018 (LSCDW362E), 32143109 (LSCDW254SNX1), 32143117 (LSCDW258E), 32143125 (LSCDW252-1), 32143133 (LSCDW254-1), 32143141 (LSCDW144-1), 32143158 (LSCDW254SXXT), 32143166 (LSCDW263), 32143174 (LSCDW478), 32143182 (LSCDW374),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

32143190 (LSCDW479E), 32143208 (LSCDW274SNX), 32145005 (LSCDW36-1), 32145013 (LSCDW578),
32145104 (LSCDW35-1), 32145112 (LSCDW36E), 32145120 (LSCDW374-1), 32145138 (LSCDW376-1),
32145146 (LSCDW378), 32145153 (LSCDW480E), 32147001 (LSCI7950GH), 32147100 (LSCI7950X), 32147118
(LSCI7950BD), 32147126 (LSCI7950BA), 32148009 (LSCI7850W), 32148108 (LSCI7850N), 32148116
(LSCI7850X), 32152001 (LSCD242), 32152019 (LSCD372), 32152100 (LSCD352), 32152126 (LSCD260SCH),
32152134 (LSCD257), 32152142 (LSCD352ARG), 32152159 (LSCD242UK), 32152167 (LSCD353SITA),
32152175 (LSCD500), 32152191 (LSCD600), 32152209 (LSCD602S), 32152217 (LSCD602SX), 32153108
(LSCD474SX), 32153116 (LSCD585HSIT), 32153124 (LSCD687S), 32153132 (LSCD490SCH), 32153140
(LSCD474S), 32153157 (LSCD474SY), 32153173 (LSCD474SB), 32153181 (LSCD585HS), 32153199
(LSCD585HSARG), 32153207 (LSCD474SXITA), 32153223 (LSCD472), 32153231 (LSCD476BLU), 32153249
(LSCD702T), 32158008 (LSCD797SMARTIT), 32158107 (LSCD797SMX), 32158115 (LSCD797SMSY), 32158123
(LSCD797SMARTAC), 32158131 (LSECOTEMPO), 32158149 (LSCD798SM), 32158156 (LSECOTEMPO-1),
32158164 (LSCDE701A), 32158172 (LSCD801T), 32158180 (LSCD651S), 32159006 (LSCDW484-1), 32159105
(LSCDW485-1), 32159113 (LSCDW586-1S), 32159121 (LSCDW583), 32159139 (LSCDW588E), 32164006
(LSCD262), 32164113 (LSCD243AFR), 32164121 (LSCD263AFR), 32164139 (LSCD263AXFR), 32165003
(LSCD373), 32165102 (LSCD489DAC), 32165110 (LSCD483AC), 32165128 (LSCD475S), 32165136
(LSCD475SX), 32165144 (LSCD587HS), 32165151 (LSCD572ES), 32165169 (LSCD571E), 32165177
(LSCD484AFR), 32165185 (LSCD675S), 32165193 (LSCD675SX), 32183006 (LSCD711S), 32183105
(LSCD711XIT), 32183147 (LSCD711ES), 32188005 (LSCD701IT), 32188104 (LSCD701XIT), 32188112
(LSCD701NIT), 32188120 (LSCD701BIT), 32188138 (LSCD701YIT), 32188146 (LSCDE701TNOR), 32188153
(LSCDE701TXNO), 32189003 (LSCD800SIT), 32189102 (LSCD800SXIT), 32189110 (LSCD800ES), 32191009
(LSCD834UK), 32191108 (LSCD934UK), 32193104 (LSCD950UK), 32195000 (LSCD501IT), 32195109
(LSCD601IT), 32196008 (LSCD383FR), 32196115 (LSCD384A), 32196123 (LSCD384AX), 32216004
(LSCD451TNORD), 32900028 (CDS120W-02S), 32900029 (CDS120N-02S), 32900030 (CDS120X-02S),
32900031 (CDS150X-02S), 32900032 (CDS150N-84S), 32900033 (CDS150W-84S), 32900035 (CDI2015-02),
32900036 (CDI3015-02), 32900037 (CDS350XDUEDI), 32900038 (CDI1012-S), 32900039 (CDI2015-S),
32900040 (CDI3015-S), 32900041 (CDI4015-S), 32900042 (CDS450XFIFTIES), 32900043 (CDS250XPLAN),
32900044 (CDIPLAN), 32900046 (CDS120ALU-47), 32900060 (CDI1012-80), 32900061 (CDI2012-80),
32900062 (CDS120X-80), 32900070 (CDS350WDUEDI), 32900071 (CDS350NDUEDI), 32900081 (CDI5015),
32900083 (CDS2550XPL), 32900084 (CDI5550), 32900092 (CDI5515-S), 32900156 (CDI5650P2-S), 32900161
(CDI5012E10), 32900183 (CDI2012E10-02), 32900200 (CDI22E10-80), 32900205 (CDS530N-47), 32900220
(CDS530X-47), 32900221 (CDS530W-47), 32900222 (CDI36E10-47), 32900232 (CDI5515E10-S), 32900233
(CDI5015E10-S), 35268663 (CFCC5541MF), 36003606 (F331WCOREA)

EPMS

GASFIRE

GASFIRE Dishwasher 32047003 (LS GLS2100ST), 32047607 (LS GLS 1100), 32048001 (LS GLS1091 W),
32048605 (LS GLS1091 N), 32048613 (LS GLS1091XN), 32062002 (LS GLS 2091W), 32062606 (LS GLS 2091N),
32062614 (LS GLS2091XN)

GASFIRE Washing Machine A0000372 (DISHWASHER SECTI)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

HOOVER

HOOVER Dishwasher 32000009 (LS HD 97 E), 32000010 (LS HD 95 M), 32000011 (LS HD 83 M), 32000019 (LS DAA 835K), 32000020 (LS DAA 977K), 32000057 (LS HD 73 MUK), 32000058 (LS HD 98 E), 32000059 (LS HD73M ALU), 32000067 (HD 96 M ALU), 32000068 (LS HD 96 M), 32000081 (HND 615 80), 32000082 (HND315SILVER), 32000083 (HND 315 80), 32000093 (LSHND815-47), 32000094 (LSHND715-47), 32000095 (HND815ALU47), 32000096 (LSHND915-47S), 32000119 (HND 615 S-80), 32000128 (HND315A-85S), 32000129 (HND615A-85S), 32000130 (HND715T-30S), 32000131 (HND915T-30S), 32000132 (HND315AAL-85), 32000133 (HND615AAL-85), 32000134 (HND715TAL-16), 32000152 (HND715T-86S), 32000158 (HND315AX-37S), 32000163 (PDF15SILVER), 32000164 (PDF15-80), 32000175 (HND925-80), 32000177 (HND625-80), 32000178 (HD312-80), 32000179 (HND325SILV), 32000180 (HND325-80), 32000181 (HND915X-47), 32000189 (CKD HND 615 A), 32000192 (HDGX 5000-30S), 32000195 (HND6155-83), 32000278 (LSHND9515Z), 32000279 (HND955Z-47), 32000280 (HND995Z-47), 32000282 (LSHND7515AL), 32000289 (HOD 8-47), 32000290 (HOD 9-47), 32000297 (SKD HND 3515 AX), 32000307 (HOD 9-S), 32000308 (HOD 5 X-47), 32000309 (HOD 4-47), 32000310 (HOD 3-47), 32000325 (HOD 5-47), 32000355 (CKDHOD9-S), 32000357 (HOD9-86S), 32000394 (HPPX 5000 - S), 32000410 (HND 7102-80), 32000414 (HOD7715-60), 32000418 (HND 7102 S), 32000447 (HOD 4G10 BL-47), 32000448 (HOD 5G10X-47), 32000449 (HOD 5G10-47), 32000450 (HOD 8G10-47), 32000459 (HOD 75G10 AL-S), 32000460 (HOD 75G10-S), 32000465 (HND 8510-80), 32078305 (LS D7621NORD), 32079006 (LS D 7630 W), 32079600 (LS D 7630 CH), 32081002 (LS D 7640UNI), 32082000 (LS D 7650UNI), 32082604 (LS D 7650 CH), 32094005 (LS D 820 UK), 32094203 (LS D 815 CE), 32094211 (LS D 825 CE), 32094302 (LS D811 NORD), 32094310 (LS D821 NORD), 32094500 (LS D 7610 UK), 32094526 (LS DA 82007), 32094609 (LS S 813 UNI), 32094617 (LS D 823 UNI), 32094625 (LS D 823 CH), 32094641 (LS D823 SIN), 32094658 (LS D 823 017), 32094674 (LS D824 011), 32094690 (LS D824 021), 32094708 (LS D 822 071), 32094716 (LS D 816 031), 32094724 (LS D 812 071), 32094732 (LS D 814 011), 32095002 (LS D 830 UK), 32095200 (LS D 835 CE), 32095309 (LS D831 NORD), 32095507 (LS D839 001), 32096000 (LS D 840 UK), 32096018 (LS D846), 32096604 (LS D 845 UNI), 32096612 (LS D 845 CH), 32096620 (LS D845 SIN), 32096638 (LS D 846 021), 32096646 (LS D 940 001), 32133001 (LS D834), 32133605 (LS D 832 071), 32133613 (LS D836 031), 32146102 (LS D834-1011), 32146110 (LS D836-1031), 32146128 (LS D832-1071), 32151003 (LSD7610-2001), 32151011 (LS DS 732), 32151102 (LS D814-1011), 32151110 (LS D816-1031), 32151128 (LS D812-1071), 32151136 (LS D824-1011), 32151169 (LS D822-1071), 32154007 (LS D820-1001), 32154106 (LS D821 001), 32163008 (LS D 834 K), 32176109 (LS DH833A SY), 32176117 (LS DH836T SY), 32176125 (LSDH836TNORD), 32177008 (LS AAA 977), 32177107 (LS DT 999 UK), 32177115 (LA DF 967), 32177123 (LS DT999A FR), 32177149 (LS DF997AALU), 32177156 (LS DT999T SY), 32177164 (LS DT999SYAL), 32177180 (LSDF967TNORD), 32207003 (LS HD 72 M), 32207102 (LS D 73 SY), 32207110 (LS D 73 A SY), 32900047 (HFI 3015 - 80), 32900075 (HDI 1540-30), 32900076 (HDI1530-30S), 32900085 (HFI 4015-80), 32900086 (HLSI 3000-30S), 32900087 (HLSI 4000-30S), 32900173 (HLSI 500G-30), 32900175 (HFI 5G10-80), 32900198 (HFI 3G10-80), 32900218 (HFI 5G10-1-80), 32900229 (HLSI 500G-1-S)

IBERNA

IBERNA Dishwasher 32000025 (LS LSI 50 N), 32000026 (LS LSI 87), 32000027 (LS LSI 77), 32000202 (LS IDF 80), 32072001 (LS LSI 56 W), 32072019 (LS LSI 47), 32072613 (LS LSI 46 W), 32072621 (LS LSI 66W),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

32072639 (LS LSI 57), 32072647 (LS LSI 67), 32142010 (LS LSI 51 B), 32181000 (LS LSI 48 N), 32900011 (LS LSI 51-1), 32900063 (LS IDS 20 N), 32900064 (IDI 12-02)

INDESIT

KELVINATOR

KELVINATOR Dishwasher 32000021 (LS KD 86), 32000169 (KD96-04S), 32007601 (LS K61 50-60), 32019630 (LS K61.1 WS), 32057002 (LS K 64.1), 32057606 (LS K 65 ES), 32057614 (LS K64 50-60), 32057622 (LSK64 115-60), 32104002 (LS KD 75 UNI), 32104010 (LS KD 85), 32104022 (LS KD 85-1), 32105009 (LS KD 74 UNI), 32105017 (LS KD 74-1), 32105108 (LS KD 74-1 F), 32105116 (LS KD 74-1 G), 32105603 (LS KD 74 OS), 32105611 (LSKD74OS115V), 32111007 (LS KDI 64 M)

MAYTAG

MAYTAG Dishwasher 32000013 (LS MJD 3000), 32000014 (LSMJD 2000), 32000159 (MJD2005AAW), 32000160 (MJD 3005AAW), 32000161 (MJD 3005AAS), 32000194 (MJD2005AAS), 32900072 (MJD3005ANW), 32900073 (MJD3005ANS)

OTSEIN

OTSEIN Dishwasher 32000055 (LSLVOH499A-1), 32000135 (OHND 915-37), 32000136 (OHND615AX37), 32000137 (OHND6155E37), 32000138 (OHND 615A-37), 32000139 (OHND 315P-37), 32000140 (OHND 312-37), 32000273 (OHND 6515Z-37), 32000274 (OHND 6515 ZX-37), 32000275 (OHND 6155-1Z EXP), 32000276 (OHND7515Z), 32037004 (LSLV4012PWSP), 32038002 (LSLV2012PWSP), 32039000 (LSLV3012PWSP), 32058000 (LS LV2112SPA), 32059008 (LS LV3112 SP), 32102006 (LS LVO 2400), 32102014 (LS LVO 2401), 32102600 (LS LVE 2500), 32102618 (LS LVE 2501), 32102626 (LS LVD 21), 32103004 (LS LVO 3700), 32103012 (LS LVO 3801), 32103608 (LS LVO 4750), 32103616 (LS LVO 3750), 32103624 (LS LVO 3851), 32149007 (LS LVO 522), 32149106 (LS LVE2501-1), 32149114 (LS LVO2401-1), 32149122 (LS LVD 21-1), 32149130 (LS LVC 225), 32149148 (LS LVO 526), 32149155 (LS LVC 205), 32149163 (LS LVD 21 H), 32149171 (LS LVC 225 H), 32149189 (LS LVO 526 H), 32149197 (LS LVC 205 H), 32149205 (LS LVOH 2401), 32149213 (LS LVC 255 H), 32149221 (LS LVC 265 H), 32149239 (LS LVD 216 H), 32155004 (LS LVO3851-1), 32155103 (LS LVO385ALU), 32155111 (LS LVO 3651), 32155129 (LS LVO4851-1), 32155137 (LS LVOH 3651), 32171001 (LS LVO 591 E), 32174005 (LS LVO 3951), 32174013 (LS LVOH 3951), 32174021 (LS LVOH399 A), 32174104 (LS LVO 4951), 32174112 (LS LVOH 4951), 32174120 (LS LVOH499 A), 32178006 (LS LVOH599 A), 32205007 (LS LVOH 2575), 32206005 (LS LVOH199 A), 32206104 (LS LVOH299 A), 32206112 (LSLVOH3951AL)

ROSIERES

ROSIERES Dishwasher 32000190 (RDSX5000), 32000293 (RLP 500-47), 32049017 (LS LV139RB-1), 32049025 (LS R6241HPB), 32049108 (LS R6241HPN), 32049603 (LS LV146PNFR), 32049611 (LS LV 154 RB), 32049629 (LS LV154PNFR), 32049645 (LS LV145RBFR), 32049652 (LS LV 138 RB), 32049678 (LS LV 145 PN), 32049686 (LS LV139 RB), 32052011 (LS LVI 361), 32052607 (LS LVI360UNI), 32053621 (LS LVI244 IN), 32054009 (LS LV 170 RB), 32054603 (LS LV 170 PN), 32054611 (LS LV 170 B), 32084006 (LS LV 175 RB), 32084600 (LS LV 175 PN), 32084618 (LS LV 175BLK), 32085607 (LS LV 155 PN), 32086001 (LS LVI 275RB), 32086605 (LS LVI 275PN), 32086613 (LS LVI 275IN), 32087009 (LS LVI 255RB), 32087603 (LS LVI 255PN), 32087611 (LS LVI 255IN), 32097008 (LSLVI256RUST), 32097602 (LSLVI256RURB), 32097610 (LVI 256 RUV), 32097628 (LSLVI256RUBM), 32106007 (LS LV5230HRB), 32106015 (LS LV213H RB), 32106601 (LS LV5230HPN), 32106619 (LS LV213H PN),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

32107005 (LS LV 1230RB), 32107013 (LS LV 205 RB), 32107021 (LS LV205RB-1), 32107609 (LS LV 1230PN),
32107617 (LS LV1230ERB), 32107625 (LS LV 205 PN), 32107633 (LS LV 205ERB), 32108003 (LS LVI6349RB),
32108011 (LS LVI 977 E), 32108102 (LS LVI 551), 32108607 (LS LVI6349PN), 32109001 (LS LV5349HRB),
32109605 (LS LV 5335RB), 32113003 (LSRDW 265 WC), 32115008 (LS LV 433 RB), 32126005 (LS LVI239RB),
32126013 (LSLVI239RB-1), 32126104 (LSLVI239PN-1), 32127003 (LS LVI423RB), 32127607 (LS LVI423PN),
32128001 (LS LVI633RB), 32128019 (LSLVI633RB-1), 32128605 (LS LVI633IN), 32128613 (LSLVI633IN-1),
32128621 (LSLVI423RB-1), 32128639 (LSLVI423PN-1), 32131005 (LS LV640H RB), 32132003 (LS LVI840RB),
32132607 (LS LVI840PN), 32137002 (LS LVI 351), 32156002 (LS LVI256RIN), 32156119 (LVI256RUBM-1),
32156127 (LVI256RUV-1), 32156135 (LVI256RUB-1), 32156143 (LSLVI256RU-1), 32156150 (LSLVI255IN-1),
32185100 (LS LVI980ASY), 32187007 (LS RSI268 IN), 32187106 (LS RSI268 N), 32187114 (LS RSI268 B),
32194003 (LS RC 225), 32197006 (LSRSIC522PN), 32197105 (LSRSIC522RB), 32198004 (LS RSI522 PN),
32198103 (LS RSI522 RB), 32199002 (LS RSI622 RU), 32199101 (LS RSI622RUB), 32199119 (LS RSI622RUV),
32199127 (LSRSI622RUBM), 32201006 (LS RSIC777PN), 32201105 (LS RSIC777RB), 32202004 (LS RSIC877PN),
32202103 (LS RSIC877RB), 32203002 (LS LVIC980PN), 32203101 (LS LVIC980RB), 32213100 (LS RSI622RU),
32900001 (LSRSIC269 IN), 32900002 (LSRSI 269 RB), 32900004 (LSRSIC269 PN), 32900012 (LSRSIC777 IN),
32900016 (RSI622-1RURB), 32900017 (RSIC522-1RB), 32900018 (RSIC522-1PN), 32900019 (LSRSI622-1RU),
32900020 (RSI622-1RUV), 32900021 (RSI622-1RUBM), 32900027 (LS RSIC780IN), 32900045 (LVI 990-47),
32900051 (RSI580PN-47), 32900052 (RSI580RB-47), 32900053 (RSI680RU-47), 32900054 (RSI680RURB),
32900055 (RSI680RUV), 32900056 (RSI680RUBM), 32900057 (RSI880RB-47), 32900058 (RSI880PN-47),
32900059 (RSI880IN-47), 32900074 (RSI 580 IN-04), 32900078 (LVI 990-80 S), 32900103 (RLI 90 PN-47),
32900104 (RLI 90 RB-47), 32900112 (RLF 200-47), 32900124 (RLI 920 MRB-47), 32900125 (RLI 920 MPN-47),
32900126 (RLI 920 MIN-47), 32900129 (RLF 210-47), 32900167 (RLI 920 IN-04), 32900174 (RLF 310-47),
32900208 (RLI 5353MPN-47), 32900223 (RLF 5342-47), 32900224 (RLI 5342 MRB-47), 32900225 (RLI 5342
MPN-47), 32900226 (RLI 5353 MIN-47), 32900227 (RLF 5353-47), 32900228 (RLI 5342 MIN-47)

ROSIERES Washing Machine 32022618 (LS LVI300 FR), 32049637 (LSLVI270RBFR), 32051005 (LSLVI270RBFR),
32051609 (LSLVI270PNFR), 32052003 (LS LVI 340FR), 32053001 (LSLVI244RBFR), 32053605 (LSLVI244PNFR),
32053613 (LSLVI244GTFR), 32053639 (LSLVI238PNFR), 32053647 (LSLVI238RBFR), 32185001 (LS LVI980AFR)

WHIRLPOOL

ZEROWATT

ZEROWATT Dishwasher 32000003 (LS ZH 882 SE), 32000004 (LS ZH 862SEA), 32000005 (LS ZH 882SEA),
32000006 (LS ZH862 SEN), 32000007 (LS ZH 862 SE), 32000008 (LS ZH 852 SE), 32000017 (LS ZJ800 AA),
32000072 (LS ZL 832), 32000196 (KITZDF80), 32056004 (LS ZL 720), 32056608 (LS ZL 720 NX), 32056616
(LSZL720COREA), 32056624 (LS RZ720CECA), 32098006 (LSZL733UNI), 32098600 (LSZL733NXUNI), 32098618
(LS RZ 731), 32099004 (LS ZL 744UNI), 32101008 (LS ZL 722UNI), 32101016 (LS ZL 821), 32101107 (LS RZ
721-1), 32101602 (LS ZL 721), 32101610 (LSRZ721RO-ZW), 32101628 (LS HZL 721), 32134009 (LS ZL825
ECO), 32134017 (LSZL825-1ECO), 32134108 (LS ZL 821-1), 32135006 (LS ZL 835ECO), 32135014
(LSZL845ECO-1), 32135105 (LS ZL 835NX), 32135113 (LS ZL 835NN), 32135121 (LS ZL 831ECO), 32135139
(LS RZ 831ECO), 32135147 (LS ZL845 ECO), 32135154 (LS RZ 831-1), 32135162 (LSZL835ECO-1), 32135170
(LS ZL 831-1E), 32135188 (ZL835NXECO-1), 32135196 (ZL835NNECO-1), 32135212 (LSZL835SILVE),



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

32135220 (LS ZLH 845), 32179004 (LS ZH 850 IT), 32179103 (LS ZH 860 IT), 32179111 (LS ZH 880), 32179129 (LS ZH860N IT), 32179137 (LS ZH860 ALU), 39858006 (LS.620 L), 39868005 (LS 625 L)

