

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Electrovalva 1 cale 90° 1 intrare ø3/4" 1 iesire ø13.5mm 220/240Vac ELBI 350 #3120008

Fara TVA: 54,62 Lei

Pret cu TVA: 65,00Lei

Electrovalva 1 cale 90° 1 intrare ø3/4" 1 iesire ø13.5mm 220/240Vac ELBI 350 #3120008

Numar de cai: 1 cale

UNghi: 90°

1 intrare ø3/4"

1 iesire ø13,5mm.

Tensiune de alimentare: 20/240Vac

Frecventa: 50/60Hz

Temperatura maxima de lucru: 90°C

Compatibil cu:

GEV 373016

ALPENINOX

ATA

DANUBE

ELECTROLUX PROFESSIONAL

GRANDIIMPIANTI

IMESA

PRIMUS

SPAZIALE

WHIRLPOOL - INDESIT

ZANUSSI

Potrivit pentru:

ATA Dishwasher AF55, AF55PS, AL54, AL55, AL55PS, KYRA1WAG

ATA Glasswasher/Cupwasher AL03, AL07, AL10, AL15, AL20, AL350, AL401, AL45

GRANDIIMPIANTI Washing machine F11, F23, F26, F33, F8, R11, R18, R26, R33, R8, wf11 (WF11), wf18 (WF18),
WF23, WF26, WF33, wf8 (WF8), WFC8E, WMEC11, WMEC17, WMEC23, WMEC8, WR11, WR18, WR26, WR33,
WR8, WREC8

PRIMUS Washing machine FS1000, FS1200, FS800, RS27

SPAZIALE Glasswasher/Cupwasher SPL-35.20 (200207-Rev.00), SPL-35.20 (200310-Rev.01), SPL-45.28
(200207-Rev.00), SPL-45.28 (200310-Rev.01), SPL-50.29 (200207-Rev.00), SPL-50.29 (200310-Rev.01)

WHIRLPOOL - INDESIT Washing machine 851221001000 (AGB210WPRC), 851221201000 (AGB212WPRC),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

851221801000 (AGB218WPRC), 851223301000 (AGB233WPLM), 851223401000 (AGB234WPLM),
851223501000 (AGB235WPLM), 851224001000 (AGB240WPLM), 851224101000 (AGB241WPLM),
851225101000 (AGB251WPLM), 853202501000 (ALA025), 853202801000 (ALA028), 853202901000 (ALA029),
853204301000 (ALA043), 853204401000 (ALA044)

ZANUSSI Bratt pan RBR/G700 (195600), RBR/E700 (195601), RBR/G700 (195602), RBR/E700 (195650),
BRN70G (200322), BRN70E (200323), BRN/70GZ (210322), BRN/70EZ (210323), BR70GZ (214038), BR70EZ
(214039), BRNG70A (220322), BRNE70A (220323), BR70G (291100), BR70E (291101), ZRBR/G700 (770010),
ZRBR/G700D (770011), RBR/G700 (770012), RBR/E700 (770020)

ZANUSSI Dishwasher LS500F (500062), LS501F (500072), LS540F (500082), LS540DK (500083), LS541F
(500092), LS540 (500484), LS500F (500600), LS500UK (500604), LS501 (500606), LS501UK (500610), LS540D
(500615), LS540/63 (500635), LS541 (500800), LS521 (501030), LS521D (501031), LS521F (501032), LS521M
(501038), LS521K (501039), LS521 (501045), LS7D (503000), LS7 (503001), LS7UK/RP (503002), LV70
(503003), LS7F (503004), LS7DEK (503005), LS7/1UK (503006), LS7/60 (503009), WT40/9 (503010), WT40/F
(503011), LS500 (5CF07B), LS501 (5CF08B), LS540 (5CF09B), 652120Z (5CF10B), ALS540 (690206), FL700
(698015), HYDRA700 (727015), LS720N (727122), LSE720Z (770403), Z70 (777310)

ZANUSSI Dishwasher hood type LS720F (500322), LSE720DK (500323), LSE720PH (500324), LS860F (500332),
LS860DK (500333), LS860PH (500334), LS1080F (500342), LS1080UK (500343), LS1080PH (500344), LSE721F
(500352), LS861F (500362), LS1080M (500487), LS1080 (500488), LS1080D (500489), LS1080UK (500492),
LS1080/63 (500493), LSE721 (500705), LS720 (500706), LSE720UK (500710), LS721UK (500711), LSE720D
(500715), LS860 (500847), LS860 (500848), LS860D (500849), LS860UK (500852), LS861UK (500853),
LS860/63 (500854), LS861 (500855), LS10D (504000), LS10 (504001), LS10UKRP (504002), LC100 (504003),
ECOTEMP12- (504004), LS10/60 (504005), LS10/1 (504006), LS10/12KW (504007), LS10F (504008), LS10DEK
(504009), LS10/1UKRP (504010), LS10SW (504011), LS10/50J (504012), LS10/60J (504013), LS10DP (504014),
LS10/HD (504015), LS10/UK1 (504018), LS10/UK3 (504019), LS12D (504020), LS12 (504021), LS12UK/RP
(504022), LC120 (504023), LS12DP (504024), LS12/60 (504025), LS12F (504028), LS12DEK (504029), LS12HD
(504053), LS12/UK3 (504061), ECOTEMP12SW (504063), ECOTEMP12INS (504065), LS12MEX (504078), LS10N
(504080), LS8D (505000), LS8 (505001), LS8UK/RP (505002), LC80 (505003), LS8F (505004), LS8DEK
(505005), LS8/9 (505006), LS8/60 (505007), LS8/1UKRP (505008), LS8/DP (505009), WT50/9 (505010),
WT50/UK9RF (505011), WT50/F9 (505012), WT50/6 (505014), WT50/1UKRP (505015), WT50/1 (505016),
D800/9 (505017), D800/6 (505018), WT50/60 (505019), WT50/N (505020), LS8/HD (505021), WT50/J50
(505023), WT50/J60 (505024), LS8/UK1 (505026), LS8UK3 (505027), WT50/UK1 (505028), WT50/UK3 (505029),
LS8/9DD (505031), LS8DEK (505037), LS860 (5CF11B), LS1080 (5CF12B), HT1200elm (698020), HT1000elm
(698021), HT800 (698025), HYDRA1200 (727020), HYDRA1000 (727021), HYDRA800 (727025), LS860
(770404), LS1080 (770405), LS860 (777407), LS1080 (777408), LSCE10 (777410), LSCE12 (777420), Z80
(777430)

ZANUSSI Dishwasher pull-through RT10SR (531302), RT10SL (531303), RT10ERF60 (531306), RT10ELF60
(531307), RT10ERF (531308), RT10ELF (531309), RT10ERBF60 (531310), RT10ELBF60 (531311), RT10ERG
(531312), RT10ELG (531313), RT10SRB (531316), RT10SLB (531317), RT10ERBF (531320), RT10ELBF
(531321), RT10ERBG (531324), RT10ELBG (531325), RT10SRC (531332), RT10SLC (531333), RT10ERCF

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(531338), RT10ELCF (531339), RT10ERCG (531342), RT10ELCG (531343), RT10SRCB (531346), RT10SLCB (531347), RT10ERCBF (531350), RT10ELCBF (531351), RT10ERCBG (531354), RT10ELCBG (531355), RT10ERASIA (531360), RT10ELASIA (531361), RT10SRASIA (531364), RT10SLASIA (531365), RT10ERCINA (531372), RT10ELCINA (531373), RT10ERROWH (531374), RT10ELROWH (531375), RT10ERH (531376), RT10ELH (531377), RT10ERROW (531378), RT10ELROW (531379), RT10ERROW6 (531380), RT10ELROW6 (531381), NERT10ER (533300), NERT10EL (533301), WT90ER60 (533306), WT90EL60 (533307), WT90ERB60 (533310), WT90ELB60 (533311), NERT10ERG (533312), NERT10ELG (533313), NERT10ERB (533314), NERT10ELB (533315), NERT10SR (533322), NERT10SL (533323), WT90ERBG (533324), WT90ELBG (533325), ET90ERCINA (533326), ET90ELCINA (533327), ET90ERROW (533328), ET90ELROW (533329), NERT10ERC (533330), NERT10ELC (533331), NERT20SR (533336), NERT20SL (533337), NERT10SRC (533340), NERT10SLC (533341), WT90ERCG (533342), WT90ELCG (533343), NERT10ERCB (533344), NERT10ELCB (533345), WT90ERCBG (533354), WT90ELCBG (533355), WT90ERASIA (533360), WT90ELASIA (533361), WT90SRASIA (533364), WT90SLASIA (533365), WT90ERCINA (533368), WT90ELCINA (533369), NERT20ERH (533370), NERT20ELH (533371), WT90ERH (533372), WT90ELH (533373), NERT20ER (533374), NERT20EL (533375), NERT20ER60 (533376), NERT20EL60 (533377), RT180ERG (698106), RT180ELG (698107), RT180ER (698155), RT180EL (698156), RT180ERB (698157), RT180ELB (698158), RT180ERC (698159), RT180ELC (698160), RT180ERCB (698161), RT180ELCB (698162), LV180ER (698400), LV180EL (698401), LV180ERB (698402), LV180ELB (698403), LV180ERC (698404), LV180ELC (698405), LV180ERCB (698406), LV180ELCB (698407)
ZANUSSI Vegetable washing machine LVA100B (601524), LVA70 (660038), LVA70MA (660057), LVA100Z (660071), LVA100B (660072), LVA100 (660073), LVA100-A (660074)
ZANUSSI Washing machine LB120EPH (401211), LB120E (401215), LB160EPH (401311), LB160E (401315), LB160V (401335), CLB160E (401415), CLB160V (401435), LB110E (411208), LB120E (6LB21B), LB160EZ (6LB25B), LB160V (6LB27B), CLB160E (6LB28B), CLB160V (6LB29B)

