

## Rezistenta cuptor 2100W 230V 74x2310 #D355205

Fara TVA: 473,00 Lei

Pret cu TVA: 572,33Lei

Rezistenta cuptor 2100W 230V 74x2310 #D355205

grill length 360/270mm

width 320mm

flange 121x22mm

cross piece 345mm

Compatibil cu:

DE DIETRICH 74X2310

FAGOR BRANDT 74X2310

VEDETTE 74X2310

EPMS 74X2310

EPMS 725204

DE DIETRICH Electric oven 8X0637 (DOC740X), 8X0633 (DOC760X), 8X0612 (DOP705X), 8X0453 (DOP720B), 8X0455 (DOP720W), 8X0444 (DOP720X), 8X0464 (DOP740B), DOP740B1 (DOP740B), DOP740B1-E (DOP740B), DOP740B2 (DOP740B), DOP740B2-E (DOP740B), DOP740B3 (DOP740B), DOP740B3-E (DOP740B), DOP740BS1 (DOP740BS), DOP740BS1-E (DOP740BS), DOP740BS2 (DOP740BS), DOP740BS3 (DOP740BS), 8X0466 (DOP740W), DOP740W1 (DOP740W), DOP740W1-E (DOP740W), DOP740W2 (DOP740W), DOP740W2-E (DOP740W), DOP740W3 (DOP740W), DOP740W3-E (DOP740W), DOP740WS1 (DOP740WS), DOP740WS2 (DOP740WS), DOP740WS3 (DOP740WS), 8X0460 (DOP740X), DOP740X1 (DOP740X), DOP740X2 (DOP740X), 8X0551 (DOP750B), DOP750B1 (DOP750B), 8X0555 (DOP750W), 8X0541 (DOP750X), DOP750X1 (DOP750X), DOP750X4 (DOP750X), 8X0548 (DOP750Z), DOP760W1 (DOP760), 8X0596 (DOP760B), DOP760B1 (DOP760B), 8X0595 (DOP760W), 8X0593 (DOP760X), 8X0586 (DOP770B), 8X0582 (DOP770W), 8X0569 (DOP770X), DOP770X1 (DOP770X), 8X0580 (DOP770Z), DOP785W1 (DOP785W), DOP785W2 (DOP785W), 8X0605 (DOP790B), 8X0599 (DOP790W), 8X0607 (DOP790X), DOP790X2 (DOP790X), DOP790X4 (DOP790X), 8X0606 (DOP790Z), DOP840BB1 (DOP840BB), DOP840BB2 (DOP840BB), DOP960X2 (DOP960X)

DE DIETRICH Kitchen DCI1198W1 (DCI1198W), DCI1198W2 (DCI1198W), DCI1198W3 (DCI1198W), DCI999W1 (DCI999W), DCM1050W1 (DCM1050W), DCM350WE12 (DCM350WE1), 7DC0401 (DCM740W), DCM940W1 (DCM940W), DCM940W2 (DCM940W)

DE DIETRICH Kitchen gas 7DC0322 (DCG300WE1), 7DC0321 (DCG310WE1), 7DC0327 (DCG440WE1), 7DC0364 (DCG440WE1), 7DC0375 (DCG550W), 7DC0379 (DCG550X), 7DC0374 (DCG630W), 7DC0400 (DCM750W), DCM750W1 (DCM750W), DCM750W2 (DCM750W), DCM750W3 (DCM750W)

DE DIETRICH Kitchen glass-ceramics DCI900X1 (DCI900X), DCI900X (DCI900XU1), 7DC0392 (DCV768W), DCV768W1 (DCV768W), 7DC0393 (DCV768X), DCV768X1 (DCV768X)

FAGOR BRANDT Electric oven 5H-720B2 (5H-720B), 5H-720N1 (5H-720N), 5H-720N2 (5H-720N), 5H-720X1

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

(5H-720X), 5H-720X2 (5H-720X), 5H-721B1 (5H-721B), 5H-721N1 (5H-721N), 5H-721X1 (5H-721X), 5H-730B1 (5H-730B), 5H-730B2 (5H-730B), 5H-730N1 (5H-730N), 5H-730N2 (5H-730N), 5H-730X1 (5H-730X), 5H-730X2 (5H-730X), 5H-740B1 (5H-740B), 5H-740B2 (5H-740B), 5H-740N1 (5H-740N), 5H-740N2 (5H-740N), 5H-740X1 (5H-740X), 5H-740X2 (5H-740X), 5H-741B1 (5H-741B), 5H-741N1 (5H-741N), 5H-741N4 (5H-741N), 5H-741X1 (5H-741X), 5H-741X2 (5H-741X), 5H-745B1 (5H-745B), 5H-745N1 (5H-745N), 5H-745X1 (5H-745X), 5H-750B1 (5H-750B), 921110344 (5H-750BEPOCA), 5H-750N1 (5H-750N), 5H-750N2 (5H-750N), 921110353 (5H-750NEPOCA), 5H-760B1 (5H-760B), 5H-760B2 (5H-760B), 5H-760B3 (5H-760B), 5H-760B4 (5H-760B), 5H-760B5 (5H-760B), 5H-760B6 (5H-760B), 5H-760N1 (5H-760N), 5H-760N2 (5H-760N), 5H-760N3 (5H-760N), 5H-760N4 (5H-760N), 5H-760N5 (5H-760N), 5H-760N6 (5H-760N), 5H-760X1 (5H-760X), 5H-760X2 (5H-760X), 5H-760X3 (5H-760X), 5H-760X4 (5H-760X), 5H-760X5 (5H-760X), 5H-760X6 (5H-760X), 5H-770X1 (5H-770X), 5H-770X2 (5H-770X), 5H-770X3 (5H-770X), 5H-775X1 (5H-775X), 5H-775X2 (5H-775X), 5H-780X1 (5H-780X), 5H-780X2 (5H-780X), 5H-790X1 (5H-790X), 5H-860X1 (5H-860X), FP1052B1 (FP1052B), FP1052X1 (FP1052X), FP1060W1 (FP1060W), FP1061B1 (FP1061B), FP1061W1 (FP1061W), FP1371X1 (FP1371X), FP211XN11 (FP211XN1), FP212XN11 (FP212XN1), FP212XN12 (FP212XN1), FP224MN11 (FP224MN1), FP224MN12 (FP224MN1), FP224WN11 (FP224WN1), FP224WN12 (FP224WN1), FP224XN11 (FP224XN1), FP224XN12 (FP224XN1), FP225BS11 (FP225BS1), FP225BS12 (FP225BS1), FP225BS13 (FP225BS1), FP225WS11 (FP225WS1), FP225WS12 (FP225WS1), FP225WS13 (FP225WS1), FP225XS11 (FP225XS1), FP225XS12 (FP225XS1), FP225XS13 (FP225XS1), FP228MN11 (FP228MN1), FP228MN12 (FP228MN1), FP228XN11 (FP228XN1), FP228XN12 (FP228XN1), FP228ZN11 (FP228ZN1), FP228ZN12 (FP228ZN1), FP229BS11 (FP229BS1), FP229BS12 (FP229BS1), FP229BS13 (FP229BS1), FP229WS11 (FP229WS1), FP229WS12 (FP229WS1), FP229WS13 (FP229WS1), FP229XS11 (FP229XS1), FP229XS12 (FP229XS1), FP229XS13 (FP229XS1), FP230XN11 (FP230XN1), FP252BF11 (FP252BF1), FP252BF12 (FP252BF1), FP252WF11 (FP252WF1), FP252WF12 (FP252WF1), FP252XF11 (FP252XF1), FP252XF12 (FP252XF1), FP252XF13 (FP252XF1), FP254BF11 (FP254BF1), FP254BF12 (FP254BF1), FP254WF11 (FP254WF1), FP254WF12 (FP254WF1), FP261BF11 (FP261BF1), FP261BF12 (FP261BF1), FP261BF13 (FP261BF1), FP261WF11 (FP261WF1), FP261WF12 (FP261WF1), FP261WF13 (FP261WF1), FP262BF11 (FP262BF1), FP262BF12 (FP262BF1), FP262WF11 (FP262WF1), FP262WF12 (FP262WF1), FP262XF11 (FP262XF1), FP262XF12 (FP262XF1), FP262XF13 (FP262XF1), FP262ZF11 (FP262ZF1), FP262ZF12 (FP262ZF1), FP263DF11 (FP263DF1), FP263DF12 (FP263DF1), FP263DF13 (FP263DF1), FP263EF11 (FP263EF1), FP263EF12 (FP263EF1), FP263EF13 (FP263EF1), FP265BF11 (FP265BF1), FP265BF12 (FP265BF1), FP265WF11 (FP265WF1), FP265WF12 (FP265WF1), FP271BF11 (FP271BF1), FP271WF11 (FP271WF1), FP362BF11 (FP362BF1), FP362BF12 (FP362BF1), FP362BF13 (FP362BF1), FP362WF11 (FP362WF1), FP362WF12 (FP362WF1), FP362WF13 (FP362WF1), FP362XF11 (FP362XF1), FP362XF12 (FP362XF1), FP362XF13 (FP362XF1), FP365BF11 (FP365BF1), FP365BF12 (FP365BF1), FP365BF13 (FP365BF1), FP365WF11 (FP365WF1), FP365WF12 (FP365WF1), FP365WF13 (FP365WF1), FP411XN11 (FP411XN1), FP411XN12 (FP411XN1), FP424MN11 (FP424MN1), FP424MN12 (FP424MN1), FP424WN11 (FP424WN1), FP424WN12 (FP424WN1), FP424XN11 (FP424XN1), FP424XN12 (FP424XN1), FP424ZN11 (FP424ZN1), FP424ZN12 (FP424ZN1), FP428MN11 (FP428MN1), FP428MN12 (FP428MN1), FP428XN11 (FP428XN1), FP428XN12 (FP428XN1), FP452BF11 (FP452BF1), FP452BF12 (FP452BF1), FP452WF11 (FP452WF1), FP452WF12 (FP452WF1), FP452WF13 (FP452WF1),

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

FP452WF14 (FP452WF1), FP452XF11 (FP452XF1), FP452XF12 (FP452XF1), FP462BF11 (FP462BF1), FP462BF12 (FP462BF1), FP462WF11 (FP462WF1), FP462WF12 (FP462WF1), FP462WF13 (FP462WF1), FP462WF14 (FP462WF1), FP462XF11 (FP462XF1), FP462XF12 (FP462XF1), FP462ZF11 (FP462ZF1), FP462ZF12 (FP462ZF1), FP464BF11 (FP464BF1), FP464WF11 (FP464WF1), FP464WF12 (FP464WF1), FP464XF11 (FP464XF1), FP465BF11 (FP465BF1), FP465BF12 (FP465BF1), FP465WF11 (FP465WF1), FP465WF12 (FP465WF1), FP465WF13 (FP465WF1), FP465WF14 (FP465WF1), FP551BF11 (FP551BF1), FP551WF11 (FP551WF1), FP551XF11 (FP551XF1), FP561BF11 (FP561BF1), FP561WF11 (FP561WF1), FP561XF11 (FP561XF1), FP562X1 (FP562X), FP562X2 (FP562X), FP611XN11 (FP611XN1), FP624WN11 (FP624WN1), FP624XGN11 (FP624XGN1), FP624XN11 (FP624XN1), FP624ZN11 (FP624ZN1), FP628XGN11 (FP628XGN1), FP628XN11 (FP628XN1), FP652BF11 (FP652BF1), FP652WF11 (FP652WF1), FP652XF11 (FP652XF1), FP662BF11 (FP662BF1), FP662BF12 (FP662BF1), FP662WF11 (FP662WF1), FP662XF11 (FP662XF1), FP662XF12 (FP662XF1), FP662ZF11 (FP662ZF1), FP663DF11 (FP663DF1), FP663EF11 (FP663EF1), FP664BF11 (FP664BF1), FP664BF12 (FP664BF1), FP664M1 (FP664M), FP664M2 (FP664M), FP664WF11 (FP664WF1), FP664WF12 (FP664WF1), FP664XF11 (FP664XF1), FP664XF12 (FP664XF1), FP665BF11 (FP665BF1), FP665WF11 (FP665WF1), FP665XF11 (FP665XF1), FP666BF11 (FP666BF1), FP666WF11 (FP666WF1), FP666XF11 (FP666XF1), FP667XS11 (FP667XS1), FP852BF11 (FP852BF1), FP852BF12 (FP852BF1), FP871B2 (FP871B), FP971X1 (FP971X), FP980X1 (FP980X), HH-229PX1 (HH-229PX), 921110184 (HMP198N), HP197B1 (HP197B), 921110148 (HP-197B), HP197N1 (HP197N), 921110157 (HP-197N), HP197X1 (HP197X), 921110139 (HP-197X), HPM198B1 (HPM198B), HPM198B2 (HPM198B), 921110175 (HPM-198B), HPM198N1 (HPM198N), HPM198N2 (HPM198N), 921110184 (HPM-198N), HPM198X1 (HPM198X), HPM198X2 (HPM198X), 921110166 (HPM-198X), HPM-199CX1 (HPM-199CX), SFP665K1 (SFP665K)

FAGOR BRANDT Kitchen KG361XE11 (KG361XE1), KG361XE12 (KG361XE1), KG361XE13 (KG361XE1), KG361XE14 (KG361XE1), KG363WE11 (KG363WE1), KG363WE12 (KG363WE1), KG363WE13 (KG363WE1), KG363WE14 (KG363WE1), KG363WE15 (KG363WE1), KG561XE11 (KG561XE1), KG561XE12 (KG561XE1), KG566WE11 (KG566WE1), KGC1013W1 (KGC1013W), KGC605X1 (KGC605X), KGP610W1 (KGP610W), KI365WE11 (KI365WE1), KI365WE13 (KI365WE1), KI365WE14 (KI365WE1), KIP712W1 (KIP712W), KM365TE11 (KM365TE1), KM365TE12 (KM365TE1), KM365TE13 (KM365TE1), KM365TE14 (KM365TE1), KM365TE15 (KM365TE1), KM365WE11 (KM365WE1), KM365WE12 (KM365WE1), KM365WE13 (KM365WE1), KM365WE14 (KM365WE1), KM365XE11 (KM365XE1), KM365XE13 (KM365XE1), KM365XE14 (KM365XE1), KM365XE15 (KM365XE1), KM365XE16 (KM365XE1), KM366WE11 (KM366WE1), KM366WE12 (KM366WE1), KM366WE13 (KM366WE1), KM366WE14 (KM366WE1), KM367WE11 (KM367WE1), KM367WE12 (KM367WE1), KM367WE13 (KM367WE1), KM367WE14 (KM367WE1), KM465WE11 (KM465WE1), KM465WE12 (KM465WE1), KM466WE11 (KM466WE1), KM565TE11 (KM565TE1), KM565WE11 (KM565WE1), KM565XE11 (KM565XE1), KM566WE11 (KM566WE1), KMP1010W1 (KMP1010W), KMP1015W1 (KMP1015W), KMP1015W2 (KMP1015W), KMP1115W1 (KMP1115W), KMP612W1 (KMP612W), KMP615T1 (KMP615T), KMP615W1 (KMP615W), KMP617W1 (KMP617W), KMP715T1 (KMP715T), KMP715T2 (KMP715T), KMP715T3 (KMP715T), KMP715W1 (KMP715W), KMP715W2 (KMP715W), KMP715W3 (KMP715W), KMP715X1 (KMP715X), KMPC1000W1 (KMPC1000W), KMPM1001W1 (KMPM1001W), KR365WE11 (KR365WE1), KR365WE13 (KR365WE1), KR365WE14 (KR365WE1), KR365WE15 (KR365WE1)

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

FAGOR BRANDT Kitchen electric KE361WE11 (KE361WE1), KE361WE12 (KE361WE1), KE361WE13 (KE361WE1), KE361WE14 (KE361WE1), KE361WE15 (KE361WE1), KIP710X2 (KIP710X), KIP915 (KIP915W1), KMP1015T1 (KMP1015T), KMP1018W1 (KMP1018W)

FAGOR BRANDT Kitchen gas KG369XE11 (KG369XE1), KG369XE12 (KG369XE1), KG369XE13 (KG369XE1), KGC1005E1 (KGC1005E), KGC1005W1 (KGC1005W)

FAGOR BRANDT Kitchen glass-ceramics KIP615W1 (KIP615W), KIP710W1 (KIP710W), KIP710W2 (KIP710W), KIP710W3 (KIP710W), KIP711W1 (KIP711W), KIP711W2 (KIP711W), KIP711W3 (KIP711W), KV361WE11 (KV361WE1), KV361WE12 (KV361WE1), KV361WE13 (KV361WE1), KV361WE14 (KV361WE1), KV369WE11 (KV369WE1), KV369WE12 (KV369WE1), KV374WE11 (KV374WE1), KV374WE12 (KV374WE1), KV374XE11 (KV374XE1), KV374XE12 (KV374XE1), KV462WE11 (KV462WE1), KV462WE12 (KV462WE1), KV561WE11 (KV561WE1), KVP661W1 (KVP661W), KVP661W2 (KVP661W)

FAGOR BRANDT Pot stove CFF-631MP1 (CFF-631MP), CFF-631P1 (CFF-631P), CFF-631P2 (CFF-631P), CFF-631P3 (CFF-631P)

VEDETTE Kitchen VGE630B1 (VGE630B), 7VC0198 (VMP640B), VMP640B1 (VMP640B), 7VC0174 (VMP65B), 7VC0184 (VMP65B), VMP65B1 (VMP65B), VMP65B2 (VMP65B), 7VC0188 (VMP66B), VMP66B1 (VMP66B)

VEDETTE Kitchen gas 7VC0211 (VGE620B)

