

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta cuptor 1200W 220/240V 400/295mm #D355188

Fara TVA: 201,68 Lei

Pret cu TVA: 240,00Lei

Rezistenta cuptor 1200W 220/240V 400/295mm #D355188

lower length 400/295mm

width 390mm flange 70x22mm

Compatibil cu:

DE DIETRICH 74X3170

FAGOR BRANDT 74X3170

VEDETTE 74X3170

BACKER FACSA 9500713973

EPMS 74X3170

EPMS 725159

DE DIETRICH Electric oven 7DF0751 (DOC310BE1), DOC310BE11 (DOC310BE1), 7DF0749 (DOC310WE1), 7DF0800 (DOC310XE1), 7DF0752 (DOC310ZE1), 7DF0807 (DOC315DF1), 7DF0806 (DOC315EF1), 7DF0758 (DOC410BE1), DOC410BE11 (DOC410BE1), 7DF0757 (DOC410WE1), DOC410WE11 (DOC410WE1), 7X9494 (DOC410XA1), 7DF0759 (DOC410XE1), DOC410XE11 (DOC410XE1), 7X0454 (DOC410XJ1), 7X8938 (DOC505XE1), 7X9564 (DOC505XE1), 7X9377 (DOC540BE1), 7X9376 (DOC540WE1), 7X9497 (DOC540XA1), 7X9723 (DOC540XA1), 7X9375 (DOC540XE1), 7X9374 (DOC560XE1), 8X0530 (DOC710B), 8X0535 (DOC710W), 8X0518 (DOC710X), 8X0637 (DOC740X), 8X0633 (DOC760X), 7X1699 (DOD338XU1), 7DF0773 (DOD348WG1), 7DF0804 (DOD348XG1), 7X1463 (DOD428XU1), 7X9368 (DOD428XU1), 7X1314 (DOD438BU1), 7X8425 (DOD438BU1), 7X1295 (DOD438WU1), 7X8491 (DOD438WU1), 7X1105 (DOD438XU1), 7X8914 (DOD438XU1), 7DF0788 (DOD448BG1), 7DF0813 (DOD448BG1), 7DF0787 (DOD448WG1), 7DF0815 (DOD448WG1), 7X0171 (DOD448XA1), 8X0409 (DOD448XA1), 7DF0789 (DOD448XG1), 7DF0814 (DOD448XG1), 7X1787 (DOE405WJ1), 7X9682 (DOE405WJ1), 7X1789 (DOE405XJ1), 7X9679 (DOE405XJ1), 7X8659 (DOE505BE1), 7X9562 (DOE505BE1), 7X8553 (DOE505WE1), 7X9560 (DOE505WE1), 7X8497 (DOE505XE1), 7X9559 (DOE505XE1), 8X0627 (DOE705X), DOP320BE11 (DOP320BE1), DOP320WE11 (DOP320WE1), DOP320XE11 (DOP320XE1), DOP330BE11 (DOP330BE1), DOP330WE11 (DOP330WE1), DOP330XE11 (DOP330XE1), DOP340BE11 (DOP340BE1), DOP340WE11 (DOP340WE1), DOP340XE11 (DOP340XE1), DOP340ZE11 (DOP340ZE1), DOP350BE11 (DOP350BE1), DOP350WE11 (DOP350WE1), DOP370WE11 (DOP370WE1), DOP420BE11 (DOP420BE1), 7X1652 (DOP420WJ1), 7X1651 (DOP420XJ1), 7X9393 (DOP430WJ1), 7X9394 (DOP430XJ1), 7DF0780 (DOP440BE1), DOP440BE11 (DOP440BE1), 7DF0790 (DOP440WE1), DOP440WE11 (DOP440WE1), 7X1660 (DOP440WJ1), DOP440WJ11 (DOP440WJ1), 7DF0786 (DOP440XE1), DOP440XE11 (DOP440XE1), 7X1657 (DOP440XJ1), 7DF0792 (DOP440ZE1), 7DF0797 (DOP450BE1), DOP450BE11 (DOP450BE1), 7DF0795 (DOP450WE1), DOP450WE11 (DOP450WE1), 7DF0796 (DOP450XE1), DOP450XE11 (DOP450XE1), 7DF0812 (DOP450ZE1), 8X0287 (DOP455XD1), 7DF0811 (DOP458BF1), 7DF0810 (DOP458WF1), 7DF0809 (DOP458XF1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

7DF0776 (DOP460BE1), DOP460BE11 (DOP460BE1), 7DF0775 (DOP460WE1), DOP460WE11 (DOP460WE1),
7DF0778 (DOP460XE1), DOP460XE11 (DOP460XE1), 8X0285 (DOP465XD1), 7DF0777 (DOP470BE1), 7DF0774
(DOP470WE1), 7DF0779 (DOP470XE1), 7DF0793 (DOP470ZE1), 8X0284 (DOP475XD1), 8X0283 (DOP475ZD1),
7DF0782 (DOP490BE1), 7DF0781 (DOP490WE1), 7DF0783 (DOP490XE1), 7X9744 (DOP490XT1), 7DF0784
(DOP490ZE1), 8X0277 (DOP495XD1), 8X0282 (DOP495ZD1), 7X8941 (DOP505BE1), 7X8940 (DOP505WE1),
7X8942 (DOP505XE1), 8X0612 (DOP705X), 8X0453 (DOP720B), 8X0455 (DOP720W), 8X0444 (DOP720X),
8X0464 (DOP740B), DOP740B1 (DOP740B), DOP740B1-E (DOP740B), DOP740B2 (DOP740B), DOP740B2-E
(DOP740B), DOP740B3 (DOP740B), DOP740B3-E (DOP740B), DOP740BS1 (DOP740BS), DOP740BS1-E
(DOP740BS), DOP740BS2 (DOP740BS), DOP740BS3 (DOP740BS), 8X0466 (DOP740W), DOP740W1 (DOP740W),
DOP740W1-E (DOP740W), DOP740W2 (DOP740W), DOP740W2-E (DOP740W), DOP740W3 (DOP740W),
DOP740W3-E (DOP740W), DOP740WS1 (DOP740WS), DOP740WS2 (DOP740WS), DOP740WS3 (DOP740WS),
8X0460 (DOP740X), DOP740X1 (DOP740X), DOP740X2 (DOP740X), 8X0551 (DOP750B), DOP750B1 (DOP750B),
8X0555 (DOP750W), 8X0541 (DOP750X), DOP750X1 (DOP750X), DOP750X4 (DOP750X), 8X0548 (DOP750Z),
DOP760W1 (DOP760), 8X0596 (DOP760B), DOP760B1 (DOP760B), 8X0595 (DOP760W), 8X0593 (DOP760X),
8X0586 (DOP770B), 8X0582 (DOP770W), 8X0569 (DOP770X), DOP770X1 (DOP770X), 8X0580 (DOP770Z),
DOP785W1 (DOP785W), DOP785W2 (DOP785W), 8X0605 (DOP790B), 8X0599 (DOP790W), 8X0607 (DOP790X),
DOP790X2 (DOP790X), DOP790X4 (DOP790X), 8X0606 (DOP790Z), DOP840BB1 (DOP840BB), DOP840BB2
(DOP840BB), DOP960X2 (DOP960X), FC541BF14 (FC541BF1)

DE DIETRICH Kitchen DCI1198W1 (DCI1198W), DCI1198W2 (DCI1198W), DCI1198W3 (DCI1198W), DCI999W1
(DCI999W), DCM350WE12 (DCM350WE1), 7DC0328 (DCM440WE1), 7DC0363 (DCM440WE1), 7DC0373
(DCM630W), DCM630W1 (DCM630W), DCM630W2 (DCM630W), DCM630W3 (DCM630W), 7DC0372 (DCM640A),
7DC0370 (DCM640W), 7DC0401 (DCM740W), DCM940W1 (DCM940W), DCM940W2 (DCM940W)

DE DIETRICH Kitchen gas 7DC0329 (DCM450WE1), 7DC0362 (DCM450WE1), DCM450WE11 (DCM450WE1),
DCM450WE12 (DCM450WE1), 7DC0330 (DCM450XE1), 7DC0361 (DCM450XE1), DCM450XE11 (DCM450XE1),
DCM450XE12 (DCM450XE1), 7DC0336 (DCM469WE1), 7DC0391 (DCM469WE1), 7DC0371 (DCM650W),
7DC0376 (DCM650X), 7DC0400 (DCM750W), DCM750W1 (DCM750W), DCM750W2 (DCM750W), DCM750W3
(DCM750W)

DE DIETRICH Kitchen glass-ceramics 7DC0323 (DCI399AE1), DCI399AE13 (DCI399AE1), 7DC0324
(DCI399WE1), DCI399WE11 (DCI399WE1), DCI399WE12 (DCI399WE1), DCI399WE13 (DCI399WE1), 7DC0325
(DCI399XE1), DCI399XE12 (DCI399XE1), 7DC0332 (DCI499AE1), 7DC0368 (DCI499AE1), 7DC0331
(DCI499WE1), 7DC0369 (DCI499WE1), 7DC0333 (DCI499XE1), 7DC0367 (DCI499XE1), DCI499XE11
(DCI499XE1), 8X0011 (DCI499XU1), 7DC0396 (DCI798X), 7DC0399 (DCI799A), 7DC0398 (DCI799W),
DCI799W1 (DCI799W), 7DC0397 (DCI799X), DCI799X1 (DCI799X), DCI799X2 (DCI799X), DCI900X1 (DCI900X),
7DC0334 (DCV469WE1), 7DC0366 (DCV469WE1), 7DC0389 (DCV469WE1), 7DC0335 (DCV469XE1), 7DC0378
(DCV469XE1), 7DC0390 (DCV469XE1), 7DC0392 (DCV768W), DCV768W1 (DCV768W), 7DC0393 (DCV768X),
DCV768X1 (DCV768X), 7DC0394 (DCV769W), 7DC0395 (DCV769X)

FAGOR BRANDT Electric oven 5H-720B2 (5H-720B), 5H-720N1 (5H-720N), 5H-720N2 (5H-720N), 5H-720X1
(5H-720X), 5H-720X2 (5H-720X), 5H-721B1 (5H-721B), 5H-721N1 (5H-721N), 5H-721X1 (5H-721X), 5H-730B1
(5H-730B), 5H-730B2 (5H-730B), 5H-730N1 (5H-730N), 5H-730N2 (5H-730N), 5H-730X1 (5H-730X), 5H-730X2

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(5H-730X), 5H-740B1 (5H-740B), 5H-740B2 (5H-740B), 5H-740N1 (5H-740N), 5H-740N2 (5H-740N), 5H-740X1 (5H-740X), 5H-740X2 (5H-740X), 5H-741B1 (5H-741B), 5H-741N1 (5H-741N), 5H-741N4 (5H-741N), 5H-741X1 (5H-741X), 5H-741X2 (5H-741X), 5H-745B1 (5H-745B), 5H-745N1 (5H-745N), 5H-745X1 (5H-745X), 5H-750B1 (5H-750B), 921110344 (5H-750BEPOCA), 5H-750N1 (5H-750N), 5H-750N2 (5H-750N), 921110353 (5H-750NEPOCA), 5H-760B1 (5H-760B), 5H-760B2 (5H-760B), 5H-760B3 (5H-760B), 5H-760B4 (5H-760B), 5H-760B5 (5H-760B), 5H-760B6 (5H-760B), 5H-760N1 (5H-760N), 5H-760N2 (5H-760N), 5H-760N3 (5H-760N), 5H-760N4 (5H-760N), 5H-760N5 (5H-760N), 5H-760N6 (5H-760N), 5H-760X1 (5H-760X), 5H-760X2 (5H-760X), 5H-760X3 (5H-760X), 5H-760X4 (5H-760X), 5H-760X5 (5H-760X), 5H-760X6 (5H-760X), 5H-770X1 (5H-770X), 5H-770X2 (5H-770X), 5H-770X3 (5H-770X), 5H-775X1 (5H-775X), 5H-775X2 (5H-775X), 5H-780X1 (5H-780X), 5H-780X2 (5H-780X), 5H-790X1 (5H-790X), 5H-860X1 (5H-860X), FBI981X1 (FBI981X), FC1032B1 (FC1032B), FC1032X1 (FC1032X), FC1040W1 (FC1040W), FC212XN11 (FC212XN1), FC212XN12 (FC212XN1), FC222MN11 (FC222MN1), FC222WN11 (FC222WN1), FC222XN11 (FC222XN1), FC222ZN11 (FC222ZN1), FC223XN11 (FC223XN1), FC232BF11 (FC232BF1), FC232WF11 (FC232WF1), FC241BF11 (FC241BF1), FC241WF11 (FC241WF1), FC242BF11 (FC242BF1), FC242WF11 (FC242WF1), FC242XF11 (FC242XF1), FC242ZF11 (FC242ZF1), FC243DF11 (FC243DF1), FC243EF11 (FC243EF1), FC272WN11 (FC272WN1), FC272XN11 (FC272XN1), FC300BS11 (FC300BS1), FC300WS11 (FC300WS1), FC342XF11 (FC342XF1), FC342XF12 (FC342XF1), FC342XF13 (FC342XF1), FC422MN11 (FC422MN1), FC422MN12 (FC422MN1), FC422WN11 (FC422WN1), FC422WN12 (FC422WN1), FC422XN11 (FC422XN1), FC422XN12 (FC422XN1), FC422ZN11 (FC422ZN1), FC422ZN12 (FC422ZN1), FC432BF11 (FC432BF1), FC432WF11 (FC432WF1), FC432XF11 (FC432XF1), FC442BF11 (FC442BF1), FC442WF11 (FC442WF1), FC442XF11 (FC442XF1), FC472XN11 (FC472XN1), FC472XN12 (FC472XN1), FC520BS11 (FC520BS1), FC520WS11 (FC520WS1), FC520XS11 (FC520XS1), FC541BF11 (FC541BF1), FC541BF12 (FC541BF1), FC541BF13 (FC541BF1), FC541BF14 (FC541BF1), FC541WF11 (FC541WF1), FC541WF12 (FC541WF1), FC541WF13 (FC541WF1), FC541WF14 (FC541WF1), FC541XF11 (FC541XF1), FC541XF12 (FC541XF1), FC541XF13 (FC541XF1), FC541XF14 (FC541XF1), FC622WN11 (FC622WN1), FC622XGN11 (FC622XGN1), FC622XN11 (FC622XN1), FC632BF11 (FC632BF1), FC632FB11 (FC632BF1), FC632WF11 (FC632WF1), FC632XF11 (FC632XF1), FC632XF12 (FC632XF1), FC632XF13 (FC632XF1), FC641BF11 (FC641BF1), FC641BF12 (FC641BF1), FC641BF13 (FC641BF1), FC641WF11 (FC641WF1), FC641WF12 (FC641WF1), FC641XF11 (FC641XF1), FC641XF12 (FC641XF1), FC642BF11 (FC642BF1), FC642BF12 (FC642BF1), FC642WF11 (FC642WF1), FC642WF12 (FC642WF1), FC642XF11 (FC642XF1), FC642XF12 (FC642XF1), FC672XN11 (FC672XN1), FC935X1 (FC935X), FE200BS11 (FE200BS1), FE200BS12 (FE200BS1), FE200WCKD1 (FE200WCKD), FE200WCKD2 (FE200WCKD), FE200WS11 (FE200WS1), FE200WS12 (FE200WS1), FE200XN11 (FE200XN1), FE200XN12 (FE200XN1), FE201XU12 (FE201XU1), FE210WN11 (FE210WN1), FE210XN11 (FE210XN1), FE210XN12 (FE210XN1), FE211BS11 (FE211BS1), FE211BS12 (FE211BS1), FE211WS11 (FE211WS1), FE211WS12 (FE211WS1), FE211XS12 (FE211XS1), FE211XS13 (FE211XS1), FE212BF11 (FE212BF1), FE212BF12 (FE212BF1), FE212WCKD1 (FE212WCKD), FE212WF11 (FE212WF1), FE212WF12 (FE212WF1), FE212XCKD1 (FE212XCKD), FE212XF11 (FE212XF1), FE212XF12 (FE212XF1), FE213XN11 (FE213XN1), FE213XN12 (FE213XN1), FE222BS11 (FE222BS1), FE222BS12 (FE222BS1), FE222WS11 (FE222WS1), FE222WS12 (FE222WS1), FE222XS11 (FE222XS1), FE222XS12 (FE222XS1), FE222ZS11 (FE222ZS1), FE222ZS12 (FE222ZS1), FE300BF11 (FE300BF1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FE300WF11 (FE300WF1), FE310XU11 (FE310XU1), FE410WN11 (FE410WN1), FE410WN12 (FE410WN1),
FE410XN11 (FE410XN1), FE410XN12 (FE410XN1), FE412XN11 (FE412XN1), FE412XN12 (FE412XN1),
FE422BF11 (FE422BF1), FE422BF12 (FE422BF1), FE422BF13 (FE422BF1), FE422BS11 (FE422BS1), FE422WF11
(FE422WF1), FE422WF12 (FE422WF1), FE422WF13 (FE422WF1), FE422WS11 (FE422WS1), FE422XF11
(FE422XF1), FE422XS11 (FE422XS1), FE422ZS11 (FE422ZS1), FE600XS11 (FE600XS1), FE601WS11
(FE601WS1), FE601XS11 (FE601XS1), FE610WN11 (FE610WN1), FE610XN11 (FE610XN1), FE611BS11
(FE611BS1), FE611WS11 (FE611WS1), FE611XS11 (FE611XS1), FE612XN11 (FE612XN1), FE622BS11
(FE622BS1), FE622WS11 (FE622WS1), FE622XS11 (FE622XS1), FP1052B1 (FP1052B), FP1052X1 (FP1052X),
FP1060W1 (FP1060W), FP1061B1 (FP1061B), FP1061W1 (FP1061W), FP1061X1 (FP1061X), FP1371X1
(FP1371X), FP211XN11 (FP211XN1), FP212XN11 (FP212XN1), FP212XN12 (FP212XN1), FP224MN11
(FP224MN1), FP224MN12 (FP224MN1), FP224WN11 (FP224WN1), FP224WN12 (FP224WN1), FP224XN11
(FP224XN1), FP224XN12 (FP224XN1), FP225BS11 (FP225BS1), FP225BS12 (FP225BS1), FP225BS13
(FP225BS1), FP225WS11 (FP225WS1), FP225WS12 (FP225WS1), FP225WS13 (FP225WS1), FP225XS11
(FP225XS1), FP225XS12 (FP225XS1), FP225XS13 (FP225XS1), FP228MN11 (FP228MN1), FP228MN12
(FP228MN1), FP228XN11 (FP228XN1), FP228XN12 (FP228XN1), FP228ZN11 (FP228ZN1), FP228ZN12
(FP228ZN1), FP229BS11 (FP229BS1), FP229BS12 (FP229BS1), FP229BS13 (FP229BS1), FP229WS11
(FP229WS1), FP229WS12 (FP229WS1), FP229WS13 (FP229WS1), FP229XS11 (FP229XS1), FP229XS12
(FP229XS1), FP229XS13 (FP229XS1), FP230XN11 (FP230XN1), FP252BF11 (FP252BF1), FP252BF12 (FP252BF1),
FP252WF11 (FP252WF1), FP252WF12 (FP252WF1), FP252XF11 (FP252XF1), FP252XF12 (FP252XF1),
FP252XF13 (FP252XF1), FP254BF11 (FP254BF1), FP254BF12 (FP254BF1), FP254WF11 (FP254WF1), FP254WF12
(FP254WF1), FP261BF11 (FP261BF1), FP261BF12 (FP261BF1), FP261BF13 (FP261BF1), FP261WF11
(FP261WF1), FP261WF12 (FP261WF1), FP261WF13 (FP261WF1), FP262BF11 (FP262BF1), FP262BF12
(FP262BF1), FP262WF11 (FP262WF1), FP262WF12 (FP262WF1), FP262XF11 (FP262XF1), FP262XF12
(FP262XF1), FP262XF13 (FP262XF1), FP262ZF11 (FP262ZF1), FP262ZF12 (FP262ZF1), FP263DF11 (FP263DF1),
FP263DF12 (FP263DF1), FP263DF13 (FP263DF1), FP263EF11 (FP263EF1), FP263EF12 (FP263EF1), FP263EF13
(FP263EF1), FP265BF11 (FP265BF1), FP265BF12 (FP265BF1), FP265WF11 (FP265WF1), FP265WF12
(FP265WF1), FP271BF11 (FP271BF1), FP271WF11 (FP271WF1), FP362BF11 (FP362BF1), FP362BF12
(FP362BF1), FP362BF13 (FP362BF1), FP362WF11 (FP362WF1), FP362WF12 (FP362WF1), FP362WF13
(FP362WF1), FP362XF11 (FP362XF1), FP362XF12 (FP362XF1), FP362XF13 (FP362XF1), FP365BF11 (FP365BF1),
FP365BF12 (FP365BF1), FP365BF13 (FP365BF1), FP365WF11 (FP365WF1), FP365WF12 (FP365WF1),
FP365WF13 (FP365WF1), FP411XN11 (FP411XN1), FP411XN12 (FP411XN1), FP424MN11 (FP424MN1),
FP424MN12 (FP424MN1), FP424WN11 (FP424WN1), FP424WN12 (FP424WN1), FP424XN11 (FP424XN1),
FP424XN12 (FP424XN1), FP424ZN11 (FP424ZN1), FP424ZN12 (FP424ZN1), FP428MN11 (FP428MN1),
FP428MN12 (FP428MN1), FP428XN11 (FP428XN1), FP428XN12 (FP428XN1), FP452BF11 (FP452BF1),
FP452BF12 (FP452BF1), FP452WF11 (FP452WF1), FP452WF12 (FP452WF1), FP452WF13 (FP452WF1),
FP452WF14 (FP452WF1), FP452XF11 (FP452XF1), FP452XF12 (FP452XF1), FP462BF11 (FP462BF1), FP462BF12
(FP462BF1), FP462WF11 (FP462WF1), FP462WF12 (FP462WF1), FP462WF13 (FP462WF1), FP462WF14
(FP462WF1), FP462XF11 (FP462XF1), FP462XF12 (FP462XF1), FP462ZF11 (FP462ZF1), FP462ZF12 (FP462ZF1),
FP464BF11 (FP464BF1), FP464WF11 (FP464WF1), FP464WF12 (FP464WF1), FP464XF11 (FP464XF1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FP465BF11 (FP465BF1), FP465BF12 (FP465BF1), FP465WF11 (FP465WF1), FP465WF12 (FP465WF1),
FP465WF13 (FP465WF1), FP465WF14 (FP465WF1), FP551BF11 (FP551BF1), FP551WF11 (FP551WF1),
FP551XF11 (FP551XF1), FP561BF11 (FP561BF1), FP561WF11 (FP561WF1), FP561XF11 (FP561XF1), FP562X1
(FP562X), FP562X2 (FP562X), FP611XN11 (FP611XN1), FP624WN11 (FP624WN1), FP624XGN11 (FP624XGN1),
FP624XN11 (FP624XN1), FP624ZN11 (FP624ZN1), FP628XGN11 (FP628XGN1), FP628XN11 (FP628XN1),
FP652BF11 (FP652BF1), FP652WF11 (FP652WF1), FP652XF11 (FP652XF1), FP662BF11 (FP662BF1), FP662BF12
(FP662BF1), FP662WF11 (FP662WF1), FP662XF11 (FP662XF1), FP662XF12 (FP662XF1), FP662ZF11 (FP662ZF1),
FP663DF11 (FP663DF1), FP663EF11 (FP663EF1), FP664BF11 (FP664BF1), FP664BF12 (FP664BF1), FP664WF11
(FP664WF1), FP664WF12 (FP664WF1), FP664XF11 (FP664XF1), FP664XF12 (FP664XF1), FP665BF11
(FP665BF1), FP665WF11 (FP665WF1), FP665XF11 (FP665XF1), FP666BF11 (FP666BF1), FP666WF11
(FP666WF1), FP666XF11 (FP666XF1), FP667XS11 (FP667XS1), FP852BF11 (FP852BF1), FP852BF12 (FP852BF1),
FP871B2 (FP871B), FP971X1 (FP971X), FP980X1 (FP980X), HH-229PX1 (HH-229PX), 921110184 (HMP198N),
HP197B1 (HP197B), 921110148 (HP-197B), HP197N1 (HP197N), 921110157 (HP-197N), HP197X1 (HP197X),
921110139 (HP-197X), HPM198B1 (HPM198B), HPM198B2 (HPM198B), 921110175 (HPM-198B), HPM198N1
(HPM198N), HPM198N2 (HPM198N), 921110184 (HPM-198N), HPM198X1 (HPM198X), HPM198X2 (HPM198X),
921110166 (HPM-198X), HPM-199CX1 (HPM-199CX), OH311XU11 (OH311XU1), SFP665K1 (SFP665K)
FAGOR BRANDT Kitchen BCM6653W1 (BCM6653), KI360WE11 (KI360WE1), KI360WE12 (KI360WE1),
KI360WE13 (KI360WE1), KI365WE11 (KI365WE1), KI365WE13 (KI365WE1), KI365WE14 (KI365WE1), KIP712W1
(KIP712W), KM360WE11 (KM360WE1), KM360WE12 (KM360WE1), KM361TE11 (KM361TE1), KM361WE11
(KM361WE1), KM361WE12 (KM361WE1), KM362WE11 (KM362WE1), KM362WE12 (KM362WE1), KM363WE11
(KM363WE1), KM363WE12 (KM363WE1), KM363WE13 (KM363WE1), KM364WE11 (KM364WE1), KM364WE12
(KM364WE1), KM365TE11 (KM365TE1), KM365TE12 (KM365TE1), KM365TE13 (KM365TE1), KM365TE14
(KM365TE1), KM365TE15 (KM365TE1), KM365WE11 (KM365WE1), KM365WE12 (KM365WE1), KM365WE13
(KM365WE1), KM365WE14 (KM365WE1), KM365XE11 (KM365XE1), KM365XE13 (KM365XE1), KM365XE14
(KM365XE1), KM365XE15 (KM365XE1), KM365XE16 (KM365XE1), KM366WE11 (KM366WE1), KM366WE12
(KM366WE1), KM366WE13 (KM366WE1), KM366WE14 (KM366WE1), KM367WE11 (KM367WE1), KM367WE12
(KM367WE1), KM367WE13 (KM367WE1), KM367WE14 (KM367WE1), KM460WE11 (KM460WE1), KM465WE11
(KM465WE1), KM465WE12 (KM465WE1), KM466WE11 (KM466WE1), KM468WA12 (KM468WA1), KM468WA13
(KM468WA1), KM559WE11 (KM559WE1), KM561WE11 (KM561WE1), KM565TE11 (KM565TE1), KM565WE11
(KM565WE1), KM565XE11 (KM565XE1), KM566WE11 (KM566WE1), KMC1103W1 (KMC1103W), KMC601W1
(KMC601W), KMC606W1 (KMC606W), KMC606W2 (KMC606W), KMC909W1 (KMC909W), KMC909W2
(KMC909W), KME1002W1 (KME1002W), KMP1010W1 (KMP1010W), KMP1015W1 (KMP1015W), KMP1015W2
(KMP1015W), KMP1115W1 (KMP1115W), KMP615T1 (KMP615T), KMP615W1 (KMP615W), KMP617W1
(KMP617W), KMP715T1 (KMP715T), KMP715T2 (KMP715T), KMP715T3 (KMP715T), KMP715W1 (KMP715W),
KMP715W2 (KMP715W), KMP715W3 (KMP715W), KMP715X1 (KMP715X), KMPC1000W1 (KMPC1000W),
KMPM1001W1 (KMPM1001W), KR361WE11 (KR361WE1), KR361WE12 (KR361WE1), KR365WE11 (KR365WE1),
KR365WE13 (KR365WE1), KR365WE14 (KR365WE1), KR365WE15 (KR365WE1)
FAGOR BRANDT Kitchen electric KE360TE11 (KE360TE1), KE360TE12 (KE360TE1), KE360WE11 (KE360WE1),
KE360WE12 (KE360WE1), KE361WE11 (KE361WE1), KE361WE12 (KE361WE1), KE361WE13 (KE361WE1),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

KE361WE14 (KE361WE1), KE361WE15 (KE361WE1), KE369WE11 (KE369WE1), KE369WE12 (KE369WE1),
KE375WE11 (KE375WE1), KE560WE11 (KE560WE1), KE569WE11 (KE569WE1), KE569WE12 (KE569WE1),
KEC660W1 (KEC660W), KMP1015T1 (KMP1015T), KMP1018W1 (KMP1018W)

FAGOR BRANDT Kitchen glass-ceramics KI469WE11 (KI469WE1), KI569WE11 (KI569WE1), KI569WE12
(KI569WE1), KIP615W1 (KIP615W), KIP710W1 (KIP710W), KIP710W2 (KIP710W), KIP710W3 (KIP710W),
KIP711W1 (KIP711W), KIP711W2 (KIP711W), KIP711W3 (KIP711W), KV360WE11 (KV360WE1), KV361WE11
(KV361WE1), KV361WE12 (KV361WE1), KV361WE13 (KV361WE1), KV361WE14 (KV361WE1), KV367WE11
(KV367WE1), KV367WE12 (KV367WE1), KV368WE11 (KV368WE1), KV369WE11 (KV369WE1), KV369WE12
(KV369WE1), KV371WE11 (KV371WE1), KV372WE11 (KV372WE1), KV373WE11 (KV373WE1), KV373XE11
(KV373XE1), KV374WE11 (KV374WE1), KV374WE12 (KV374WE1), KV374XE11 (KV374XE1), KV374XE12
(KV374XE1), KV462WE11 (KV462WE1), KV462WE12 (KV462WE1), KV560WE11 (KV560WE1), KV561WE11
(KV561WE1), KV567WE11 (KV567WE1), KV567WE13 (KV567WE1), KV568WE11 (KV568WE1), KV568WE13
(KV568WE1), KV571WN11 (KV571WN1), KV571WN12 (KV571WN1), KV571XN11 (KV571XN1), KV571XN12
(KV571XN1), KV600WN11 (KV600WN1), KVC660W1 (KVC660W), KVC660W2 (KVC660W), KVP661W1
(KVP661W), KVP661W2 (KVP661W)

FAGOR BRANDT Pot stove CFF-631MP1 (CFF-631MP), CFF-631P1 (CFF-631P), CFF-631P2 (CFF-631P), CFF-631P3
(CFF-631P)

VEDETTE Kitchen 7VC0210 (VMC630B), 7VC0195 (VME620B), VME620B1 (VME620B), VME620B2 (VME620B),
VME620B3 (VME620B), 7VC0178 (VME64B), 7VC0193 (VME64B), VME64B1 (VME64B), VME64B2 (VME64B),
7VC0198 (VMP640B), VMP640B1 (VMP640B), 7VC0174 (VMP65B), 7VC0184 (VMP65B), VMP65B1 (VMP65B),
VMP65B2 (VMP65B), 7VC0188 (VMP66B), VMP66B1 (VMP66B)

VEDETTE Kitchen electric 7VC0181 (VEE61B), 7VC0191 (VEE61B), 7VC0202 (VEE61B), VEE61B1 (VEE61B),
VEE61B2 (VEE61B), VEE61B3 (VEE61B)

VEDETTE Kitchen glass-ceramics 7VC0179 (VVC61B), 7VC0192 (VVC61B), 7VC0200 (VVC61B), 7VC0204
(VVC61B), VVC61B1 (VVC61B), VVC61B2 (VVC61B), VVC61B3 (VVC61B), 7VC0209 (VVC62B)

