

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Aprindere electronica 2 iesiri 230VAC 48x32x32mm DPF 56mm F2.8x0.8 #101012

Fara TVA: 33,61 Lei

Pret cu TVA: 40,00Lei

Aprindere electronica 2 iesiri 230VAC 48x32x32mm DPF 56mm F2.8x0.8 #101012

iesiri 2

alimentare 230VAC

dimensiuni 48x32x32mm

distanța piese de fixare 56mm

intrare F2,8x0,8

tip ZIG2

frecvența 50-60 Hz

iesire F2,8x0,8

Compatibil cu:

ALPENINOX 003376, 004240, 051884, 053647, 0A2073

AMATIS X163014000

AMBACH 5060401734, 5060402386

ANGELO PO 32T0040, 32T0041, 32T0050, 32T0210

BARON 6A050100, 6A050105, BN6A050100

BERTOS 22164232, 31002600, 31003000, 32164200

BONNET 308465

CAPIC E050505

CB 08060011

CHARVET 02161A, 2161

COLGED RTBF800129, RTCU700096

COOKMAX RTCU700096

COVEN EMACA000

DEXION RTBF800129

ELECTROLUX 003376, 004240, 051884, 053647, 0A2073

ELETTROBAR RTBF800129, RTCU700096

EMMEPI 813434, 8C1700, C00507, C10167

EPMS 1410109, LF3181002

ERRE 2 539613240, 539613242

FAGOR 12020231, 12024347, 163014000, R073007, R073007000, X163014, X163014000



magazin online *HORECA*

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FIAMMA RST 91116.220.005
FOINOX 0825
GICO 539613240, 539613242
GIGA X50000
GIORIK 6041059
HENDI 3181002
HOBART RTBF800129
HORECAPARTS 3181002
JEMI 240037
LAINOX 50102700, 50102710, MA2971400, R65180280, R65180290
MARENO 1450300, 2971400, MA2971400
MBM RTBF800129, RTCU700096
METOS 6A050100, 6A050105, BN6A050100
MODULAR 661.118.00, 96103000
OLIS 6A050100, 6A050105, BN6A050100
PALUX BN6A050100
REPAGAS 1430008
ROSINOX RX94027802, RX94805108
SAGI 32T0040, 32T0041, 32T0050, 32T0210
SILKO 0101193, 0101196, 0101197
SOCOLMATIC B42
SOGECO ACCENDITORE001
STAR10 068034
TECNOINOX RC00862000, RCK6041059
THIRODE 308465
UNOX KVE1065A, VE1065A0
WHIRLPOOL 483286009414
ZANUSSI 003376, 004240, 051884, 053647, 0A2073
AMATIS
AMBACH Boiling Pan Electric BPG-50
ANGELO PO Bain-Marie Gas 090BM1G, 190BM2G
ANGELO PO Boiling Pan Gas 191PD1G, 191PD2G, 191PI1G, 191PI1GA, 191PI2G, 191PI2GA, 291PD3G, 291PI3G
ANGELO PO Bratt Pan 291BR2G
ANGELO PO Bratt Pan Gas 191BR1G, 191BR1GA, 191BR2G, 191BR2GA, 1A1BR1G, 1A1BR1GA, 1A1BR2G, 1A1BR2GA, 1D1BR1G, 1D1BR1GA, 1D1BR2G, 1D1BR2GA, 291BR1G, 291BR1GA, 291BR2GA, 2A1BR1G, 2A1BR1GA, 2A1BR2G, 2A1BR2GA, 2D1BR1G, 2D1BR1GA, 2D1BR2G, 2D1BR2GA
ANGELO PO Convection Oven STEAM FCV101DS CSA
ANGELO PO Convection Oven Gas FC101, FC241G, FC61, FCV101, FCV101DM, FCV101DS, FCV141, FCV141DM, FCV141DS, FCV241G, FCV241GDM, FCV241GDS, FCV61, FCV61DM, FCV61DS



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ANGELO PO Fry Top Gas 08WFT1GV, 08WFT2GV, 08WFT3GV, 08WFT4GV, 08WFT6GV, 08WFT7GV, 090FT1G, 090FT2G, 090FT4G, 090FT5G, 090FT7G, 190FT15G, 190FT1G, 190FT2G, 190FT3G, 190FT42G, 190FT4G, 190FT6G, 190FT72G, 190FT7G, 6040560, 6042490, 6042500, 6043200

ANGELO PO Fryer Gas 06WFR3GD, 091FR1G, 091FR1GD, 091FR3G, 091FR3GD, 0A1FR1G VERS 2004, 0A1FR1GD VERS 2004, 0A1FR3G, 0A1FR3GD, 0B1FR1G, 0B1FR1GD, 0D1FR1G, 0D1FR1G VERS 2004, 0D1FR1GD, 0D1FR1GD VERS 2004, 0D1FR3G, 0D1FR3GD, 0G1FR3G, 0G1FR3GD, 10WFR4GD, 191FR2G, 191FR2GD, 191FR4G, 191FR4GD, 1A1FR2G, 1A1FR2G VERS 2004, 1A1FR2GD, 1A1FR2GD VERS 2004, 1A1FR4G, 1A1FR4GD, 1D1FR2G, 1D1FR2G VERS 2004, 1D1FR2GD, 1D1FR2GD VERS 2004, 1D1FR4G, 1D1FR4GD, 1G1FR4G, 1G1FR4GD

ANGELO PO Grill Gas 08WGRGV, 090GRG, 6042120 08WGRGV

ANGELO PO Hot Plate Gas 090FAVA

ANGELO PO Kitchen Gas 090FAA, 12WFA6G, 190FAB, 191FAAG, 191FABG, 191FADG, 191FAG, 291FAG, 291FAGF, 2N1FAGF, 391FAG

ANGELO PO Lava Rock Grill GRILL 190GRG

ANGELO PO Pasta Cooker 191CP2G

ANGELO PO Pasta Cooker Gas 06WCP1GM, 08WCP1GM, 091CP1G, 0N1CP1GH, 0N1CP1GL, 10CP1GA, 12CP1GA, 18CP2GA, 191CP1G, 191CP1GA, 1N1CP2GH, 1N1CP2GL

ANGELO PO Pot Stove Gas 04WFAAV, 0A1FR1G, 0A1FR1GD, G1FAGS, G1FAGST

ANGELO PO Solid Top 190TP0, 191TPG, 291TPCG, RANGE GAS 10WTPGV

ASCASO

BARON Bratt Pan Gas 7BR-GM30, 7BR-GM31, 9BR-G80, 9BR-G81, 9BR-GM80

BERTOS Boiling Pan Gas G9P10D, G9P10DA, G9P10I, G9P10IA, G9P15D, G9P15DA, G9P15I, G9P15IA, LXG9P15I, SG9P10D, SG9P10DA, SG9P10I, SG9P10IA, SG9P15D, SG9P15DA, SG9P15I, SG9P15IA

BERTOS Bratt Pan Gas G9BR8-I, LXG9BR8-I, LXG9BR8-I-RM, SG9BR8-I

BERTOS Convection Oven Gas FMG10, FMG10EP, FMG10M, FMG6, FMG6EP, FMG6M, FPG12, FPG6, WAVG12, WAVG5U, WAVG6

BERTOS Fryer Gas 9GL22-22MEL, GL18-18MI, GL18MI, LX9GL22EL, SGL18MIE, SGL18MIEL

BERTOS Kitchen Electric G6F6PW-FE1, G6F6PW-TE

BERTOS Kitchen Gas G6F2BPW, G6F2MPW, G6F2MPW-AE, G6F4BPW, G6F4MPW, G6F4PW-FG1, G6F4W-FE1, G6F6BPW, G6F6MPW, G6F6PW-FG1, G6F6PW-T, GL18-18MI-E, GL18MI-E

BERTOS Pasta Cooker Gas SG7CP40M

BERTOS Pot Stove Electric G6F4PW-FE1-AE

BERTOS Pot Stove Gas G6F2BPW-AE, G6F4BPW-AE, G6F4MPW-AE, G6F4PW-FG1-AE, G6F6BPW-AE, G6F6MPW-AE

CAPIC Boiling Pan Gas W294021, W294022, W294121, W294122, W296211, W384021, W384022, W384121, W384122

CAPIC Bratt Pan Gas W291815, W295021, W295022, W295023, W295024, W295027, W295127, W381815, W381825, W381835, W385021, W385022, W385023, W385024, W385025

CAPIC Electric Oven W292966, W293061, W383061



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

CAPIC Fry Top Electric W340918

CAPIC Fry Top Gas W290915, W290917, W291515, W291525, W291535, W291545, W340915, W340917, W380917, W380925, W380927, W380935, W380937, W380945, W380947, W381515, W381535, W381545

CAPIC Fryer Electric W381035

CAPIC Fryer Gas W291035

CAPIC Grill Gas W290912, W290913, W340912, W380922, W380929, W380932, W380939, W380942, W380949

CAPIC Pot Stove Electric W382966

CAPIC Pot Stove Gas W290511, W290515, W296513, W296523, W296533, W296543, W380161, W380162, W380261, W380511, W380521, W380531, W380541, W382561, W382562, W382661, W382662, W386513, W386523, W386533, W386543

CAPIC Solid Top RANGE GAS W290411, W290413, W290415, W380413, W380423, W380433, W380443, W380461

CB Rotisserie Gas G-12P, G-20P, P10-4 GAS, P10-5 GAS, P10-6 GAS, P10-8 GAS, P7-5 GAS

COVEN Gas Oven TEC 10G, TEC 10GMD, TEC 10GP, TEC 10GP MEC, TEC 20G, TEC 20GMD, TEC 5GP, TEC 6GMD, TEC 6GMX

DEXION Convection Oven Gas FC006-03-002GM

DEXION Fry Top Gas LX9GBRAVIT

DEXION Fryer Gas LX7GF7IM

DEXION Kitchen Gas MG066-03-010

DEXION Pot Stove Gas MG106-03-010

EMMEPI Bratt Pan Gas EBRG94, EBRGC7

EMMEPI Fry Top Electric FT702L, FT702LC, FT702R, FT704L, FT704LC, FT704LR, FT704R, FT706L, FT706LC, FT706LR, FT706R

EMMEPI Fry Top Gas FT702, FT704, FT706

EMMEPI Kitchen Electric E706FB-8

EMMEPI Kitchen Gas E702A-8, E704F-P22, E704F-P23, E704F-P25, E706F-P33, E706F-P35, E706F-P38, E706FB-P33, E706FB-P35, E706FB-P37, E706FB-P38

EMMEPI Pot Stove Gas 652, 652SC, E702A, E706FB

FAGOR BG9-05AD, BG9-05PLUS-I, BG9-10PLUS-I, CG-7200, CG-7415, CG9-20AD-H, CG9-20PLUS-H, CG9-31PLUS-D, CG9-31PLUS-I, CG9-41AD-H, CG9-41PLUS-H, CG9-61AD-H, CG9-61PLUS-H, CGF9-121D-AD, CGF9-121PLUS-D, CGF9-121PLUS-I, CPG9-05AD-S, CPG9-05PLUS-S, FG7-05-1C, FG7-05-2C, FG7-10-2C, FG7-10-4C, FG7-104C, FG9-05-1C, FG9-05-2C, FG9-05PLUS-S

FAGOR Boiling Pan Gas MG9-10AD, MG9-10BMAD, MG9-10PLUS, MG9-10PLUSBM, MG9-15AD, MG9-15BMAD, MG9-15PLUS, MG9-15PLUSBM, MG9-20AD, MG9-20PLUS

FAGOR Bratt Pan Electric SBE7-10, SBE710, SBE9-10, SBE9-10I, SBE9-10IM, SBE9-10M, SBE9-15IM, SBE9-15IMS

FAGOR Bratt Pan Gas SBE-710, SBE9-10IMS, SBE9-10IS, SBE9-10MS, SBE9-10S, SBG-710, SBG7-10, SBG9-00, SBG9-10, SBG9-10I, SBG9-10IAD, SBG9-10IM, SBG9-10IMAD, SBG9-10IMS, SBG9-10IS, SBG9-10M, SBG9-10MS, SBG9-10PLUSI, SBG9-10PLUSIM, SBG9-10S, SBG9-15IM, SBG9-15IMAD, SBG9-15IMS, SBG9-15PLUSIM



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FAGOR Fry Top Gas FTG9-05PLUS, FTG9-05PLUSV, FTG9-10PLUS, FTG9-10PLUSV

FAGOR Fryer Electric FE-700, FE-710, FE-720, FE7-05, FE7-10, FE9-05, FE9-05S, FE9-10, FG-700

FAGOR Fryer Electronic FE9-00

FAGOR Fryer Gas FG-710, FG-720, FG7-05, FG7-10, FG9-00, FG9-05, FG9-05AD, FG9-05PLUS, FG9-05PLUS, FG9-05S, FG9-05SAD, FG9-10, FG9-10AD, FG9-10PLUS, FGCL9-051C, FGCL9-052C, FGCL9-05S1C, FGCL9-05S2C

FAGOR Grill Gas BG9-05PLUS, BG9-10AD, BG9-10PLUS

FAGOR Kitchen Electric CGE9-41AD

FAGOR Kitchen Gas CG9-05AD, CG9-05PLUS, CG9-10AD, CG9-10PLUS, CG9-11AD, CG9-11PLUS, CG9-20AD, CG9-20PLUS, CG9-31PLUS, CG9-40AD, CG9-40PLUS, CG9-41AD, CG9-41PLUS, CG9-60AD, CG9-60PLUS, CG9-61AD, CG9-61PLUS, CG9-82AD, CG9-82PLUS, CGE9-41PLUS, CGF9-120PLUS, CGF9-121AD, CGF9-121PLUS, CGFE9-120AD

FAGOR Lava Rock Grill GRILL GAS BG9-05AD

FAGOR Pasta Cooker Electric CPE9-05AD, CPE9-05ADS, CPE9-05PLUS, CPE9-05PLUS

FAGOR Pasta Cooker Gas CPG9-05AD, CPG9-05ADS, CPG9-05PLUS, CPG9-05PLUS

FAGOR BRANDT 7415, BG9-05AD, BG9-05PLUS-I, BG9-10AD, BG9-10PLUS-I, CG-, CG-7200, CG9-05AD, CG9-05PLUS, CG9-10AD, CG9-10PLUS, CG9-11AD, CG9-11PLUS, CG9-20AD, CG9-20AD-H, CG9-20PLUS, CG9-20PLUS-H, CG9-31PLUS-D, CG9-31PLUS-I, CG9-41, CG9-41AD, CG9-41AD-H, CG9-41PLUS, FAGOR

GIGA Bratt Pan KBRGM, KBRGM12, KBRGM12IN, KBRGMIN

GIGA Bratt Pan Gas KBRG, KBRG12, KBRG12IN, KBRGIN, OPBRG, OPBRG12, OPBRG12IN, OPBRGIN, OPBRGM, OPBRGM12, OPBRGM12IN, OPBRGMIN

GIGA Fryer Gas CF15DG8, CF15G4, KFG4, KFG8

GIORIK Convection Oven Gas GF5GM, GN10VGMX, GN6MX

GIORIK Fryer Gas 13FG, 13FG-C, 17FG, 17FG-C, 207FG, 207FG-C, 213FG, 213FG-C, 217FG, 217FG-C, 917FG, 917FG-C, 921PGC, 927FG, 927FG-C, 934FG, 934FG-C, FG07CL, FG17CL, FG213CL, FG217CL, FG7217MT, FG7813P, FG9117T, FG9417P, FG9821P, FRG9521

HOBART Bratt Pan Gas BCGABP, BCGMBP, BMGMBP

HOBART Kitchen Gas HG4SF6, HG6SF6, HG6SFE6, HG6SFEA6

LAINOX Convection Oven Gas FG051M, FG051X, FG101M, FG101X, FG102M, FG102X, FG105M, FG105X, FG110M, FG110X, FG210M, FG210X, PG040M, PG040X, PG041M, PG041X, PG051M, PG051X, PG080M, PG080X, PG081M, PG081X, PG101M, PG101X

MARENO Boiling Pan Gas NPD78G8, NPD96G5, NPD98G10, NPD98G15, NPD98G15A, NPI76G5, NPI78G8, NPI96G5, NPI98G10, NPI98G14, NPI98G14A

MARENO Bratt Pan Electric NBR912EFM

MARENO Bratt Pan Gas 94-10KBGI, BR9-12GFM, BR9-12GIM, BR9-8GF, BR9-8GFM, BR9-8GI, BR9-8GIM, NBR912GFM, NBR912GIM, NBR98GF, NBR98GFM, NBR98GI

MARENO Fryer Electric NF98G23K

MARENO Fryer Gas NF94G23K

MARENO Pasta Cooker Gas NPC74G, NPC76G, NPC78G, NPC94G, NPC96G, NPC98G

MBM Boiling Pan Gas G100I9N, G100IT9N, G150I9N, G150IT9N



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

MBM Bratt Pan Gas GBR, GBR9T, GBRA, GBRA9T, GBRAVI9T, GBRVI9T

MBM Convection Oven Gas FCG10, FCG20, FCG6, FGP050, FGP080, FGP160

MBM Fryer Gas GF408N, GF411, GF477IM, GF777IM, GF908N, GF911

MBM Kitchen Gas G6SF6, G6SFA6

MBM Pasta Cooker Gas GC411-SC, GC911-SC

MBM Pot Stove Gas G4SF6

MODULAR

MODULAR Fryer Gas 70-FRGVL, 90FRGVL

OLIS Bratt Pan Gas 74-02KBGB, 74-02KBGBI, 74-02KBGMB, 74-02KBGMBI, 94-04KGB, 94-04KBGM, 9BR-G80, 9BR-G81, 9BR-GM80

OLIS Fryer Gas 72-02FRGM, 73-02FRGM, 74-02FRGM, 92-04FRG20L, 94-04FRG20L

PALUX

SILKO Kitchen Gas CCG1041, CCG1042, CCG1045, CCG1061, CCG1062, CCG10652, CCG10653, CCG1081, CCG1082, CCG1085, CCG10852, CCG7020, CCG7021, CCG7022, CCG7040, CCG7041, CCG7042, CCG7061, CCG7062, CCG70662, CCG9020, CCG9021, CCG9022, CCG9040, CCG9040-1, CCG9041, CCG9041-1, CCG9042, CCG9042-1, CCG9045-1, CCG9046-1

SILKO Oven Under CCG7045, CCG70652, COOKTOP GAS CCG7001

SILKO Oven Under Cooktop Electric CCG7046, CCG70653, CCG70663

SILKO Pizza Oven Gas CFS9050, CFS9055

SILKO Pot Stove Gas CCG9045, CCG9046

SILKO Solid Top CTT1042, CTT1045, CTT9040, CTT9041, CTT9042, CTT9045, CTT9046, CTT90652R, RANGE GAS CTT1041

STAR-10

STAR10 BSC6FG, FT1GC-4521

TECNOINOX Fryer Gas FR43FG9, FR47FG9, FR83FG9, FR87FG9, FRV41FG9, FRV43FG9, FRV47FG9, FRV81FG9, FRV83FG9, FRV87FG9

TECNOINOX Gas Oven BF105G, BF70G

TECNOINOX Kitchen Gas PF105GG0, PF105GGG6, PF5GG0, PF5GGG6, PF70GG0, PF70GGG6, PFL105GG0, PFL105GGG6, PFL5GG0, PFL5GGG6, PPF5GG0, PPF5GGG6, PPFL5GG0, PPFL5GGG6

UNIVERSAL PART

UNOX Convection Oven Gas XG813G, XVC2015G, XVC314G, XVC315G, XVC4015G, XVC714G, XVC715G

VIRTUS VS7080BRGI, VS7080BRGIM, VS7080PG50, VS7080PGI50, VS9080BRGI, VS9080BRGIM, VS9080PGI150

ZANUSSI Boiling Pan E9BSGHDP40 (391296), E9BSGHIN40 (391290), E9BSGHIR40 (391293)

ZANUSSI Boiling Pan Electric A7BSEHINF0 (373094), A9BSEHINF0 (393117), A9BSEHIPF0 (393118), A9BSEHIPFR (393119), A9BSEHIRF0 (393120), A9BSEHIRFR (393121), E7BSEHINF0 (371094), E7BSEHINFR (371095), E7BSGHDN40 (371254), E7BSGHIN40 (371252), E7BSGHIN4R (371253), E9BSEHINF0 (391117), E9BSEHIPF0 (391118), E9BSEHIPFR (391119), E9BSEHIRF0 (391120), E9BSEHIRFC (391122), E9BSEHIRFR (391121), Z7BSEHINF0 (372094), Z7BSEHINFR (372095), Z9BSEHINF0 (392117), Z9BSEHIPF0 (392118), Z9BSEHIPFR (392119), Z9BSEHIRF0 (392120), Z9BSEHIRFC (392122), Z9BSEHIRFR (392121)

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI Boiling Pan Gas A7BSGHDNF0 (373089), A7BSGHINF0 (373087), A9BSGHDPF0 (393106), A9BSGHDRF0 (393107), A9BSGHINF0 (393099), A9BSGHIPF0 (393100), A9BSGHIPFR (393101), A9BSGHIRF0 (393102), A9BSGHIRFR (393103), E7BSGHDNF0 (371089), E7BSGHINF0 (371087), E7BSGHINFR (371088), E9BSGHDPF0 (391106), E9BSGHDRF0 (391107), E9BSGHDRFC (391108), E9BSGHINF0 (391099), E9BSGHIPF0 (391100), E9BSGHIPFR (391101), E9BSGHIRF0 (391102), E9BSGHIRFC (391104), E9BSGHIRFR (391103), KPD/G10 (200275), KPD/G15 (200276), KPD/G15A (200277), KPI/G06 (200280), KPI/G10 (200271), KPI/G10H (200287), KPI/G15 (200272), KPI/G15A (200278), KPI/G15H (200285), OPD/G260 (178434), OPI/G260P (178436), PPD/G260 (178134), PPI/G260P (178136), QPD/G10 (210275), QPD/G15 (210276), QPI/G06 (210280), QPI/G10 (210271), QPI/G10H (210287), QPI/G15 (210272), QPI/G15H (210285), ROPN/G1000 (774880), ROPN/G1015 (774881), ROPN/G1020 (774883), TPD/G260 (178734), TPI/G260P (178736), WPD/G10 (220275), WPD/G15 (220276), WPD/G15A (220277), WPI/G06 (220280), WPI/G10 (220271), WPI/G10H (220287), WPI/G15 (220272), WPI/G15A (220278), WPI/G15H (220285), Z7BSGHDNF0 (372089), Z7BSGHINF0 (372087), Z7BSGHINFR (372088), Z9BSGHDPF0 (392106), Z9BSGHDRF0 (392107), Z9BSGHDRFC (392108), Z9BSGHINF0 (392099), Z9BSGHIPF0 (392100), Z9BSGHIPFR (392101), Z9BSGHIRF0 (392102), Z9BSGHIRFC (392104), Z9BSGHIRFR (392103)

ZANUSSI Bratt Pan Electric A9BREHDOF0 (393145), A9BREHDOFM (393146), A9BREHMOF0 (393143), A9BREHMOFM (393144), A9BREJDPF0 (393149), A9BREJDPFM (393150), A9BREJMPF0 (393147), A9BREJMPFM (393148), E9BREHDOF0 (391145), E9BREHDOFM (391146), E9BREHMOF0 (391143), E9BREHMOFM (391144), E9BREJDPF0 (391149), E9BREJDPFM (391150), E9BREJMPF0 (391147), E9BREJMPFM (391148), Z9BREHDOF0 (392145), Z9BREHDOFM (392146), Z9BREHMOF0 (392143), Z9BREHMOFM (392144), Z9BREJDPF0 (392149), Z9BREJDPFM (392150), Z9BREJMPF0 (392147), Z9BREJMPFM (392148)

ZANUSSI Bratt Pan Gas A9BRGHDOF0 (393136), A9BRGHDOFM (393137), A9BRGHMOF0 (393134), A9BRGHMOFM (393135), A9BRGJDPF0 (393140), A9BRGJDPFM (393141), A9BRGJMPF0 (393138), A9BRGJMPFM (393139), ABR/G820 (221534), ABR/G825 (221535), BR70G (291100), E9BRGHDOF0 (391136), E9BRGHDOFA (391226), E9BRGHDOFB (391227), E9BRGHDOFM (391137), E9BRGHMO40 (391279), E9BRGHMOF0 (391134), E9BRGHMOFA (391224), E9BRGHMOFB (391225), E9BRGHMOFM (391135), E9BRGJDPF0 (391140), E9BRGJDPFA (391230), E9BRGJDPFB (391231), E9BRGJDPFM (391141), E9BRGJMPF0 (391138), E9BRGJMPFA (391228), E9BRGJMPFB (391229), E9BRGJMPFM (391139), HBR/G1003 (295013), HBR/G1003 (295014), HBR/G1003 (2KB07B), HBR/G1004 (295018), HBR/G1004 (770213), HBR/G1013 (295057), HBR/G1013 (2KB08B), HBR/G803 (295003), HBR/G803 (295006), HBR/G803 (295009), HBR/G803 (295051), HBR/G803 (2KB03B), HBR/G804 (295004), HBR/G804 (295008), HBR/G804 (295052), HBR/G804 (2KB04B), HBR/G805 (295012), HBR/G820 (201534), HBR/G825 (201535), KBR/G2C (200302), KBR/G2CH (200316), KBR/G2F (200301), KBR/G2FH (200315), KBR/G3C (200305), KBR/G3CH (200306), KBR/G3CJ (200319), KBR/G3F (200303), KBR/G3FH (200304), QBR/G2C (210302), QBR/G2CH (210316), QBR/G2F (210301), QBR/G2FH (210315), QBR/G3C (210305), QBR/G3CH (210306), QBR/G3F (210303), QBR/G3FH (210304), ROBR/G1000 (774870), ROBR/G1010 (774871), ROBR/G1510 (774872), WBR/G2C (220302), WBR/G2CH (220316), WBR/G2F (220301), WBR/G2FH (220315), WBR/G3C (220305), WBR/G3CH (220306), WBR/G3F (220303), WBR/G3FH (220304), Z9BRGHDOF0 (392136), Z9BRGHDOFA (392226), Z9BRGHDOFB (392227), Z9BRGHDOFM (392137), Z9BRGHMOF0 (392134), Z9BRGHMOFA (392224), Z9BRGHMOFB (392225), Z9BRGHMOFM (392135),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Z9BRGJDPFO (392140), Z9BRGJDPFA (392230), Z9BRGJDPFB (392231), Z9BRGJDPFM (392141), Z9BRGJMPFO (392138), Z9BRGJMPFA (392228), Z9BRGJMPFB (392229), Z9BRGJMPFM (392139)

ZANUSSI Convection Oven ACFG10160H (697311), ECFG201-T (260629), ECFG202-T (260644), FCF/G101/1 (240261), FCFG10160H (240221), RCF101G (697502), RCF201G (697504), RCFG202 (697516)

ZANUSSI Convection Oven Gas 4236N (724236), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), COCO10G (724206), COCO20G (724212), COCO6G (724222), COCVE423AF (724302), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), FCF/G6 (2FC02B), FCF102GMS (240224), FCF201GMS (240225), FCFC202 (2FC07B), FCFG10 (241100), FCFG101 (2FC03B), FCFG101-1J (240264), FCFG101-60 (240269), FCFG101/0 (240201), FCFG102-0 (240202), FCFG102-0T (240262), FCFG102-1J (240265), FCFG10D (241105), FCFG10J (243204), FCFG10J (243205), FCFG10J (243230), FCFG10J (243232), FCFG10NL (241120), FCFG20 (241200), FCFG201 (2FC04B), FCFG201-0 (240203), FCFG202 (2FC05B), FCFG202-0 (240204), FCFG20D (241205), FCFG20F (241210), FCFG20J (243210), FCFG20J (243212), FCFG20J (243234), FCFG20J (243236), FCFG40 (241300), FCFG40D (241306), FCFG40F (241310), FCFG40J (243218), FCFG40J (243220), FCFG40J (243240), FCFG41 (241301), FCFG41J (243238), FCFG6 (241500), FCFG6D (241006), FCFG6F (241510), FCFG6J (243226), FCFG6J (243227), FCFG6J (243228), FCFG6J (243229), FCV/G6-1 (2FM06B), FCVG10-2 (245402), FCVG10-2 (245412), FCVG10-2 (245482), FCVG10-2UK (245442), FCVG10-4 (245404), FCVG10-4 (245484), FCVG10-4D (245414), FCVG10-4UK (245444), FCVG10-ISG (245405), FCVG10-ISG (724350), FCVG10-P (256319), FCVG10PUK (257319), FCVG20-2 (246402), FCVG20-2 (246412), FCVG20-2UK (246442), FCVG20-4 (246404), FCVG20-4 (246482), FCVG20-4D (246414), FCVG20-4D (246484), FCVG20-4UK (246444), FCVG20-P (260319), FCVG20PUK (261319), FCVG6-1 (244401), FCVG6-1UK (244441), FCVG6-3 (244403), FCVG6-3UK (244443), FF/G10 (697710), FF/G20 (697730), FF/G40 (697740), FF/G6 (697690), JCF/G101/1-1 (697361), JCF/G101/1-2 (697391), JCF/G102/1-1 (697362), JCF/G102/1-2 (697392), NCF/G101/1 (724051), NCF/G102/1 (724052), PFCFG20 (241215), PFCFG40F (241315), PFCFG6 (241515), RCF10GK (697508), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104), ZOFCE/G10D (770334), ZOFCE/G20D (770347), ZOFCE/G6D (770345), ZOFCE/G102 (2FM16B), ZOFCE/G104 (2FM18B), ZOFCE/G202 (2FM26B), ZOFCE/G204 (2FM28B), ZOFCE/G6-3 (2FM08B)

ZANUSSI Fry Top Gas HRA/G802 (292435), HRA/G812 (770525), HRS/G802 (292250), HRS/G812 (292258), ROR/G1000 (774924), ROR/G500 (774920), RORA/G1000 (774844), RORA/G500 (774840), ZHRAG802CR (2KT71B)

ZANUSSI Fryer E9FRGD1J4E (391287), E9FRGD1J4O (391288), E9FRGD1J4P (391289)

ZANUSSI Fryer Gas A9FRGD1JFE (393081), A9FRGD1JFO (393082), A9FRGD1JFP (393083), AFH/G435 (221050), AFR/G410 (221001), AFR/G410D (221003), AFR/G410NL (221005), AFR/G411 (221018), AFR/G412 (221022), AFR/G810 (221002), AFR/G810D (221004), BOFR/G500 (774860), CFR/G700 (174933), E9FRGD1JFE (391081), E9FRGD1JFO (391082), E9FRGD1JFP (391083), HFH/G430 (201038), HFH/G435 (201050), HFR/G410 (201001), HFR/G410D (201003), HFR/G410NL (201005), HFR/G411 (201018), HFR/G412 (201022), HFR/G420 (296021), HFR/G420 (296024), HFR/G420 (2KF01B), HFR/G420NL (296027), HFR/G421 (296120), HFR/G810 (201002), HFR/G810D (201004), HFR/G810NL (201006), HFR/G840 (296031), HFR/G840 (296032), HFR/G840 (296034), HFR/G840 (296037), HFR/G840 (2KF05B), KFH/G1 (200351), KFH/G1EH (200355), KFH/G1ELH (200353),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

M35GFR (174501), M40GFR90 (221006), M70GFR (174502), MFR/G350 (161901), MFR/G350D (161906), MFR/G350E (161914), MFR/G350F (161912), MFR/G700 (161902), MFR/G700D (161907), MFR/G700E (161915), MFR/G700F (161913), OFR/G810 (221038), QFH/G1 (210351), QFH/G1EH (210355), QFH/G1ELH (210353), RFR/G301 (196001), RFR/G301 (196022), RFR/G301 (2SF12B), RFR/G350 (171501), RFR/G350D (171506), RFR/G350F (171512), RFR/G700 (171502), RFR/G700D (171507), RFR/G700F (171513), RFR/G701 (196101), RFR/G701 (2SF14B), RFR/G701F (196122), ROFR/G1000 (774861), WFH/G1 (220351), WFH/G1EH (220355), WFH/G1ELH (220353), XFR/G350D (174506), XFR/G350F (174512), XFR/G700D (174507), XFR/G700F (174513), Z9FRGD1JFE (392081), Z9FRGD1JFO (392082), Z9FRGD1JFP (392083), ZFH/G430 (211038), ZFH/G435 (211050), ZFR/G410 (211001), ZFR/G410D (211003), ZFR/G411 (211018), ZFR/G412 (211022), ZFR/G810 (211002), ZFR/G810D (211004), ZHFRG421 (2KF02B)

ZANUSSI Kitchen E9GCGDTC00 (391240), E9GCGDTC0M (391241), E9GCGHTC00 (391242), E9GCGHTC0M (391243), E9GCGLTC00 (391251), E9GCGLTC0M (391252)

ZANUSSI Kitchen Gas 74FE07F (171090), 74FG07F (171089), 76FG10F (171091), M105GCK/E (174004), M105GCK/E (174085), M105GCK/G (174084), M70GCH/E (174083), M70GCK/G (174003), M70GCK/G (174082), MCF/G1050 (161003), MCF/G1050 (161091), MCF/G1050 (171026), MCF/G1050D (161021), MCF/G1052 (161084), MCF/G1055 (161001), MCF/G1055E (161005), MCF/G1055F (161009), MCF/G1090 (161059), MCF/G1095 (161071), MCF/G700 (161002), MCF/G700 (161007), MCF/G700 (161089), MCF/G700D (161006), MCF/G702 (161082), MCF/G705 (161000), MCF/G705E (161004), MCF/G705F (161008), MCF/G705NL (161010), MCF/GE700 (161090), MCF/GE702 (161083), MCFG1055NL (161023), MCFGE1050 (161092), MCFGE1052 (161085), RCF/G1052 (171081), RCF/G1020 (170203), RCF/G1020 (170223), RCF/G1020 (2SC17B), RCF/G1030 (2SC18B), RCF/G1050 (171006), RCF/G1050D (171014), RCF/G1052 (171084), RCF/G700 (171004), RCF/G700 (171025), RCF/G700D (171015), RCF/G702 (171082), RCF/G720 (170202), RCF/G720 (2SC15B), RCF/G720F (170222), RCF/G730 (2SC16B), RCF/GE1051 (171092), RCF/GE1052 (171085), RCF/GE702 (171083), RCFG1030 (170208), RCFG730 (170207), ROCA/G1000 (774801), ROCA/G500 (774800), ROCF/G1000 (774802), XCF/G1050D (174016), XCF/G1050F (174021), XCF/G700D (174015), XCF/G700F (174020), XCF/G705NL (174026), XCFG1055NL (174027)

ZANUSSI Pasta Cooker CR/40V (291165), CR42V (291162), CRN15VA (220394), CRN15VZ (210394), STEAM CRN15V (200394)

ZANUSSI Pasta Cooker Electric CR40E (291166), CR42E (291163), CRN15E (200395), CRN15EA (220395), CRN15EZ (210395)

ZANUSSI Pasta Cooker Gas 7CPG07P (173002), CR/40G (291164), CR42G (291161), CRN/20G (200387), CRN/22GZ (210384), CRN15G (200393), CRN15GA (220393), CRN15GZ (210393), CRN20GA (220387), CRN20GZ (210387), CRN22G (200384), CRN30G (200390), CRN30GA (220390), CRN30GZ (210390), DCP/G400 (224009), HCP/G400 (291514), HCP/G401 (291515), HCP/G800 (291504), HCP/G801 (291505), HCPA/G121 (2KQ20B), HCPA/G121 (2KQ21B), HCPA/G1219 (291107), KCP/G1 (200376), KCP/G1R (200377), KCP/G2 (200378), KCP/G2R (200379), M70GPC (176002), MCP/G700 (163402), QCP/G1 (210376), QCP/G1R (210377), QCP/G2 (210378), QCP/G2R (210379), RCP/G700 (195500), RCP/G700 (775200), WCP/G1 (220376), WCP/G1R (220377), WCP/G2 (220378), WCP/G2R (220379), ZHCP/G400 (774400), ZHCP/G401 (774405), ZHCP/G800 (774410), ZHCP/G801 (774415)

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ZANUSSI Pot Stove Gas 72FG03T (171086), 74FG07T (171087), 76FG10T (171088), JC/G1 (168600), JC/G2 (168601), JCV/G2 (168602), JCV/G3 (168603), MC/G1 (168800), MC/G1050 (161043), MC/G1050 (161088), MC/G1050D (161049), MC/G1052 (161081), MC/G1055 (161042), MC/G1055NL (161050), MC/G2 (168801), MC/G350 (161030), MC/G350 (161086), MC/G350D (161032), MC/G352 (161079), MC/G355 (161029), MC/G355E (161031), MC/G355F (161033), MC/G355NL (161034), MC/G700 (161037), MC/G700 (161087), MC/G700D (161039), MC/G702 (161080), MC/G705 (161036), MC/G705E (161038), MC/G705F (161051), MC/G705NL (161040), MCV/G2 (168802), MCV/G3 (168803), RC/G1 (168000), RC/G1050 (171033), RC/G2 (168001), RC/G350 (171000), RC/G350D (171016), RC/G350F (171023), RC/G352 (171079), RC/G700 (171002), RC/G700D (171017), RC/G700F (171024), RC/G702 (171080), RCV/G2 (168002), RCV/G3 (168003), ROC/G1000 (774901), ROC/G500 (774900), T105GCK (174081), T35GCK (174000), T35GCK (174079), T70GCK (174001), T70GCK (174080), XC/1050D (174014), XC/G1 (168400), XC/G1050 (174002), XC/G2 (168401), XC/G350D (174012), XC/G350F (174018), XC/G700D (174013), XC/G700F (174019), XCV/G2 (168402), XCV/G3 (168403)

ZANUSSI Solid Top MT/G700F (162509), MTF/G1055F (162512), MTF/G700F (162510), MTFGE1055F (162513), RANGE GAS MTF/GE1050 (162508), ROSD/G1000 (774808), ROSD/G1000 (774809), ROSF/G1000 (774811), ROSS/G1000 (774810), ROT/G1000 (774903), ROT/G500 (774902), ROTA/G1000 (774804), ROTA/G500 (774803), ROTF/E1000 (774813), ROTF/G1000 (774805), RT/G700F (172259), RTF/G1020 (177302), RTF/G1020 (2SS17B), RTF/G1020F (177322), RTF/G1030 (177307), RTF/G1030 (2SS18B), RTF/G1050 (172262), RTF/G700 (172260), RTF/G720 (2SS16B), RTF/G720F (177122), RTFG720 (177102)

ZANUSSI Washing Machine LB8G (400305), LB8G (400325), LB8G (6LB03B), LB8G/63 (400307), LB8GF (400308), LB8GPH (400311), LB8GPHM (400328)

