

magazin online *HORECA*

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Rezistenta CY 91200888 2500W 230V EGO 20.35437.000 #D355313

Fara TVA: 46,22 Lei

Pret cu TVA: 55,00Lei

Rezistenta CY 91200888 2500W 230V EGO 20.35437.000 #D355313

external ø190mm

flange 70x22mm

Compatibil cu:

ATEL

BAUMATIC

CANDY

HOOVER

IBERNA

NARDI

ROSIERES

WHIRLPOOL - INDESIT

EGO 2035437000

EPMS 723064

GEV LFD355313

GEV S5201434

BAUMATIC Electric oven 33701690 (BOFM604B), 33701692 (BOFM604W), 33701691 (BOFM604X), 33701689 (BOFT604X), 33701687 (BOMT608X)

CANDY Electric oven 36222156 (F254/3CN), 36222149 (F254/3CW), 36222131 (F254/3CX), 36222644 (F254CN), 36222636 (F254CW), 36222628 (F254CX), 36222602 (F254W), 36054666 (F330/1FRW), 36054633 (F330FRN), 36054658 (F330FRS), 36054625 (F330FRW), 36054609 (F330N), 36054617 (F330S), 36054005 (F330W), 33900071 (FCO827XL), 33900080 (FCO827XL), 33701631 (FCXE825VX), 33701558 (FET929NXLJV), 33701557 (FET929WXLJV), 33701556 (FET929XLJV), 33700618 (FHP827X), 33700852 (FHP829X), 33700625 (FHP927X), 33700363 (FHP975X), 33700468 (FHP975X), 33700042 (FL503X), 36047009 (FLK330N), 33700265 (FNP602XUK), 33700263 (FNP622X), 33700274 (FNP815X), 33700272 (FNP815XUK), 33700271 (FNP825X), 33700270 (FNP827AL), 33700269 (FNP827X), 33900014 (FNPC825X), 33700456 (FOFNP602XUK), 33700459 (FOFNP815X), 33700470 (FOFNP815XUK), 33700457 (FOFNP825X), 33700460 (FOFNP827X), 33700060 (FOFP602XUK), 33700092 (FOFP622N), 33700093 (FOFP622X), 33700004 (FOFP815AL), 33700094 (FOFP815N), 33700095 (FOFP815WUK), 33700002 (FOFP815X), 33700097 (FOFP815XUK), 33700005 (FOFP825AL), 33700007 (FOFP825X), 33700001 (FOFP827AL), 33700003 (FOFP827X), 36296101 (FOFP827X), 33700098 (FOFP835CX), 33700022 (FP815NUK), 33700023 (FP815XUK), 36291136 (FP835CAL), 36291151 (FP835CN),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

33701201 (FPE403-6N), 33701211 (FPE403-6W), 33701210 (FPE403-6X), 33701236 (FPE409-6N), 33701235 (FPE409-6W), 33701234 (FPE409-6X), 33701265 (FPE829-6XL), 33700890 (FPP403-1N), 33700896 (FPP403-1W), 33700893 (FPP403-1X), 33701042 (FPP403-1XL), 33700638 (FPP403N), 33700639 (FPP403W), 33700637 (FPP403X), 33700874 (FPP406-1X), 33701053 (FPP406-2X), 33701074 (FPP406-3X), 33700768 (FPP406X), 33700900 (FPP407-1N), 33700841 (FPP407-1W), 33700894 (FPP407-1X), 33700641 (FPP407N), 33700642 (FPP407W), 33700640 (FPP407X), 33701041 (FPP407XL), 33700842 (FPP409W), 33700845 (FPP409X), 33700636 (FPP827X), 33700964 (FPP8291X), 33700840 (FPP829X), 33700892 (FPP829XL), 33700856 (FVH703-1X), 33700727 (FVH927X), 33700858 (FVH929X), 33700859 (FVH929XL), 33700728 (FVP927X), 33700860 (FVP929X), 33700864 (FVP929XL), 33701274 (FXE829VX), 33700978 (FXH825VX), 33700979 (FXP825VX), 33701097 (FXP829X), 33700020 (R43-3GHCRUK), 36282150 (R43-3XUK)

CANDY Kitchen39657507 (FLGK1331TB)

HOOVER Electric oven 33700118 (FOHFO415B), 33700119 (FOHFO415W), 33700116 (FOHMO837X), 33701228 (HCGF304-6 WPP), 33701043 (HCGF304WPP), 33700498 (HFO 0415-1X), 33700304 (HFO 415-1 B), 33700302 (HFO 415-1 X), 33700501 (HFO 415-1B), 33700500 (HFO 415-1W), 33700499 (HFO 415-1X), 33700548 (HMO 837X), 33701039 (HO 423 VW), 33701037 (HO 423 VX), 33701215 (HO 423-6VW), 33701214 (HO423-6VB), 33701213 (HO423-6VX), 33701681 (HO786VX WIFI), 33701710 (HO929-6VX), 33701175 (HOA 2 VX), 33700934 (HOA03VB), 33700935 (HOA03VW), 33700932 (HOA03VX), 33701511 (HOA03VX WIFI), 33701706 (HOA20VX), 33700930 (HOL03LVX), 33700931 (HOL03RVX), 33700781 (HOP 2043 B), 33700782 (HOP 2043 W), 33700780 (HOP 2043 X), 33700789 (HOP 4074 X), 33700788 (HOP 4075 VX), 33700250 (HOP 455 X), 33700509 (HOP 455X), 33700793 (HOS 4075 VX), 33700251 (HOS 456 X), 33700496 (HOS 456X), 33700252 (HOS 556 X), 33700497 (HOS 556X), 33700794 (HOS4075VXDISPLAY)

IBERNA Electric oven 33701699 (IBOF600X), 33701700 (IBOF605X)

ROSIERES Electric oven 33700516 (FC3163-1IN), 33700121 (FOFC3163IN), 36279016 (FOFR2040-3IN), 36279008 (FOFR2040IN), 33701429 (RFA2VIN), 33701463 (RFA2VIN RC), 33701534 (RFN5282IN)

