

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Selector 5 pozitii EGO 46.25866.521 SWITCH CANDY 41003026 #2104026

Fara TVA: 42,02 Lei

Pret cu TVA: 50,00Lei

Selector 5 pozitii EGO 46.25866.521 SWITCH CANDY 41003026 #2104026

Tensiune: 250V

Capacitate de comutare: 16A

Lungime arbore: 23mm.

Pozitii de operare: 5

Utilizare: cuptor

Nr. producator: 41003026

Arbore: Ø6x4,6mm.

Poli: 2

Conexiuni: tip terminal

Capacitate de contact (faza): 10A-380V 14A-240V 16A-250V

Compatibil cu:

CANDY

GASFIRE

HOOVER

IBERNA

ZEROWATT

EGO 4625866521

EPMS 41003026

EPMS 42814656

GOTTAK 8505151

Potrivit pentru:

CANDY Electric oven 31007052 (CLT273L-47), 33701530 (CMFS4N), 33701529 (CMFS4X), 34295014 (COZSV025), 33900078 (FCO105-1X), 33900085 (FCO105-6X), 33900068 (FCO105N), 33900067 (FCO105W), 33900070 (FCO105X), 33701492 (FET649AX), 33701201 (FPE403-6N), 33701211 (FPE403-6W), 33701210 (FPE403-6X), 33701236 (FPE409-6N), 33701235 (FPE409-6W), 33701234 (FPE409-6X), 33700890 (FPP403-1N), 33700896 (FPP403-1W), 33700893 (FPP403-1X), 33701042 (FPP403-1XL), 33700874 (FPP406-1X), 33701053 (FPP406-2X), 33701074 (FPP406-3X), 33700900 (FPP407-1N), 33700841 (FPP407-1W), 33700894 (FPP407-1X), 33701041 (FPP407XL), 33700842 (FPP409W), 33700845 (FPP409X), 33700831 (FST100-1N), 33700830

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(FST100-1W), 33700829 (FST100-1X), 33701282 (FST100-6N), 33701283 (FST100-6W), 33701180 (FST100-6X),  
33700610 (FST100N), 33700611 (FST100W), 33700609 (FST100X), 33700832 (FST201-1N), 33700833  
(FST201-1W), 33700834 (FST201-1X), 33701284 (FST201-6N), 33701198 (FST201-6X)

GASFIRE Electric oven 33701300 (GF 6100 N), 33701302 (GF 6100NX), 33700811 (GS100N), 33700922  
(GS100NX)

HOOVER Electric oven 33701228 (HCGF304-6 WPP), 33701043 (HCGF304WPP), 33701039 (HO 423 VW),  
33701037 (HO 423 VX), 33701215 (HO 423-6VW), 33701555 (HO100B), 33701554 (HO100W), 33701440  
(HO100X), 33701214 (HO423-6VB), 33701213 (HO423-6VX)

IBERNA Electric oven 36238111 (FI 010-3 N), 36238103 (FI 010-3 W), 33701699 (IBOF600X), 33701700  
(IBOF605X)

ZEROWATT Electric oven 33701738 (ZEF0012-6), 33701741 (ZEF6100N), 33701740 (ZEF6100NX)

