

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Incuietoare magnetica ø 32mm #5009179

Fara TVA: 31,09 Lei

Pret cu TVA: 37,00Lei

Incuietoare magnetica ø 32mm #5009179

Filet: M5x15mm.

Compatibil cu:

ALPENINOX

APACH

ELECTROLUX PROFESSIONAL

ZANUSSI

Potrivit pentru:

APACH Bratt pan APME-47P

APACH Fryer electric APFE-47P, APFE-77P

APACH Fryer gas APFG-47-2P, APFG-47P, APFG-77P

ZANUSSI Fryer A7FRGD1GFK (373229), A7FRGH2GFK (373230), E9FRMD1HF5 (391190), E9FRMD1HF6 (391191), E9FRGD1J4E (391287), E9FRGD1J4O (391288), E9FRGD1J4P (391289)

ZANUSSI Fryer electric PF/E1S07 (178118), PF/E2D07 (178119), PFR/E1S07 (178120), PFR/E2D07 (178121), PFR/E1S12 (178124), PFR/E2D12 (178125), PFR/E1S14 (178126), PFR/E2D14 (178127), PF/E1S07E5 (178131), PFRE2D07E5 (178132), PFRE2D12E5 (178133), OF/E1S07 (178418), OFR/E1S07 (178420), OFR/E2D07 (178421), OFR/E1S12 (178424), OFR/E2D12 (178425), TF/E1S07 (178718), TF/E2D07 (178719), TFR/E1S07 (178720), TFR/E2D07 (178721), TFR/E1S12 (178724), TFR/E2D12 (178725), TFR/E1S14 (178726), TFR/E2D14 (178727), TF/E1S07E5 (178731), TFRE2D07E5 (178732), TFRE2D12E5 (178733), TFRE1S12M0 (178827), TFRE2D12M0 (178828), TFRE1S12M4 (178840), TFRE2D12M4 (178841), KFR/E1E (200342), KFR/E2F (200343), KFH/E1 (200352), KFH/E1ELH (200354), KFH/E1EH (200356), QFR/E1E (210342), QFR/E2F (210343), QFR/E1C (210344), QFR/E2D (210345), QFH/E1 (210352), QFH/E1ELH (210354), QFH/E1H (210356), WFR/E1E (220342), WFR/E2F (220343), WFR/E1C (220344), WFR/E2D (220345), WFH/E1 (220352), WFH/E1ELH (220354), WFH/E1EH (220356), EXFRPB1BFF (285557), EXFRPB1BFQ (285558), EXFREB1BFF (285559), EXFREB1BFQ (285560), E7FRED1B00 (371075), E7FREH2B00 (371076), E7FRED1BF0 (371077), E7FREH2BF0 (371078), E7FRED1GF0 (371081), E7FREH2GF0 (371082), E7FRED1FF0 (371084), E7FREH2FF0 (371085), E7FRED120N (371140), E7FREH22FN (371141), E7FREH2FFN (371144), E7FRMD1FF5 (371162), E7FRMD1FF6 (371163), E7FRMH2FF5 (371164), E7FRMH2FF6 (371165), Z7FRED1B00 (372075), Z7FREH2B00 (372076), Z7FRED1BF0 (372077), Z7FREH2BF0 (372078), Z7FRED1GF0 (372081), Z7FREH2GF0 (372082), Z7FRED1FF0 (372084), Z7FREH2FF0 (372085), Z7FREH22FN (372141), Z7FREH2FFN (372144), A7FRED1B00 (373075), A7FREH2B00 (373076), A7FRED1GF0 (373081), A7FREH2GF0 (373082), A7FRED1FF0 (373084), A7FREH2FF0 (373085), A7FRED120N (373140), A7FREH22FN (373141), A7FREH2FFN (373144), E9FRED1GF0 (391087), E9FREH2GF0

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(391088), E9FRED1JF0 (391089), E9FREH2JF0 (391090), E9FRED1JFE (391091), E9FRED1JFO (391092), E9FRED1JFP (391093), E9FRED1HF0 (391094), E9FREH2HF0 (391095), E9FRED1HFN (391178), E9FREH2HFN (391179), Z9FRED1GF0 (392087), Z9FREH2GF0 (392088), Z9FRED1JF0 (392089), Z9FREH2JF0 (392090), Z9FRED1JFE (392091), Z9FRED1JFO (392092), Z9FRED1JFP (392093), Z9FRED1HF0 (392094), Z9FREH2HF0 (392095), Z9FRED1HFN (392178), Z9FREH2HFN (392179), A9FRED1GF0 (393087), A9FREH2GF0 (393088), A9FRED1JF0 (393089), A9FREH2JF0 (393090), A9FRED1JFE (393091), A9FRED1JFO (393092), A9FRED1JFP (393093), A9FRED1HF0 (393094), A9FREH2HF0 (393095)

ZANUSSI Fryer gas PF/G1S07 (178110), PF/G2D07 (178111), PFR/G1S07 (178112), PFR/G2D07 (178113), PFR/G1S14 (178114), PFR/G2D14 (178115), PFR/G2S40 (178116), PFRG2D14HV (178191), PFRG1S14HV (178198), OF/G1S07 (178410), OFR/G1S07 (178412), OFR/G2D07 (178413), OFR/G1S14 (178414), OFR/G2D14 (178415), TF/G1S07 (178710), TF/G2D07 (178711), TFR/G1S07 (178712), TFR/G2D07 (178713), TFR/G1S14 (178714), TFR/G2D14 (178715), TFR/G2S40 (178716), KFR/G1A (200336), KFR/G2B (200337), KFH/G1 (200351), KFH/G1ELH (200353), KFH/G1EH (200355), KFR/G1T (200361), QFR/G1E (210340), QFR/G2F (210341), QFH/G1 (210351), QFH/G1ELH (210353), QFH/G1EH (210355), QFR/G1T (210361), WFR/G1A (220336), WFR/G2B (220337), WFH/G1 (220351), WFH/G1ELH (220353), WFH/G1EH (220355), WFR/G1T (220361), E7FRGD1B00 (371066), E7FRGH2B00 (371067), E7FRGD1BF0 (371068), E7FRGH2BF0 (371069), E7FRGD1GF0 (371070), E7FRGH2GF0 (371071), E7FRGH1LFT (371072), Z7FRGD1B00 (372066), Z7FRGH2B00 (372067), Z7FRGD1BF0 (372068), Z7FRGH2BF0 (372069), Z7FRGD1GF0 (372070), Z7FRGH2GF0 (372071), Z7FRGH1LFT (372072), Z7FRGH2GFH (372159), A7FRGD1B00 (373066), A7FRGH2B00 (373067), A7FRGD1GF0 (373070), A7FRGH2GF0 (373071), E9FRGD1GF0 (391077), E9FRGH2GF0 (391078), E9FRGD1JF0 (391079), E9FRGH2JF0 (391080), E9FRGD1JFE (391081), E9FRGD1JFO (391082), E9FRGD1JFP (391083), E9FRGD1JFT (391084), Z9FRGD1GF0 (392077), Z9FRGH2GF0 (392078), Z9FRGD1JF0 (392079), Z9FRGH2JF0 (392080), Z9FRGD1JFE (392081), Z9FRGD1JFO (392082), Z9FRGD1JFP (392083), Z9FRGD1JFT (392084), A9FRGD1GF0 (393077), A9FRGH2GF0 (393078), A9FRGD1JF0 (393079), A9FRGH2JF0 (393080), A9FRGD1JFE (393081), A9FRGD1JFO (393082), A9FRGD1JFP (393083), A9FRGD1JFT (393084), A9FRGD1JFK (393210), A9FRGH2JFK (393211)

ZANUSSI Kitchen O7GCGH4CG0 (373219), A7ECED2R0K (373223), E9GCGHTCGA (391259), E9GCGHTCGB (391260), E9GCGHTCEA (391261), E9GCGLTC1A (391262), E9GCGLTC1B (391263), E9GCGP8CGA (391272), Z9GCGHTCGA (392259), Z9GCGHTCGB (392260), Z9GCGHTCEA (392261), Z9GCGLTC1A (392262), Z9GCGLTC1B (392263), Z9GCGP8SGA (392272)

ZANUSSI Kitchen electric TCF/E3QM0 (178821), TCV/E3QM0 (178822), TCF/E3QM4 (178834), TCV/E3QM4 (178835), E7ECED2R00 (371014), E7ECEH4R00 (371015), E7ECEH4RE0 (371016), E7ECEH4Q00 (371017), E7ECEH4QE0 (371018), E7ECEL6R00 (371019), E7ECED2R0N (371126), E7ECEH4R0N (371127), E7ECEH4REN (371128), E7ECEH4QEN (371129), E7ECEH4Q0N (371130), E7ECMD2R05 (371146), E7ECMD2R06 (371147), E7ECMH4RE5 (371148), E7ECMH4RE6 (371149), E7ECMH4QE5 (371150), E7ECMH4QE6 (371151), E7ECML6Q25 (371152), E7ECML6Q26 (371153), E7GCGH4CGA (371168), E7GCGH4CEA (371169), E7GCGL6C1A (371171), E7GCGL6C2A (371172), Z7ECED2R00 (372014), Z7ECEH4R00 (372015), Z7ECEH4RE0 (372016), Z7ECEH4Q00 (372017), Z7ECEH4QE0 (372018), Z7ECEL6R00 (372019), Z7ECED2R0N (372126), Z7ECEH4R0N (372127), Z7ECEH4REN (372128), Z7ECEH4QEN (372129), Z7ECEH4Q0N (372130), A7ECED2R00

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(373014), A7ECEH4R00 (373015), A7ECEH4RE0 (373016), A7ECEH4Q00 (373017), A7ECEH4QE0 (373018), A7ECEL6R00 (373019), A7ECED2R0N (373126), A7ECEH4R0N (373127), A7ECEH4REN (373128), A7ECEH4QEN (373129), A7ECEH4Q0N (373130)

ZANUSSI Kitchen gas PCV/G2 (178002), PCV/G3 (178003), PCF/G2 (178004), PCF/G3 (178005), PCF/M2 (178007), PCF/M3 (178008), PCF/M2E5 (178038), PCV/G2HV (178190), PCF/G3HV (178192), PCV/G3HV (178194), PCF/G2HV (178195), PCV/G2A (178207), PCV/G3A (178208), PCF/G2A (178209), PCF/G3A (178210), PCF/M2A (178211), PCF/M3A (178212), OCV/G2 (178302), OCF/G2 (178304), OCF/G3 (178305), TCV/G2 (178602), TCV/G3 (178603), TCF/G2 (178604), TCF/G3 (178605), TCF/M2 (178607), TCF/M3 (178608), TCF/M2E5 (178638), TCV/G2A (178807), TCV/G3A (178808), TCF/G2A (178809), TCF/G3A (178810), TCF/M2A (178811), TCF/M3A (178812), KCF/G2 (200102), KCF/G3 (200104), KCF/G4 (200105), KCF/T2 (200116), KCF/T3 (200117), KCF/T4 (200118), KCF/G2H (200121), KCF/G3H (200145), KCF/G2L (200148), KCF/G2G (200152), KCF/G3G (200154), KCF/G4G (200155), KCF/G2HG (200157), KCF/G3HG (200162), KCF/G2LG (200164), QCF/G2 (210102), QCF/G3 (210104), QCF/G4 (210105), QCF/T2 (210116), QCF/T3 (210117), QCF/T4 (210118), QCF/G2H (210121), WCF/G2 (220102), WCF/G3 (220104), WCF/G4 (220105), WCF/G2H (220121), E7GCGH4CG0 (371002), E7GCGH4CE0 (371003), E7GCGL6C10 (371005), E7GCGL6C20 (371006), E7GCGH4CEN (371125), Z7GCGH4CG0 (372002), Z7GCGH4CE0 (372003), Z7GCGL6C10 (372005), Z7GCGL6C20 (372006), Z7GCGH4CEN (372125), Z7GCGH4CGA (372148), Z7GCGH4CEA (372149), Z7GCGL6C1A (372151), Z7GCGL6C2A (372152), Z7GCGH4CGH (372155), Z7GCGL6C1H (372157), A7GCGH4CG0 (373002), A7GCGH4CE0 (373003), A7GCGL6C10 (373005), A7GCGH4CEN (373125), E9GCGH4CGL (391004), E9GCGH4CG0 (391005), E9GCGH4CGM (391006), E9GCGH4CE0 (391010), E9GCGL6C10 (391013), E9GCGL6C1M (391014), E9GCGL6C10 (391015), E9GCGL6CLM (391016), E9GCGP8CG0 (391017), E9GCGH4CEN (391164), E9GCTH4CEM (391195), Z9GCGH4SGL (392004), Z9GCGH4SG0 (392005), Z9GCGH4SGM (392006), Z9GCGH4SE0 (392010), Z9GCGL6S10 (392013), Z9GCGL6S1M (392014), Z9GCGL6SL0 (392015), Z9GCGP8SG0 (392017), Z9GCGH4CGL (392029), Z9GCGH4CG0 (392030), Z9GCGH4CGM (392031), Z9GCGH4CE0 (392032), Z9GCGL6C10 (392035), Z9GCGL6C1M (392036), Z9GCGL6C10 (392037), Z9GCGP8CG0 (392038), Z9GCGH4CEN (392164), Z9GCTH4YEM (392195), A9GCGH4CG0 (393005), A9GCGH4CGM (393006), A9GCGH4CE0 (393010), A9GCGL6C10 (393013), A9GCGP8CG0 (393017)

ZANUSSI Neutral counter E7BAND0000 (371112), E7BANH0000 (371113), E7BANL0000 (371114), E7BAMD0000 (371263), E7BAMH0000 (371264), E7BAML0000 (371265), E9BAND0000 (391153), E9BANH0000 (391154), E9BANL0000 (391155), E9BAMD0000 (391326), E9BAMH0000 (391327), E9BAML0000 (391328)

ZANUSSI Pasta cooker ACPG25 (169024), ACPG25 (169123), PCP/G1S (178143), PCP/G2D (178144), PCP/E1S (178145), PCP/E2D (178146), PCP/E2SH (178147), PCP/E1SH (178148), PCP/E2SH (178149), PCP/E2SH3B (178153), OCP/G1S (178443), OCP/G2D (178444), OCP/E1S (178445), OCP/E2D (178446), OCP/E2S (178447), OCP/E1SH (178448), OCP/E2SH (178449), TCP/G1S (178743), TCP/G2D (178744), TCP/E1S (178745), TCP/E2D (178746), TCP/E2S (178747), TCP/E2SH (178749), NULL (200372), NULL (200373), KCP/E1RU (200374), KCP/E2RU (200375), KCP/G1 (200376), KCP/G1R (200377), KCP/G2 (200378), KCP/G2R (200379), KCP/E1 (200380), KCP/E1R (200381), KCP/E2 (200382), KCP/E2R (200383), NULL (200396), NULL (200397), KCP/E1U

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(200398), KCP/E2U (200399), QCP/G1 (210376), QCP/G1R (210377), QCP/G2 (210378), QCP/G2R (210379), QCP/E1 (210380), QCP/E1R (210381), QCP/E2 (210382), QCP/E2R (210383), WCP/G1 (220376), WCP/G1R (220377), WCP/G2 (220378), WCP/G2R (220379), WCP/E1 (220380), WCP/E1R (220381), WCP/E2 (220382), WCP/E2R (220383), DCP/G400 (224009), E7PCGD1KF0 (371090), E7PCGH2KF0 (371091), E7PCED1KF0 (371098), E7PCEH2KF0 (371099), Z7PCGD1KF0 (372090), Z7PCGH2KF0 (372091), Z7PCED1KF0 (372098), Z7PCEH2KF0 (372099), A7PCGD1KF0 (373090), A7PCGH2KF0 (373091), A7PCED1KF0 (373098), A7PCEH2KF0 (373099), E9PCGD1MF0 (391111), E9PCGH2MF0 (391112), E9PCED1MF0 (391126), E9PCEH2MF0 (391127), E9PCGD1MF2 (391201), E9PCGH2MF2 (391202), E9PCED1MF2 (391203), E9PCEH2MF2 (391204), Z9PCGD1MF0 (392111), Z9PCGH2MF0 (392112), Z9PCED1MF0 (392126), Z9PCEH2MF0 (392127), A9PCGD1MF0 (393111), A9PCGH2MF0 (393112), A9PCED1MF0 (393126), A9PCEH2MF0 (393127), A9PCGD1MFK (393212), A9PCGH2MFK (393213)

ZANUSSI Pot stove gas QCF/G3H (210145), QCF/G2L (210148), E9STGH10GA (391264), E9STGLT01A (391265), Z9GCGL6SLM (392016), Z9STGLT01A (392265)

ZANUSSI Solid top range PTV/G2 (178081), PTF/G2 (178082), PSF/G2 (178083), PSV/G2 (178084), PSF/G3 (178085), PTV/G2N (178201), TTV/G2 (178681), TTF/G2 (178682), TSF/G2 (178683), TSV/G2 (178684), TSF/G3 (178685), KS/G2 (200230), KSF/G2 (200231), KSCF/G3 (200232), QS/G2 (210230), QSF/G2 (210231), QSCF/G3 (210232), WS/G2 (220230), WSF/G2 (220231), WSCF/G3 (220232), E7STGH1000 (371007), E7STGH10G0 (371008), E7STGH30G0 (371009), E7STGL3010 (371010), E7STGH3000 (371011), E7STGL5000 (371012), E7STGH10GA (371217), E7STGL301A (371218), Z7STGH1000 (372007), Z7STGH10G0 (372008), Z7STGH30G0 (372009), Z7STGL3010 (372010), Z7STGH3000 (372011), Z7STGL5000 (372012), Z7STGH100H (372160), A7STGH1000 (373007), A7STGH10G0 (373008), A7STGH30G0 (373009), A7STGL3010 (373010), A7STGH3000 (373011), E9STGH1000 (391018), E9STGH10G0 (391019), E9STGH30G0 (391020), E9STGL3010 (391021), E9STGL3C30 (391215), Z9STGH1000 (392018), Z9STGH10G0 (392019), Z9STGH30G0 (392020), Z9STGL3010 (392021), Z9STGL3C30 (392215), Z9STGH10GA (392264), A9STGH1000 (393018), A9STGH10G0 (393019), A9STGL3010 (393021)

