



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Regulator energie 230V 13A EGGO 50.57021.010 #PT00000856

Fara TVA: 84,03 Lei

Pret cu TVA: 101,68Lei

Regulator energie 230V 13A EGGO 50.57021.010 #PT00000856

Capacitate de contact: 230V 13A

Temperatura maxima de lucru: 125°C

Ax in forma de D: ø6x4.6mm.

2 directii de rotatie

Eliberare de putere 6-100 %

Compatibil cu:

GEV 380015

GEV 381642

LF 3350026

ALPENINOX

AMATIS

AMBACH

ANGELO PO

ARISTON

ARRIS CATERING EQUIPMENT

ASCOBLOC

BARTSCHER

BAUKNECHT

BEKO

BERNER

BERTO'S

BOMPANI

BONNET

BRANDT

CANDY

CB S.R.L.

CF CENEDESE

CHARVET

COMETTO

COOKMAX



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

COVEN
DE DIETRICH
DESCO
DIHR
DOSILET
EBERHARDT
EFFICOLD
ELECTROLUX
ELECTROLUX PROFESSIONAL
EMMEPI
ERRE 2
EURAST
FAGOR
FIAMMA
FIMAR
GICO
GIERRE
GIGA
GIORIK
HAKA
HOTPOINT
ICOS
IKEA
ILVE
INOXTREND
KELVIN
KING
KREFFT
KROMO
KÜPPERSBUSCH
LOHBERGER
LOTUS
METOS
MODULAR
MODULINE
NAYATI
PALUX
RIEBER
RINALDI SUPERFORNI



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ROKA
ROSINOX
SAMMIC
SIRMAN
SMEG
SOFRACA
SOLYMAC
STAR 10
TECNOGAS
TECNOINOX
TELLIER
THERMOR
THIRODE
UBERT
UNIVERSAL
VEDETTE
VOSS
WHIRLPOOL - INDESIT
ZANOLLI
ZANUSSI
EGO 50.17011.000
EGO 50.17021.000
EGO 50.37011.000
EGO 50.37021.000
EGO 50.57011.000
EGO 50.57021.010
EPMS 1150011
EPMS 163900005
EPMS 3150788234
EPMS 481227328267
EPMS 481927328279
EPMS 705005
EPMS 705010
EPMS 705013

Potrivit pentru:

ANGELO PO Boiling pan electric 291PI3E, 2A1PI3E

ANGELO PO Bratt pan 06WBR3E, 0G1BR3E, 191BR1E, 191BR2E, 191BR2EA, 1A1BR1E, 1A1BR2E, 1A1BR2EA,
1D1BR1E, 1D1BR2E, 1D1BR2EA, 1G1BR3E, 1N1BR2E, 1N1BR2EA, 1N1BR3E, 1N1BR3EA, 1N1BR3EF, 291BR1E,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

291BR2E, 291BR2EA, 2A1BR1E, 2A1BR2E, 2A1BR2EA, 2D1BR1E, 2D1BR2E, 2D1BR2EA, 2N1BR2E, 2N1BR2EA, 2N1BR3E, 2N1BR3EA

ANGELO PO Convection oven FC1011E, FC1011G, FC1221E, FC1221G, FC611E, FC611G

ANGELO PO Fry top 0G0PEVTR

ANGELO PO Grill 08WGREV, 0N0GRE, 190GRE, 1G0GRE, 1N0GRE, 2N0GRE

ANGELO PO Pot stove glass-ceramics 1G0PEVTR

ANGELO PO Potato heater 090SPE, 0G0SPE, 0N0SPE

ARISTON Convection oven FC97P.1-E AN (T), FC97P.1-E IX (T), FC98P.1 IX, FD77P IX, FD960P.2-E BK (T), FD960P.2-E WH (T), 28368 (FD97P CH), 28370 (FD97P GC), 28369 (FD97P SL), 28352 (FD98P.1 ICE), 28353 (FD98P.1 MR), FO97P.1-E AN (T), FO97P.1-E IX (T), FO97P.1-E WH (T), FO98P.1 IX, FO98P.1 IX DIGITAL, H10.1IX, H101.1IX, H60.1(ALU), H60.1IX, H60VP.1IX, H60VP.1IX-Y, H61.1(BK), H61.1(WH), H61.1IX, H622.1IX, H62C.1IX, H66.1IX, H66V.1IX, H87V.1(ALU), H87V.1IX, H87VP.1(ALU), H87VP.1IX, H89V.1IX, H89VP.1IX, 26976 (HB20AC(WH)), 26977 (HB22AC(IX)), 26978 (HB22AC(WH)), 29829 (HB22AC.1(WH)), 29123 (HB22AC.1IX), 26507 (HB50ER(ALU)), 26506 (HB50ER(IX)), 29126 (HB50ER.2(ALU)), 29127 (HB50ER.2IX), 26987 (HB52AC(BK)), 26986 (HB52AC(WH)), 29121 (HB52AC.1(BK)), 29122 (HB52AC.1(WH)), 26985 (HB52C(IX)), 29120 (HB52C.2IX), 26996 (HB56C(BK)), 26994 (HB56C(IX)), 26995 (HB56C(WH)), 29119 (HB56C.2IX), 29118 (HB86C.2IX), 27438 (HB86CIX), 22224 (HD50(BK)), 24020 (HD50(ICE)), 22225 (HD50(MR)), 24021 (HD50IX), 28394 (HD870C(ICE)), 28395 (HD870C(MR)), 28396 (HD870C(SL)), 29104 (HD870C.2(ICE)), 29105 (HD870C.2(MR)), 29106 (HD870C.2(SL)), 18194 (HD87C(BK)), 22226 (HD87C(MR)), 18191 (HD87C(WH)), 18194 (HD87C(WH)), 13552 (HM27M), 13553 (HM27M), 05479 (HM27V), 05480 (HM27V), 05481 (HM27V), 06267 (HM37V), 06268 (HM37V), 22222 (HM55R(BK)), 22221 (HM55R(WH)), 22223 (HM55RIX), 16567 (HM87V), 16568 (HM87V), 16569 (HM87V), 26509 (HO10(ALU)), 26510 (HO10(BM)), 26508 (HO10(IX)), 29115 (HO10.2IX), 26512 (HO50(ALU)), 26513 (HO50(BM)), 26511 (HO50(IX)), 29111 (HO50.2(ALU)), 29112 (HO50.2(BM)), 29113 (HO50.2IX), HO50.2TIX, 26997 (HO87EC(IX)), HO87EC.2-EIX, HO87EC.2IX, 26515 (HO87EF(ALU)), 26516 (HO87EF(BM)), 26514 (HO87EF(IX)), 29108 (HO87EF.1(ALU)), 29109 (HO87EF.1(BM)), HO87EF.1-E(ALU), HO87EF.1-E(BM), HO87EF.1-EIX, HO87EF.1IX, HO87EF.2-ETDIX, HO97P.1-E IX (T), HO97P.1-EIX, HR10.1IX, HR50.2IX, HR50.2TIX, HR86T.1IX, HR87.1IX, HR87.1TIX, HR87P.1IX

ARISTON Kitchen electric 06995 (C504VE3)

ARISTON Kitchen gas A6V530WEX, A6V530XEX, CE6VP6(W)EU, CP65S F8, 04858 (G1MCGR), 14689 (G1MCR), 05466 (G2VCGR), 13710 (G650MC)

ARISTON Kitchen glass-ceramics C3V7M(B)R, C3V7M(X)R, C3V7M.3(W)R, C3V7MW-R, C3V8P(W)U, C3V8P(X)U, C3V8P.2(W)U, C3V8P.2(X)U, 27642 (C3V9EWF), 26051 (C3V9P(W)U), C3V9P.2(W)U, 26053 (C3V9PWR), C3VM5(W)R, C3VM5(X)R, C3VM6(W)F, C3VM6(X)F, C3VP6(W)R, C3VP6(X)R, 21694 (C6V9P(W)F), 22095 (C6V9P(W)R), C6V9P(W)U, C6V9P.3(W)U, C6V9P.5(W)R, 22096 (C6V9PAR), C6V9PW-SK230, C6V9PW-SK400, C6V9PX-SK230, C6V9PX-SK400, C6VF7(X)R, C6VF8(X)R, C6VF8XU, C6VP1(W)SK230, C6VP1(X)SK230, C6VP4(W)R, C6VP4(X)R, CE6VP4(X)R, CE6VP5(W)GR, CE6VP5(X)GR, CP0V9M(X)AUS, CP0V9M(X)DE, CP0V9MXDES, VL04S.1&2, 24491 (XC95MK(AN)), 24490 (XC95MK(IX))

ARISTON Pot stove gas 29500 (PH723RQOGH), PH723RQOGHAUS, 15638 (PH941MSTB), 15639 (PH941MSTB), 24917 (PH941MSTB(GH)), PH941MSTB(IX), 21661 (PH941MSTB(IX)NG), PH941MSTBGH, 18676

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(PH941MSTBUIX), 27732 (XP90K)

ARISTON Pot stove glass-ceramics A2032-2, A2033-2, KBM6002DHCL, KBM6004 IX, KBM6004CL, KBM6011DH IX, KBM6014D IX, KBT6003I BI, KBT6003I IX, KBT6004I BI, KBT6004I IX, KBT6011DH IX, KBT6013T BI, KBT6013T IX, KBT6013T-C IX, KBT6114ID-C IX, KBT6412I-C IX, KBT8134DO IX, 17962 (KM600), 17963 (KM600), 17964 (KM600), 17965 (KM600), 17970 (KM6000Q), 17971 (KM6000Q), 17972 (KM6000Q), 17973 (KM6000Q), 17974 (KM6001H), 17975 (KM6001H), 17976 (KM6001H), 17977 (KM6001H), 17978 (KM6002H), 17979 (KM6002H), 17980 (KM6002H), 17981 (KM6002H), 22249 (KM6002HGB), 22250 (KM6002HGB), 22251 (KM6002HGB), 22252 (KM6002HGB), KOT7424IO BI, 18209 (KP600Q), 18210 (KP600Q), 18211 (KP601H), 18212 (KP601H), NRM640X, 05672 (VL04S), 05673 (VL04S), 06348 (VL04S), 09856 (VL04S), 09857 (VL04S), 11564 (VL04S.1), 11565 (VL04S.1), 11566 (VL04S.1), 11591 (VL04S.1), 17771 (VL04S.1), 17772 (VL04S.1), 11564 (VL04S.2), 11565 (VL04S.2), 11566 (VL04S.2), 11591 (VL04S.2), 17771 (VL04S.2), 17772 (VL04S.2), 05884 (VL13S), 05885 (VL13S), 09858 (VL13S), 11567 (VL13S.1), 11568 (VL13S.1), 11569 (VL13S.1), 17234 (VL13S.1), 17235 (VL13S.1), 17236 (VL13S.1), 11567 (VL13S.H), 11568 (VL13S.H), 11569 (VL13S.H), 17234 (VL13S.H), 17235 (VL13S.H), 17236 (VL13S.H), 05674 (VL22S), 05675 (VL22S), 06565 (VL22S), 11570 (VL22S.1), 11571 (VL22S.1), 11572 (VL22S.1), 11592 (VL22S.1), 17237 (VL22S.1), 17238 (VL22S.1), 17239 (VL22S.1), 17240 (VL22S.1), 11570 (VL22S.H), 11571 (VL22S.H), 11572 (VL22S.H), 11592 (VL22S.H), 17237 (VL22S.H), 17238 (VL22S.H), 17239 (VL22S.H), 17240 (VL22S.H), 12597 (VP04), 12598 (VP04), 12599 (VP04), VP04.1-04.2, 12600 (VP042), 12601 (VP042), 12602 (VP042), 14645 (VP042.1), 14646 (VP042.1), 14647 (VP042.1), 12543 (VP13), 12544 (VP13), 12545 (VP13), 12546 (VP13), 14639 (VP13.1), 14640 (VP13.1), 14641 (VP13.1), 27456 (XBC901K), 18193 (XP90K.1)

BAUKNECHT Pot stove SLE348001BW

BONNET Pasta cooker B107CP4PE, B-B909.CP400 P075756

BRANDT Electric oven MP4330EX1 (MP4330EX), MP4330EX2 (MP4330EX), MP4330EX3 (MP4330EX)

BRANDT Kitchen EN626-1 (EN626), EN626-2 (EN626), EN634-1 (EN634), K5026-1 (K5026), K5026-2 (K5026), K5026-2 (K5026B), K5026-2 (K5026N), K522-1 (K522), K522-2 (K522), K534-1 (K534), K534-1 (K534N), K626-1 (K626), K626-2 (K626), K626-2 (K626B), K626C2 (K626C), K626C2 (K626CN), K626-2 (K626N), K634-1 (K634), K634-2 (K634), K634-3 (K634), K634-3 (K634B), K634C1 (K634C), K634-3 (K634N), KB522-1 (KB522), KB622-1 (KB622), KB622-2 (KB622), KB622-2 (KB622N), KB624-1 (KB624), KB624-2 (KB624), KB624-5 (KB624), KB624-2 (KB624B), KB624-2 (KB624N), KB626-1 (KB626), KB634/1 (KB634), KB634-1 (KB634), KBN624-1 (KBN624), KBN624-2 (KBN624), KF625-1 (KF625), KF625-1 (KF625B), KF625-1 (KF625N), KF639-1 (KF639), KF639-2 (KF639), KF639-2 (KF639N), KFB628-1 (KFB628), KFB628-2 (KFB628), KFB630-1 (KFB630), KFB630-2 (KFB630), KFBN628-1 (KFBN628), KFBN630-1 (KFBN630), KN626C1 (KN626C)

BRANDT Kitchen electric E626-1 (E626), E626-2 (E626), E626C1 (E626C), E626C2 (E626C), E634-1 (E634), E634-2 (E634), E634-3 (E634), EN626C1 (EN626C), EN626C-2 (EN626C)

BRANDT Kitchen glass-ceramics KD173W1G1 (KD173W1G), KD173W1G2 (KD173W1G), KN173W1G1 (KN173W1G), KN173W1G2 (KN173W1G), KNA13W1N1 (KNA13W1N), KNA43W1N1 (KNA43W1N), KNA84W1N1 (KNA84W1N), KNA85W1N1 (KNA85W1N), KNW95W1N1 (KNW95W1N), KV372WE11 (KV372WE1), KV571WN11 (KV571WN1), KV571WN12 (KV571WN1), KV571XN11 (KV571XN1), KV571XN12 (KV571XN1), KV600WN11 (KV600WN1), VBM51BW-1 (VBM51BW)

magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

BRANDT Pot stove HFD53B1F1 (HFD53B1F), HFD53B1F2 (HFD53B1F), HFD53F1F1 (HFD53B1F), HFD53F1F2 (HFD53F1F), HFD53W1F1 (HFD53W1F), HFD53W1F2 (HFD53W1F), HFL12B1E1 (HFL12B1E), HFL12B1E2 (HFL12B1E), HMT51F1F1 (HMT51F1F), HMT51W1F1 (HMT51W1F), HMT51X1F1 (HMT51X1F), HMT51X1F2 (HMT51X1F), T106RV2 (T106RV), TLE40H2 (TLE40H), TLK31B4 (TLK31B), TLK31C2 (TLK31C), TLK31C4 (TLK31C)

BRANDT Pot stove electric DE89B1 (DE89B), DE89H1 (DE89H), TLK31H4 (TLK31H)

BRANDT Pot stove gas SD882C3 (SD882C), SD882C4 (SD882C), SD882H3 (SD882H), SD882H4 (SD882H), SE884B2 (SE884B), SE884B3 (SE884B), SE884C2 (SE884C), SE884C3 (SE884C), SE884H2 (SE884H), SE884H3 (SE884H), SK883B3 (SK883B), SK883B4 (SK883B), SK883B5 (SK883B), SK883C3 (SK883C), SK883C4 (SK883C), SK883C5 (SK883C), SK883H3 (SK883H), SK883H4 (SK883H), TLE40B2 (TLE40B)

BRANDT Pot stove glass-ceramics BV60B-1 (BV60B), BV60W-1 (BV60W), BV60X-1 (BV60X), BV60X-2 (BV60X), HFJ15B1E1 (HFJ15B1E), HFT15B1E1 (HFT15B1E), TRH622N1 (TRH622N), TRH631N1 (TRH631N), TV610BT11 (TV610BT1), TV611BT11 (TV611BT1)

BRANDT Pot stove induction VI-390R1 (VI-390R)

CANDY Pot stove glass-ceramics 36069607 (PVS31N), 36069003 (PVS31W), 36069615 (PVS31X), 36070605 (PVS32N), 36070001 (PVS32W), 36070613 (PVS32X)

CB S.R.L. Sausage grill 2P, 4P, SW1, W12-5, W18-7, W24-5, W24-7, W32-9, W32-9S

CB S.R.L. Vacuum packer DIPA, DIPA50

CF CENEDESE Toaster TN30PLUS

DE DIETRICH Electric oven 7DF0350 (FM1648D1), FM1648D21 (FM1648D2), 7DF0362 (FM2642D1), 7DF0421 (FM2642D1), 7DF0372 (FM5642D1), 7DF0351 (FW1648D1), 7DF0417 (FW1648D1), 7DF0364 (FW2642D1), 7DF0400 (FW2642D1), 7DF0194 (FW4427E1), REP-005321 (FW4427E2), 7DF0374 (FW4427E3), REP-005322 (FW4427E3), 7DF0303 (FW4821E1), REP-005382 (FW4821E3), REP-005413 (FX1648D1), REP-005449 (FX1648D1), REP-005417 (FX2642D1), REP-005436 (FX2642D12), REP-005323 (FX4427E1), REP-005324 (FX4427E2), 7DF0379 (FX4427E3), REP-005325 (FX4427E3), REP-005383 (FX4821E1), REP-005385 (FX4821E3), FX5847E31 (FX5847E3), FX5847E32 (FX5847E3)

DE DIETRICH Pot stove 1241A, DTV103XE11 (DTV103XE1)

DE DIETRICH Pot stove electric REP-006321 (WN1349E1)

DE DIETRICH Pot stove gas 7DT0271 (DTG115BE1), 7DT0861 (DTG315XL1), 7DT0877 (DTG315XL1)

DE DIETRICH Pot stove glass-ceramics REP-006323 (WN1339E1), REP-006322 (WN1379E1), 7DT0252 (WN1438E1), REP-006351 (WN1536E1), 7DT0378 (WN1537E1), WN1537E11 (WN1537E1), 7DT0374 (WN1577E1), 7DT0375 (WN1578E1), REP-006352 (WW1536E1), REP-006387 (WW1578U1)

DE DIETRICH Pot stove induction 8X0264 (DTV301XD1), 7DT0903 (DTV303JE1), 7DT0318 (DTV304XE1), 7DT0449 (WM1049E2), 7DT0450 (WM1079E2), 7DT0256 (WM1339E1), 7DT0254 (WM1349E1), 7DT0255 (WM1379E1), 7DT0377 (WM1536E1), 7DT0408 (WM1578U1)

DESCO Convection oven E2CDA107GCG, FCA6E

DIHR Salamander S1

DOSILET Toaster electric GG4000, TT6000

ELECTROLUX Dishwasher ASU4060I (91172502000), ASU4040IW (91182300700), ASU4040IB (91182300800),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

ASU4040IS (91182300900), ASU4040IN (91182301000), ASU4050I (91182500300), AKE4123IW (92344101400), AME3039NN (94960021200), AME3051NN (94960031000), AHE4062UB (94972024600)
ELECTROLUX Electric oven 5020E-B (94031602300), E57415-4-M R05 (94032015300), FMT45N (94772702100), FMT45N (94772703200)

ELECTROLUX Fryer electric AME3040NN (94960061800), EHB334X (94960064500), ZKM3040XX (94960068300)

ELECTROLUX Hood AEF3100N (90000005400)

ELECTROLUX Kitchen C6033V-A EURO (94031307600), 30006VE-W (94031310700), E 1000-EW EURO (94031644800), E 1000-B EURO (94031644900), E 1000-M1 EURO (94031645000), E 4100-D EURO (94031645500), E 4100-EW EURO (94031645600), E 4100-B EURO (94031645700), E 4100-M EURO (94031645800), CE4100-1-D EURO (94031667500), CE4100-1-W EURO (94031667600), CE4100-1-B EURO (94031667700), CE4100-1-M EURO (94031667800), CE4100-1-A EURO (94031667900), CE1100-2-W EURO (94031679400), CE1100-2-B EURO (94031679500), CE1100-2-M EURO (94031679600), E4101-4-M EU R05 (94032028700), E4101-5-M DE R08 (94032039801), E4101-5-M EU R08 (94032039901), AHE4062US (94972024800)

ELECTROLUX Pot stove ASK4022D (94166808600)

ELECTROLUX Pot stove electric AME2200KB (9413262500), AME2200KW (94132626600), AME2250KB (94168364100), AME2250KW (94168364200), AME3011NN (94960000500), AME3024KN (94960010800), AME3064KN (94960042000), AME3079NN (94960051300), EHB334X (94960060200), AME3040NN (94960060500), ZH2SGF (94960060800), DGF310X (94960060900), EHB334X (94960061500), DGF310X (94960062100), DGF310X (94960063000), EHB334X (94960063500), DGF310X (94960064300)

ELECTROLUX Pot stove glass-ceramics

130FG-M (94117742300), EHB334X (94117764100), AME2222KB (94168363100), AME2222KW (94168363200), AME2222KS (94168363300), AME2222KJ (94168363400), AME2222KN (94168363500), EHO602W (94959070900), EHO602K (94959071000), EHO603K (94959071600), EHO603W (94959071700), EHO603B (94959071800), K641X (94959097000), K641X X50 (94959117500), K641X 63D (94959162600), EHP663X 75L (94959200100), K641X 63C (94959223700), EHP663X 30S (94959296501), 130FG-M (94960068000), 94159265600 (EHO600), 94159265700 (EHO600K), 94159265800 (EHO601), 94159265900 (EHO601K)

FIAMMA Kitchen glass-ceramics IRCT1.8W (201303-), IRCT2x1.8W (201303-)

FIAMMA Salamander SEF-450 (200410-), SEF-450 (200809-), SEF-450 (201211-), SEF-450I (200609-), SEF-450I (201211-), SEF-650 (200410-), SEF-650 (200809-), SEF-650 (201211-), SEF-650I (200609-), SEF-650I (201211-)

FIMAR Panini grill electric RW8

FIMAR Salamander RS40, RS70

GICO Kitchen electric CE7N037C, CE7N037T, CE7N057C, CE7N057FEB, CE7N057T

GIERRE Convection oven FEV-106M, FEV-107M, FEV-166E, FEV-166M, FEV-166P, FEV-167E, FEV-167M, FEV-167P, FEV-168E, FEV-168M, FEV-56M, FEV-57M

GIGA Bain-marie electric CBE4, CBE6, CBE8, SKB40E, SKB60E, SKB80E, TB40E, TB60E, TB80E

GIGA Grill CR4E, CR6E, CRE4, CRE6, IRE4, IRE6, SKR40E, SKR60E, TR40E, TR60E

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

GIGA Kitchen electric C4VFCE, C4VFE

GIGA Kitchen glass-ceramics SK4VFCE

GIGA Pot stove glass-ceramics SKCV40E, SKCV80E

GIGA Salamander S600E, S680E

GIORIK Boiling pan electric PEI705, PEI915

GIORIK Convection oven CG06ES, DE06ES, DE06MX, DE102ES, DE102MX, DE10ES, DE10MX, DG06ES, DG06MX, DG102MX, DG10ES, DG10MX, EF10GM, EF4PM, EF5GM, EF6PM, EF7GM, EF8PM, EG423, EGE05, EGE10, EGG05, EGG10, EGG10M, EN10MX, EN10VEMC, EN20MX, EN6MX, EN6VEMC, EPE04, EPE04R, EPE05, EPE10, G10VEMX, G10VGMX, G20VEMX, G6VGMX, GF10GM, GF4PM, GF5GM, GF6PM, GF7GM, GF8PM, GN10VGMX, GN6MX, ME102, ME102X, ME42, ME4232, ME52, ME5232, ME5232X, ME52X, ME72, ME72X, MG102, MG52, MG72, MME102, MME102S, MME52, MME523, MME523S, MME52S, MME72, MME72S, MMG102, MMG102S, MMG52, MMG52S, MMG72, MMG72S, MR32, MR321, MR42, VE06MX, VE102MX, VE10MX, VE20MX, VG06MX, VG102MX, VG10MX, VG20MX

GIORIK Grill GL72GE

GIORIK Salamander S505, S505R, S510, S510S, S511, S511S, SE520, SR512R

HOTPOINT Electric oven electric HH831ERJIX-HA

HOTPOINT Kitchen electric EW12P

HOTPOINT Kitchen gas CI6VE9(W)R-HA, CI6VE97(W)RU-HA, CI6VE97A1XHA, CI6VE97A1XHA.0, CI6VE97XRUHA, CP9VP6DE-HAS, EW12C

HOTPOINT Kitchen glass-ceramics C3BM6(W)F-HA, C3BM6(X)F-HA, C3VM5(W)R-HA, C3VM5(W)UA-HA, C3VM5(X)R-HA, C3VM57(W)RU-HA, C3VM57(X)RU-HA, C3VP6(W)R-HA, C3VP6(X)R-HA, C3VP6WRHAS, C3VP6XRHAS, CE6VP4(X)R-HA, CE6VP5(W)GR-HA, CE6VP5(X)GR-HA, CE6VP5XGRHAS, CE6VP6(W)EU-HA, CI3VP6(X)R-HA, CI3VP67(X)RU-HA, H5V56WRU, H5V56XRU, H5VMC6AXRU, H5VMH5AW, H5VMH5AX, H5VMH6AXEA, H5VMH6AXPL, H6V530ARU, H6V560WRU, H6V560XRU, H6V5D60WRU, H6V5D60XRU, H6V9CA1WFR, H6VMC2AWFR, H6VMC6A.B(X)FR, H6VMC6AWFR, H6VMH6A.BXGR, HT5VM4AANE, HT5VM4AOWEA

HOTPOINT Pot stove gas GF941BX, PH941MSTB(IX)-HA, PH941MSTBGH-HA

HOTPOINT Pot stove glass-ceramics 7HKRM641DXRUHA, 7HKRM641DXRU-HA, CEM645DX, CRM641DC, CRM641DX, E6011, E6011X, E6014, E6014X, EC6011, EC6014, EX901X, KBM6001HIX-HA, KBM6004CL-HA, KBM6004IX-HA, KBM6014DIX-HA, KRM630C, KRM640C, KRM641DX, XBC901K-HA

IKEA Pot stove electric CKH422, CKH432, HB42000126580, HBD40S00123505, HBD50S60123507, HOB40S10095168

INOXTREND Convection oven AUA-606E, AUA-606G, AUA-610E, AUA-610G, BUA-606E, BUA-606G, BUA-610G, CBA-107E, CBA-111E, CBA-220E, CDA-107E, CDA-107G, CDA-111E, CDA-111G, CDA-120E, CDA-120G, CDA-207E, CDA-207G, CDA-211E, CDA-211G, CDA-220E, CDA-305E, CRUA-107E, CRUA-110E, CUA-107E, CUA-107G, CUA-111E, CUA-111G, CUA-120E, CUA-207E, CUA-211E, CUA-211G, CUA-220E, FBA-106E, FBA-106G, FBA-110E, FBA-110G, FBA-120E, FBA-120G, FBA-210E, FBA-210G, FBA-220E, FBA-220G, FDA-106E, FDA-106G, FDA-110E, FDA-110G, FDA-120G, FDA-210E, FDA-210G, FDA-220E, FDA-220G, FUA-106E, FUA-106G, FUA-110E, FUA-110G, FUA-120E, FUA-120G, FUA-210E, FUA-210G, FUA-220E, FUA-220G, MB1A-10E,

magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

MB1A-10G, MB1E-10E, MB1E-10G, MBE-6E, MBE-6G, MDA-10E, MDA-10G, MDA-6E, MDA-6G, MDE-10E, MDE-10G, MDE-6E, MDE-6G, RDA-105E, RDA-110E, RDA-115E, RDA-305E, RUA-105E, RUA-110E, RUA-115E, RUA-305E, RUA-605E, SDA-4E, SDA-4EM, SDA-5E, SDA-5EM, TAU-606E, TAU-610E, TAU-610G, VB1E-210E, VB1E-210G

KÜPPERSBUSCH Boiling pan electric EES060, EES080, NEK040, NEK060, NEK080, NEK100, NEK150, NEM100, NER500, NES040, NES060, NES080, NES100, NES150, OES060, OES080, OES100

KÜPPERSBUSCH Fry top LEB231, LEB431, LEB631, NEB431, NEB631, NEB831, SEB231, SEB431, SEB631

KÜPPERSBUSCH Fryer electric EEF040, FEF040, LEF040, NEF040, SEF400, TEF400

KÜPPERSBUSCH Grill SER400, SER600

KÜPPERSBUSCH Hot plate electric FEH430, OEH230, OEH430, OEH435, OEH630, OEH633, OEH635

KÜPPERSBUSCH Kitchen electric EEH210, EEH410, EEH413, EEH610, EEH613, OEH410 3x440V, OEH610 3x440V

KÜPPERSBUSCH Kitchen glass-ceramics EEH300, EEH500, EEH503, EEH700, EEH703, FEH300, FEH310, FEH500, FEH503, FEH505, FEH510, FEH513, FEH515, FEH700, FEH703, FEH705, FEH710, FEH713, FEH715, LEH500, LEH503, LEH505, LEH700, LEH703, LEH705, NEH500, NEH505, NEH510, NEH515, NEH700, NEH705, NEH710, NEH715, OEH300, OEH310, OEH500, OEH503, OEH505, OEH510, OEH513, OEH515, OEH700, OEH703, OEH705, OEH710, OEH713, OEH715, PEH508, PEH518, PEH708, PEH718, SEH300, TEH300

KÜPPERSBUSCH Solid top range FEH230, FEH433, FEH435, FEH630, FEH633, FEH635, OEH433

LOTUS Fry top CWK-74ET (201201-), CWK-78ET (201201-), CWK-94ET (201201-), CWK-98ET (201201-), CWKT-64ET (201201-), CWKT-68ET (201201-), CWKT-74ET (201201-), CWKT-78ET (201201-), CWKT-94ET (201201-), CWKT-98ET (201201-), FTC-4EM (200410), FTC-4EM (200411-Vers1), FTC-4EM (200411-Vers2), FTC-4EMX (200410), FTC-4EMX (200411-Vers1), FTC-4EMX (200411-Vers2), FTC-61EM (200406), FTC-61EM (200407-), FTC-61ET (200406), FTC-61ET (200407-), FTC-62EM (200406), FTC-62EM (200407-), FTC-62ET (200406), FTC-62ET (200407-), FTC-6EM (200410), FTC-6EM (200411-Vers1), FTC-6EM (200411-Vers2), FTC-6EMX (200410), FTC-6EMX (200411-Vers1), FTC-6EMX (200411-Vers2), FTC-6ET (200410), FTC-6ET (200411-Vers1), FTC-6ET (200411-Vers2), FTC-74ET (-200601), FTC-74ET (200602-), FTC-74ET (201201-), FTC-78ET (-200601), FTC-78ET (200602-), FTC-78ET (201201-), FTC-8EMX (200410), FTC-8EMX (200411-Vers1), FTC-8EMX (200411-Vers2), FTC-8ET (200410-200410), FTC-8ET (200410-Vers1), FTC-8ET (200411-Vers1), FTC-8ET (200411-Vers2), FTC-94ET (-201112), FTC-94ET (201201-), FTC-98ET (-201112), FTC-98ET (201201-), FTCD-64EM, FTCD-66ET, FTCT-64ET (-201112), FTCT-64ET (201201-), FTCT-66ET (-201112), FTCT-66ET (201201-), FTCT-74ET (-201112), FTCT-74ET (201201-), FTCT-78ET (-201112), FTCT-78ET (201201-), FTCT-94ET (-201112), FTCT-94ET (201201-), FTCT-98ET (-201112), FTCT-98ET (201201-)

LOTUS Glass-ceramic plate CFC-62EM (-200309-Vers1), CFC-62EM (-200309-Vers2), CFC-62EM (200310-200706), CFC-62EM (200707-), CFC-62ET (-200309-Vers1), CFC-62ET (-200309-Vers2), CFC-62ET (200310-200706), CFC-62ET (200707-), PCC-61EM (-200210), PCC-61EM (200211-), PCC-62EM (-200210), PCC-62EM (200211-), PCC-62ET (-200210), PCC-62ET (200211-)

LOTUS Kitchen glass-ceramics CFC4-8ET

LOTUS Pot stove glass-ceramics PCC-4EM, PCC-4EMX, PCC-4ET, PCC-6EM, PCC-6EMX, PCC-6ET, PCC-8EMX, PCC-8ET

magazin online HORECA

**Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

LOTUS Salamander SA-400EM, SA-400EMX, SA-600EM, SA-600EMX, SA-600ET, SA-600ETX, SL-600 (Vers1),
SL-600 (Vers2), SL-600 (Vers3), SL-600EM, SL-600EMX, SL-600ET, SL-600ETX, SL-600X, SLC-600EM, SLC-600ET

LOTUS Sausage grill CWKD-64ET

MODULAR Convection oven NWM-6E-AV, NWV-10G, NWV-6G

MODULAR Electric oven NWM-10E-AV

MODULINE Convection oven RB056M, RB142M, RC101M, RC153M, RC162M, RM112M, RMC20M, RRT153M

PALUX Fryer electric ELECTRIC-APPLIANCES-614-TO-629

PALUX Grill BISTROLINE-STEAK-GRILL

PALUX Pot stove electric FUNCTIONLINE-COOKER, TOPLINE-VARIO-COOKER

PALUX Pot stove glass-ceramics BISTROLINE-CERAMIC-RANGE

PALUX Potato heater BISTROLINE-CHIP-SCUTTLE, COMPACT-ELECTRIC-CHIP-SCUTTLE,
FUNCTIONLINE-CHIP-SCUTTLE, TOPLINE-CHIP-SCUTTLE

PALUX Salamander SALAMANDER

RIEBER Chaffing dish electric ROLLITO RO-WT-2

RIEBER Food-service trolley BUFFETTO WARM TOP

RIEBER Pot stove electric VARITHEK CK 3,4

SAMMIC Salamander SGF-450, SGF-650

SIRMAN Panini grill electric HOTDOG, HOTDOG 3 Y06, HOTDOG 4 Y06

SIRMAN Pasta cooker GW 5 CE, GW 7 CE

SIRMAN Salamander SALAMANDRA BASIC, SALAMANDRA FISSA, SALAMANDRA PRO, SALAMANDRA PRO 1/1 G
CE, SALAMANDRA PRO 1/2 G CE

SIRMAN Sausage grill electric GW 9 CE

SMEG Electric oven S101X-5, S104X-5, S106X-5, S106X-6, S108X-5, S108X-6, S200, S200-1, S200EB,
S200EB-1, S200X, S200X-1, S201X, S300, S300EB, S300X, S300X-5, S301X-5, S302X, SC041MFX, SC0468X-8,
SC0485X-8, SC04MFX, SC0521X-8, SC0578X-8, SC061MFX, SC061X-8, SC06MFX, SC081MFX, SC081X-8,
SC08MFX, SC51X, SC54X, SC63MFX, SC64MFX, SC73MFX, SC74MFX, SE101EB, SE101NE, SE101X, SE105EB,
SE105EB-1, SE105NE, SE105NE-1, SE105X, SE105X-1, SE106EB, SE106EB-1, SE106NE, SE106NE-1, SE106X,
SE106X-1, SE106X-5, SE108X-1, SE286X, SE286X-5, SE50X-5, SE51X-5, SE62MFX-5, SE63MFX-5, SE72MFX-5,
SE73MFX-5, SE820MF, SE820MF-1, SE820MFB1, SE820MFEB, SE90, SE90-1, SE90EB, SE90EB-1, SE90MB,
SE90MB-1, SE90X, SE90X-1, SE92, SE92EB, SE96, SE96-1, SE96EB, SE96EB-1, SE96MB, SE96MB-1, SE96X,
SE96X-1, SF0351X, WE200, WE200-1, WE200EB, WE200EB-1, WE200X, WE200X-1, WI200, WI200EB, WI200X,
WI300, WI300EB, WI300X

SMEG Kitchen electric CE6CMX, CE92CMX, CE9CMX, CE9CMXA, CIE66MDK3, SUK60CMFA, SUK60CMFX,
UK60CMFA, UK60CMFA1, UK60CMFX, UK60CMFX1

SMEG Kitchen gas S854XQV-A, SUK60GA, SUK60GX, SUK60MFA, SUK60MFX, SUK80GA, SUK80GX, SUK80MFA,
SUK80MFX, UK60MFA, UK60MFA1, UK60MFX, UK60MFX1, UK80MFA, UK80MFA1, UK80MFX, UK80MFX1

SMEG Pot stove PDX12RUSB

SMEG Pot stove electric P652, P752, P764AO, P764PO, P775AO, P775PO, P864A, P864A-9, P864P, P864P-9,
P875A, P875P, PDX30B-1, PDX30BBR2, PDX30C-1, PDX30CBR2, PDXF30B, PDXF30B-1, PDXF30C, PDXF30C-1,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

PDXK30B, PDXS30B, PDXS30B-1, PDXS30C, PDXS30C-1, PGA32C, PGF30B, PGF32C, S264C, SA661X1, SE641X, SE660, SE660-1, SE660X, SE660X1, SE661X, SE661X1

SMEG Pot stove glass-ceramics PDXK30C

TECNOINOX Bratt pan BR35E0, BR35E1, BR35E60, BR35E61, BRS35E0, BRS35E1, BRS35E60, BRS35E61

TECNOINOX Convection oven FCV10E, FCV10ES, FCV10G, FCV10GS, FCV6E, FCV6ES, FCV6G, FCV6GS

TECNOINOX Gas oven BF120GE

TECNOINOX Grill GD35E7, GD4E7, GD4FE7, GD70E7, GD8E7, GD8FE7, GR35E0, GR35E2, GR35E60, GR35E62, GR35E7, GR4E7, GR4FE7, GR70E0, GR70E60, GR70E7, GR8E7, GR8FE7

TECNOINOX Kitchen electric PFC70E0, PFC70E60, PFC70E7, PFC70V7, PFC8E7, PFC8V7

TECNOINOX Kitchen gas EFX105GGE7, EFX12GGE9, PFX105GGE7, PFX12GGE7, PFXG12GGE7, PFXG12GGE9

TECNOINOX Pot stove electric PCC35E0, PCC35E1, PCC35E60, PCC35E61, PCC35E7, PCC4E7, PCC4FE7, PCC70E0, PCC70E60, PCC70E7, PCC8E7, PCC8FE7, PCCM8FE7

TECNOINOX Potato heater DSP35E0, SP35E0, SP35E6-0, SP35E7, SP4E7, SP4E9, SP4FE7, SP4FE9

TECNOINOX Proving oven AUPC, AUPL

TECNOINOX Salamander SCP0, SE400, SE60-0, SE604, SE800, SEC400, SEC600, SEC604, SEF10, SEF20, SEF22, TSP0, TSP1

TECNOINOX Solid top range PP70E7, PP8E7, PP8FE7, PPF70E7, PPF70V7, PPF8E7

TECNOINOX Toaster TE60, TE61, TS14, TS15, TS20, TS22

THERMOR Pot stove 7HT0157 (TT106B), 7TT0009 (TT106B), 7HT0160 (TT106RB), 7TT0012 (TT106RB), 7HT0159 (TT106RN), 7TT0011 (TT106RN), 7HT0158 (TT106S), 7TT0010 (TT106S), 7HT0153 (TT206B), 7HT0154 (TT206N), 7HT0156 (TT206S), 7HT0155 (TT206X)

THERMOR Pot stove glass-ceramics 7HT038 (VF603N), 7HT037 (VL613N), 7HT0086 (VM40N), 7HT0095 (VM41B), 7HT0094 (VM41N), 7HT0092 (VM42B), 7HT0090 (VM42N)

UNIVERSAL Convection oven B1064ER, B1064MR, B464ER, B464MR, B664ER, B664MR, G1111ER, G1111ER-GAS, G1111MR, G1111MR-GAS, G511ER, G511MR, G711ER, G711ER-GAS, G711MR, G711MR-GAS, P1064ER, P1064ER-GAS, P1064MR, P1064MR-GAS, P664ER, P664ER-GAS, P664MR, P664MR-GAS

VEDETTE Kitchen 7VC0006 (55KC3BB), 7VC0016 (55KC3BB), 7VC0016 (55KC3BBN), 7VC0016 (55KC3BBP), 55KP4BB1 (55KP4BB), 7VC0008 (55KP4BB), 7VC0021 (55KP4BB), 7VC0021 (55KP4BBN), 7VC0021 (55KP4BBP), 7VC0001 (60DC2BB), 7VC0019 (60DC2BB), 7VC0019 (60DC2BBN), 7VC0019 (60DC2BBP), 60KC2BB1 (60KC2BB), 7VC0003 (60KC2BB), 7VC0010 (60KC2BB), 7VC0010 (60KC2BBN), 7VC0010 (60KC2BBP), 60KC2BD1 (60KC2BD), REP-008011 (60KC2BD), 60KC2BD1 (60KC2BDN), REP-008011 (60KC2BDN), 60KC2BD1 (60KC2BDP), REP-008011 (60KC2BDP), 7VC0040 (60KC30BB), 7VC0073 (60KC30BB), 60KC4BB1 (60KC4BB), 7VC0015 (60KC4BB), REP-008012 (60KC4BB), 7VC0015 (60KC4BBN), 7VC0015 (60KC4BBP), 60KP5BB1 (60KP5BB), 7VC0009 (60KP5BB), 7VC0014 (60KP5BB), 7VC0014 (60KP5BBN), 7VC0014 (60KP5BBP)

VEDETTE Kitchen electric 7VC0042 (60EC20BB), 7VC0007 (60EC2BB), 7VC0017 (60EC2BB)

VEDETTE Pot stove 7VT0001 (KX4BB), 7VT0003 (KX4BB), 7X2348 (KX4BB), 7X2636 (KX4BB), REP-008242 (MX4BD), REP-008294 (MX4BD)

WHIRLPOOL - INDESIT Convection oven 854450101000 (ADN501), 856389101000 (AGS891), EHM304CN, F016250 (FDE1BR&WH), F016251 (FDE1BR&WH), F023549 (FDE1RG), 24040 (HGM10K(IX)), F024040

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(HGM10K(IX)), F030157 (HGM300K.C(BR)), F030156 (HGM300K.C(WH)), F030155 (HGM300K.C(IX)), F030162 (HGM30K.C(BR)), F030161 (HGM30K.C(WH)), F030160 (HGM30K.C(IX)), F068272 (HI50EK.AIX), F036797 (HI50EK.B(WH)), F036798 (HI50EK.B(IX)), F058894 (HI53EK.BIXGR), F036799 (HI56EK.B(IX)), F038108 (HI56EK.BIXGR), F081390 (HIM 20K.A(BK)-2), F074485 (HIM506EK.AIX), F078293 (HIM506EK.AIX-2), F074486 (HIM506EK.AWH), F078298 (HIM506EK.AWH2), F078287 (HIM50EK.AIX2), F074487 (HIM531EK.AIX), F078301 (HIM531EK.AIX-2), F074488 (HIM537EKAIX), F060836 (IH51K.AIX), F078304 (IH51K.AIX2), F060837 (IH63K.AIX) WHIRLPOOL - INDESIT Electric oven 853524201140 (AKG242/AV/01), 853524201150 (AKG242/WH/01), 853542901000 (AKG429/IX), 853543222010 (AKG432/01/IX), 853543222030 (AKG432/03/IX), 853543222000 (AKG432/IX)

WHIRLPOOL - INDESIT Kitchen electric F033171 (K6E32(W)-G), F033172 (K6E32(X)-G)

WHIRLPOOL - INDESIT Kitchen gas ACMT6533IX, ACMT6533IX1, ACMT6533IX2, ACMT6533WH, 854450801000 (ADN508), 854451601000 (ADN516), 854452201000 (ADN522), 854455401000 (ADN554), 854455501000 (ADN555), 851258801000 (AGB588WP), 851263901000 (AGB639WP), AXMT6532IX, F088436 (EI6V6C6AWFR), F023079 (K647VS(W)-O), F023080 (K647VSX-O), F029288 (K648V.C(W)-O), F029289 (K648V.CX-O), F027594 (K648VW-O), F027593 (K648VX-O), F033166 (K6G32(W)-G), F033165 (K6G32(X)-G), F014038 (KG6044WV-G), F011600 (KG6405WV-O), F011601 (KG6405XV-O), F017991 (KG6407AV-G), F017491 (KG6407GV-G), F022260 (KG6407LV-G), F014037 (KG6408WV-G), F017990 (KG6408XV-G), F022215 (KG6408XV-O)

WHIRLPOOL - INDESIT Kitchen glass-ceramics ACMK5531WH, ACMK6531WH1, ACMT5531IX, ACMT5531WH, ACMT5533IX, ACMT5533IX2, ACMT5533WH, ACMT5533WH2, ACMT6533WH1, ACWT5V331IX, ACWT5V331WH, AXMT6533-IX, AXMT6534-IX, AXMT6534IX-1, AXMT6534IXU, ERC-90-V, F088232 (I5VM6HAWBG), F083520 (I6V66AWFR), F083518 (I6V6C1A.HWFR), F088426 (I6V6C5AWHU), F088424 (I6V6C5AXHU), F083520 (I6V6C6AWFR), F083812 (I6V6H1AWFR), F084285 (I6VMH2ABXGR), F083805 (I6VSH2WEX), F083807 (I6VV2AXEX), F035942 (K3C36(X)-G), F029365 (K3C8V.B(X)-G), F029364 (K3C8V.BA-G), F028467 (K3C8VA-G), F026823 (K3C8VW-G), F026824 (K3C8VX-G), F033168 (K6C32(W)-G), F033169 (K6C32(X)-G), F060903 (K6C7(IX)-SK), F057876 (K6C7(W)-NO), F033973 (K6C7(W)-SK), F033974 (K6C7(X)-SK), F073925 (KN3C76A(W)BG), F081172 (KN3C76AWBG5), F073913 (KN6C72A(X)-GR), F081167 (KN6C72AXGRS), F057476 (KP900CX), F063012 (KP902CX), F057477 (KP9508CXG), F068721 (KP9C11S(K)-G)

WHIRLPOOL - INDESIT Microwave oven 853524201050 (AKG242/BL), 853524201080 (AKG242/NB)

WHIRLPOOL - INDESIT Pot stove 853514829000 (AKG148/AV), 853514829010 (AKG148/BL), 853514929000 (AKG149/BL), 853514901090 (AKG149IX), 853515629000 (AKG156/AV), 853515629000 (AKG156/BL), 853515729000 (AKG157/AV), 853515829000 (AKG158/AV), 853515929000 (AKG159/AV), 853515929010 (AKG159/BL), 853516129000 (AKG161/AV), 853516129010 (AKG161/BL), 853516229000 (AKG162/AV), 853516229010 (AKG162/BL), 853516929000 (AKG169/AV), 853516929010 (AKG169/BL), 853517029000 (AKG170/AV), 853517029010 (AKG170/BL), 857160129000 (AKM601/NB/WP), 857160229000 (AKM602/NB/WP), 857160429000 (AKM604/NB/WP), 857190029010 (AKM900/01/NE), 857190029000 (AKM900/NE), 857190029000 (AKM900NE), 857190129010 (AKM901/01/NE), 857190129000 (AKM901/NE), 857190129020 (AKM901/NE/02), 857190729010 (AKM907/01/NOIRE), 857190729000 (AKM907/NE), 857190729010 (AKM90701NE), 857190729000 (AKM907NE)

WHIRLPOOL - INDESIT Pot stove electric 857160719000 (AKM607IX01), 857160722090 (AKM607IX01),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

857160722091 (AKM607IX01), 857160722092 (AKM607IX01), 857160722093 (AKM607IX01), 857160722094 (AKM607IX01), 857160701000 (AKM607IX02), 857160701001 (AKM607IX02), 857160701002 (AKM607IX02), 857160729000 (AKM607IX02), 857160722081 (AKM607NB01), 857160722083 (AKM607NB01), 857160722084 (AKM607NB01), 857161018040 (AKM610IX), 857161018041 (AKM610IX), 857161336000 (AKM613IX03), 857161336001 (AKM613IX03), 857162601010 (AKM626NB), 857162615020 (AKM626NB), 857162615023 (AKM626NB), 857188129000 (AKM881NB), 857189029000 (AKM890NB), 857189029001 (AKM890NB), 857189029010 (AKM890NB01), 857189029011 (AKM890NB01), 857189029012 (AKM890NB01), 857190029010 (AKM90001NE), 857190029020 (AKM900NE02), 857190029021 (AKM900NE02), 857190001000 (AKM900NE03), 857190129010 (AKM90101NE), 857190110000 (AKM901NE), 857190110003 (AKM901NE), 857190110004 (AKM901NE), 857190110005 (AKM901NE), 857190129000 (AKM901NE), 857190129020 (AKM901NE02), 857190129021 (AKM901NE02), 857190101000 (AKM901NE03), 857190101001 (AKM901NE03), 857190101002 (AKM901NE03), 857190101003 (AKM901NE03), 857190101004 (AKM901NE03), 857190101005 (AKM901NE03), 857190115000 (AKM901NE03), 857190115001 (AKM901NE03), 857190201000 (AKM902NE), 857190201001 (AKM902NE), 857190201002 (AKM902NE), 857190729020 (AKM907NE02), 857190729021 (AKM907NE02), 857190729023 (AKM907NE02), 857191001000 (AKM910IX), 859432001000 (AKT320IX), 859432001003 (AKT320IX), 859432036000 (AKT320IX), 859432036001 (AKT320IX), 859432501000 (AKT325IX), 859432501001 (AKT325IX), 859432501002 (AKT325IX), 859432501003 (AKT325IX), 859432536001 (AKT325IX)

WHIRLPOOL - INDESIT Pot stove gas F033889 (PI 640 AS(IX) IR)

WHIRLPOOL - INDESIT Pot stove glass-ceramics AKL359-NE-02, AKL359-NE-03, AKL359-NE-04, AKL359-NE-06, 857161310030 (AKM613IX01), 857161310032 (AKM613IX01), 857161310034 (AKM613IX01), 857161310035 (AKM613IX01), 857161310036 (AKM613IX01), AKM613-IX-02, AKM613-IX-04, AKM613-IX-05, 857188129000 (AKM881/NB), 857190301000 (AKM903NE), 857190301001 (AKM903NE), 857190301002 (AKM903NE), 859431501000 (AKT315IX), 859431501001 (AKT315IX), 859431501002 (AKT315IX), 859431501003 (AKT315IX), 859431501004 (AKT315IX), 859431503001 (AKT315IX), 859431503002 (AKT315IX), 859431536000 (AKT315IX), 859431536001 (AKT315IX), 859431555000 (AKT315IX), 859431589000 (AKT315IX), 859436001000 (AKT360IX), 859436001001 (AKT360IX), 859436001002 (AKT360IX), BBVTC70, 12312 (EPI04.1), 12313 (EPI04.1), 12314 (EPI04.1), F012312 (EPI04.1), F012313 (EPI04.1), F012314 (EPI04.1), 12315 (EPI13.1), 12316 (EPI13.1), 12317 (EPI13.1), F012315 (EPI13.1), F012316 (EPI13.1), F012317 (EPI13.1), 13957 (EPV04), 13958 (EPV04), 13959 (EPV04), F013957 (EPV04), F013958 (EPV04), F013959 (EPV04), 13963 (EPV04D), 13964 (EPV04D), 13965 (EPV04D), F013963 (EPV04D), F013964 (EPV04D), F013965 (EPV04D), F013960 (EPV13-13.1), F013961 (EPV13-13.1), F013962 (EPV13-13.1), ETK5240IN, F038966 (MK64RCL), F013966 (PV04), F013967 (PV04), F013968 (PV04), F013969 (PV13-PV13H), F013970 (PV13-PV13H), F013971 (PV13-PV13H), F017241 (PV13-PV13H), F017243 (PV13-PV13H), F017244 (PV13-PV13H), 13692 (PV22), 13693 (PV22), F013692 (PV22), F013693 (PV22), 25321 (PV604BK), F025321 (PV604BK), 23933 (PV604IX), F023933 (PV604IX), 12810 (PVI04.1), 12811 (PVI04.1), F012810 (PVI04.1), F012811 (PVI04.1), 06447 (PVI13), 06451 (PVI13), F006447 (PVI13), F006451 (PVI13), 12547 (PVI13.1), 12548 (PVI13.1), 12549 (PVI13.1), F012547 (PVI13.1), F012548 (PVI13.1), F012549 (PVI13.1), 12812 (PVI22.1), 12813 (PVI22.1), F012812 (PVI22.1), F012813 (PVI22.1), F068819 (VRM630C), F075810 (VRM630MC), F074066 (VRM640MC), F074065

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(VRM640MIX), F053074 (VRM640X), F074068 (VRM641MDC), F074067 (VRM641MDIX)

ZANOLLI Convection oven PLANET 5, PLANET 5G, PLANET 8, PLANET 8G

ZANOLLI Pizza oven electric CITIZEN 6 MC, CITIZEN 6-6 MC, CITIZEN 9 MC, CITIZEN 9-9 MC

ZANUSSI Boiling pan NULL (232087), NULL (232088), NULL (232089), NULL (232090), NULL (232091), NULL (232092), NULL (232093), NULL (232094), NULL (232095), NULL (232096), NULL (232097), NULL (232098), NULL (232099), NULL (232100), NULL (232101), NULL (232102), NULL (232186), NULL (232187), NULL (232188), NULL (232189), E9BSGHIN40 (391290), E9BSGHIR40 (391293), E9BSGHDP40 (391296), NULL (584404), NULL (584405), NULL (584410), NULL (584411), NULL (584419), NULL (584420), NULL (584425), NULL (584426), NULL (584434), NULL (584435), NULL (584437), NULL (584440), NULL (584443), NULL (584444), NULL (584446), NULL (584452), NULL (584453), NULL (584455), NULL (584458), NULL (584461), NULL (584467), NULL (584470), NULL (585489), 7550-2 (JUN75502), 7551-2 (JUN75512), 7552-2 (JUN75522), 7553-2 (JUN75532), 7573-2 (JUN75732), 7574-2 (JUN75742), 7575-2 (JUN75752), 7576-2 (JUN75762), 7773-2 (JUN77732), 7774-2 (JUN77742), 7775-2 (JUN77752), 7776-2 (JUN77762)

ZANUSSI Boiling pan electric MPN/EI760 (162206), MPNEI760UK (162207), MPN/EI760D (162209), 7PIE06 (172004), RPN/EI760UK (172005), RPN/EI760D (172009), M70EIKE (175004), XPN/EI760UK (175005), XPN/EI760D (175010), PPI/E260P (178138), OPI/E260P (178438), TPI/E260P (178738), KPI/E10 (200273), KPI/E15 (200274), KPI/E15A (200279), KPI/E06 (200281), KPI/E15H (200286), KPI/E10H (200288), HPN/EI815D (202016), HPN/EI810 (202017), HPN/EI815 (202018), HPN/ED811 (202021), HPN/ED816 (202022), HPA/ED825 (202025), HPA/EI825 (202026), HPNS/EI815 (202038), HPNS/EI815D (202039), HPN/EI806 (202043), HPN/EI805 (202049), QPI/E10 (210273), QPI/E15 (210274), QPI/E06 (210281), QPI/E15H (210286), QPI/E10H (210288), ZPN/EI815D (212016), ZPN/EI810 (212017), ZPN/EI815 (212018), ZPN/ED811 (212021), ZPN/ED816 (212022), HPN/ED825 (212025), HPN/EI825 (212026), ZPNS/EI815 (212038), ZPNS/EI815D (212039), ZPN/EI805 (212049), WPI/E10 (220273), WPI/E15 (220274), WPI/E15A (220279), WPI/E06 (220281), WPI/E15H (220286), WPI/E10H (220288), APN/EI815D (222016), APN/EI810 (222017), APN/EI815 (222018), APN/ED816 (222022), APNS/EI815 (222038), APN/EI805 (222049), EBS50. (232103), EBS50H (232104), EBS100. (232105), EBS100H (232106), EBS150. (232107), EBS150H (232108), EBS200. (232109), EBS200H (232110), EBS300. (232111), EBS300H (232112), EBV50. (232113), EBV50H (232114), EBV100. (232115), EBV100H (232116), EBV150 (232117), EBV150H (232118), EBV200. (232119), EBV200H (232120), EBV300. (232121), EBV300H (232122), EBVC50 (232123), EBVC50H (232124), EBVC100 (232125), EBVC100H (232126), EBVC150 (232127), EBVC150H (232128), EBVC200 (232129), EBVC200H (232130), EBVC300 (232131), EBVC300H (232132), EBP100. (232133), EBP100M (232134), EBP150 (232135), EBP150M (232136), EBP200. (232137), EBP200M (232138), EBP300. (232139), EBP300M (232140), EBPC100 (232141), EBPC100M (232142), EBPC150 (232143), EBPC150M (232144), EBPC200 (232145), EBPC200M (232146), EBPC300 (232147), EBPC300M (232148), MED50H (232150), MED100H (232151), MED150H (232152), MED200H (232153), MED300H (232154), TOP50H (232155), TOP100H (232156), TOP150H (232157), TOP200H (232158), TOP300H (232159), TOPC50H (232160), TOPC100H (232161), TOPC150H (232162), TOPC200H (232163), TOPC300H (232164), NULL (232165), NULL (232166), NULL (232167), NULL (232168), E7BSEHINFO (371094), E7BSEHINFR (371095), E7BSGHIN40 (371252), E7BSGHIN4R (371253), E7BSGHDN40 (371254), Z7BSEHINFO (372094), Z7BSEHINFR (372095), A7BSEHINFO (373094), E9BSEHINFO (391117), E9BSEHIPFO (391118), E9BSEHIPFR (391119), E9BSEHIRFO

(391120), E9BSEHIRFR (391121), E9BSEHIRFC (391122), Z9BSEHINFO (392117), Z9BSEHIPFO (392118), Z9BSEHIPFR (392119), Z9BSEHIRFO (392120), Z9BSEHIRFR (392121), Z9BSEHIRFC (392122), A9BSEHINFO (393117), A9BSEHIPFO (393118), A9BSEHIPFR (393119), A9BSEHIRFO (393120), A9BSEHIRFR (393121), NULL (584401), NULL (584402), NULL (584407), NULL (584408), NULL (584416), NULL (584417), NULL (584422), NULL (584423), NULL (584431), NULL (584432)

ZANUSSI Boiling pan gas RPI/G260P (168135), XPI/G260P (168535), MPI/G260P (168935), PPD/G260 (178134), PPI/G260P (178136), OPD/G260 (178434), OPI/G260P (178436), TPD/G260 (178734), TPI/G260P (178736), KPI/G10 (200271), KPI/G15 (200272), KPD/G10 (200275), KPD/G15 (200276), KPD/G15A (200277), KPI/G15A (200278), KPI/G06 (200280), KPI/G15H (200285), KPI/G10H (200287), QPI/G10 (210271), QPI/G15 (210272), QPD/G10 (210275), QPD/G15 (210276), QPI/G06 (210280), QPI/G15H (210285), QPI/G10H (210287), WPI/G10 (220271), WPI/G15 (220272), WPD/G10 (220275), WPD/G15 (220276), WPD/G15A (220277), WPI/G15A (220278), WPI/G06 (220280), WPI/G15H (220285), WPI/G10H (220287), E7BSGHINFO (371087), E7BSGHINFR (371088), E7BSGHDNFO (371089), Z7BSGHINFO (372087), Z7BSGHINFR (372088), Z7BSGHDNFO (372089), A7BSGHINFO (373087), A7BSGHDNFO (373089), E9BSGHINFO (391099), E9BSGHIPFO (391100), E9BSGHIPFR (391101), E9BSGHIRFO (391102), E9BSGHIRFR (391103), E9BSGHIRFC (391104), E9BSGHDPFO (391106), E9BSGHDRFO (391107), E9BSGHDRFC (391108), Z9BSGHINFO (392099), Z9BSGHIPFO (392100), Z9BSGHIPFR (392101), Z9BSGHIRFO (392102), Z9BSGHIRFR (392103), Z9BSGHIRFC (392104), Z9BSGHDPFO (392106), Z9BSGHDRFO (392107), Z9BSGHDRFC (392108), A9BSGHINFO (393099), A9BSGHIPFO (393100), A9BSGHIPFR (393101), A9BSGHIRFO (393102), A9BSGHIRFR (393103), A9BSGHDPFO (393106), A9BSGHDRFO (393107)

ZANUSSI Bratt pan RMV/E1C (168036), RMV/E2C (168037), XMV/E1C (168436), XMV/E2C (168437), JMV/E1C (168636), JMV/E2C (168637), MMV/E1C (168836), MMV/E2C (168837), PMV/E1C (178104), PMV/E2C (178105), OMV/E1C (178404), OMV/E2C (178405), TMV/E1C (178704), TMV/E2C (178705), KBR/G2F (200301), KBR/G2C (200302), KBR/G3F (200303), KBR/G3FH (200304), KBR/G3C (200305), KBR/G3CH (200306), KBR/E2F (200307), KBR/E2C (200308), KBR/E3F (200309), KBR/E3FH (200310), KBR/E3C (200311), KBR/E3CH (200312), KMV/G2C (200313), KMV/E2C (200314), KBR/G2FH (200315), KBR/G2CH (200316), KBR/E2FH (200317), KBR/E2CH (200318), KBR/G3CJ (200319), BRN70G (200322), BRN70E (200323), HBR/G800 (201501), HBR/G805 (201502), HBR/G801 (201503), HBR/G806 (201504), HBR/G810 (201505), HBR/G815 (201506), HBR/G811 (201507), HBR/G816 (201508), HBR/G800D (201509), HBR/G805D (201510), HBR/G801D (201511), HBR/G806D (201512), HBR/G810D (201513), HBR/G815D (201514), HBR/G811D (201515), HBR/G816D (201516), HBR/E800 (201517), HBR/E805 (201518), HBR/E801 (201519), HBR/E806 (201520), HBR/E810 (201521), HBR/E815 (201522), HBR/E811 (201523), HBR/E816 (201524), HBR/G800NL (201525), HBR/G805NL (201526), HBR/G810NL (201527), HBR/G800UK (201532), HBR/E800UK (201533), HBR/G800 (201558), HBR/G805 (201559), HBR/G810 (201560), HBR/G815 (201561), HBR/G811 (201562), HBR/G816 (201563), HBR/E800 (201564), HBR/E805 (201565), HBR/E810 (201566), HBR/E815 (201567), HBR/E811 (201568), HBR/E816 (201569), HBR/G800UK (201570), HBR/E800UK (201571), QBR/G2F (210301), QBR/G2C (210302), QBR/G3F (210303), QBR/G3FH (210304), QBR/G3C (210305), QBR/G3CH (210306), QBR/E2F (210307), QBR/E2C (210308), QBR/E3F (210309), QBR/E3FH (210310), QBR/E3C (210311), QBR/E3CH (210312), QMV/G2C (210313), QMV/E2C (210314), QBR/G2FH (210315), QBR/G2CH (210316), QBR/E2FH (210317), QBR/E2CH (210318), BRN/70GZ (210322), BRN/70EZ (210323), ZBR/G800 (211501), ZBR/G805 (211502), ZBR/G801

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații**
Automatizări / Materiale Electrice

(211503), ZBR/G806 (211504), ZBR/G810 (211505), ZBR/G815 (211506), ZBR/G811 (211507), ZBR/G816 (211508), ZBR/G800D (211509), ZBR/G805D (211510), ZBR/G801D (211511), ZBR/G806D (211512), ZBR/G810D (211513), ZBR/G815D (211514), ZBR/G811D (211515), ZBR/G816D (211516), HBR/E800 (211517), ZBR/E805 (211518), BR/E806 (211520), ZBR/E810 (211521), ZBR/E815 (211522), ZBR/E811 (211523), ZBR/E816 (211524), ZBR/G800UK (211532), ZBR/E800UK (211533), ZBR/G800 (211558), ZBR/G805 (211559), ZBR/G810 (211560), ZBR/G815 (211561), ZBR/G811 (211562), ZBR/G816 (211563), ZBR/E800 (211564), ZBR/E805 (211565), ZBR/E810 (211566), ZBR/E815 (211567), ZBR/E811 (211568), ZBR/E816 (211569), ZBR/G800UK (211570), ZBR/E800UK (211571), BR70GZ (214038), BR70EZ (214039), WBR/G2F (220301), WBR/G2C (220302), WBR/G3F (220303), WBR/G3FH (220304), WBR/G3C (220305), WBR/G3CH (220306), WBR/E2F (220307), WBR/E2C (220308), WBR/E3F (220309), WBR/E3FH (220310), WBR/E3C (220311), WBR/E3CH (220312), WBR/G2FH (220315), WBR/G2CH (220316), WBR/E2FH (220317), WBR/E2CH (220318), BRNG70A (220322), BRNE70A (220323), ABR/G800 (221558), ABR/G805 (221559), ABR/G810 (221560), ABR/G815 (221561), ABR/G811 (221562), ABR/G816 (221563), ABR/E800 (221564), ABR/E805 (221565), ABR/E810 (221566), ABR/E815 (221567), ABR/E811 (221568), ABR/E816 (221569), ABR/E800UK (221571), OBR/G800UK (221575), OBR/E800UK (221576), SBRE350 (285517), SBRE350 (285757), BR70G (291100), BR70E (291101), E7MFGDDDD00 (371105), E7MFGHDI00 (371106), E7MFEDDD00 (371109), E7MFEHDI00 (371110), Z7MFGDDDD00 (372105), Z7MFGHDI00 (372106), Z7MFEDDD00 (372109), Z7MFEHDI00 (372110), A7MFGDDDD00 (373105), A7MFGHDI00 (373106), A7MFEDDD00 (373109), A7MFEHDI00 (373110), E9MFGHDI00 (391142), E9MFEHDI00 (391151), Z9MFGHDI00 (392142), Z9MFEHDI00 (392151), A9MFGHDI00 (393142), A9MFEHDI00 (393151)

ZANUSSI Convection oven FCF_E6_I (240000), FCF10EMET (240001), FCF6EMET (240002), FCF6EOEM (240003), FCF10EOEM (240004), FCF101EZ (240005), FCF6E (240015), FCF061EV (240032), FCF061EOEM (240033), FCF101EV (240034), FCF101EOEM (240035), NULL (240200), FCFG101/0 (240201), FCFG102-0 (240202), FCFG201-0 (240203), FCFG202-0 (240204), FCF/E6-0 (240205), FCFE101-0 (240206), FCFE102-0 (240207), FCFE201-0 (240208), FCFE202-0 (240209), FCF061ELN (240211), FCF101ELN (240212), FCF6EHOR (240215), FCFG10160H (240221), NULL (240222), FCF102GMS (240224), FCF201GMS (240225), FCF061ENS (240226), FCF101ENS (240227), FCF102ENS (240228), FCF201ENS (240229), NULL (240260), FCF/G101/1 (240261), FCFG102-0T (240262), NULL (240263), FCFG101-1J (240264), FCFG102-1J (240265), FCFE6-1J (240266), FCFE101-1J (240267), FCFE102-1J (240268), FCFG101-60 (240269), 7CO30 (240913), CCO30G (240914), FCFG6D (241006), FCFE6D (241051), FCFE6D (241052), FCFG10 (241100), FCFG10D (241105), FCFG10NL (241120), FCFE10 (241150), FCFE10UK (241155), FCFG20 (241200), FCFG20D (241205), FCFG20F (241210), PFCFG20 (241215), FCFE20 (241250), FCFE20UK (241255), FCFG40 (241300), FCFG41 (241301), FCFG40D (241306), FCFG40F (241310), PFCFG40F (241315), FCFE40 (241350), FCFE40D (241351), FCFE40UK (241355), PFCFE40F (241365), FCFG6 (241500), FCFG6F (241510), PFCFG6 (241515), FCFE6 (241550), FCFE6UK (241555), PFCFE6 (241565), FCFE6J50 (243200), FCFE6J60 (243202), FCFG10J (243204), FCFG10J (243205), FCFE10J (243206), FCFE10J (243208), FCFG20J (243210), FCFG20J (243212), FCFE20J (243214), FCFE20J (243216), FCFG40J (243218), FCFG40J (243220), FCFE40J (243222), FCFE40J (243224), FCFG6J (243226), FCFG6J (243227), FCFG6J (243228), FCFG6J (243229), FCFG10J (243230), FCFG10J (243232), FCFG20J (243234), FCFG20J (243236), FCFG41J (243238), FCFG40J (243240), FCVG6-1 (244401), FCVG6-3

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(244403), FCVG6-1UK (244441), FCVG6-3UK (244443), FCVG10-2 (245402), FCVG10-4 (245404), FCVG10-2 (245412), FCVG10-4D (245414), FCVG10-2UK (245442), FCVG10-4UK (245444), FCVG10-2 (245482), FCVG10-4 (245484), FCVG20-2 (246402), FCVG20-4 (246404), FCVG20-2 (246412), FCVG20-4D (246414), FCVG20-2UK (246442), FCVG20-4UK (246444), FCVG20-4 (246482), FCVG20-4D (246484), C7E4/200-3 (260100), C7E4/230-3 (260101), C7E4/400-3N (260102), C7E6/400-3N (260103), C7PE4/200-3 (260104), C7PE4/230-3 (260105), C7PE4/400-3N (260106), C7PT4/400-3N (260107), C104200-3 (260108), C104230-3 (260109), C104400-3N (260110), C106400-3N (260111), C10T4/400- (260112), C10P4200-3 (260113), C10P4230-3 (260114), C10P44003N (260115), C10P64003N (260116), C10PT4/400 (260117), C204200-3 (260118), C20230-3 (260119), C204400-3N (260120), C206400-3N (260121), C20T4/400- (260122), C20P4200-3 (260123), C20P4230-3 (260124), C20P44003N (260125), C20P64003N (260126), C20PT4/400 (260127), ECF_E6_I (260155), ECFG201-T (260629), ECFE201-T (260634), ECFE202-T (260640), ECFG202-T (260644), ECF/E6-T (260645), ECFE101-T (260646), ECFE102-T (260648), NULL (260700), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), ECF/E6-0 (260705), ECFE101-0 (260706), ECFE102-0 (260707), ECFE201-0 (260708), ECFE202-0 (260709), NULL (260722), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), ECF061ENS (260726), ECF101ENS (260727), ECF102ENS (260728), ECF201ENS (260729), ECF061E5M (260730), ECF061ECV (260731), ECO312CF (260913), OTS100 (260914), FCF/G6 (2FC02B), FCFG101 (2FC03B), FCFG201 (2FC04B), FCFG202 (2FC05B), FCFC202 (2FC07B), FCF/E6 (2FC52B), FCFE202 (2FC55B), FCV/G6-1 (2FM06B), ZOFCV/G6-3 (2FM08B), ZOFCV/G102 (2FM16B), ZOFCV/G104 (2FM18B), ZOFCV/G202 (2FM26B), ZOFCV/G204 (2FM28B), NULL (697300), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), ACF/E6-0 (697305), ACFE101-0 (697306), ACFE102-0 (697307), ACFE201-0 (697308), ACFE202-0 (697309), ACFG10160H (697311), JCF/G6-1 (697360), JCF/G101/1-1 (697361), JCF/G102/1-1 (697362), JCF/E6-1 (697365), JCF/E101/1-1 (697366), JCF/E102/1-1 (697367), JCF/G6-2 (697390), JCF/G101/1-2 (697391), JCF/G102/1-2 (697392), JCF/E6-2 (697395), JCF/E101/1-2 (697396), JCF/E102/1-2 (697397), NULL (697500), RCF061E (697501), RCF101G (697502), RCF101E (697503), RCF201G (697504), RCF201E (697505), NULL (697506), RCF06EK (697507), RCF10GK (697508), RCF10EK (697509), RCF06EDIG (697511), RCF10EDIG (697512), RCFE102 (697513), RCFE202 (697514), RCFG202 (697516), FF/E40 (697595), AFCF/E6 (697680), FF/G6 (697690), FF/E10 (697700), FF/G10 (697710), FF/E20 (697720), FF/G20 (697730), FF/G40 (697740), AFCF/E40 (697750), NCF/G6-0 (724050), NCF/G101/1 (724051), NCF/G102/1 (724052), NCF/E6-0 (724055), NCF/E101/1 (724056), NCF/E102/1 (724057), COCO10G (724206), COCO10E (724208), COCO20G (724212), COCO20E (724214), COCO6G (724222), COCO6E (724224), 4236N (724236), 4238N (724238), COCVE423AF (724302), FCFE061 (770234), FCFE101 (770258), FCFE201 (770259), ZOFCF/G10D (770334), ZOFCF/G6D (770345), ZOFCF/G20D (770347), ZCF/G6-0 (775100), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104), ZCF/E6-0 (775105), ZCF/E101/1 (775106), ZCF/E102/1 (775107), ZCF/E201/1-0 (775108), ZCF/E202/1-0 (775109)

ZANUSSI Fry top ZR/G413 (211519)

ZANUSSI Grill SGE350 (285516), SGE350 (285756), GR35E6U (285819)

ZANUSSI Hot cupboard RI12H1F (732061), RI27H2F (732062), RI12H2FT (732063), RI27H4FT (732186), BCFCV101/1 (922112), BCFCV102/1 (922113), BCFCV101/1 (922124), BCFCV102/1 (922125)

ZANUSSI Icemaker C15OW (9L1230), C300A (9L1231), C300W (9L1232), CB1565W (9L1234), CB246W

*magazin online HORECA***Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice**

(9L1236), CB416W (9L1239), CB955W (9L1243), DSS42W (9L1244), C80W (9L1245), CB1565A (9L1246), C80A (9L1247), CB246A (9L1250), CB416A (9L1253), C150A (9L1257), CB955A (9L1258), DSS42A (9L1270)
ZANUSSI Kitchen 7507-2 (JUN75072), 7508-2 (JUN75082), 7707-2 (JUN77072)
ZANUSSI Pasta cooker BCP/E1 (162321), RCP/E2S (168144), MCP/E1SH (168745), MCP/E1SUH (168746), MCP/E2SUHS (168747), MCP/E2S (168944), MCP/E2SH (168945), MCP/E2SUH (168947), MCP/E2SUT (168948), MCP/E2SHB (168949), PCP/E2SHP (178147), PCP/E1SH (178148), PCP/E2SH (178149), PCP/E2SH3B (178153), OCP/E2S (178447), OCP/E1SH (178448), OCP/E2SH (178449), TCP/E2S (178747), TCP/E2SH (178749), NULL (200372), NULL (200373), KCP/E1RU (200374), KCP/E2RU (200375), KCP/G1 (200376), KCP/G1R (200377), KCP/G2 (200378), KCP/G2R (200379), KCP/E1 (200380), KCP/E1R (200381), KCP/E2 (200382), KCP/E2R (200383), NULL (200396), NULL (200397), KCP/E1U (200398), KCP/E2U (200399), HCP/E400 (204013), HCP/E410 (204014), HCP/E800 (204015), HCP/E810 (204016), HCPS/E400 (204027), HCPS/E410 (204028), QCP/G1 (210376), QCP/G1R (210377), QCP/G2 (210378), QCP/G2R (210379), QCP/E1 (210380), QCP/E1R (210381), QCP/E2 (210382), QCP/E2R (210383), ZCP/E400 (214013), ZCP/E410 (214014), ZCP/E800 (214015), ZCP/E810 (214016), ZCPS/E400 (214027), ZCPS/E410 (214028), WCP/G1 (220376), WCP/G1R (220377), WCP/G2 (220378), WCP/G2R (220379), WCP/E1 (220380), WCP/E1R (220381), WCP/E2 (220382), WCP/E2R (220383), DCP/G400 (224009), ACP/E400 (224013), ACP/E410 (224014), ACP/E800 (224015), ACP/E810 (224016), ACPS/E400 (224027), ACPS/E410 (224028), HCP/E800 (295554), HCP/E801 (295555), HCP/E400 (295564), HCP/E401 (295565), E9PCGD1MF2 (391201), E9PCGH2MF2 (391202), E9PCED1MF2 (391203), E9PCEH2MF2 (391204), EKAROMOOOO (580512), UKDROEOOOO (580936), UKDROEOOOQ (580938), AKAROAoooo (582379), AKAROFOOOO (582380), DKAROEoooo (591501), EKAROEoooo (591511), AKAROFUOOC (599611), AKAROAUOOC (599612), ZHCP/E800 (770440), ZHCP/E400 (774430), ZHCP/E401 (774435), HCP/E800 (774440), ZHCP/E801 (774445)
ZANUSSI Pot stove electric SIE350 (285503), SVE700 (285504), SIE350 (285743), SVE700 (285744)
ZANUSSI Potato heater SCCE350 (285513), SCCE350 (285753), SCCE350 (285822)
ZANUSSI Refrigerated cupboard KUMAC (881433)
ZANUSSI Salamander SL/E851 (283420), SL/E901 (283430), SAL-E1 (697237), SAL-E2 (697238), SALE04 (775301), SALE06 (775302)
ZANUSSI Self service counter DCBE41 (380402), DCB/E41U (380406), DCBE42 (380502), DCB/E42U (380506)



Kalva Solutions SRL
PLOIESTI, str. Cuza Voda nr.9 D8B parter
Tel.: 0737095202

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

