



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

Termostat siguranta 360°C EGO 55.32574.800 #3444293

Fara TVA: 405,88 Lei

Pret cu TVA: 483,00Lei

Termostat siguranta 360°C EGO 55.32574.800 #3444293

with manual reset

capillary length covered 1500 mm - 16A 250V

bulb ø 4x110 mm

Maximum Temperature (°C): 360

Type: Safety thermostat with manual reset

Bulb Type: Pen-Shaped

Bulb ø (mm): 4

2 Bulbs: No

Capillary Length (mm): 1490

Sheath: Yes

Gland: No

Contacts No.: 2

Contact Capacity (Phase): Single-Phase

Selector Switch: No

PART NUMBER EGO 5532574800

EGO CODES NO. ADAPTABLE 5134955030

Compatibil cu:

CZA327 ASCASO

ANP137 ASCASO

ZA.169 ASCASO

EGO 5532574800, 55.32574.800

EGO 5534955030, 55.34955.030

EGO 5134955030, 51.34955.030

EPMS

GEV 375344

ALPENINOX

ANGELO PO

EBERHARDT

ELECTROLUX PROFESSIONAL

LAINOX

NAYATI



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

SAGI

WHIRLPOOL

ZANUSSI

ANGELO PO Bratt pan gas 0G1BR3G, 1G1BR3G

ANGELO PO Fry top gas 08WFT4GV, 08WFT6GV, 090FT4G, 090FT5G, 0A0FT1G, 0A0FT2G, 0A0FT4G, 0A0FT5G, 0B0FT1G, 0B0FT2G, 0B0FT4G, 0B0FT5G, 0D0FT1G, 0D0FT2G, 0D0FT4G, 0D0FT5G, 0G0FT4G, 0G0FT4G VERS 03-2008, 0G0FT5G, 0G0FT5G VERS 03-2008, 0N0FT4G, 0N0FT5G, 190FT15G, 190FT42G, 190FT4G, 190FT6G, 1A0FT1G, 1A0FT2G, 1A0FT3G, 1A0FT4G, 1A0FT6G, 1B0FT4G, 1B0FT6G, 1D0FT1G, 1D0FT2G, 1D0FT3G, 1D0FT4G, 1D0FT6G, 1G0FT4G, 1G0FT4G VERS 03-2008, 1G0FT6G, 1G0FT6G VERS 03-2008, 1N0FT4G, 1N0FT6G, 6040560, 6042490, 6042500, 6043200

ANGELO PO Kitchen gas 1N1FAAG, 1N1FAAGV, 1N1FABGV, 1N1FADG, 1N1FADGV, 1N1FAG, 1N1FAGV, 291FAGF, 2N1FAAGV, 2N1FAGF, 2N1FAGV

ANGELO PO Solid top range gas 1N1TPG, 1N1TPGV, 2N1TPBG, 2N1TPBGV

SILKO Bratt pan electric SE74CRM, SE74IRM, SE84CRA, SE84IRA, SE94CRM, SE94IRM

SILKO Fry top electric CGE7020, CGE7020C, CGE7020R, CGE7021, CGE7021C, CGE7021R, CGE7022, CGE7022C, CGE7022R, CGE7040, CGE7040C, CGE7040LR, CGE7040LRC, CGE7040R, CGE7041, CGE7041C, CGE7041LR, CGE7041LRC, CGE7041R, CGE7042, CGE7042C, CGE7042LR, CGE7042R, CGE7042RC

SILKO Fry top gas CGG7020C, CGG7021C, CGG7040C, CGG7040LRC, CGG7041C, CGG7041LRC

SILKO Kitchen electric CCQ9046, CCQ9046V

SILKO Kitchen gas CCG70662, CCG9046-1, CCG90662, CCG90662-1, CCG90663-1

SILKO Oven under cooktop electric CCG7046, CCG70662P, CCG70663, CE84EPQ, CG84EPS

SILKO Pizza oven electric CFS9066

SILKO Pot stove electric CCT72662

SILKO Pot stove gas CCG7046P, CCG9046, CCG9046P, CCG90662P, CCG90663

SILKO Solid top range gas CTT9046

ZANUSSI Bratt pan electric HBR/E800 (201517), HBR/E805 (201518), HBR/E801 (201519), HBR/E806 (201520), HBR/E810 (201521), HBR/E815 (201522), HBR/E811 (201523), HBR/E816 (201524), HBR/E800UK (201533), HBR/E800 (201564), HBR/E805 (201565), HBR/E810 (201566), HBR/E815 (201567), HBR/E811 (201568), HBR/E816 (201569), HBR/E800UK (201571), HBR/E800 (211517), ZBR/E805 (211518), BR/E806 (211520), ZBR/E810 (211521), ZBR/E815 (211522), ZBR/E811 (211523), ZBR/E816 (211524), ZBR/E800UK (211533), ZBR/E800 (211564), ZBR/E805 (211565), ZBR/E810 (211566), ZBR/E815 (211567), ZBR/E811 (211568), ZBR/E816 (211569), ZBR/G800UK (211570), ZBR/E800UK (211571), ABR/E800 (221517), ABR/E805 (221518), ABR/E801 (221519), ABR/E806 (221520), ABR/E810 (221521), ABR/E815 (221522), ABR/E811 (221523), ABR/E816 (221524), ABR/E800UK (221533), ABR/E800 (221564), ABR/E805 (221565), ABR/E810 (221566), ABR/E815 (221567), ABR/E811 (221568), ABR/E816 (221569), ABR/E800UK (221571), OBR/E800UK (221576), HBR/E801 (295022), HBR/E803 (295025), HBR/E804 (295027), HBR/E805UK (295028), HBR/E1003 (295033), HBR/E1013 (295061), HBR/E801 (2KB53B), HBR/E803 (2KB54B), HBR/E804 (2KB55B), HBR/E1003 (2KB57B), HBR/E1013 (2KB58B), E7BREHMNF0 (371107), E7BREHSNF0 (371108), Z7BREHMNF0 (372107), Z7BREHSNF0

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

(372108), A7BREHMNF0 (373107), A7BREHSNF0 (373108)

ZANUSSI Bratt pan gas MBR/G701 (161608), MBR/G706 (161609), MBR/G701UK (161610), MBR/G751 (161611), MBR/G756 (161612), RBR/G2FM (168030), RBR/G2IM (168031), RBK/G2FM (168032), XBR/G2FM (168430), XBR/G2IM (168431), XBK/G2FM (168432), JBR/G2FM (168630), MBR/G2FM (168830), MBR/G2IM (168831), MBK/G2FM (168832), 7BRG60 (171757), 7BRG60X (171758), RBR/G701UK (171759), RBR/G751 (171760), RBR/G756 (171761), XBR/G701 (174760), M70GBP (174761), XBR/G701UK (174762), XBR/G751 (174763), XBR/G756 (174764), CBR/G700 (174765), PBR/G2FM (178098), PBR/G2IM (178099), OBR/G2FM (178398), OBR/G2IM (178399), TBR/G2FM (178698), TBR/G2IM (178699), HBR/G800 (201501), HBR/G805 (201502), HBR/G801 (201503), HBR/G806 (201504), HBR/G810 (201505), HBR/G815 (201506), HBR/G811 (201507), HBR/G816 (201508), HBR/G800D (201509), HBR/G805D (201510), HBR/G801D (201511), HBR/G806D (201512), HBR/G810D (201513), HBR/G815D (201514), HBR/G811D (201515), HBR/G816D (201516), HBR/G800NL (201525), HBR/G805NL (201526), HBR/G810NL (201527), HBR/G800UK (201532), HBR/G800 (201558), HBR/G805 (201559), HBR/G810 (201560), HBR/G815 (201561), HBR/G811 (201562), HBR/G816 (201563), HBR/G800UK (201570), HBR/G821UK (201574), ZBR/G800 (211501), ZBR/G805 (211502), ZBR/G801 (211503), ZBR/G806 (211504), ZBR/G810 (211505), ZBR/G815 (211506), ZBR/G811 (211507), ZBR/G816 (211508), ZBR/G800D (211509), ZBR/G805D (211510), ZBR/G801D (211511), ZBR/G806D (211512), ZBR/G810D (211513), ZBR/G815D (211514), ZBR/G811D (211515), ZBR/G816D (211516), ZBR/G800UK (211532), ZBR/G821 (211556), ZBR/G826 (211557), ZBR/G800 (211558), ZBR/G805 (211559), ZBR/G810 (211560), ZBR/G815 (211561), ZBR/G811 (211562), ZBR/G816 (211563), ABR/G800 (221501), ABR/G805 (221502), ABR/G801 (221503), ABR/G806 (221504), ABR/G810 (221505), ABR/G815 (221506), ABR/G811 (221507), ABR/G816 (221508), ABR/G800D (221509), ABR/G805D (221510), ABR/G801D (221511), ABR/G806D (221512), ABR/G810D (221513), ABR/G815D (221514), ABR/G811D (221515), ABR/G816D (221516), ABR/G805NL (221526), ABR/G800 (221558), ABR/G805 (221559), ABR/G810 (221560), ABR/G815 (221561), ABR/G811 (221562), ABR/G816 (221563), OBR/G800UK (221575), HBR/G803 (295003), HBR/G804 (295004), HBR/G803 (295006), HBR/G804 (295008), HBR/G803 (295009), HBR/G805 (295012), HBR/G1003 (295013), HBR/G1003 (295014), HBR/G1004 (295018), HBR/G803 (295051), HBR/G804 (295052), HBR/G1013 (295057), HBR/G803 (2KB03B), HBR/G804 (2KB04B), HBR/G1003 (2KB07B), HBR/G1013 (2KB08B), E7BRGHMNF0 (371103), E7BRGHSNF0 (371104), E7BRGHMNF0 (371180), E7BRGHDNF0 (371181), Z7BRGHMNF0 (372103), Z7BRGHSNF0 (372104), Z7BRGHMNF0 (372180), Z7BRGHDNF0 (372181), A7BRGHMNF0 (373103), A7BRGHSNF0 (373104), A7BRGHMNF0 (373180), A7BRGHDNF0 (373181)

ZANUSSI Convection oven FCFG10160H (240221), FCF/G101/1 (240261), ECFG201-T (260629), ECFG202-T (260644), ACFG10160H (697311), NULL (697500), RCF101G (697502), RCF201G (697504), RCFG202 (697516)
ZANUSSI Convection oven electric FCF/E3 (240270), FCF/E2 (240800), FCF/E2D (240801), FCF/E2UK (240825), FCF/E2 (697660), FCF/E2 (724190), FCF/E2D (770293)

ZANUSSI Convection oven gas NULL (240200), FCFG101/0 (240201), FCFG102-0 (240202), FCFG201-0 (240203), FCFG202-0 (240204), NULL (240222), FCF102GMS (240224), FCF201GMS (240225), NULL (240260), FCFG102-0T (240262), NULL (240263), FCFG101-1J (240264), FCFG102-1J (240265), FCFG101-60 (240269), FCFG6D (241006), FCFG10 (241100), FCFG10D (241105), FCFG10NL (241120), FCFG20 (241200), FCFG20D (241205), FCFG20F (241210), PFCFG20 (241215), FCFG40 (241300), FCFG41 (241301), FCFG40D (241306),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații
Automatizări / Materiale Electrice

FCFG40F (241310), PFCFG40F (241315), FCFG6 (241500), FCFG6F (241510), PFCFG6 (241515), FCFG10J (243204), FCFG10J (243205), FCFG20J (243210), FCFG20J (243212), FCFG40J (243218), FCFG40J (243220), FCFG6J (243226), FCFG6J (243227), FCFG6J (243228), FCFG6J (243229), FCFG10J (243230), FCFG10J (243232), FCFG20J (243234), FCFG20J (243236), FCFG41J (243238), FCFG40J (243240), NULL (260700), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), NULL (260722), ECF101GMS (260723), ECF102GMS (260724), ECF201GMS (260725), FCF/G6 (2FC02B), FCFG101 (2FC03B), FCFG201 (2FC04B), FCFG202 (2FC05B), FCFC202 (2FC07B), NULL (697300), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), JCF/G6-1 (697360), JCF/G101/1-1 (697361), JCF/G102/1-1 (697362), JCF/G6-2 (697390), JCF/G101/1-2 (697391), JCF/G102/1-2 (697392), NULL (697506), RCF10GK (697508), FF/G6 (697690), FF/G10 (697710), FF/G20 (697730), FF/G40 (697740), NCF/G6-0 (724050), NCF/G101/1 (724051), NCF/G102/1 (724052), COCO10G (724206), COCO20G (724212), COCO6G (724222), 4236N (724236), COCVE423AF (724302), ZOFCF/G10D (770334), ZOFCF/G6D (770345), ZOFCF/G20D (770347), ZCF/G6-0 (775100), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104)
ZANUSSI Fry top electric DR/CCE (601596), DR/CUK (601597), DR/LCE (601599), DR/LUK (601600), ER/LUSA (601601)
ZANUSSI Fry top gas HR/G420D (200541), HR/G820D (200542), HR/G420 (200565), HR/G820 (200566), HR/G821 (200570), ZR/G420 (210565), ZR/G820 (210566), ZR/G821 (210570), ZR/G413 (211519), AR/G420 (220565), AR/G820 (220566), AR/G821 (220570)

