

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Comutator (selector) 0-6 EGO 43.27232.000 #605.061.060

Fara TVA: 252,10 Lei

Pret cu TVA: 300,00Lei

Comutator (selector) 0-6 EGO 43.27232.000 #605.061.060

Capacitatea de comutare 32A/250V 25A/400V

Numar poli 1 sau 2 cu 2 faze de la 400V

Semnal de contact

Pozitii de lucru 0-6

Suruburi pentru conexiuni electrice 5 + 4

Montaj cu 2 X suruburi

OFF + 6 Pozitii

Ax standard Ø 6x4,6 mm

Compatibilitate:

LVA 605\_061\_060, 605.061.060

ALPENINOX 300142

ALPENINOX 0A2022

ALPENINOX 0K4922

ALPENINOX A2022

AMBACH 5060904041

ANGELO PO 32W2920

ALTART 4327232000

BONNET 300010

COMETTO 50002

EGO 43.27232.000, 4327232000

EEVAD TIQ8708

EMMEPI C00214

FOEM 05010076150

FOEM 5010076150

GEV 300106

GEV 300235

I7PS

JUNO 0H6394 231069

JUNO ROED SENKING 231069

JUNO ROED SENKING 231496

KUPPERSBUSCH 183104

LOTUS 537027700



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

MARENO 1937800  
MARENO 21131099  
MALAG 106072  
MBM RTCU800051 RTCU800151  
MKN 203560  
MODULAR 96100000  
MODULAR 961.000.00  
MORICE DE0785  
OMGAS 09  
OMGAS 16520029  
ROSINOX RX94015021  
SAGI 32W2920  
SILKO 0101399  
SILKO 101399  
THIELMANN 141187  
TECNOINOX RCO1482000  
THIRODE 300010  
WHIRLPOOL 481227328239  
ZANUSSI ELECTROLUX 0A2022  
ZANUSSI ELECTROLUX 0K4922  
AMBACH CUISINIERE ELECTRIQUE + FOUR  
JUNO ROED SENKING 14003(1986 09 01 )  
JUNO ROED SENKING 14023(1986 09 01 )  
JUNO ROED SENKING 14043(1986 09 01 )  
JUNO ROED SENKING 14053(1986 09 01 )  
JUNO ROED SENKING 14083(1986 09 01 )  
JUNO ROED SENKING 14103(1986 09 01 )  
JUNO ROED SENKING 14113(1986 09 01 )  
JUNO ROED SENKING 14133(1986 09 01 )  
JUNO ROED SENKING 14143(1986 09 01 )  
JUNO ROED SENKING 14163(1986 09 01 )  
JUNO ROED SENKING 14173(1986 09 01 )  
JUNO ROED SENKING 14183(1986 09 01 )  
JUNO ROED SENKING 16003(1986 09 01 )  
JUNO ROED SENKING 16023(1986 09 01 )  
JUNO ROED SENKING 16043(1986 09 01 )  
JUNO ROED SENKING 16103(1986 09 01 )  
JUNO ROED SENKING 16143(1986 09 01 )  
JUNO ROED SENKING 472073(1982 06 01 )



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

JUNO ROED SENKING 572073(1982 06 01 )  
JUNO ROED SENKING 672073(1982 06 01 )  
JUNO ROED SENKING WEH72073(1982 06 01 )  
AMBACH electric range + oven HEE-81 199107-  
ANGELO-PO electric salamander grills 60SME 19960901-20001010  
ANGELO-PO electric salamander grills 60SME 20001011-20001109  
ANGELO-PO electric salamander grills 60SME 20001011-20010625  
ANGELO-PO electric salamander grills 60SME 20001110-20010625  
ANGELO-PO electric salamander grills 60SME 20010626-20011010  
ANGELO-PO electric salamander grills 60SME 20010626-20020315  
ANGELO-PO electric salamander grills 60SME 20020316-20030608  
ANGELO-PO electric salamander grills 60SME 20030609-20050509  
ANGELO-PO electric salamander grills 60SME 20050510-20050718  
ANGELO-PO electric salamander grills 60SME 20050719-20050925  
ANGELO-PO electric salamander grills 60SME 20050926-20060320  
ANGELO-PO electric salamander grills 60SME 20060321-20070522  
ANGELO-PO electric salamander grills 60SME 20070523-20110404  
ANGELO-PO electric salamander grills 60SME 20110405-  
ELECTROLUX bain marie 580220 01-01-  
ELECTROLUX bain marie 580264 01-01-  
ELECTROLUX bain marie 580265 01-01-04022005  
ELECTROLUX bain marie 580477 01-01-  
ELECTROLUX bain marie 580479 01-01-  
ELECTROLUX bain marie 580484 01-01-04022005  
ELECTROLUX bain marie 580485 01-01-04022005  
ELECTROLUX bain marie 581092 01-01-  
ELECTROLUX bain marie 581093 01-01-  
ELECTROLUX bain marie 581094 01-01-  
ELECTROLUX bain marie 581097 01-01-  
ELECTROLUX bain marie 581099 01-01-  
ELECTROLUX bain marie 581101 01-01-  
ELECTROLUX bain marie 581102 01-01-  
ELECTROLUX bain marie 581124 01-01-04022005  
ELECTROLUX bain marie 581125 01-01-  
ELECTROLUX bain marie 581126 01-01-04022005  
ELECTROLUX bain marie 581127 01-01-04022005  
ELECTROLUX bain marie 581128 01-01-04022005  
ELECTROLUX bain marie 581129 01-01-04022005  
ELECTROLUX bain marie 581130 01-01-



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

ELECTROLUX bain marie 581131 01-01-04022005  
ELECTROLUX bain marie 581132 01-01-04022005  
ELECTROLUX bain marie 581133 01-01-04022005  
ELECTROLUX bain marie 581134 01-01-04022005  
ELECTROLUX bain marie 581135 01-01-04022005  
ELECTROLUX bain marie 581136 01-01-04022005  
ELECTROLUX bain marie 581137 01-01-04022005  
ELECTROLUX bain marie 581138 01-01-04022005  
ELECTROLUX bain marie 581139 01-01-04022005  
ELECTROLUX bain marie 581140 01-01-04022005  
ELECTROLUX bain marie 581141 01-01-04022005  
ELECTROLUX bain marie 581142 01-01-04022005  
ELECTROLUX bain marie 581143 01-01-04022005  
ELECTROLUX bain marie 581144 01-01-04022005  
ELECTROLUX bain marie 581145 01-01-04022005  
ELECTROLUX bain marie 581146 01-01-04022005  
ELECTROLUX bain marie 581147 01-01-04022005  
ELECTROLUX bain marie 581693 01-01-  
ELECTROLUX bain marie 592011 01-01-  
ELECTROLUX bain marie 592021 01-01-  
ELECTROLUX bain marie 592031 01-01-  
ELECTROLUX bain marie 592401 01-01-  
ELECTROLUX bain marie 592402 01-01-  
ELECTROLUX bain marie 592403 01-01-  
ELECTROLUX bain marie 592404 01-01-  
ELECTROLUX bain marie 592411 01-01-  
ELECTROLUX bain marie 592413 01-01-  
ELECTROLUX bain marie 592421 01-01-04022005  
ELECTROLUX bain marie 592422 01-01-04022005  
ELECTROLUX bain marie 592423 01-01-04022005  
ELECTROLUX bain marie 592424 01-01-04022005  
ELECTROLUX bain marie 592441 01-01-  
ELECTROLUX bain marie 592442 01-01-04022005  
ELECTROLUX bain marie 592443 01-01-  
ELECTROLUX bain marie 592444 01-01-04022005  
ELECTROLUX bain marie 592451 01-01-  
ELECTROLUX bain marie 592453 01-01-  
ELECTROLUX bain marie 592461 01-01-04022005  
ELECTROLUX bain marie 592462 01-01-04022005



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

ELECTROLUX bain marie 592463 01-01-04022005  
ELECTROLUX bain marie 592464 01-01-04022005  
ELECTROLUX electric range + oven 580408 01-01-  
ELECTROLUX electric range + oven 580434 01-01-  
ELECTROLUX electric grill 580238 01-01-04022005  
ELECTROLUX electric grill 581148 01-01-04022005  
ELECTROLUX electric grill 581149 01-01-  
ELECTROLUX electric grill 581150 01-01-04022005  
ELECTROLUX electric grill 581151 01-01-  
ELECTROLUX electric grill 581153 01-01-04022005  
ELECTROLUX electric grill 581154 01-01-04022005  
ELECTROLUX electric grill 581155 01-01-04022005  
ELECTROLUX electric grill 581156 01-01-04022005  
ELECTROLUX electric grill 581157 01-01-04022005  
ELECTROLUX electric grill 581158 01-01-04022005  
ELECTROLUX electric grill 581159 01-01-04022005  
ELECTROLUX electric grill 581160 01-01-04022005  
ELECTROLUX electric grill 581600 01-01-04022005  
ELECTROLUX electric grill 592321 01-01-  
ELECTROLUX electric grill 592322 01-01-  
ELECTROLUX electric grill 592323 01-01-04022005  
ELECTROLUX electric grill 592324 01-01-04022005  
ELECTROLUX electric grill 592331 01-01-  
ELECTROLUX electric grill 592341 01-01-  
ELECTROLUX electric grill 592342 01-01-  
ELECTROLUX electric grill 592343 01-01-04022005  
ELECTROLUX electric grill 592344 01-01-04022005  
ELECTROLUX electric grill 592351 01-01-  
ELECTROLUX hot plate MOL1604  
ELECTROLUX range 581076 01-01-04022005  
ELECTROLUX range 581077 01-01-04022005  
ELECTROLUX range 581095 01-01-  
ELECTROLUX range 581594 01-01-04022005  
ELECTROLUX range 581595 01-01-04022005  
ELECTROLUX range 581596 01-01-  
ELECTROLUX range 581597 01-01-  
ELECTROLUX range 582381 01022003-  
ELECTROLUX range 582382 01022003-  
ELECTROLUX range 582383 01022003-



*magazin online HORECA*  
**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

ELECTROLUX range 582384 01022003-  
ELECTROLUX range 582385 01022003-  
ELECTROLUX range 582386 01022003-  
ELECTROLUX range 582387 01022003-  
ELECTROLUX range 582388 01022003-  
ELECTROLUX range 582389 01022003-  
ELECTROLUX range 582390 01022003-  
ELECTROLUX range 582391 01022003-  
ELECTROLUX range 582392 01022003-  
ELECTROLUX range 582393 01022003-  
ELECTROLUX range 582394 01022003-  
ELECTROLUX range 582395 01022003-  
ELECTROLUX range 582396 01022003-  
ELECTROLUX range 582397 01022003-  
ELECTROLUX range 582398 01022003-  
ELECTROLUX range 582399 01022003-  
ELECTROLUX range 582400 01022003-  
ELECTROLUX range 582401 01022003-  
ELECTROLUX range 582402 01022003-  
ELECTROLUX range 582403 01022003-  
ELECTROLUX range 582404 01022003-  
ELECTROLUX range 582521 26012004-  
ELECTROLUX range 582522 26012004-  
ELECTROLUX range 582523 26012004-  
ELECTROLUX range 591521 01-01-04022005  
ELECTROLUX range 591526 01-01-04022005  
ELECTROLUX range 591532 01-01-04022005  
ELECTROLUX range 591543 01-01-04022005  
ELECTROLUX range 591561 01-01-04022005  
ELECTROLUX range 591564 01-01-04022005  
ELECTROLUX range 591568 01-01-04022005  
ELECTROLUX range 591603 01-01-04022005  
ELECTROLUX range 591605 01-01-04022005  
ELECTROLUX range 591612 01-01-04022005  
ELECTROLUX range 591625 01-01-04022005  
ELECTROLUX range 591644 01-01-04022005  
ELECTROLUX range 591645 01-01-04022005  
ELECTROLUX range 592041 01-01-  
ELECTROLUX range 592042 01-01-



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

ELECTROLUX range 592043 01-01-04022005  
ELECTROLUX range 592044 01-01-04022005  
ELECTROLUX range 592048 01-01-  
ELECTROLUX range 592049 01-01-  
ELECTROLUX range 592050 01-01-04022005  
ELECTROLUX range 592053 01-01-04022005  
ELECTROLUX range 592061 01-01-  
ELECTROLUX range 592062 01-01-  
ELECTROLUX range 592063 01-01-04022005  
ELECTROLUX range 592064 01-01-04022005  
ELECTROLUX range 592067 01-01-04022005  
ELECTROLUX range 592081 01-01-04022005  
ELECTROLUX range 592082 01-01-04022005  
ELECTROLUX range 592083 01-01-04022005  
ELECTROLUX range 592251 01-01-  
ELECTROLUX range 592271 01-01-  
ELECTROLUX range 592272 01-01-  
ELECTROLUX range 592275 01-01-  
ELECTROLUX range 592276 01-01-  
ELECTROLUX range 592279 01-01-04022005  
ELECTROLUX range 592601 01-01-  
ELECTROLUX range 592602 01-01-  
ELECTROLUX range 592603 01-01-04022005  
ELECTROLUX range 592604 01-01-04022005  
ELECTROLUX range 592605 01-01-  
ELECTROLUX range 592606 01-01-  
ELECTROLUX range 592611 01-01-  
ELECTROLUX range 592612 01-01-  
ELECTROLUX range 592613 01-01-04022005  
ELECTROLUX range 592614 01-01-04022005  
ELECTROLUX range 592615 01-01-  
ELECTROLUX range 592616 01-01-  
ELECTROLUX range 592651 01-01-  
ELECTROLUX range 592652 01-01-  
ELECTROLUX range 592653 01-01-  
ELECTROLUX range 592654 01-01-04022005  
ELECTROLUX range 592655 01-01-  
ELECTROLUX range 592656 01-01-  
ELECTROLUX range 592659 01-01-04022005



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

ELECTROLUX range 592671 01-01-04022005  
ELECTROLUX range 592672 01-01-04022005  
ELECTROLUX range 592673 01-01-04022005  
ELECTROLUX range 592675 01-01-  
ELECTROLUX range 592676 01-01-  
ELECTROLUX range 592871 01-01-04022005  
ELECTROLUX range 592872 01-01-04022005  
ELECTROLUX range 592873 01-01-04022005  
ELECTROLUX range 592875 01-01-04022005  
ELECTROLUX range 592876 01-01-04022005  
ELECTROLUX range 592877 01-01-04022005  
ELECTROLUX range 592879 01-01-  
ELECTROLUX range 592881 01-01-04022005  
ELECTROLUX range 592891 01-01-04022005  
ELECTROLUX range 592892 01-01-04022005  
ELECTROLUX range 592893 01-01-04022005  
ELECTROLUX range 592894 01-01-04022005  
ELECTROLUX range 592895 01-01-04022005  
ELECTROLUX range 592896 01-01-04022005  
ELECTROLUX range 592897 01-01-04022005  
ELECTROLUX range 592898 01-01-04022005  
ELECTROLUX range 592901 01-01-04022005  
ELECTROLUX range 592902 01-01-04022005  
ELECTROLUX range 592903 01-01-04022005  
ELECTROLUX range 592904 01-01-04022005  
ELECTROLUX range 592905 01-01-04022005  
ELECTROLUX range 592911 01-01-04022005  
ELECTROLUX range 592921 01-01-04022005  
ELECTROLUX range 592931 01-01-04022005  
ELECTROLUX range 592941 01-01-04022005  
ELECTROLUX range 592951 01-01-04022005  
ELECTROLUX range 592961 01-01-04022005  
ELECTROLUX range 592962 01-01-04022005  
ELECTROLUX range 592971 01-01-04022005  
ELECTROLUX range 592972 01-01-04022005  
ELECTROLUX range 593901 01-01-04022005  
ELECTROLUX range 593902 01-01-04022005  
ELECTROLUX range 593911 01-01-04022005  
ELECTROLUX range 593912 01-01-04022005





*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

ELECTROLUX range 593931 01-01-04022005  
ELECTROLUX range 593932 01-01-04022005  
ELECTROLUX range 593933 01-01-04022005  
ELECTROLUX range 593941 01-01-04022005  
ELECTROLUX range 593942 01-01-04022005  
ELECTROLUX range 593943 01-01-04022005  
ELECTROLUX range 594901 01-01-04022005  
ELECTROLUX range 594902 01-01-04022005  
KUPPERSBUSCH electric range EHO101  
KUPPERSBUSCH electric range EHO111  
LINCAR electric range G0100 200512-  
LINCAR electric range G0102 200512-  
LINCAR electric range G0104 200511-  
LINCAR electric range G0105 200512-  
LINCAR electric range G0107 200512-  
LINCAR electric range G0110 200512-  
LINCAR electric range G0112 200512-  
LINCAR electric range G0114 200511-  
LINCAR electric range G0115 200512-  
LINCAR electric range G0117 200511-  
LINCAR electric range G0700 201405-  
LINCAR electric range G0702 201405-  
LINCAR electric range G0703 201405-  
LINCAR electric range G0704 201405-  
LINCAR electric range G0705 201405-  
LOTUS pyroceram range + electric oven CF4-98ET -201112  
LOTUS pyroceram range + electric oven CF4-98ET 201201-  
LOTUS pyroceram range + electric oven CF4-98ETX 201201-  
LOTUS pyroceram range + electric oven CF6-912ET  
LOTUS pyroceram range + electric oven CF8-916ET -201112  
LOTUS pyroceram range + electric oven CF8-916ET 201201-  
LOTUS pyroceram range + electric oven CFQ4-98ET -201112  
LOTUS pyroceram range + electric oven CFQ4-98ET 201201-  
LOTUS pyroceram range + electric oven CFQ4-98ETX 201201-  
LOTUS pyroceram range + electric oven CFQ6-912ET  
LOTUS pyroceram range + electric oven CFQ8-916ET 201201-  
LOTUS pyroceram range + electric oven CFQ9-916ET  
LOTUS pyroceram range + electric oven CFV4-98ET 201201-  
LOTUS pyroceram range + electric oven CFV6-912ET 201201-



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

LOTUS pyroceram range + electric oven CFVQ4-98ET 201201-  
LOTUS pyroceram range + electric oven CFVQ6-912ET 201201-  
LOTUS electric range CF6-912ETV -200601  
LOTUS electric range CF6-912ETV 200602-  
LOTUS electric range CF6-912ETV 201201-  
LOTUS electric range CF6-912ETVX -200601  
LOTUS electric range CF6-912ETVX 200602-  
LOTUS electric range CF6-912ETVX 201201-  
LOTUS electric range CF8-916ETV -200601  
LOTUS electric range CF8-916ETV 200602-  
LOTUS electric range CF8-916ETV 201201-  
LOTUS electric range CFQ6-912ETV -200601  
LOTUS electric range CFQ6-912ETV 200602-  
LOTUS electric range CFQ6-912ETV 201201-  
LOTUS electric range CFQ6-912ETVX -200601  
LOTUS electric range CFQ6-912ETVX 200602-  
LOTUS electric range CFQ6-912ETVX 201201-  
LOTUS electric range CFQ8-916ETV -200601  
LOTUS electric range CFQ8-916ETV 200602-  
LOTUS electric range CFQ8-916ETV 201201-  
LOTUS electric range CFV6-912ETV 201201-  
LOTUS electric range CFVQ6-912ETV 201201-  
LOTUS electric range PC-912ET -201112  
LOTUS electric range PC-912ET 201201-  
LOTUS electric range PC-912ETX 201201-  
LOTUS electric range PC-916ET -201112  
LOTUS electric range PC-916ET 201201-  
LOTUS electric range PC-916ETX 201201-  
LOTUS electric range PC-94ET -201112  
LOTUS electric range PC-94ET 201201-  
LOTUS electric range PC-94ETX 201201-  
LOTUS electric range PC-98ET -201112  
LOTUS electric range PC-98ET 201201-  
LOTUS electric range PC-98ETX 201201-  
LOTUS electric range PCQ-912ET -201112  
LOTUS electric range PCQ-912ET 201201-  
LOTUS electric range PCQ-916ET -201112  
LOTUS electric range PCQ-916ET 201201-  
LOTUS electric range PCQ-94ET -201112



*magazin online HORECA*  
**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

LOTUS electric range PCQ-94ET 201201-  
LOTUS electric range PCQ-98ET -201112  
LOTUS electric range PCQ-98ET 201201-  
LOTUS electric range PCQD-84ET  
LOTUS electric range PCQD-88ET  
LOTUS electric range PCQT-912ET -201112  
LOTUS electric range PCQT-912ET 201201-  
LOTUS electric range PCQT-916ET -201112  
LOTUS electric range PCQT-916ET 201201-  
LOTUS electric range PCQT-94ET -201112  
LOTUS electric range PCQT-94ET 201201-  
LOTUS electric range PCQT-94ETX 201201-  
LOTUS electric range PCQT-98ET -201112  
LOTUS electric range PCQT-98ET 201201-  
LOTUS electric range PCQT-98ETX 201201-  
LOTUS electric range PCT-912ET -201112  
LOTUS electric range PCT-912ET 201201-  
LOTUS electric range PCT-912ETX 201201-  
LOTUS electric range PCT-916ET -201112  
LOTUS electric range PCT-916ET 201201-  
LOTUS electric range PCT-916ETX 201201-  
LOTUS electric range PCT-94ET -201112  
LOTUS electric range PCT-94ET 201201-  
LOTUS electric range PCT-94ETX 201201-  
LOTUS electric range PCT-98ET -201112  
LOTUS electric range PCT-98ET 201201-  
LOTUS electric range PCT-98ETX 201201-  
MARENO electric oven C7FE8E 200806-  
MARENO electric oven C7FE8EC 200806-  
MARENO electric oven C9FE8E 200806-  
MARENO electric oven C9FE8EC 200806-  
MARENO electric range C74EC 200208-  
MARENO electric range C78EC 200208-  
MARENO electric range C78EQC 200208-  
MARENO electric range C7FE8EQ 200208-  
MARENO electric range C94E 200208-  
MARENO electric range C94EC 200208-  
MARENO electric range C98E 200208-  
MARENO electric range C98EC 200208-

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

MARENO electric range NC94E 200709-  
MARENO electric range NC94E2 200709-  
MARENO electric range NC98E 200709-  
MARENO electric range NC98E2 200709-  
MARENO electric range + oven NC9FE8E 200709-  
MARENO electric range + oven NC9FE8E2 200709-  
SILKO electric range CCQ9020 200112-  
SILKO electric range CCQ9021 200112-  
SILKO electric range CCQ9022 200112-  
SILKO electric range CCQ9040 200112-  
SILKO electric range CCQ9041 200112-  
SILKO electric range CCQ9042 200112-  
SILKO electric range CE82APQ 200604-  
SILKO electric range CE82GPQ 200207-  
SILKO electric range CE82GPQ 200604-  
SILKO electric range CE82TPQ 200604-  
SILKO electric range CE84APQ 200604-  
SILKO electric range CE84EPQ 200604-  
SILKO electric range CE84GPQ 200207-  
SILKO electric range CE84GPQ 200604-  
SILKO electric range CE84TPQ 200604-  
SILKO electric range CE92APQ 200604-  
SILKO electric range CE92GPQ 200604-  
SILKO electric range CE92TPQ 200604-  
SILKO electric range CE94APQ 200604-  
SILKO electric range CE94EPQ 200604-  
SILKO electric range CE94GPQ 200604-  
SILKO electric range CE94TPQ 200604-  
SILKO electric range + oven CCQ9046 200112-  
SILKO electric range + oven CE84EPQ 200207-

