



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Electrovalva apa 230V model ELBI Tip 329 pozitie 180° #3120005

Fara TVA: 46,22 Lei

Pret cu TVA: 55,00Lei

Electrovalva apa 230V model ELBI Tip 329 pozitie 180° #3120005

220/240V 50/60Hz

Temperatura maxima 90°C

Intrare 3/4"

Iesire ø 10.5 mm

Compatibil cu:

20006 ADLER

20007 ADLER

10703 ALBA

J055132 ALPENINOX

0780048894 ALPENINOX

0780055132 ALPENINOX

0780047756 ALPENINOX

0780086014 ALPENINOX

0696611800 ALPENINOX

0696609800 ALPENINOX

0696801000 ALPENINOX

0696801001 ALPENINOX

055132 ALPENINOX

047756 ALPENINOX

048894 ALPENINOX

086014 ALPENINOX

0L3335 ALPENINOX

481955112 ALPENINOX

30000985 ALPENINOX

65010500 ALPENINOX

71047756 ALPENINOX

7021047756 ALPENINOX

7021048894 ALPENINOX

71048894 ALPENINOX

50047756007 ALPENINOX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

50055132000 ALPENINOX

7021055132 ALPENINOX

71055132 ALPENINOX

71086014 ALPENINOX

554055132 ALPENINOX

554048894 ALPENINOX

554047756 ALPENINOX

80700808 ALPENINOX

240011 AMIKA

240018 AMIKA

240016 AMIKA

33D2310 ANGELO PO

33D3260 ANGELO PO

02026 ANIMO

120800009 BAKE OFF

Z1ID002 BARLINE

650105.00 BARLINE

650105.74 BARLINE

0240011 BARTSCHER

23116200 BERTO'S

0282 BERTO'S

120800009 BEST FOR

E10703 BOBECK

2001650H BONNET

2001651H BONNET

144937 BONNET

314334 BONNET

6.016.001.001 BRAVILOR BONAMAT

6.016.001.017 BRAVILOR BONAMAT

6.016.001.078 BRAVILOR BONAMAT

90422130 CANDY

DEV3S16 COLGED

/ELF120021 COLGED

240011 COLGED

240016 COLGED

240018 COLGED

240005 COLGED

RTFOC00022 COLGED

REB240011 COLGED



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

5001059 CONVOTHERM  
COOKMAX  
23120021 DESCO  
10703 DESCO  
AZ005-00 DESCO  
240011 DEXION  
240016 DEXION  
240018 DEXION  
RTFOC00022 DEXION  
10703 DIHR  
223087 EBERHARDT  
J055132 ELECTROLUX PROFESSIONAL  
0780048894 ELECTROLUX PROFESSIONAL  
0780055132 ELECTROLUX PROFESSIONAL  
0780047756 ELECTROLUX PROFESSIONAL  
0780086014 ELECTROLUX PROFESSIONAL  
0696611800 ELECTROLUX PROFESSIONAL  
0696609800 ELECTROLUX PROFESSIONAL  
0696801000 ELECTROLUX PROFESSIONAL  
0696801001 ELECTROLUX PROFESSIONAL  
055132 ELECTROLUX PROFESSIONAL  
047756 ELECTROLUX PROFESSIONAL  
048894 ELECTROLUX PROFESSIONAL  
086014 ELECTROLUX PROFESSIONAL  
0L3335 ELECTROLUX PROFESSIONAL  
481955112 ELECTROLUX PROFESSIONAL  
30000985 ELECTROLUX PROFESSIONAL  
65010500 ELECTROLUX PROFESSIONAL  
71047756 ELECTROLUX PROFESSIONAL  
7021047756 ELECTROLUX PROFESSIONAL  
7021048894 ELECTROLUX PROFESSIONAL  
71048894 ELECTROLUX PROFESSIONAL  
50047756007 ELECTROLUX PROFESSIONAL  
50055132000 ELECTROLUX PROFESSIONAL  
7021055132 ELECTROLUX PROFESSIONAL  
71055132 ELECTROLUX PROFESSIONAL  
71086014 ELECTROLUX PROFESSIONAL  
554055132 ELECTROLUX PROFESSIONAL  
554048894 ELECTROLUX PROFESSIONAL



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

554047756 ELECTROLUX PROFESSIONAL  
80700808 ELECTROLUX PROFESSIONAL  
DEV3S16 ELETTROBAR  
/ELF120021 ELETTROBAR  
240005 ELETTROBAR  
240011 ELETTROBAR  
240018 ELETTROBAR  
240016 ELETTROBAR  
RTFOC00022 ELETTROBAR  
REB240011 ELETTROBAR  
23120021 ELFRAMO  
23120021 EMMEPI  
902390 EMMEPI  
809327 EMMEPI  
809335 EMMEPI  
Z701135 EPMS  
342001 EPMS  
342034 EPMS  
EPMS  
53943410240 ERRE 2  
240011 EUROWASH  
240016 EUROWASH  
240018 EUROWASH  
0002089 FLONASA  
0000028 FLONASA  
0282 FOINOX  
ELE1V GARBIN  
53943410240 GICO  
SD902390 GIGA  
D240011 GIGA  
041035H EMERSON  
ELVA1V HILTA  
240011 HOBART  
240016 HOBART  
240018 HOBART  
00-371450-021 HOBART  
00-775742-002 HOBART  
371450-21 HOBART  
775742-2 HOBART



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

RTFOC00022 HOBART  
26629 HOONVED  
90422130 HOOVER  
90422130 IBERNA  
CEEV1 IME OMNIWASH  
C00375206 INDESIT  
483286008141 INDESIT  
C00337304 INDESIT  
C00194396 INDESIT  
C3057-00 INOXTREND  
AZ005-00 INOXTREND  
2017007 JEMI  
JORDAO  
90422130 KELVINATOR  
23120021 KOMEL  
62-240011 KREFFT  
10703 KROMO  
103370 KRUPPS  
50102860 LAINOX  
R65110010 LAINOX  
0300025 LAMBER  
537012600 LOTUS  
462.000.00 MARELS  
462.010.00 MARELS  
2709000 MARENO  
MA2709000 MARENO  
DEV3S16 MBM  
/ELF120021 MBM  
23120021 MBM  
240005 MBM  
240011 MBM  
240016 MBM  
240018 MBM  
REB240011 MBM  
RTFOC00022 MBM  
10703 METOS  
3103620 METOS  
BN3103620 METOS  
462.000.00 MODULAR



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

462.010.00 MODULAR  
18010938 NUOVA SIMONELLI  
3103620 OLIS  
BN3103620 OLIS  
90422130 OTSEIN  
90422130 PHILCO  
30600 PROJECT SYSTEMS  
65240011 RANCILIO  
1230013 REPAGAS  
51100004 RHIMA  
90422130 ROSIERES  
33D2310 SAGI  
33D3260 SAGI  
23120021 SAMMIC  
Z1ID002 SCOTSMAN  
650105.00 SCOTSMAN  
650105.74 SCOTSMAN  
902390 SILANOS  
2709000 SILKO  
Z1ID002 SIMAG  
650105.00 SIMAG  
650105.74 SIMAG  
CEEV1 SO.WE.BO.  
843101 TEIKOS  
2001650H THIRODE  
2001651H THIRODE  
144937 THIRODE  
314334 THIRODE  
483286008141 WHIRLPOOL  
481981728265 WHIRLPOOL  
481981729329 WHIRLPOOL  
481981729013 WHIRLPOOL  
481981729022 WHIRLPOOL  
240011 WOLK  
240016 WOLK  
240018 WOLK  
J055132 ZANUSSI  
0780048894 ZANUSSI  
0780086014 ZANUSSI



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

0780047756 ZANUSSI

0780055132 ZANUSSI

0696611800 ZANUSSI

0696609800 ZANUSSI

0696801000 ZANUSSI

0696801001 ZANUSSI

055132 ZANUSSI

047756 ZANUSSI

048894 ZANUSSI

086014 ZANUSSI

0L3335 ZANUSSI

71047756 ZANUSSI

65010500 ZANUSSI

481955112 ZANUSSI

30000985 ZANUSSI

7021048894 ZANUSSI

7021047756 ZANUSSI

71048894 ZANUSSI

50047756007 ZANUSSI

50055132000 ZANUSSI

7021055132 ZANUSSI

71055132 ZANUSSI

71086014 ZANUSSI

554048894 ZANUSSI

554047756 ZANUSSI

554055132 ZANUSSI

80700808 ZANUSSI

90422130 ZEROWATT

ADLER Dishwasher A500, CF235, DS1200A, ECO50DP, EVO50DP, L50

ADLER Dishwasher hood type CF1000, CF1000DPPDPB, CF1201A, CF1201A-BLACK, DS1200, EVO1000DP, F1201A

ADLER Glasswasher/Cupwasher CF35, CF35-DP, CF40DL, CF40DP, CF40E, COMPACT EXTRACTIBLE, DL240, DL240DP, ECO35DP, ECO40DP, EVO35DP, EVO40DP, HOME12

AMIKA Dishwasher 3X, 5X, 6X, 6XA, 6XL, 6XLB, 7XL

AMIKA Dishwasher hood type 30X, 40X, 40XH, 41XL, 50X, 60X, 60XL, 61XL, 80X, 8XL, 8XLE, 8XXL

ANGELO PO Dishwasher KD37, KD40, KD60, KD60E, KD60EAT, KD60M, KD60MA, KD60ME, KD60MPS, KD60MPSA, KD60PS, KD60PSD, KD6EATSD, KD85E, KD85EA, KD85EAT, KD85EATS, KD85EPS, KD85EPSA, KN37, KN40, KN50, KN50M, KN50MPS, KN50PSDD, KN80, KN80PS, LC100 VERS 2001, LC130 VERS 2001, LF50, LF50E, LF50E VERS 12-2012, LF50E VERS 2007, LF50EM, LF50EM VERS 12-2012, LF50EMPS



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

ANGELO PO Dishwasher hood type LC100, LC130, LC80

ANGELO PO Glasswasher/Cupwasher KD37 VERS 11-2009, KD37PS, KD40 VERS 11-2009, KD40PS, KN35, KN37PS, KN40PS, KN40PSD

ANGELO PO Pan/utensilwashing machines LP202, LP202HC, LP302, LP302HC, LP402, LP402HC, LP402V, LP70, LPG300

ANIMO Filter coffee machine CB1X40L, CB1X40LR, CB1X40R, CB2X40, CB40

ANIMO Thermos WIKI 80N, WIKI 10N, WIKI 20N 3KW, WIKI 20N 6KW, WIKI 40N, WIKI 60, WIKI 60N, WIKI 80N

BAKE OFF Convection oven electric BISTROT 364-05, BISTROT 434, BISTROT 464, BISTROT 464-05, BISTROT 664, CHEF 6T, E4-5, GOURMET 711

BAKE OFF Proving oven LBE16

BARLINE Icemaker BARLINE17105, BARLINE1718, BARLINE1721, BARLINE1725, BARLINE1731, BARLINE1740, BARLINE1745, BARLINE1750, BARLINE1755, BARLINE1775, BARLINE21, BARLINE25, BARLINE31, BARLINE40, BARLINE45, BARLINE50, BARLINE55, BARLINE75

BERTO'S Convection oven electric FC200EA, FC200EB, FPE6TURBO, WAVE12TURBO, WAVE6, WAVE6TURBO, WAVE-E5

BERTO'S Convection oven gas FC100GEP, FC100GM, FC200GA, FC200GB, FC60GEP, FPG12, FPG6, PASTRYEM, PASTRYVIPEMU, WAVG12, WAVG5U, WAVG6

BERTO'S Electric oven FC100EM, FC100EP, WAVE12

CANDY Kitchen gas 39346952 (CFC6604M)

CANDY Washing machine 31054745 (C420), 853764029500 (C420), 31054752 (C422), 853724229020 (C422), 31091630 (CI627T), 37500709 (CT502), 37500691 (CT504), 37500683 (CT513), 37500667 (CT524), 37500675 (CT535), 37500576 (CT546T), 37500584 (CT548T), 37500592 (CT559T), 37500154 (CT703), 37500451 (CT708T), 37500527 (CT714), 37500469 (CT716T), 37500162 (CT725T), 37500444 (CT735T), 37500170 (CT745T), 37500188 (CT908), 37500493 (CT919T), 37500485 (CT922T), 37500519 (CT934), 37500196 (CT946T), 31000946 (CTH1270AA), 37502481 (CTI1023V), 37502473 (CTI1034ES), 37502572 (CTI523), 37502424 (CTI643T), 37504388 (CTI814V), 37502499 (CTI822TV), 37502465 (CTI984ES), 37507340 (CTL103TV), 37507332 (CTL1040), 37504966 (CTS40), 37505211 (CTS60T), A0000373 (DISHWASHERSECTI), A0001884 (DISHWASHERSECTI), A0001885 (DISHWASHERSECTI), A0001887 (DISHWASHERSECTI), A0001888 (DISHWASHERSECTI), A0001889 (DISHWASHERSECTI), A0001890 (DISHWASHERSECTI), A0001891 (DISHWASHERSECTI), A0002388 (DISHWASHERSECTI), 39896006 (LB.CP1000), 39896600 (LB.CP600), 39958343 (LB.CP800), 31085517 (LBACT.101PUK), 31085525 (LBACT.121PUK), 31085616 (LBACT100P-D), 31085301 (LBACT100PLN), 31085632 (LBACTIVA100), 31085608 (LBACTIVA100P), 31086200 (LBACTIVA106P), 31086218 (LBACTIVA126P), 31089626 (LBACTIVA50), 31098007 (LBACTIVA64SL), 31086002 (LBACTIVA86P), 31085624 (LBACTIVA90PL), 31093529 (LBAQUA1000ES), 31056583 (LBAQUA1200ES), 31043920 (LBAQUAV.6), 31042781 (LBAQUAV.8), 31066673 (LBAQUAVI10ES), 39930086 (LBCH630), 31048820 (LBCHIARA4XT), 31033772 (LBCHIARA51XT), 31043946 (LBCHIARA5XT), 31043953 (LBCHIARA6XT), 31042807 (LBCHIARA81AQ), 31066202 (LBCI1006ES), 31066657 (LBCI1008ES), 31066665 (LBCI1009ES), 31071319 (LBCI1204ES), 31071632 (LBCI1204ES), 31048887 (LBCI426XT), 31094626 (LBCI438T), 31048895 (LBCI459XT), 31048853 (LBCI487XT), 31048838 (LBCI496XT), 31051717 (LBCI5130XT), 31091614 (LBCI537T), 31043961





magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(LBCI626XTIT), 31091630 (LBCI627T), 31043995 (LBCI658XT), 31092604 (LBCI813T), 31042815 (LBCI843XT), 39956123 (LBCP1000S), 39932462 (LBCP400P), 39931670 (LBCPI1010), 39931324 (LBCPI610), 31093008 (LBECO1000UK), 39980941 (LBENERGCB735), 31048879 (LBEXCLUS.40), 31043102 (LBEXCLUS.60), 31048804 (LBSELECTA40X), 31043987 (LBSELECTA60X), 31033798 (LBSL6AQUAV), 37500063 (TS16P), 37500071 (TS23P)

COLGED Dishwasher BETA235, BETA250, BETA253, BETA258, GL43, GL56, GL56S, GL56SPS, GS55, GS55CRP, GS56, GS57, GS60, ISYTECH38-10 D, ISYTECH38-11 D, ISYTECH38-11 GD, NEOTECH500, NEOTECH500-2, NEOTECH500-2P, NEOTECH500-2S, NEOTECH500DDP, NEOTECH500G, NEOTECH500GS, NEOTECH600, NEOTECH600-2, NEOTECH600-2P, NEOTECH600-2S, NEOTECH600G, NEOTECH600GS, NEOTECH600GSLP, NEOTECH600PS, NEOTECH700, NEOTECH800CRP, NEOTECH800DP, NEOTECH800G, NEOTECH803, NEOTECH803N, NEOTECH900, ONYX50, PROTECH28-10, PROTECH611, PROTECH611G, PROTECH611GCLS, PROTECH710, S58S, S59, SILVER50, SILVER50 MARINE, SILVER50GW, SILVER50S, STARTECH605, STARTECH605-2, STARTECH605P-2, STARTECH605S-2, STARTECH705, STEEL31H, STEEL31R, STEEL31S, STEEL31S NSM, STEEL45, STEEL51, STEEL51HP, STEEL53BD, STEEL53MS, STEEL58, STEELTECH13-00, STEELTECH13-00D13A, STEELTECH14-00, STEELTECH14-00D13A, STEELTECH14-01, STEELTECH14-01S, STEELTECH15-00, STEELTECH16-00, STEELTECH16-03, STEELTECH16-03DD, STEELTECH17-00, STEELTECH33-00, STEELTECH33-01, STEELTECH34-00, STEELTECH34-01, STEELTECH350, STEELTECH35-00, STEELTECH35-01, STEELTECH350K, STEELTECH36-00, STEELTECH36-00M, STEELTECH36-01, STEELTECH36-01M, STEELTECH360BK, STEELTECH360SK, STEELTECH361, STEELTECH361-2, STEELTECH370, STEELTECH37-00, STEELTECH371, STEELTECH38-00, STEELTECH38-00D, STEELTECH38-01D, TOPTECH25-20C, TOPTECH25-20G, TOPTECH25-20GT, TOPTECH25-20T, TOPTECH26-20, TOPTECH26-20G, TOPTECH26-20GT, TOPTECH26-20T, TOPTECH27-20, TOPTECH27-20G, TOPTECH27-20GT, TOPTECH34-20, TOPTECH34-21, TOPTECH35-20, TOPTECH35-21, TOPTECH36-20, TOPTECH36-21, TOPTECH37-20, TOPTECH38-21D, TOPTECH400, TOPTECH500, TOPTECH500CRP, TOPTECH520, TOPTECH520CLS, TOPTECH521, TOPTECH521CLS, TOPTECH620, TOPTECH620CLS, TOPTECH920

COLGED Dishwasher hood type BETA270, C600, GL270, GL270HP, GL71, GL72, GL72CRP, GL74, GL74 MARINE, GL740, GL74A, GL74CRP, GL81, GL82, GLA, ISYTECH28-00, ISYTECH28-00 I, ISYTECH28-00 ID, ISYTECH28-02 GNRG, ISYTECH28-02 GTNRG, L61, L62, L63, L64, NEO800N, NEO803L, NEO803N, NEOTECH27-05, NEOTECH28-05, NEOTECH28-05 DP, NEOTECH28-05 I, NEOTECH28-05 ID, NEOTECH28-06, NEOTECH28-06DP, NEOTECH28-06ID, NEOTECH800, PRO811L, PRO811R, PRO811RCLS, PRO831L, PROTECH28-10DP, PROTECH28-10T, PROTECH28-16, PROTECH28-16I, PROTECH28-16T, PROTECH810, PROTECH811, PROTECH811G, PROTECH811GCLS, PROTECH811ID, PROTECH811S, PROTECH811SID, SILVER71, SILVER72, STARTECH805, STEEL70, STEEL7-3, STEELTECH18-00, STEELTECH380BK, STEELTECH381, STEELTECH383G, STEELTECH7-3, TOPTECH28-20, TOPTECH28-20GT, TOPTECH28-26, TOPTECH28-26G, TOPTECH28-26T, TOPTECH28-26TG, TOPTECH28-26TNRG, TOPTECH38-20D, TOPTECH38-21DE, TOPTECH39-20D, TOPTECH39-21D, TOPTECH740, TOPTECH820

COLGED Dishwasher pull-through GL80, ISYTECH31-11.1, ISYTECH31-11.2, ISYTECH31-11G.1, PROTECH1113, PROTECH1117, PROTECH1122, TOPTECH31-21.1, TOPTECH31-21.2, TOPTECH31-22.1, TOPTECH31-22.1G, TOPTECH31-22.2, TOPTECH31-22.2G, TOPTECH31-22.3, TOPTECH31-22.3G



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

COLGED Glasswasher/Cupwasher BETA235R, BETA240, BETA245, GL42, ISYTECH24-00, ISYTECH24-00DP, ISYTECH24-00R, ISYTECH24-00S, ISYTECH24-00SR, ISYTECH24-01G, ISYTECH26-00S, ISYTECH26-01, ISYTECH26-01 D, ISYTECH26-01 DP, ISYTECH33-10, ISYTECH33-10 D, ISYTECH33-10 RD, ISYTECH33-10 SD, ISYTECH33-11 D, ISYTECH35-10 D, ISYTECH35-10 SD, ISYTECH35-11 D, ISYTECH36-10, ISYTECH36-10 D, ISYTECH36-10 MD, ISYTECH36-10 SD, ISYTECH36-11, ISYTECH36-11 D, ISYTECH36-11 GD, ISYTECH36-11 M, ISYTECH36-11 MD, NEOTECH24-05, NEOTECH24-05 DP, NEOTECH24-05 GD, NEOTECH24-05 GDP, NEOTECH24-05 GSD, NEOTECH24-05 GSDP, NEOTECH24-05 R, NEOTECH24-05 S, NEOTECH24-05 SR, NEOTECH25-05, NEOTECH25-05 DP, NEOTECH25-05 GD, NEOTECH25-05 GDP, NEOTECH25-05 S, NEOTECH25-05 SDP, NEOTECH26-05, NEOTECH26-05 D, NEOTECH26-05 DP, NEOTECH26-05 GD, NEOTECH26-05 GDP, NEOTECH26-05 GSD, NEOTECH26-05 GSDP, NEOTECH26-05 S, NEOTECH26-05 SDP, NEOTECH400, NEOTECH400-2, NEOTECH400-2S, NEOTECH400G, NEOTECH400GS, NEOTECH400PS, NEOTECH400R-CT, NEOTECH400S, NEOTECH700-2, NEOTECH700DPD, NEOTECH700SAS, ONYX40, ONYX40CT, ONYX50S, PROTECH25-10, PROTECH25-10CDP, PROTECH25-10T, PROTECH26-10, PROTECH26-10CDP, PROTECH26-10CP, PROTECH26-10T, PROTECH26-10TDP, PROTECH27-10, PROTECH511, PROTECH511 MARINE, PROTECH511-2, PROTECH511-2T, PROTECH511CLS, PROTECH511CLSID, PROTECH511G, PROTECH511GCLS, PROTECH511ID, PROTECH610, PROTECH610CLS, PROTECH610PS, PROTECH611-2, PROTECH611-2T, PROTECH611CLS, PROTECH611CLSID, PROTECH611ID, SILVER35, SILVER40, SILVER40S, SILVER45, STARTECH405, STARTECH405-2, STARTECH405P-2, STARTECH405R, STARTECH405S, STARTECH405S-2, STARTECH705-2, STEEL31, STEEL41, STEEL41H, STEEL510, STEEL510D, STEELTECH330, STEELTECH330-2, STEELTECH330H, STEELTECH330H-2, STEELTECH330K, STEELTECH340, STEELTECH340-2, STEELTECH340-2S, STEELTECH340H, STEELTECH340H-2, STEELTECH340K, STEELTECH350-2, STEELTECH360, STEELTECH360-2, STEELTECH360K

COLGEDPan/utensilwashing machinesLP60, LP81S, LP91, LP92, NEOTECH901, NEOTECH902, TOPTECH921, TOPTECH922, TOPTECH923, TOPTECH924

CONVOTHERM Convection oven electric OEB10.10, OEB10.20, OEB12.20, OEB20.10, OEB20.20, OEB6.10, OEB6.20, OES10.10, OES10.20, OES12.20, OES20.10, OES20.20, OES6.10, OES6.20

CONVOTHERM Convection oven gas OGB10.10, OGB10.20, OGB12.20, OGB20.10, OGB20.20, OGB6.10, OGB6.20, OGS10.10, OGS10.20, OGS12.20, OGS20.10, OGS20.20, OGS6.10, OGS6.20, OSG10.10, OSG12.20, OSG6.10

DESCO Convection oven electric FCA6E

DESCO Convection oven gas FBM6G

DESCO Dishwasher DS40D, DS50TS, LP35

DEXION Convection oven electric FC008-03-641EM, FC020-03-001EM, FV120-03-105EA, FV120-23-115EA

DEXION Convection oven gas FC006-03-002GM

DEXION Dishwasher D400LB, D500LS, D501LS, LB035-06-000-13A, LB036-06-000, LB037-06-000, LB041-06-000, LB041-10-001PD, LB043-06-001, LB044, LB044P, LB046-10-001, LB047-10-001, LP045-10-000, LP048-10-000, LP051-06-000, LP051-06-000P, LP051-06-100, LP051-10-000, LP051-10-000MPD, LP051-10-100, LP053, LP053-06-000, LP053-10-000, LP053-10-100, LP053BT-DP, LP054-ZH, LP056-10-000, LP057-10-000, LP058-00-010MPD, LP058-06-CRP, LP061-00-000H, LP800-00-092, LP802



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

DEXION Dishwasher hood type D600LK, LP100-06-000, LP101-98-00, LP102-98-00, LP103-06-000, LP103-98-00, LP801-00-000

DEXION Electric oven electric 48FEMD

DIHR Dishwasher 103U (DS35), 103UT (DS35 TOUCHE RL09), 104U (DS37), 104UT (DS37 TOUCHE RL09), 105U (DS40), 105UT (DS40 TOUCHE RL09), 121EN (DS50), 78R (DS50), 78U (DS50), 78UT (DS50 TOUCHE RL09), 20ELK (ELECTRON1000), 123EU (ELECTRON1000 PLUS), 125EU (ELECTRON400), 32ELK (ELECTRON400), 32ELKC (ELECTRON400 ACQUA PULITA), 124EU (ELECTRON500), 124PU (ELECTRON500), 29ELK (ELECTRON500), ELECTRON500 CLEAN, 122EU (ELECTRON600), 83ELK (ELECTRON600), 100U (G35), 67R (G35), 67U (G35), 38R (G600), 38U (G600), 7R (GASTRO450), 7U (GASTRO450), 29S (GASTRO500), 295U (GASTRO500 PLUS), GASTRO750, 297R (GASTRO750 PLUS), 297U (GASTRO750 PLUS), 29S (GASTRO750S), GASTRO900, 128MU (GS35), 101U (GS37), 73R (GS37), 73U (GS37), 102U (GS40), 10U (GS40), 74R (GS40), 74U (GS40), 31R (GS45), 31U (GS45), 9R (GS50), 9U (GS50), 66R (GS85), 66U (GS85), 6R (LINEAR), 6U (LINEAR), 81E (LP3S PLUS), 81E (LP3STR PLUS), 108EU (OPTIMA500 CUTLERY), 106EK (PREMIUM40), 32P (TEKNO4), 32R (TEKNO4), 29P (TEKNO6), 29R (TEKNO6)

DIHR Glasswasher/Cupwasher 1R (DERBY), 1U (DERBY), 86U (DS45), 106EU (OPTIMA400), 107EU (OPTIMA500), STARCF, STARLS, 321P (TEKNO4 ACQUA PULITA), 291P (TEKNO6 ACQUA PULITA)

DIHR Pan/utensilwashing machines 109E (GRANUL1000), 110EU (GRANUL900), 68E (GRANUL900), 123ES5U (LP1S5), 123ES5U (LP1S5 PLUS), 70R (LP1S8), 70U (LP1S8), 117EU (LP1S8 PLUS), 118EU (LP2 PLUS), 119EU (LP3 PLUS), 120EU (LP4S8 PLUS), 82E (LP4S8 PLUS), 82E (LP4S8TR PLUS)

ELETTROBAR Dishwasher E100, E110, E120, E140, E40H C.T, E45P, E46, E50, E50D, E50D FRN, E50FRN, E50PS, E50SA, E51, E51D, E51PS, E52, E55, E55EB, E60, FAST130R, FAST135, FAST135D, FAST135H-2, FAST140R, FAST140S, FAST145, FAST145-2, FAST145-2S, FAST145D, FAST160, FAST160-2, FAST160-2D, FAST160-2DP, FAST160-2P, FAST160-2S, FAST160C, FAST160D, FAST160DP, FAST161, FAST161-2, FAST161-2DP, FAST161-2P, FAST161-2S, FAST161D, FAST161DP, FAST161PA, FAST40, FAST40D, FAST40DE, FAST40E, FAST40R, FAST40S, FAST50, FAST50D, FAST50DE, FAST50E, FAST50S, FAST51M, FAST51MD, FAST51MDP, FAST51T, FAST51TD, FAST51TDP, FAST60D, FAST60DE, FAST60M, FAST60MS, FAST60S, FAST60SD, MISTRAL51, NIAGARA251, NIAGARA251D, NIAGARA261, NIAGARA261HPDP, NIAGARA261SA, NIAGARA271, NIAGARA271-2, NIAGARA291, NIAGARA341, NIAGARA341DP, NIAGARA341P, NIAGARA341SR, NIAGARA351, NIAGARA351DP, NIAGARA351S, NIAGARA351SDP, NIAGARA361, NIAGARA361D, NIAGARA361DP, NIAGARA361S, NIAGARA371, NIAGARA371BT, NIAGARA371S, NIAGARA42DE, NIAGARA42RD, NIAGARA42SD, NIAGARA51, OCEAN340, OCEAN340DP, OCEAN340S, OCEAN340SDP, OCEAN340SR, OCEAN360, OCEAN360DP, OCEAN360M, OCEAN360MDP, OCEAN360MSDP, OCEAN360S, OCEAN360SDP, OCEAN41SD, OCEAN51, OCEAN51D, OCEAN51DE, OCEAN61SD, PLUVIA260, PLUVIA270, PLUVIA270SAS, RIVER252, RIVER252-2, RIVER252-2T, RIVER252ECS, RIVER253, RIVER253ECS, RIVER262, RIVER262-2, RIVER262-2T, RIVER262ECS, RIVER272-2, RIVER280, RIVER282TDE, RIVER294, RIVER295, RIVER295P, RIVER296, RIVER296P, RIVER297, RIVER352, RIVER362, RIVER362C, RIVER362T, RIVER362TDE, RIVER372, RIVER372TDE, RIVER40D, RIVER44CRP, RIVER44CRP-ST, RIVER44D, RIVER50, RIVER50CRP, RIVER50D, RIVER53T, RIVER54, RIVER54CRP, RIVER54D, RIVER54PS, RIVER54WRCCRP, RIVER61, RIVER61CRP, RIVER70, RIVER71, STEEL31H, STEEL31HS, STEEL31NSM

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

ELETTROBAR Dishwasher conveyor type NIAGARA441-2

ELETTROBAR Dishwasher hood type C600, E78, FAST170, FAST180, FAST181, FAST60, FAST73, FAST80, FAST80D, gl74th (GL74), GL74A, GL74CA, GL74CABT, GL74CNS, GL74CRP, GL74FIERA, GL74NS, NIAGARA281, NIAGARA281-2, NIAGARA281C, NIAGARA281CDD, NIAGARA281DD, NIAGARA281HP, NIAGARA283, NIAGARA283-2 FURNOTEL, NIAGARA283A, NIAGARA283L-2, NIAGARA341CF, NIAGARA381, NIAGARA381D, NIAGARA381DP, NIAGARA381HPD, NIAGARA381I, NIAGARA381L, NIAGARA381L DP, NIAGARA381LI, OCEAN380, OCEAN380DD, OCEAN81D, OCEAN81DE, PLUVIA280, RIVER281CRP, RIVER282, RIVER282-2, RIVER282CRP, RIVER282LS-2TDE, RIVER382, RIVER382 RESTOREX, RIVER382H, RIVER382L, RIVER382L NRG, RIVER382L-2, RIVER382LR, RIVER382TDE, RIVER482, RIVER80, RIVER81, RIVER81A, RIVER81C, RIVER81CRP, RIVER81PAP, RIVER82, RIVER82CRP, RIVERE78, RIVERE80

ELETTROBAR Dishwasher pull-through NIAGARA412-2, RIVER414-2, RIVERMULTI413-1, RIVERMULTI413-2, RIVERMULTI414-2, SEVEN E

ELETTROBAR Glasswasher/Cupwasher CLEAN140, CLEAN140S, CLEAN161, CLEAN161S, CLEAN3, E35, E35 ELECTRONICS, E35C.T, E35D, E35D ELECTRONICS, E35H, E35HD, E40, E40 NEUTRAL, E40 ROUND BASKET, E40D, E40D ELECTRONICS, E40H, E40HD, E40HP, E40P, E40SA, E40SL, E41, E41D, E42, E45, E45D, FAST130, FAST130DP, FAST130S, FAST130SR, FAST135-2, FAST135-2S, FAST135H, FAST135H-2S, FAST135HCT, FAST135HD, FAST139, FAST139-2, FAST139CT, FAST139D, FAST139H, FAST139H-2S, FAST139PA, FAST140, FAST140D, FAST140DP, FAST140P, FAST140SR, FAST150, FAST30, FAST30D, FAST30DE, FAST30E, FAST30R, FAST30S, FAST70D, LA40, LA40E, LA40S, MISTRAL40, MISTRAL40C.T, MISTRAL40D, MISTRAL51D, MISTRAL51PS, NIAGARA241, NIAGARA241-2, NIAGARA241-2S, NIAGARA241CT, NIAGARA241D, NIAGARA241DDP, NIAGARA241DP, NIAGARA251-2, NIAGARA251-2S, NIAGARA251DP, NIAGARA261-2, NIAGARA261-2P, NIAGARA261-2S, NIAGARA261D, NIAGARA261DDP, NIAGARA261DP, NIAGARA261HP, NIAGARA261HPDG, NIAGARA261HPDPDG, NIAGARA341R, NIAGARA341S, NIAGARA35, NIAGARA35C.T, NIAGARA35D, NIAGARA361SDP, NIAGARA381ID RESTOREX, NIAGARA40, NIAGARA40CRP, NIAGARA40D, NIAGARA40D INK, NIAGARA40DP NEUTRA, NIAGARA40P, NIAGARA40SA, NIAGARA42D, NIAGARA45, NIAGARA45D, NIAGARA45WRC, NIAGARA51D, NIAGARA51MT, NIAGARA51MTPS, NIAGARA51MTPSSA, NIAGARA51MTSA, NIAGARA52D, NIAGARA52DE, NIAGARA52SD, NIAGARA62D, NIAGARA62DE, NIAGARA62SD, NIAGARA72D, NIAGARA72SD, NIAGARA92D, OCEAN31, OCEAN31D, OCEAN31DE, OCEAN31RD, OCEAN41, OCEAN41D, OCEAN41DE, OCEAN41RD, OCEAN61D, OCEAN61DE, PLUVIA240, PLUVIA240CT, PLUVIA240DP, PLUVIA240S, PLUVIA260DP, PLUVIA260P, PLUVIA260S, PLUVIA270DPD, RIVER40, RIVER40CRP, RIVER43, RIVER44, RIVER48

ELETTROBAR Glasswasher/Cupwasher hood type NIAGARA82D

ELETTROBAR Pan/utensilwashing machines LP00, LP092, LP60, LP800, LP92, NIAGARA292, NIAGARA293, RIVER298, U60E

ELFRAMO Dishwasher BE40, BE50, BE50T, C44ELT, C66ELT, C77ELT, D120, D120DGT, D30, D35, D36, D40, D45, D80F, D85, SQ60

ELFRAMO Dishwasher hood type C33, C34DGT, C44, C44DGT, C66, C66DGT, C77, CE24, LP60H

ELFRAMO Glasswasher/Cupwasher B11, B15, BD11, BD13, BD22, BD46, BD47, BE35, D40I, SQ42, SQ42E, SQ48, SQ48E, SQ55

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

ELFRAMO Pan/utensilwashing machines LP60, LP61, LP61H

EMMEPI Dishwasher L50, L50A, L50AP, L50P, LB40DG, LB40DGP, LB40EDG, LBE34, LBE34DG, LBE35ECO, LBE40E, LBE40ECO, LP0061, LS0011, LS005P, LS008, LS009, LS009E, LS011, LS05, LS055E, LS055EP, LS09, LS09E

EMMEPI Glasswasher/Cupwasher LS005

EUROWASH Dishwasher 330, 340, 341, 342, 350, 360, 363, 373, 403, 403P, 430, 440, 440H, 441, 441SL, 453P, 460, 460S, 461, 461C, 463, 503, 503PS, 503S, 513, 513S, 553, 583, 593, EW3102, EW3103, EW3104, EW3105

EUROWASH Dishwasher hood type 383, 393, 393BT, 450, 481, 481CRP, 713, 723, GL72, GL723

EUROWASH Glasswasher/Cupwasher 361, 403C.T, 403S, 403S.I

FOINOX Convection oven electric FC 100 EEP, FC 100 ETD, FC 201 EEP, FC 201 EM, FC 201 ETD, FC 401 EEP, FC 401 EM, FC 401 ETD, FM 201 CEEPA, FM 201 EM, FM 401 EEP-ED, FM 401 EM, FM 60 EM, FM201ETD, FM401ETD, FM60ETD, MM201 ED, MM201 EEP, MM201 EM, MM201 ETD, MM23 EEP, MM23 EM, MM401 ED, MM401 EEP, MM401 EM, MM401 ETD, W41K1PS, WGN4ME

FOINOX Convection oven gas FC 201 GEP, FC 201 GM, FC 401 GEP, FC 401 GM, FC201CGTD, FC201GTD, FC401GTD, FM 100 GM, FM 201 GM, FM 401 GEP GD, FM 401 GM, FM201GTD, FM401GTD, MM201 GD, MM201 GEP, MM201 GM, MM201 GTD, MM401 GD, MM401 GEP, MM401 GM, MM401 GTD

FOINOX Pastry oven electric FDE10-155M, FDE10-155TD, FDE55EP, FDE55M, FDE55TD, FP 160 CEM1, FP 40 EEP, FP 40 EM, FP 80 EEP, FP 80 EM, FP160EEP

FOINOX Pastry oven gas FDG10-155M, FDG10-155TD, FDG55M, FDG55TD

GARBIN Convection oven electric 23 MX, 23 MX UNI, 31 GX UMI, 36 PX UMI, 41 GX UMI, 43 DX, 43 DX UMI, 43 MX, 43 MX UMI, 44 PX UMI

GARBIN Convection oven gas 41 EGX UMI, 41 FGX UMI, 43 FGX UMI, 44 EGX UMI, 44 FGX UMI

GARBIN Steam oven electric 25 EX, 31 EX, 36 EX, 41 EX, 43 SE, 44 EX

GIGA Dishwasher LP57, LP57 TRONIC, N50 TRONIC

GIGA Dishwasher hood type E1000, N1000 TRONIC

HILTA Dishwasher FAST S41, S41, S42MA, S42TA, S49TA

HILTA Dishwasher hood type W13, W14, W15

HOBART Convection oven electric HEFC023, HFCE6, HFEC023

HOBART Dishwasher CHF45, CLG26DNA-10, ECOMAX 500, EF40, H400, H500, H60, STBE40DUK-11

HOBART Dishwasher hood type AM 900, AMS 900, AMX900, AMXX1300, AUXX1300, ECOMAX 651, ECOMAX 683, GL71, GL72, GL74

HOBART Glasswasher/Cupwasher ECOMAX 400, GC, GE400, GF60, GF60S

HOONVED Dishwasher 60BT, AP43E, AP48E, AP53E, AP60E, C35, C43, C43 2°, C43D, C43E, C46E, C48 2°, C48 DL, C48D 2°, C53, C53D, C53E, C53ED, C6, C60, C60D, C60E, C60ED, C68DE, C68E, C68EBT, C6D, C6DE, C6E, CR43, CR43D, DP45DE, DP45E, DP50DE, DP50E, GS-X1011 2°, GS-X1011WEH 2°, RSP40, RSP40A, RSP50, RSP50A, SD5E PD, SD5E PS, SD5EBT PD, SD5EBT PS, SG4E PD, SG4E PS, SG5E PD, SG5E PS, SP35 2°, SP35E, SP35ED, SP40 2°, SP40D 2°, SP40E, SP40ED, SP43, SP43D, SP45E, SP45ED, SP5, SP50E, SP50ED, SP5D, SP5DE, SP5E, SP68DE, SP68E, SPR43, SPR43D, ST43E, ST48E, ST53DE, ST60DE, ST60E, VS-X313, VS-X313 DOS, VS-X313 LP, VS-X515, VS-X515 DOS, VS-X515 LP



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

HOONVED Dishwasher hood type CAP10BT, SH120E BT PD, SH120E BT PS

HOONVED Dishwasher pull-through FW35E, FW40E, FW45E, FW50E

HOONVED Glasswasher/Cupwasher AP43E, AP48E, AP53E, C48, C48D, C48D DL, CR48, CR48D, SD5, SD5BT, SG4, SG5, SPB35, ST53E

HOOVER Washing machine 31095888 (LB A 040 S), 31095003 (LB A 0400), 31095706 (LB A 0400 CH), 31095730 (LB A 0400ISR), 31095904 (LB A 041 S), 31095789 (LB A 042 S), 31095607 (LB A 0420), 31095813 (LB A 045 SX), 31095862 (LB A 051 SX), 31095839 (LB A 055 SX), 31095797 (LB A 062 S), 31095755 (LB A 0620ISR), 31095805 (LB A 065 SX), 31095722 (LB A 0820UNI), 31095714 (LB A0620SUNI), 31095847 (LB A065SX CH), 39932868 (LB HSUPER7X), 31138175 (LB HV 16 DE), 31138159 (LB HV 16 FR), 31138167 (LB HV 16 UK), 31138118 (LB HV16 SY EAST), 31138126 (LB HV16 SY NE), 31138241 (LB HV16SY CE), 31138209 (LB HV16SY RE), 37502853 (T0500), 37502408 (T0550), 37502846 (T0830), 37502788 (T0850), 37502838 (T0850NORD), 37502796 (T1050), 37502812 (ZT1090NORD), 37502820 (ZT1090SUISSE)

IBERNA Washing machine 37506409 (ITL513), 31096613 (LB I 5 WD), 31084619 (LB LBI 2505), 31084007 (LB LBI 2514T), 31084650 (LB LBI 2524T), 31084718 (LB LBI 2534), 31084726 (LB LBI 2544T), 31084627 (LB LBI2518TX), 31084759 (LB LBI2544TA), 31084734 (LB LBI2544TX), 31084668 (LB LBI2610 T), 31084676 (LB LBI2612TX), 31096605 (LBIWD5100TCH), 31084700 (LBI2518T-1)

IME OMNIWASH Dishwasher 4K50, 4Q82, 4Q82ECO, J50, J500, J50-3, J50-3D, J50-3DD, J50-3DDPS, J50-3PS, J50D, J50DD, J50DDPS, J50PS, MASTER 50, MASTER 50M, MASTER 50MPS, MASTER 50PS, N50, N500, OMPD500ABSD, OMPD500SD, OMPG500S, OMPG500SD, QUATTROT82

IME OMNIWASH Dishwasher hood type 61 P, 62 P-S, SEI1P, SEI2P

IME OMNIWASH Glasswasher/CupwasherOMBD500, OMBG500, QUATTRO Q-82

INOXTREND Convection oven electric BUA-606E, BUE-606E, BUE-610E, CBP-107E, CBP-111E, CDT-107E, CDT-111E, CRCA-207E, CRUA-107E, CRUA-110E, CUA-107E, CUA-111E, CUA-120E, CUA-207E, CUA-211E, CUA-220E, CUE-107E, CUE-111E, CUF-107E, CUF-111E, FBA-106E, FBA-110E, FBA-120E, FBA-210E, FBA-220E, FBE-106E, FBE-110E, FBE-120E, FBE-220E, FDP-106E, FDP-110E, FDP-120E, FDP-210E, FDP-220E, FUA-106E, FUA-110E, FUA-120E, FUA-210E, FUA-220E, FUE-106E, FUE-110E, FUE-120E, FUE-210E, FUE-220E, MB1A-10E, MB1E-10E, MBE-6E, MHA-10E, MHA-6E, RCA-605E, RUA-105E, RUA-110E, RUA-305E, RUA-105E, RUA-110E, RUA-115E, RUA-305E, RUA-605E, RUA-610E, RUF-605E, RUF-610E, SDA-107E, SDA-304E, SDA-4E, SDA-4EM, SDA-5E, SDA-5EM, SDE-104E, SUA-104E, SUA-4E, SUA-5E, SUA-B6031E, SUA-B6041E, SUA-L604E, SUE-604E, VB1E-210E, XBP-120E, XBP-220E

INOXTREND Convection oven gas BUA-606G, BUA-610G, BUE-606G, BUE-610G, CUA-107G, CUA-111G, CUA-211G, CUE-107G, CUE-111G, FBA-106G, FBA-110G, FBA-120G, FBA-210G, FBA-220G, FBE-106G, FBE-110G, FBE-120G, FDP-106G, FDP-110G, FDP-120G, FDP-210G, FDP-220G, FUA-106G, FUA-110G, FUA-120G, FUA-210G, FUA-220G, FUE-106G, FUE-110G, FUE-120G, FUE-210G, MB1A-10G, MB1E-10G, MBE-6G, MHA-6G, PUE-10G, PUE-8G, VB1E-210G, XBP-220G

JEMI Dishwasher GS100, GS102, GS18, GS19, GS2, GS20, GS3, GS30, GS4 AF, GS4-2, GS4-2-AF, GS6, GS6 AF, GS7, GS82, GS8-2, GS82M, GS83, GS9, GSP45, GSP46

JEMI Glasswasher/Cupwasher GS-4

KELVINATOR Washing machine 31097611 (LB K 4 UNI), 31097645 (LB K 6 T UNI), 31097009 (LB KM 46 ZA),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

31097603 (LB KM 46R ZA), 39956115 (LB KM110 W), 39956313 (LB KM120 W), 39953211 (LB KM44 W),  
39953237 (LB KM45W 115), 39953229 (LB KM45W 230), 39954144 (LB KM65 W), 39958350 (LB KM85 W)

KOMEL Dishwasher 8033, 8034DGT, 8044, 8044DGT, 8044ELT, 8066, 8066DGT, 8066ELT, 8077, 8077ELT, F11,  
F13, F22, F46, F47, F912, F912DGT, F93, F94, F96, F97, F98F, F99

KOMEL Dishwasher hood type K8033, K8034, K8044, K8066

KOMEL Glasswasher/Cupwasher BE35 KOMEL, BE40 KOMEL, BE50 KOMEL, BE50T KOMEL, F86, F88, F89, F92,  
F94I, F95

KOMEL Pan/utensilwashing machines KLP60, KLP60H, KLP61, KLP61H

KRUPPS Dishwasher COMPACK B40, COMPACK B43, COMPACK B43DB, COMPACK B48, COMPACK B53,  
COMPACK B55, COMPACK GL450, COMPACK GL600, COMPACK S65, COMPACK S85, CUBE C320, CUBE C327,  
CUBE C426, CUBE C432, CUBE C453, CUBE C537, CUBE C537T, CUBE C640, ELITECH EL42, ELITECH EL42E,  
ELITECH EL45E, ELITECH EL50E, ELITECH EL51E, ELITECH EL53E, ELITECH EL55E, EXUS S56DB, KORAL 1100,  
KORAL 1450DB, KORAL 500, KORAL 540DB, KORAL 560DB, KORAL 580E, KORAL 600, KORAL 630DB, KORAL  
800, KORAL 840DB, KORAL 900, KORAL 950DB, KORAL 960DB, KORAL K450E, KORAL K540E, KORAL K560E,  
KORAL K580E, KORAL K840E, X45E, X54E

KRUPPS Dishwasher hood type COMPACK S130, COMPACK S140, COMPACK S155, COMPACK S157, COMPACK  
S160, COMPACK S165, CUBE CH120, ECOCLEAN EC1100E, ECOCLEAN EC1200E, ELITECH EL60, ELITECH EL60E,  
ELITECH EL62E, ELITECH EL70E, ELITECH EL80, ELITECH EL80E, EXUS S130DB, EXUS S140DB, EXUS S54DB,  
KORAL 1100DB, KORAL 1200, KORAL 1200DB, KORAL 1250, KORAL 1250DB, KORAL 1300, KORAL 1350, KORAL  
1350DB, KORAL 1400DB, KORAL 1500DB, KORAL 1550DB, KORAL 1600, KORAL 1600DB, KORAL 1650, KORAL  
1650DB, KORAL 450DB, KORAL K1100E, KORAL K1200E, KORAL K1500E, KORAL K1600E

KRUPPS Glasswasher/Cupwasher ARIS G3527, ARIS G4026, ARIS G4032, D5037, ECOCLEAN EC205E,  
ECOCLEAN EC208E, ECOCLEAN EC209E, ECOCLEAN EC450E, ECOCLEAN EC540E, ECOCLEAN EC560E,  
ECOCLEAN EC580E, ELITECH EL40, ELITECH EL40E, KORAL 205, KORAL 205DB, KORAL 206, KORAL 206DB,  
KORAL 207, KORAL 207DB, KORAL 208, KORAL 208 LS, KORAL 208DB, KORAL 208E, KORAL 209, KORAL 209DB,  
KORAL 210, KORAL K205E, KORAL K207E, KORAL K208E, KORAL K209E, KORAL SR400

KRUPPS Pan/utensilwashing machines COMPACK GL860, COMPACK GL890, ELITECH EL951E, ELITECH EL981E,  
ELITECH EL99, ELITECH EL991E, KORAL 950, KORAL 960, KORAL 980, KORAL 980DB, KORAL 990, KORAL  
990DB, KORAL K951E, KORAL K981E

KRUPPS Pan/utensilwashing machines hood type CUBE CH110, ELITECH EL95, ELITECH EL96

LAINOX Convection oven electric EM006M, EM020M, EV006M, EV006P, EV010H, EV010M, EV010P, EV020M,  
FE051M, FE051X, FE101M, FE101X, FE102M, FE102X, FE105M, FE105X, FE110M, FE110X, FE210M, FE210X,  
FEI101M, FME201, ME106M, ME106X, ME110M, ME110X, ME120M, ME120X, ME210M, ME210X, ME220M,  
ME220X, MEC20M, MEC20X, MEC24M, MEC24X, MEC40M, MEC40X, MES20M, MES20X, MES24M, MES24X,  
MES40M, MES40X, PE005M, PE008M, PE015M, PE040M, PE040X, PE041M, PE041X, PE051M, PE051X, PE080M,  
PE080X, PE081M, PE081X, PE088M, PE101M, PE101X, VE106D, VE106H, VE106L, VE106M, VE106P, VE106S,  
VE106T, VE106X, VE110D, VE110H, VE110L, VE110M, VE110P, VE110S, VE110T, VE110X, VE120D, VE120H,  
VE120L, VE120M, VE120P, VE120S, VE120T, VE120X, VE210D, VE210H, VE210L, VE210M, VE210P, VE210S,  
VE210T, VE210X, VE220D, VE220H, VE220M, VE220P, VE220X, VEC20D, VEC20H, VEC20M, VEC20P, VEC20X,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

VEC24D, VEC24H, VEC24M, VEC24P, VEC24X, VEC40D, VEC40H, VEC40M, VEC40P, VEC40X, VES20D, VES20H, VES20M, VES20P, VES20X, VES24D, VES24H, VES24M, VES24P, VES24X, VES40D, VES40H, VES40M, VES40P, VES40X

LAINOX Convection oven gas FG051M, FG051X, FG101M, FG101X, FG102M, FG102X, FG105M, FG105X, FG110M, FG110X, FG210M, FG210X, FMG201A, FMG201S, GM020M, GV010H, GV010M, GV020H, MG106M, MG106X, MG110M, MG110X, MG120M, MG120X, MG210M, MG210X, MG220M, MG220X, MGC20M, MGC20X, MGC24M, MGC24X, MGC40M, MGC40X, MGS20M, MGS20X, MGS24M, MGS24X, MGS40M, MGS40X, PG005M, PG008M, PG015M, PG040M, PG040X, PG041M, PG041X, PG051M, PG051X, PG080M, PG080X, PG081M, PG081X, PG088M, PG101M, PG101X, VG106D, VG106H, VG106L, VG106M, VG106P, VG106S, VG106T, VG106X, VG110D, VG110H, VG110L, VG110M, VG110P, VG110S, VG110T, VG110X, VG120D, VG120H, VG120L, VG120M, VG120P, VG120S, VG120T, VG120X, VG210D, VG210H, VG210L, VG210M, VG210P, VG210S, VG210T, VG210X, VG220D, VG220H, VG220M, VG220P, VG220X, VGC20D, VGC20H, VGC20M, VGC20P, VGC20X, VGC24D, VGC24H, VGC24M, VGC24P, VGC24X, VGC40D, VGC40H, VGC40M, VGC40P, VGC40X, VGS20D, VGS20H, VGS20M, VGS20P, VGS20X, VGS24D, VGS24H, VGS24M, VGS24P, VGS24X, VGS40D, VGS40H, VGS40M, VGS40P, VGS40X

LAMBER Dishwasher 01F, 01F ADD, 01F DEP, 01F DY, 01F DY ADD, 01F EK, 01F EK ADD, 01F EK DEP, 040F, 040F DEP, 040F EK, 040F EK ADD, 040F EK DEP, 045F, 045F ADD, 045F DEP, 045F EK, 045F EK ADD, 045F EK DEP, 050F, 050F ADD, 050F DEP, 050F EK, 050F EK ADD, 050F UL, 075F, 075F ADD, 075F DEP, 075F DY, 075F DY ADD, 075F EK, 075F EK ADD, 075F EK DEP, 50F EK ADD, DSP4, F840 CV, F85, F85 ADD, F85 DEP, F85 RGB, F85 RGB ADD, F85 UL, F92, F92 DEP, F92 DY, F92 DY ADD, F92 EK, F92 EK ADD, F92 EK DEP, F92 UL, F94 DY, F94 DY ADD, F94 EK, F94 EK ADD, GS350, GS581P, GS800, GS900, L21 UL, L25 UL, LS415, NS455, NS455 DEP, NS456, NS456 DEP

LAMBER Dishwasher conveyor type A410, LINEAR 30, LINEAR 40 PRC, LINEAR 60 PRC, LINEAR 80 PRC

LAMBER Dishwasher hood type 015-24L, 015-24L DY, A240, A410 EK, DSP 5, DSP5, L18, L20, L21, L21 EK, L21 EK ADD, L21 RGB, L21 RGB ADD, L24 DY PLUS, L24 EK, L25, L25 DY, L25 EK, L305 CV, L305 DY CV

LAMBER Dishwasher pull-through M115, M150, M150A, M180, M180A, MA-10, MA-20, MA-33, MA-39, MA-59, MATIC 10, MATIC 20, MATIC 33 PRC, MATIC 33A, MATIC 39, MATIC 49, MATIC 49A, MATIC 59, MATIC 59A

LAMBER Glasswasher/Cupwasher DSP1, DSP2, DSP26, DSP26 ADD, DSP3, GS400, GS581, MINIBAR, S200, S240, S260, S260 ADD, S260 DEP, S280, S280 ADD, S280 DEP, S280 UL, S400 EK, S400 EK ADD, S460 ADD, S460 EK, S460 EK ADD, S480 EK, S480 EK ADD, S510, S510 ADD, S510 DEP, S510 EK, S510 EK ADD, SL1, SL4, SUPER QS, SUPER QS ADD, SUPER QS DEP

LAMBER Pan/utensilwashing machines LP31 EK, LP31-L EK, LP38 EK, LP38-L EK, LP6 EK, LP6L, LP6-L DY, LP6-L EK, LP8 EK, LP8-L DY, LP8-L EK, P440 CV, P440 EK, P550, P550 DY CVP, P550 EK, P700, P700 DY, P700 DY CVP, P700 EK, PT1500 EK, PT1500-L EK, PT800 DY, PT800 DY CVP, PT800 EK, PT850 EK, PT850-L DY, PT850-L EK

LAMBER Pan/utensilwashing machines pull-through M130

LAMBER Vegetable washing machine LV84

LOTUS Pasta cooker electric CP-4ET, CP-6ET

MACH Dishwasher MB9240, MS351, MS353, MS400E, MS451, MS453, MS500E, MS500T, MS800E, MS9351, MS9353, MS9400, MS9401, MS9403, MS9451, MS9453, MS9500, MS9501, MS9503, MS9800, MS9801, MS9803





magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

MACH Dishwasher hood type MS905

MACH Glasswasher/Cupwasher MB235LI, MB240LI, MB510, MB510ER, MB9235

MACH Pan/utensilwashing machines MLP50, MLP56

MARELS Dishwasher ECO4, ECO5, L45, OPT 50, OPT 70

MARELS Dishwasher hood type HT 52 PS DT, HT 53 PS DT, OPT 100, OPT 120, OPT 130

MARENO Bain-marie electric B12-4E

MARENO Neutral counter warm SDVC15, SDVC15S

MARENO Sausage grill electric CRE-6220, CRE-6230, CRE-6320, CRE-6330

MARENO Self service counter SDPC08, SDPC12, SDPC12S, SDPC15, SDPC15S, SDVC08, SDVC08S, SDVC12, SDVC12S, SNA12, SNA16, SNA20, SNA708, SNA712, SNA715, SNAC12, SNAC16, SNAC20, SNAC712, SNAC715, SNG08, SNG12, SNG16, SNG20, SPAC712, SPAC715, SPCG708, SPCG712, SPCG715, SVAC16, SVAC20, SVAC712, SVAC715, SVCG08, SVCG12, SVCG16, SVCG20, SVCG708, SVCG712, SVCG715

MBM Convection oven DRIVE 110, DRIVE 210, DRIVE 610

MBM Convection oven electric FCE10, FCE108, FCE20, FCE6, FCE68, FEC023, FEM110, FEM207, FEM207SC, FEM209, FEM210, FEM610, FEMD023, FEMD207SC, FEMD209, FEMD48, FEP050, FEP080, FEP160

MBM Convection oven gas FCG10, FCG108, FCG20, FCG6, FCG68, FGM110, FGM207, FGM207SC, FGM209, FGM210, FGM610, FGMD207, FGMD209, FGP050, FGP080, FGP160

MBM Dishwasher KLF500E, KLF580, LF50, LF500, LF55, LF550, LF551, LF55E, LF56, LF59, LF60, LFD50, LFD60, LFDX50, LS500A (LS500), LS501, LS505M, LS505PT, LS505T, LS511, LS520, LS521, LS522, LS525

MBM Dishwasher hood type GOLD74, L61, L62, L63, L64, LK100, LK1000, LK100EM, LK110, LK1100, LK130, LK1300, LK600, LK605, LK611, LK611G, LK620, LK621, LK622, LK622I, LK625, LKD130, LKDX110, LVC50

MBM Glasswasher/Cupwasher D500LS, D501LS, E40, E55, KLB40, LB135, LB140, LB145, LB35, LB350, LB350D, LB355, LB35C, LB40, LB400, LB405, LB40E, LB411, LB421, LB422, LB42BT, LB45, LBD40, LBDX40

MBM Pan/utensilwashing machines L065, LOD102, LOD202, LOD302, LOD304, LOD402, LOD502, LOD65, LP00, LP092, LP800, LP92

MBM Pot stove electric E46

MODULAR Convection oven gas GCE10T, GCE6T, GME10T, GME10T-S, GME6T, GME6T-S

MODULAR Dishwasher DW50, DW50DT, DW51, DW51DT, DWD45, DWD45DT, DWD51, DWD51DT, DWD59, DWD59DT, ECO41, ECO42, ECO43A, ECO45, ECO46, ECO47A, ECO51, ECO51-2, ECO51T, ECO51T-2, ECO52, ECO52-2, ECO52T, ECO52T-2, ECO56A, ECO56A-2, ECO56AT, ECO56AT-2, GW35, GW40, GW41, GWD40, GWD40DT, GWD41, GWD41DT, L451, L451-2, L452, L452-2, L456A, L456A-2, OPT510, OPT510-2, OPT512, OPT560A, OPT560A-2, OPT706A, OPT706A-2, OPT710, OPT710-2, OPT712, OPT712-2, OPT910, OPT912, OPT960A

MODULAR Dishwasher hood type HT50, HT51, HT52DT, HT53DT, OPT1010, OPT1012, OPT1060A, OPT1210, OPT1212, OPT1310, OPT1312

MODULAR Electric oven 6CE6T, 6ME6T, 6ME6T-S, ECE10T, ECE6T, EME10T, EME10T-S

OLIS Convection oven electronic ECVM10GS2, ECVM20GS2, ECVM21GS2, ECVM6GS2, ECVP10GS2, ECVP20GS2, ECVP21GS2, ECVP6GS2

OLIS Electric oven CV10E, CV10E-2, CV10E-S, CV10E-S2, CV20E, CV20E-2, CV20E-S, CV20E-S2, CV21E,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CV21E-2, CV21E-S, CV21E-S2, CV6E, CV6E-2, CV6EB, CV6E-S, CV6E-S2, CVM10E, CVM10E-2, CVM10E-S, CVM10E-S2, CVM20E, CVM20E-2, CVM20E-S, CVM20E-S2, CVM21E, CVM21E-2, CVM21E-S, CVM21E-S2, CVM6E, CVM6E-2, CVM6E-S, CVM6E-S2, ECVM10E, ECVM10ES2, ECVM20E, ECVM20ES2, ECVM21E, ECVM21ES2, ECVM6E, ECVM6ES2, ECVP10E, ECVP10ES2, ECVP20E, ECVP20ES2, ECVP21E, ECVP21ES2, ECVP6E, ECVP6ES2, FC10E, FC10E-2, FC10E-2S, FC10E-S, FC20E, FC20E-2, FC20E-2S, FC20E-S, FC21E, FC21E-2, FC21E-2S, FC21E-S, FC6E, FC6E-2, FC6E-2S, FC6E-S, FCM10E, FCM10E-2, FCM10E-2S, FCM10E-S, FCM10E-S2, FCM20E, FCM20E-2, FCM20E-2S, FCM20E-S, FCM21E, FCM21E-2, FCM21E-2S, FCM21E-S, FCM6E, FCM6E-2, FCM6E-2S, FCM6E-S, NECVM10ES2, NECVM10GS2, NECVM1GS2, NECVM20ES2, NECVM20GS2, NECVM21ES2, NECVM21GS2, NECVM6ES2, NECVM6GS2, NECVP10ES2, NECVP10GS2, NECVP20ES2, NECVP20GS2, NECVP21ES2, NECVP21GS2, NECVP6ES2, NECVP6GS2, NFCV10E-PS2, NFCV10G-PS2, NFCV20E-PS2, NFCV20G-PS2, NFCV21E-PS2, NFCV21G-PS2, NFCV6E-PS2, NFCV6G-PS2, NFCVM10E-PS2, NFCVM10G-PS2, NFCVM20E-PS2, NFCVM20G-PS2, NFCVM21E-PS2, NFCVM21G-PS2, NFCVM6E-PS2, NFCVM6G-PS2

OLIS Gas oven CV10G, CV10G-2, CV10GB, CV10G-S, CV10G-S2, CV20G, CV20G-2, CV20GB, CV20G-S, CV20G-S2, CV21G, CV21G-2, CV21G-S, CV21G-S2, CV6G, CV6G-2, CV6GB, CV6G-S, CV6G-S2, CVM10G, CVM10G-2, CVM10G-S, CVM10G-S2, CVM20G, CVM20G-2, CVM20G-S, CVM20G-S2, CVM21G, CVM21G-2, CVM21G-S, CVM21G-S2, CVM6G-2, CVM6G-S, CVM6G-S2, FC10G, FC10G-2, FC10G-2S, FC10G-S, FC20G, FC20G-2, FC20G-2S, FC20G-S, FC21G, FC21G-2, FC21G-2S, FC21G-S, FC6G, FC6G-2, FC6G-2S, FC6G-S, FCM10G, FCM10G-2, FCM10G-2S, FCM10G-S, FCM20G, FCM20G-2, FCM20G-2S, FCM20G-S, FCM21G, FCM21G-2, FCM21G-2S, FCM21G-S, FCM6G, FCM6G-2, FCM6G-2S, FCM6G-S

OTSEIN Dryer 35550219 (P450ALTHA), 35550227 (RC4REDCLASS91)

OTSEIN Washing machine 98099435 (1300AXANE), 98099724 (3011OTSEIN87/88), 98099799 (3028B87/88), 98099807 (30821B87/88), 98099542 (4011C4004.92), 35550037 (6000C4004.92), 98099492 (B1191), 98099815 (B11C4004.92), 31138100 (LB HV 16 ES), 31138217 (LB HV16ESALU), 39980230 (LB LBHO 33.6), 39980149 (LB LBO 33.6), 39980032 (LB LEO 633 I), 39980834 (LB LEO 831), 39931332 (LB LF 63 IP), 39932843 (LB LFO 1070I), 31083140 (LB LLOH33.8A), 39932827 (LB LN 1070 I), 31088602 (LB LN 400 A), 31088610 (LB LN 410 A), 31088636 (LB LN 415), 31088651 (LB LN 430 I), 31088644 (LB LN 615), 39931639 (LB LN1000I), 39932439 (LB LN400), 39932447 (LB LN410), 39931266 (LB LN420I), 39931274 (LB LN420IP), 39931290 (LB LN630IP), 39931308 (LB LN640I), 39931621 (LB LN840I), 39930037 (LB.LE 633I), 39897616 (LB.LN 42I), 39897624 (LB.LN 42IP), 39897673 (LB.LN 633I), 39897632 (LB.LN 63I), 39897640 (LB.LN 63IP), 39958335 (LB.LN 84I), 39897004 (LB.LN40), 39897608 (LB.LN41), 39897657 (LB.LN64I), 98099278 (LYS511B), 98099195 (LYS70091), 98099617 (LYS700C4004.92), 98099096 (LYS703C40), 98099583 (LYS708VC4004.92)

PHILCO Washing machine 39954086 (LB PFW 656)

PROJECT SYSTEMS Dishwasher E50, G50, P500, S100, S50, S80, T50, T80, UNICA35, UNICA40, UNICA50, UNICA80

PROJECT SYSTEMS Dishwasher hood type T1200, T150, T155, T255

PROJECT SYSTEMS Glasswasher/Cupwasher ALPHA35, ALPHA40, ALPHA50, E35, E40, G35, G40, P350, P350S, P400, S35, S40, T35, T35S, T40

ROSIERES Washing machine 39980826 (LB LH 332), 39956941 (LB LH38), 39956107 (LB LH510), 39953195 (LB LH54), 39955232 (LB LH56), 39932207 (LB LHP 812), 39881602 (LB.60.10RB), 39885603 (LB.LL.33.8RB),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

37500220 (T410)

SAMMIC Pan/utensilwashing machines LP-60, LP-61, LP-61H

SCOTSMAN Icemaker AC046, AC056, AC086, AC106, DXG35, EC046, EC056, EC086, EC106, NW308, NW508

SILANOS Dishwasher 024, 600, 620, 620TRONIC, 645, 645PS, 650, 650PS, 650PS TRONIC, 660TRONIC, 670F, 670F PDG-PBG, 670TRONIC, 700, 800, 900, A660TRONIC, A670F, E35, E35 PRIMA, E40H, E45, E50, GDW1000, GDW1001, GDW811, GGW1001, HBS 100 WP, LB EVO 62, LC100E, LC130E, LF50, LF50M, LV 45 MONO, LV 45 TRI, LV EVO 50, LVC EVO 50, N45, n50 (N50), N50PS, N50TRONIC PDS-PBS, N600, N600 EVO, N700, N700F, N700F PS, N700PS, N90, NE1000ECO, S021, S026, V45, V50, W350, W700A

SILANOS Dishwasher hood type 1000, 1300, 1300S, E1000, N1000, N1000TRONIC, N1300, N1300TRONIC, NE1000PRIMA

SILANOS Glasswasher/Cupwasher 020, 030, 030PS, 630, A630TRONIC PS-PDG-PBG, A670F PS, DC050, E40, S021PS, S025, S025PS, S026PS, S030, S030PS, S045, S045 PLUS, S045PS, S045PS PLUS, S050, S050 PLUS, S050PS, S050PS PLUS, SVELTINA

SILANOS Pan/utensilwashing machines LP57, LP57 TRONIC

SILKO Sausage grill electric CRE6220, CRE6230

SIMAG Icemaker SD30

TEIKOS Dishwasher TS-601, TS-601-PS, TS-603, TS-603-PS, TS-721-SP, TS-723-SP, TS-820-PS, TS-830-PS, TS-983, TS-983-SP

TEIKOS Dishwasher hood type TS-103

TEIKOS Glasswasher/Cupwasher TS-820, TS-821, TS-830

WHIRLPOOL Dishwasher AGB 646-WP, AGB 668-WP

WHIRLPOOL Washing machine 853701029300 (AWG010/WP), 853702029400 (AWG020/WP), 853703029400 (AWG030/WP), 853704129000 (AWG041), 853704229000 (AWG042), 853705129000 (AWG051), 853705329030 (AWG053/03), 853705529000 (AWG055), 853706329000 (AWG063), 853706329010 (AWG063/BS), 853706429000 (AWG064/BL), 853708129040 (AWG081/BS), 853708329000 (AWG083), 853708329010 (AWG083/PH/BS), 853708529010 (AWG085), 853708529000 (AWG085/PH), 853701029300 (AWG1010), 853701229400 (AWG1012), 853702029400 (AWG1020), 853703029400 (AWG1030), 853725129150 (AWG251/PW), 853725229150 (AWG252/PW), 853725529150 (AWG255/PW), 853728129020 (AWG281), 853728129150 (AWG281), 853728429150 (AWG284/PW), 853728529150 (AWG285/PW), 853728629150 (AWG286/WP), 853729529150 (AWG295/PW), 853751329000 (AWG513), 853754129000 (AWG541), 853754329000 (AWG543), 853760229150 (AWG5602/WP), 853760529150 (AWG5605), 853761529150 (AWG5615), 853763329150 (AWG5633), 853760529150 (AWG605/WP), 853761029150 (AWG610/WP), 853761029160 (AWG610/WP), 853761129150 (AWG611/WP), 853761429150 (AWG614/WP), 853761529150 (AWG615/WP), 853762029150 (AWG620/WP), 853762329150 (AWG623/WP), 853763129220 (AWG631), 853763329150 (AWG633/WP), 853763429150 (AWG634/WP), 853763829150 (AWG638), 853763829150 (AWG638/WP), 853765229150 (AWG652/WP), 853765829150 (AWG658/PW), 853768118350 (AWG681/WP), 853768129150 (AWG681/WP), 853769029120 (AWG690/WP), 853769029170 (AWG690/WP), 853769129120 (AWG691/WP), 853769229120 (AWG692/WP), 853769429120 (AWG694/WP), 853769529120 (AWG695/WP), 853769629120 (AWG696/WP), 853769829120 (AWG698/WP), 853761029160 (AWG7610),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

853780229120 (AWG802F), 853780329120 (AWG803/PW), 853780429120 (AWG804), 853761429150 (AWG8614), 853762029150 (AWG8620), 853763429150 (AWG8634), 853788229120 (AWG882/PW), 853788429120 (AWG884/PW), 853788529120 (AWG885/PW), 853789229120 (AWG892), 853789329120 (AWG893/PW), 853789429120 (AWG894), 853725029150 (C5100), 853725129150 (C5101), 853725229150 (C5111), 853725529020 (C550), 853725529150 (C5501), 853765829150 (C5511), 853728129150 (C8101), 853768629450 (C846), 853728529150 (C8501), 853780329120 (EM1053), 853788229120 (EM802), 853788529120 (EM840), 853788429120 (EM851), 853789229120 (EM851/BL), 853789229120 (EM951), 853789429120 (EM952), 853780329120 (LE1092), 853789329120 (LE963), 853751329000 (M1032), 853761229150 (P8612), 853780429120 (SLE1093)

WOLK Dishwasher 400HP, 450, 500, 500HP, 563, WK1, WK120, WK2, WK3, WK3T, WK4, WK50, WKD50, WKD500, WKD500DP, WKD500P, WKD500S, WKD500W, WKD500WDP, WKD500WP, WKD500WS, WKD50CD, WKD50CDP, WKD50DP, WKD50MX, WKD50S, WKD50SX, WKD50X, WKG35X, WKG39, WKG39DP, WKG39S, WKG39SX, WKG39X, WKG450, WKT50

WOLK Dishwasher conveyor type WKR160, WKR190, WKR26, WKR270, WKR320, WKRA3000, WKU02, WKU03, WKU04, WKU05

WOLK Dishwasher hood type 120, 1200, 1500, WKH500, WKH500E, WKH500EP, WKH500P, WKHH50DDP

WOLK Glasswasher/Cupwasher 350, 400, WKG350, WKG350DP, WKG350P, WKG350S, WKG390, WKG390DP, WKG390S, WKG39WD, WKG39WDP, WKH50, WKH50P, WKH50X

ZANUSSI Boiling pan electric RPI/E240 (168133), RPI/E260 (168134), RPI/E260P (168136), XPI/E240 (168533), XPI/E260 (168534), XPI/E260P (168536), JPI/E240 (168733), JPI/E260 (168734), MPI/E240 (168933), MPI/E260 (168934), MPI/E260P (168936), PPI/E260P (178138), OPI/E260P (178438), TPI/E260P (178738), KPI/E10 (200273), KPI/E15 (200274), KPI/E15A (200279), KPI/E06 (200281), KPI/E15H (200286), KPI/E10H (200288), QPI/E10 (210273), QPI/E15 (210274), QPI/E06 (210281), QPI/E15H (210286), QPI/E10H (210288), WPI/E10 (220273), WPI/E15 (220274), WPI/E15A (220279), WPI/E06 (220281), WPI/E15H (220286), WPI/E10H (220288)

ZANUSSI Boiling pan gas RPI/G260P (168135), XPI/G260P (168535), MPI/G260P (168935), PPD/G260 (178134), PPI/G260P (178136), OPD/G260 (178434), OPI/G260P (178436), TPD/G260 (178734), TPI/G260P (178736), KPI/G10 (200271), KPI/G15 (200272), KPD/G10 (200275), KPD/G15 (200276), KPD/G15A (200277), KPI/G15A (200278), KPI/G06 (200280), KPI/G15H (200285), KPI/G10H (200287), QPI/G10 (210271), QPI/G15 (210272), QPI/G06 (210280), QPI/G15H (210285), QPI/G10H (210287), WPI/G10 (220271), WPI/G15 (220272), WPD/G10 (220275), WPD/G15 (220276), WPD/G15A (220277), WPI/G15A (220278), WPI/G06 (220280), WPI/G15H (220285), WPI/G10H (220287)

ZANUSSI Bratt pan electric HBR/E820 (201554), HBR/E825 (201555), HBR/E800 (201564), HBR/E805 (201565), HBR/E810 (201566), HBR/E815 (201567), HBR/E811 (201568), HBR/E816 (201569), HBR/E800UK (201571), ZBR/E820 (211554), ZBR/E825 (211555), ZBR/E800 (211564), ZBR/E805 (211565), ZBR/E810 (211566), ZBR/E815 (211567), ZBR/E811 (211568), ZBR/E816 (211569), ZBR/E800UK (211571), ABR/E820 (221554), ABR/E825 (221555), ABR/E800 (221564), ABR/E805 (221565), ABR/E810 (221566), ABR/E815 (221567), ABR/E811 (221568), ABR/E816 (221569), ABR/E800UK (221571), OBR/E800UK (221576)

ZANUSSI Bratt pan gas HBR/G820 (201534), HBR/G825 (201535), ABR/G820 (221534), ABR/G825 (221535), HBR/G803 (295003), HBR/G804 (295004), HBR/G803 (295006), HBR/G804 (295008), HBR/G803 (295009),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

HBR/G805 (295012), HBR/G1003 (295013), HBR/G1003 (295014), HBR/G1004 (295018), HBR/G803 (295051),  
HBR/G804 (295052), HBR/G1013 (295057), HBR/G803 (2KB03B), HBR/G804 (2KB04B), HBR/G1003 (2KB07B),  
HBR/G1013 (2KB08B), HBR/G1004 (770213)

ZANUSSI Convection oven FCF101ELN (240212), FCS061E4LN (240361), FCS061EXLN (240379),  
CS20ME4/200-3 (260054), CS20ME4/230-3 (260055), CS20ME6/230-3 (260056), CS20ME4/400-3NE (260059),  
CS20ME4/400-3 (260060), CS20ME4/440-3 (260061), CS20MT4/400-3N (260062), CS20MT6/400-3N (260063),  
CS20GE4/200-3 (260064), CS20GE4/230-3 (260065), CS20GE6/230-3 (260066), CS20GE4/400-3NE (260069),  
CS20GE4/400-3 (260070), CS20GE4/440-3 (260071), CS20GT4/400-3N (260072), CS20GT6/400-3N (260073),  
CS20LCE4/200-3 (260074), CS20LCE4/230-3 (260075), CS20LCE6/230-3 (260076), CS20LCE4/400-3N (260079),  
CS20LCE4/400-3 (260080), CS20LCE4/440-3 (260081), CS20LCT4/400-3N (260082), CS20LCT6/400-3N  
(260083), RCV061E2 (697401), RCV061E4 (697405), RCF101G (697502), RCF101E (697503), NCF/E101/1  
(724056), NCF/E102/1 (724057), ZCV/E6T4 (775061), ZCF/E101/1 (775106), ZCF/E102/1 (775107)

ZANUSSI Convection oven electric FCVE6L3J (240110), FCV/E61/1 (240123), FCV/E61/1 (240125), FCV/E61/1  
(240131), FCV/E61/1 (240133), FCV/E6L3 (240153), FCV/E20L3 (240157), FCVE202L3 (240159), FCV/E6L4  
(240161), FCV/E20L6 (240187), FCVE202L6 (240189), FVC/E201/1 (240196), FVC/E202/1 (240198), FCFE101-0  
(240206), FCFE102-0 (240207), FCFE201-0 (240208), FCFE202-0 (240209), FCFE101-1J (240267), FCFE102-1J  
(240268), FCS061E44J (240300), FCS061EP (240304), FCS061E3CI (240306), FCS201E4 (240326), FCS201EP  
(240328), FCS202E4 (240330), FCS202EP (240332), FCS061E4 (240353), FCS061E3NS (240370), FCS061EX  
(240380), FCFE6D (241051), FCFE6D (241052), FCFE10 (241150), FCFE10UK (241155), FCFE20 (241250),  
FCFE20UK (241255), FCFE40 (241350), FCFE40D (241351), FCFE40UK (241355), PFCFE40F (241365), FCFE6  
(241550), FCFE6UK (241555), PFCFE6 (241565), FCFE6J50 (243200), FCFE6J60 (243202), FCFE10J (243206),  
FCFE10J (243208), FCFE20J (243214), FCFE20J (243216), FCFE40J (243222), FCFE40J (243224), FCVE6-1U  
(244240), FCVE6-3U (244245), FCVE6-1 (244301), FCVE6-3 (244303), FCVE6-1UK (244341), FCVE6-3UK  
(244343), FCVE10-2 (245302), FCVE10-4 (245304), FCVE10-2UK (245342), FCVE10-4UK (245344), FCVE20-2  
(246302), FCVE20-4 (246304), FCVE20/P-V (246319), FCVE20-2UK (246342), FCVE20-4UK (246344), FCVE20-V  
(246502), FCVE20VUK (246542), CS7ME4/200-3 (260000), CS7ME4/230-3 (260001), CS7ME4/400-3N (260002),  
CS7ME6/400-3N (260003), CS7ME4/400-3N/EO (260004), CS7ME4/400-3/50HZ/MA (260005),  
CS7ME4/440-3/60HZ/MA (260006), CS7MT4/400-3N (260007), CS7GE4/200-3 (260008), CS7GE4/230-3  
(260009), CS7GE4/400-3N (260010), CS7GE6/400-3N (260011), CS7GE4/400-3N/EO (260012),  
CS7GE4/400-3/50HZ/MA (260013), CS7GE4/440-3/60HZ/MA (260014), CS7GT4/400-3N (260015),  
CS7LCE4/200-3 (260016), CS7LCE4/230-3 (260017), CS7LCE4/400-3N (260018), CS7LCE6/400-3N (260019),  
CS7LCE4/400-3N/EO (260020), CS7LCE4/400-3/50HZ/M (260021), CS7LCE4/440-3/60HZ/M (260022),  
CS7LCT4/400-3N (260023), CS10ME4/200-3 (260024), CS10ME4/230-3 (260025), CS10ME6/230-3 (260026),  
CS10ME4/400-3N (260027), CS10ME6/400-3N (260028), CS10ME4/400-3N/EO (260029),  
CS10ME4/400-3/50HZ/M (260030), CS10ME4/440-3/60HZ/M (260031), CS10MT4/400-3N (260032),  
CS10MT6/400-3N (260033), CS10GE4/200-3 (260034), CS10GE4/230-3 (260035), CS10GE6/230-3 (260036),  
CS10GE4/400-3N (260037), CS10GE6/400-3N (260038), CS10GE4/400-3N/EO (260039),  
CS10GE4/400-3/50HZ/M (260040), CS10GE4/440-3/60HZ/M (260041), CS10GT4/400-3N (260042),  
CS10GT6/400-3N (260043), CS10LCE4/200-3 (260044), CS10LCE4/230-3 (260045), CS10LCE6/230-3 (260046),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CS10LCE4/400-3N (260047), CS10LCE6/400-3N (260048), CS10LCE4/400-3N/EO (260049), CS10LCE4/400-3/50HZ/ (260050), CS10LCE4/440-3/60HZ/ (260051), CS10LCT4/400-3N (260052), CS10LCT6/400-3N (260053), CS20ME4/400-3N (260057), CS20ME6/400-3N (260058), CS20GE4/400-3N (260067), CS20GE6/400-3N (260068), CS20LCE4/400-3N (260077), CS20LCE6/400-3N (260078), C7E4/200-3 (260100), C7E4/230-3 (260101), C7E4/400-3N (260102), C7E6/400-3N (260103), C7PE4/200-3 (260104), C7PE4/230-3 (260105), C7PE4/400-3N (260106), C7PT4/400-3N (260107), C104200-3 (260108), C104230-3 (260109), C104400-3N (260110), C106400-3N (260111), C10T4/400- (260112), C10P4200-3 (260113), C10P4230-3 (260114), C10P44003N (260115), C10P64003N (260116), C10PT4/400 (260117), C204200-3 (260118), C20230-3 (260119), C204400-3N (260120), C206400-3N (260121), C20T4/400- (260122), C20P4200-3 (260123), C20P4230-3 (260124), C20P44003N (260125), C20P64003N (260126), C20PT4/400 (260127), 5711-3-6 (260280), 5711-3-7 (260281), 5711-3-8 (260282), 5711-3-10 (260283), 5711-3-8CH (260285), 5711-3-10CH (260286), 5714-3-6 (260300), 5714-3-7 (260301), 5714-3-8 (260302), 5714-3-8E (260303), 5714-3-10 (260304), 5717-3-6 (260310), 5717-3-7 (260311), 5717-3-8 (260312), 5717-3-8E (260313), 5717-3-10 (260314), 5717-3-8M (260315), 5717-3-8C (260316), 5717-3-8M (260317), 5711-3-10F (260360), 5711-3-10S (260361), AOS061EA (260450), AOS061EB (260451), AOS101EA (260452), AOS101EB (260453), AOS201EA (260454), AOS201EB (260455), AOS061EA3J (260456), AOS061EB3J (260457), AOS101EA3J (260458), AOS101EB3J (260459), AOS201EA3J (260460), AOS201EB3J (260461), AOS061EA2N (260462), AOS061EB2N (260463), AOS101EA2N (260464), AOS101EB2N (260465), AOS201EA2N (260466), AOS201EB2N (260467), AOS101EB5M (260469), AOS101EB6M (260472), AOS061EA0H (260510), AOS061EB0H (260511), AOS101EA0H (260512), AOS101EB0H (260513), AOS201EA0H (260514), AOS201EB0H (260515), ECFE101-0 (260706), ECFE102-0 (260707), ECV/E6T4 (260761), ECV/E20T4 (260767), ECVE202T4 (260769), ECV/E20T6 (260787), ECVE202T6 (260789), FCF/E6 (2FC52B), FCFE202 (2FC55B), FCV/E6-1 (2FM02B), FCV/E6-1 (2FM04B), ZOFVCV/E102 (2FM12B), ZOFVCV/E104 (2FM14B), ZOFVCV/E202 (2FM22B), ZOFVCV/E204 (2FM24B), ACFE101-0 (697306), ACFE102-0 (697307), ACFE201-0 (697308), ACFE202-0 (697309), JCF/E101/1-1 (697366), JCF/E102/1-1 (697367), JCF/E101/1-2 (697396), JCF/E102/1-2 (697397), AFCF/E6 (697680), FF/E10 (697700), ACV/E6C3 (697821), ACV/E20C4 (697847), ACVE202C4 (697849), ACVE20C6 (697887), ACV/E202/1 (697889), COCO10E (724208), COCO20E (724214), COCO6E (724224), 4238N (724238), NCV/E6L2 (724251), FCFE061 (770234), FCFE101 (770258), FCFE201 (770259), ZCV/E20T4 (775067), ZCV/E202/1 (775069), ZCV/E20T6 (775087), ZCV/E202/1 (775089), ZCF/E201/1-0 (775108), ZCF/E202/1-0 (775109), FCV/E20-V (775800)

ZANUSSI Convection oven gas FCV/G6L3TOWNGAS (240101), FCV/G6L3 (240102), FCV/G20L3 (240106), FCVG202L3 (240108), FCV/G6L3JAP (240116), FCV/G6L4 (240160), FCV/G20L6 (240186), FCVG202L6 (240188), FCV/G201/1 (240195), FCV/G202/1 (240197), FCFG101/0 (240201), FCFG102-0 (240202), FCFG201-0 (240203), FCFG202-0 (240204), FCFG102-0T (240262), FCS201G4 (240335), FCS201GP (240337), FCS202G4 (240339), FCS202GP (240341), FCFG6D (241006), FCFG10 (241100), FCFG10D (241105), FCFG10NL (241120), FCFG20 (241200), FCFG20D (241205), FCFG20F (241210), PFCFG20 (241215), FCFG40 (241300), FCFG41 (241301), FCFG40D (241306), FCFG40F (241310), PFCFG40F (241315), FCFG6 (241500), FCFG6F (241510), PFCFG6 (241515), FCFG10J (243204), FCFG10J (243205), FCFG20J (243210), FCFG20J (243212), FCFG40J (243218), FCFG40J (243220), FCFG6J (243226), FCFG6J (243227), FCFG6J (243228), FCFG6J (243229), FCFG10J (243230),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

FCFG10J (243232), FCFG20J (243234), FCFG20J (243236), FCFG41J (243238), FCFG40J (243240), FCVG6-1 (244401), FCVG6-3 (244403), FCVG6-1UK (244441), FCVG6-3UK (244443), FCVG10-ISG (245405), 5711-2-6 (260200), 5711-2-7 (260201), 5711-2-8 (260202), 5711-2-10 (260203), 5711-2-8CH (260205), 5711-2-10CH (260206), 5714-2-6 (260220), 5714-2-7 (260221), 5714-2-8 (260222), 5714-2-10 (260223), 5717-2-6 (260230), 5714-2-7 (260231), 5714-2-8 (260232), 5714-2-10 (260233), 5711-2-6L (260240), 5711-2-7L (260241), 5711-2-8L (260242), 5711-2-10L (260243), 5714-2-6L (260260), 5714-2-7L (260261), 5714-2-8L (260262), 5714-2-10L (260263), 5714-2-6L (260270), 5714-2-7L (260271), 5714-2-8L (260272), 5714-2-10L (260273), AOS061GA (260550), AOS101GA (260552), AOS201GA (260554), AOS201GB (260555), ECFG101-0 (260701), ECFG102-0 (260702), ECFG201-0 (260703), ECFG202-0 (260704), ECV/G6T4 (260760), ECV/G20T4 (260766), ECVG202T4 (260768), ECV/G20T4J (260776), ECV/G20T6 (260786), ECVG202T6 (260788), FCF/G6 (2FC02B), FCFG101 (2FC03B), FCFG201 (2FC04B), FCFG202 (2FC05B), FCFC202 (2FC07B), FCV/G6-1 (2FM06B), ZOFCV/G6-3 (2FM08B), ACFG101-0 (697301), ACFG102-0 (697302), ACFG201-0 (697303), ACFG202-0 (697304), JCF/G101/1-1 (697361), JCF/G102/1-1 (697362), JCF/G101/1-2 (697391), JCF/G102/1-2 (697392), FF/G20 (697730), ACV/G6C3 (697810), ACV/G20C4 (697836), ACVG202C4 (697838), ACV/G20C6 (697876), ACVG202C6 (697878), NCF/G101/1 (724051), NCF/G102/1 (724052), COCO10G (724206), COCO20G (724212), COCO6G (724222), 4236N (724236), NCV/G6L2 (724242), COCVE423AF (724302), FCVG10-ISG (724350), ZOFCF/G10D (770334), ZOFCF/G6D (770345), ZOFCF/G20D (770347), ZCV/G6T4 (775060), ZCV/G20T4 (775066), ZCV/G202/1 (775068), ZCV/G20T6 (775086), ZCV/G202/1 (775088), ZCF/G101/1 (775101), ZCF/G102/1 (775102), ZCF/G201/1 (775103), ZCF/G202/1 (775104)

ZANUSSIDishwasherNUCABG (400135), NUCABWSG (400136), LS360F (500042), LS360DK (500043), LS365F (500052), LS365 (500053), LS365PH (500054), LS360D (500110), LS365D (500111), LS360 (500120), LS365 (500121), LS360/63 (500130), LS365/63 (500131), LS367 (500145), LS7D (503000), LS7 (503001), LS7UK/RP (503002), LV70 (503003), LS7F (503004), LS7DEK (503005), LS7/1UK (503006), LS7/9 (503007), LS7/DP (503008), LS7/60 (503009), WT40/9 (503010), WT40/F (503011), LS7HD (503012), WT40/J50 (503013), WT40/J60 (503014), WT40UKRP (503015), PH4/WT40 (503016), PH4RBP/WT40 (503017), LS360 (5CF05B), LS365F (5CF06B), FL700 (698015), HYDRA700 (727015), Z70 (777310)

ZANUSSI Hot cupboard RI12H1F (732061), RI27H2F (732062), RI12H2FT (732063), RI27H4FT (732186), BCFCV101/1 (922112), BCFCV102/1 (922113), BCFCV101/1 (922124), BCFCV102/1 (922125)

ZANUSSI Icemaker CIM15A (105000), CIM15W (105010), CIM45A (105040), CIM45W (105050), CIM65A (105060), CIM65W (105070), CIM120AS (655080), CIM120WS (655090)

ZANUSSI Refrigerated cupboard KUMAC (881433)

ZEROWATT Washing machine 39980842 (AMBRA 33-800), 39966320 (KIT 0642.1 R), 39966346 (KIT 0842.1R), 39966338 (KIT LB0651.1), 39966353 (KIT LB1051.1), 39966494 (KIT R-Z633.1), 39950100 (LA 500 BROWN), 39950118 (LA 500 WHITE), 39962113 (LA T1007 240), 39930425 (LB 0833.1R), 39953146 (LB 204 E), 39953740 (LB 250), 39958111 (LB 258), 39955117 (LB 265), 39958707 (LB 268), 39956305 (LB 5120 LX), 39930045 (LB 633.1 ROM), 39980016 (LB AMBRA 33), 39980206 (LB EHX 33), 39980115 (LB EX 33), 39980099 (LB EX 336), 39953245 (LB G502), 39932421 (LB G512), 39930102 (LB H33 HAJDU), 31138001 (LB HV 16 IT), 39980958 (LB HX 33.8), 31143001 (LB HX 33.86A), 39980222 (LB HX 3307), 39980214 (LB HX 339), 39980073 (LB HZ 33), 39980800 (LB LX 33-800), 39980057 (LB M.SPACE), 39980123 (LB MILAD339X), 39932454 (LB



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

PEA.WM400), 39931647 (LB PEA.WM800), 39931316 (LB PEAB.600), 39952437 (LB PEAB.600), 39930060 (LB PEAB.633), 39932017 (LB PX675), 39980040 (LB S 3300X), 39930078 (LB S330X SEL), 39930029 (LB SPACE XI), 39932009 (LB SUPER 5 X), 39932801 (LB SUPER 7 X), 39930003 (LB X33 I), 39930409 (LB X33-800), 39932405 (LB Z410), 39932413 (LB Z412), 39932488 (LB Z522), 39980891 (LB ZX 33.8), 39931613 (LB ZX1047 IE), 39931662 (LB ZX1247 EL), 39931209 (LB ZX443), 39931217 (LB ZX447 I), 39931225 (LB ZX643), 39931233 (LB ZX645), 39931241 (LB ZX647 I), 39931258 (LB ZX648 PI), 39931605 (LB ZX847 IE), 39957774 (LB.33 IDRO), 39950134 (LB.500 LX), 39953898 (LB.540), 39953880 (LB.542), 39954508 (LB.546), 39954110 (LB.565 IDRO), 39958285 (LB.585 IDRO), 39955547 (LB.662), 39955224 (LB.668), 39958798 (LB.688 240-5), 39958079 (LB.MILLE LX), 39957790 (LB.SPACe IDR), 39980131 (LBSELEC3307X)

