

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Termostat ajustabil -30°C +30°C #3444930

Fara TVA: 218,49 Lei

Pret cu TVA: 260,00Lei

Termostat ajustabil -30°C +30°C #3444930

3 contacte 6A 250V

Cu surub ajustabil

Lungime capilar 1450mm

Bulb ø6x105mm

Compatibil cu:

ANGELO PO 32Z1090

SAGI 32Z1090

32Z1090 MBM

ANGELO PO Blast chiller SM03LT7, SM03LT7A, SM03LT7M, SM1LAM, SM1LAT, SM1LM, SM1LT, SM1LT7, SM1LT7A, SM1LT7M

ANGELO PO Display cabinet refrigerated C12Q1M, C12Q2, C12Q2M, C8Q, C8QL, C8QV-0PR02

ANGELO PO Neutral counter refrigerated 6BMABA, 6BMABB, 6BMABM, 6BMABZ, 6BMBBA, 6BMBBB, 6BMBBM, 6BMBBZ, 6BMCBA, 6BMCBB, 6BMCBM, 6BMCBZ, BM1AB, BM1BB, BM1CB

ANGELO PO Proving oven AF1B, AF1B-0PR01, AF1N, AF1N-0PR01, AF2B, AF2B-0PR01, AF2N, AF2N-0PR01

ANGELO PO Refrigerated cupboard 120B, 135B, 135BA, 135BN, 135BNX, 135BX, 135BXE, 135BXR, 135NN, 135NNX, 135XR, 40CP, 40CPX, 55B, 65B, 65BA, 65BX, 65BX-2, 65BXE, 65BXR, 65NB, 65NBX, 65XR, CX120B, CX130B, CX140B, CX140BN, CX140BR, CX150B, CX150BN, CX150BR, CX55B, CX60B, CX65B, CX65BR, CX65NB, CX70B, CX70BR, CX70NB, FG2B, FSD1B, FSD2B, FSDR2B, FX150B, FX70B, MD150BPV, MD70BPV, MX120B, MX130B, MX140B, MX150B, MX55B, MX60B, MX65B, MX70B, PD70BPV, S1200B, S1200B4, S1200BE, S125B, S125B-4, S125BE, S125BX, S125BX-4, S600B, S600B2, S600BE, S60B-2, S60BE, S60BX, S60BX-2, SP120B, SP120BN, SP135B, SP135BN, SP55B, SP65B, SP65NB, TD65B, ZE65BR, ZE65R

MBM Refrigerated cupboard 60B1

SAGI Blast chiller AM03LT7, AM03LT7A, AM03LT7M, AM1LM, AM1LT, AM1LT7, AM1LT7A, AM1LT7M

SAGI Display cabinet KC12Q1, KC12Q1M, KC12Q2, KC12Q2M, KC8Q, KC8Q-0P142, KC8QA-0P142, KC8QL-0P141, KC8QL-0P142, KC8QV-0P142, KC8QX-0P142

SAGI Proving oven KAF1B, KAF1B-0P141, KAF1N, KAF1N-0P141, KAF2B, KAF2B-0P141, KAF2N, KAF2N-0P141, KAFRI, KBF16, KBF16A, KBF16M, KBF21, KBF21A, KBF21M

SAGI Refrigerated cupboard 60B1, AS120B, AS120BN, AS140B, AS140BN, AS150B, AS55B, AS65B, AS70B, AX120B, AX120BN, AX130B, AX140B, AX140BN, AX150B, AX55B, AX60B, AX65B, AX70B, CD70BPV, DMG51ME, E1200B, E1200B4, E1200BE, E125B, E125B-4, E125BE, E125BPL, E125BPLE, E125BX, E125BX-4, E125BXE, E600B, E600B2, E600BE, E60B, E60B-2, E60BE, E60BPL, E60BPLE, E60BX, E60BX-2, E60BXE, F120B, F40CP, F55B, FD140B, FD65B, GS120B, GS120BN, GS130B, GS140B, GS140BB, GS140BN, GS140BN2, GS140BPV,

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

GS140BR, GS150B, GS55B, GS60B, GS65B, GS65BCP, GS65BPV, GS65BR, GS65NB, GS70B, GX130B, GX150B, GX60B, GX70B, KFG2B, KFSD1B, KFSD2B, KFSD2B2, N135B, N135BN, N135BPS, N65B, N65BPS, N65NB, P135B, P135BN, P65B, RX150B, RX150BB, RX150BN, RX150BN2, RX150BR, RX70B, RX70B-2, RX70BCP, RX70BR, RX70NB, SX120B, SX120BN, SX120NN, SX135B, SX135B-3, SX135B-4, SX135BAX, SX135BB, SX135BCP, SX135BE, SX135BN, SX135BN2, SX135BR, SX135NN, SX135R, SX55B, SX65B, SX65B-2, SX65BAX, SX65BE, SX65BR, SX65CPB, SX65NB, SX65R, VD150BPV, VD70BPV

SAGI Refrigerated table KIAB, KIABA, KIABM, KIBB, KIBBA, KIBBM, KICB, KICBA, KICBM, KIRAB, KIRABA, KIRABM, KIRBB, KIRBBA, KIRBBM, KIRCB, KIRCBA, KIRCBM, TM1A-B, TM1A-BA, TM1A-BX, TM1B-B, TM1B-BA, TM1B-BX, TM1C-B, TM1C-BA, TM1C-BX

