



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Termostat siguranta trifazic 350°C 16A TC-1SB31KM #5278-0-133-3-K

Fara TVA: 84,03 Lei

Pret cu TVA: 100,00Lei

Termostat siguranta trifazic 350°C 16A TC-1SB31KM #5278-0-133-3-K

Temperatura maxima 350°C

Numar de poli 3

Capacitate de comutare 16A

Tensiune 400V

Diametru sonda 3mm

Lungime sonda 235mm

Lungime capilar 1180mm

Material inox

Compatibil cu:

LF 3444354

GEV 375228

LF 3744140

GEV 390142

LF 3444445

GEV 375565

ALPENINOX

APACH

BARON

CASTA

COLGED

DEXION

ELECTROLUX PROFESSIONAL

ELETTROBAR

EMMEPI

ERRE 2

GICO

GIORIK

JUNO-RÖDER-SENKING

LINCAR INOX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

MBM

METOS

OFFCAR

OLIS

PRIMAX

SMEG

TECNOINOX

WHIRLPOOL - INDESIT

ZANUSSI

55.32562.808 EGO

55.32562.805 EGO

EGO 55.32574.040

EGO 55.34162.800

818731004.EPMS

EPMS

APACH Bratt pan APME-47P

APACH Convection oven A1-10LD, A1-20LD, A1-6LD

APACH Kitchen APRG-117FE, APRG-77FE

APACH Kitchen electric APRE-117FE, APRE-77FE, APRE-77QFE, APRE-77QFEK, APRES-77FE

DEXION Bain-marie electric ME066-03-006

DEXION Fry top LX9EFT4, LX9EFT9, ME099-05-203, ME099-15-203, ME459-05-202

DEXION Kitchen electric D77E4FQ, LX7E4F, LX9E4F, LX9E4FQ, ME099-05-009, ME099-05-010, ME139-05-010,  
ME139-05-020

DEXION Kitchen gas LX9G4SFE

DEXION Kitchen glass-ceramics LX7EVC4F

DEXION Oven under cooktop electric LX9EF09

GICO Fry top FT7N320TR

GICO Kitchen electric CE7N030C, CE7N030T, CE7N050C, CE7N050FEB, CE7N050T, CE7N055C, CE7N055FEB,  
CE7N055T, CE9N030C, CE9N030T, CE9N050C, CE9N050FE, CE9N050T, CE9N054C, CE9N054FE, CE9N054T,  
CE9N172C, CE9N172FEA

GICO Kitchen gas CG7N020C, CG7N040C, CG7N162C, CG7N162FEBA, CG9N040HC, CG9N040HF, CG9N040HT,  
CT7N224C, CT7N224FBA, CT7N224T

MBM Bain-marie electric EBM66, EBM90

MBM Bratt pan EMT477, EMT777

MBM Fry top EFT408, EFT45, EFT45L, EFT45R, EFT49, EFT498, EFT49L, EFT49R, EFT49RC, EFT777, EFT90,  
EFT908, EFT90L, EFT90LR, EFT90R, EFT99, EFT998, EFT99L, EFT99LR, EFT99LRC, EFT99R, EFT99RC, EFTA498,  
EFTA998

MBM Kitchen electric E4F, E4F77, E4F77Q, E4F8, E4F9, E4F98Q, E4F9Q, E6FA, E6FA77, E6FA77Q, E6FA8,  
E6FA9, E6FA9Q

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

MBM Kitchen gas G4SFE, G4SFE77, G4SFE77P, G4SFE9, G4SFE98, G6SFEA, G6SFEA77, G6SFEA8, G6SFEA9, G6SFEA98, G6SFMG8, MG7G4SFE77, MG7G6SFEA77

MBM Oven under cooktop electric EF077, EF09, EFB09

MBM Pot stove MG7E4FP77Q, MG7E6FA77Q

MBM Pot stove gas G4SFE8

MBM Pot stove glass-ceramics EVC4F77, MG7EVC4F77

MBM Solid top range GT4SF2E77, MG7ETF77

OFFCAR Fry top 7FTE40, 7FTE40L, 7FTE40LC, 7FTE40R, 7FTE40RC, 7FTE80, 7FTE80L, 7FTE80LC, 7FTE80LR, 7FTE80LRC, 7FTE80R, 7FTE80RC, 7TFEL, 7TFELC, 7TFELLC, 7TFELR, 7TFELRC, 7TFER, 7TFERC, 7TFERR, 7TFERRC, 8FTE40, 8FTE40L, 8FTE40LC, 8FTE40R, 8FTE40RC, 8FTE80L, 8FTE80LC, 8FTE80LR, 8FTE80LRC, 8FTE80R, 8FTE80RC, 8TFEC, 8TFEL, 8TFELC, 8TFELL, 8TFER, 8TFERC, 9FTE45, 9FTE45LC, 9FTE90L, 9FTE90LC, 9FTE90LR, 9FTE90LRC, 9FTE90R, 9FTE90RC

OFFCAR Kitchen electric 7CTE14, 7CTE16, 7CTE26, 7CTE26C, 8CQE14, 8CQE16, 8CQE26, 8CQE26C

OFFCAR Kitchen gas 7CBG14FE, 7CBG16XLE, 7CBG26CFE, 7CBG26FE, 8CBG14FE, 8CBG16FE, 8CBG16XLE, 8CBG26CFE, 8CBG26FE, 8TPG10FE, 8TPG22CFE, 9CBG14FE, 9CBG16FE, 9CBG16XLE, 9CBG28FE, U7CBG14FE, U7CBG16FE

OLIS Kitchen electric 74-02CTEE

OLIS Kitchen gas 2FX-PCF, 4FX, 4FX-PCF, 72-02CG, 72-02TCG, 74-02-2CTGG, 74-02CG, 74-02CGE, 74-02CGG, 74-02CTG, 74-02CTGE, 74-02CTGG, 74-02TCG, 74-02TCTG, 76-02-4CTGG, 76-02CG, 76-02CGE, 76-02CGEE, 76-02CGFL, 76-02CGG, 76-02CGGE, 76-02CTG, 76-02CTGG, 76-02CTGGE, 76-02TCG, 76-02TCTGG

OLIS Kitchen glass-ceramics 72-02TVTCV, 72-02VTCV, 74-02TVTCV, 74-02VTCEV, 74-02VTCV

OLIS Solid top range 74-02CTE, 74-02TCTE

SMEG Convection oven ALFA341EK, ALFA341VE, ALFA341XM

SMEG Electric oven ALFA135B1, ALFA135BM, ALFA135BV, ALFA135GH, ALFA135VM, ALFA135X, ALFA135X1, ALFA135XB, ALFA135XM, ALFA135XP, ALFA135XV, ALFA136BM, ALFA151X, ALFA161X, ALFA161XK, ALFA200X, BU135XV, FOVP, RFT644, RFT744, RFT844, RFT844B, RFT844V

TECNOINOX Bratt pan BR35E0, BR35E1, BR35E60, BR35E61, BRM35E7, BRM4FE7, BRM70E7, BRM8FE7, BRMD4FE7, BRMD8FE7, BRMS35E0, BRMS35E1, BRS35E0, BRS35E1, BRS35E60, BRS35E61

TECNOINOX Electric oven F70E7, F70V7, F8E7, F8E9, F8V7, F8V9

TECNOINOX Fry top DFTC35E0, DFTC35E1, DFTC70E0, DFTC70E2, DFTL35E0, DFTL35E1, DFTL70E0, DFTL70E2, DFTR35E0, DFTR35E1, DFTR70E0, DFTR70E2, DFTRR70E0, DFTRR70E2, ETC35G7, ETC70G7, FTC35E0, FTC35E1, FTC35E60, FTC35E61, FTC35E7, FTC35G0, FTC35G7, FTC35GG6, FTC4E7, FTC4E9, FTC4FE7, FTC4FE9, FTC4FG7, FTC4FG9, FTC4G7, FTC4G9, FTC70E0, FTC70E2, FTC70E60, FTC70E62, FTC70E7, FTC70G0, FTC70G7, FTC70GG6, FTC8E7, FTC8E9, FTC8FE7, FTC8FE9, FTC8FG7, FTC8FG9, FTC8G7, FTC8G9, FTCD4FE7, FTCD4FE9, FTCD8FE9, FTL35E0, FTL35E1, FTL35E60, FTL35E61, FTL35E7, FTL4E7, FTL4E9, FTL4FE7, FTL4FE9, FTL70E0, FTL70E2, FTL70E60, FTL70E62, FTL70E7, FTL8E7, FTL8E9, FTL8FE7, FTL8FE9, FTLD4FE7, FTLD4FE9, FTLD8FE7, FTLD8FE9, FTR35E0, FTR35E1, FTR35E60, FTR35E61, FTR35E7, FTR4E7, FTR4E9, FTR4FE7, FTR4FE9, FTR70E0, FTR70E2, FTR70E60, FTR70E62, FTR70E7, FTR8E7, FTR8E9, FTR8FE7, FTR8FE9, FTRD8FE7, FTRD8FE9, FTRR70E0, FTRR70E2, FTRR70E60, FTRR70E62, FTRR70E7, FTRR8E7, FTRR8FE7

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

TECNOINOX Kitchen electric EFR105E7, EFR105EV7, EFR70E7, EFR70EV7, EFXR105E7, EFXR105EV7, PF12E9, PF8E9, PF8VE9, PFC70E7, PFC70V7, PFC8E7, PFC8E9, PFC8V7, PFC8VE9, PFR105E7, PFR105V7, PFR12E7, PFR12V7, PFR70E7, PFR70E71, PFR70V7, PFR70V71, PFR8E7, PFR8E71, PFR8V7, PFR8V71, PFRX105E7, PFRX105VE7, PFRX12E7, PFRX12VE7, PFS105E7, PFS105V7, PFS12E7, PFS70E7, PFS8E7, PFS8V7, PFSX105E7, PFSX105VE7, PFSX12E7, PFSX12VE7, PFU105E7, PFU105V7, PFU12E7, PFU12E9, PFU12V7, PFU12VE9, PFU70E7, PFU70V7, PFU8E7, PFU8E9, PFU8V7, PFU8VE9

TECNOINOX Kitchen gas EEF105G7, EEF105GV7, EEF70G7, EEF70GV7, EF105G7, EF105GV7, EF12G9, EF12V9, EF70G7, EF70GV7, EF70SG7, EF70SGV7, EF8G9, EF8V9, EFX105G7, EFX105GV7, PF105G7, PF105V7, PF12G7, PF12V7, PF70G7, PF70V7, PF8G7, PFG12G7, PFG12G9, PFG12V7, PFG12V9, PFG8G7, PFG8G9, PFG8V9, PFX105G7, PFX105V7, PFX12G7, PFXG12G7, PFXG12V7

TECNOINOX Solid top range PPF70E7, PPF70V7, PPF8E7, PPF8E9, PPF8VE9

ZANUSSI Fry top SRE350 (285505), SRE360 (285506), SRE370 (285507), SRE700 (285508), SRE710 (285509), SRE720 (285510), SRE350 (285745), SRE360 (285746), SRE370 (285747), SRE700 (285748), SRE710 (285749), SRE720 (285750), FTL35E6U (285809), FTR35E6U (285810), FTC35E6U (285811), FTL70E6U (285812), FTR70E6U (285813), FTC70E6U (285814)

ZANUSSI Kitchen 7701-3/85 (617112), 7501-3/85. (617120), 7501-3/90.HE.4PL.(N) (617125), 7508-3/85. (617138), 7502-3/85. (617139), 7500-3/85.HE.2PL.(N) (617416), 7503-3/85.HE.6PL (617417), 7504-3/85.HE.6PL.BO (617418), 7505-3/85 (617420), 7506-3/85.HE.CER.2KZ.(N) (617421), 7507-3/85. (617422), 7511-3/85.KF.(N) (617423), 7512-3/85.KF.BO.(N) (617424), 7500-3/90.HE.2PL.(N) (617446), 7502-3/90.HE.4PL.BO.(N) (617447), 7503-3/90.HE.6PL.(N) (617448), 7504-3/90.HE.6PL.BO.(N) (617449), 7505-3/90.HE.6PL.BO.WS.(N) (617450), 7506-3/90.HE.CER.2KZ.(N) (617451), 7507-3/90.HE.CER.4KZ.(N) (617452), 7508-3/90.HE.CER.BO.(N) (617453), 7511-3/90.KF.(N) (617454), 7512-3/90.KF.BO.(N) (617455), 7700-3/85 (617478), 7703-3/85 (617479), 7706-3/85.HE.CER.2KZ.(N) (617480), 7707-3/85.HE.4KF.CER.(N) (617481), 7711-3/85.KF.(N) (617482), 7700-3/90.HE.2PL.(N) (617498), 7701-3/90.HE.4PL.(N) (617499), 7703-3/90.HE.6PL.(N) (617500), 7706-3/90.HE.CER.2KZ.(N) (617501), 7707-3/90.HE.4KF.CER.(N) (617502), 7711-3/90.KF.(N) (617503), 7502-3/85.HE.4PL.BO.EO (617632), 7508-3/85.HE.CER.BO.EO (617640), 7505-3/85.HE.6PL.BO.WS.EO (617683), 7503-3/85.HE.6PL.EO (617818), 7508-3/85.HE.CER.BO.TOPFERK (617831), 7506-3/85.HE.CER.2KZ.EO (617851), 7506-3/85.HE.CER.2KZ.TOPFERK (617853), 7501-3/85.HE.4PL.EO (617855), 7508-3/85.HE.CER.BO.TOPFERK.EO (617920), 7509-3/85.HE.CER.6KZ.TOPFERK (618018), 7500-3/85.HE.2PL.EO (618052), 7507-3/85.HE.CER.4KZ.EO.TOPFER (618134), 7506-3/85.HE.CER.2KZ.EO.TOPFER (618135), 7510-3/85.HE.CER.6KZ.BO.TOPFER (618217), 7507-3/85.HE.CER.4KZ.TOPFERK (618235), 7507-3/85.HE.CER.4KZ.EO (618252), 7509-3/85.HE.CER.6KZ (618283), 7509-3/85.HE.CER.6KZ.EO.TOPFER (618359), 7504-3/90.HE.6PL.BO.EO (618573), 7500-2 (JUN75002), 7500-3 (JUN75003), 7501-2 (JUN75012), 7501-3 (JUN75013), 7502-2 (JUN75022), 7502-3 (JUN75023), 7502-9 (JUN75029), 7503-2 (JUN75032), 7503-3 (JUN75033), 7504-2 (JUN75042), 7504-3 (JUN75043), 7504-9 (JUN75049), 7505-2-9 (JUN750529), 7505-3 (JUN75053), 7505-9-9 (JUN750599), 7506-3 (JUN75063), 7507-3 (JUN75073), 7508-3 (JUN75083), 7510-3/90.HE.CER.6KZ (JUN7510390), 7511-2 (JUN75112), 7511-3 (JUN75113), 7512-2 (JUN75122), 7512-3 (JUN75123), 7512-9 (JUN75129), 7700-2 (JUN77002), 7700-3 (JUN77003), 7701-2 (JUN77012), 7701-3 (JUN77013), 7703-2 (JUN77032), 7703-3

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(JUN77033), 7706-3 (JUN77063), 7707-3 (JUN77073), 7709-3/85 (JUN7709385), 7709-3/90 (JUN7709390), 7711-2 (JUN77112), 7711-3 (JUN77113), 9000-3 (JUN90003), 9002-3 (JUN90023), 9004-3 (JUN90043), 9006-3 (JUN90063), 9012-3 (JUN90123), 9013-3 (JUN90133), 9015-3 (JUN90153), 9200-3-0 (JUN920030), 9200-3-8 (JUN920038), 9201-3-0 (JUN920130), 9201-3-8 (JUN920138), 9203-3-0 (JUN920330), 9203-3-8 (JUN920338), 9211-3-0 (JUN921130), 9211-3-8 (JUN921138), 9213-3-0 (JUN921330), 9213-3-8 (JUN921338), 9598-3-0 (JUN959830), 9598-3-8 (JUN959838)

1006085 SLAYER BLADES

ZANUSSI Bratt pan KBR/G2F (200301), KBR/G2C (200302), KBR/G3F (200303), KBR/G3FH (200304), KBR/G3C (200305), KBR/G3CH (200306), KBR/E2F (200307), KBR/E2C (200308), KBR/E3F (200309), KBR/E3FH (200310), KBR/E3C (200311), KBR/E3CH (200312), KBR/G2FH (200315), KBR/G2CH (200316), KBR/E2FH (200317), KBR/E2CH (200318), KBR/G3CJ (200319), QBR/G2F (210301), QBR/G2C (210302), QBR/G3F (210303), QBR/G3FH (210304), QBR/G3C (210305), QBR/G3CH (210306), QBR/E2F (210307), QBR/E2C (210308), QBR/E3F (210309), QBR/E3FH (210310), QBR/E3C (210311), QBR/E3CH (210312), QBR/G2FH (210315), QBR/G2CH (210316), QBR/E2FH (210317), QBR/E2CH (210318), WBR/G2F (220301), WBR/G2C (220302), WBR/G3F (220303), WBR/G3FH (220304), WBR/G3C (220305), WBR/G3CH (220306), WBR/E2F (220307), WBR/E2C (220308), WBR/E3F (220309), WBR/E3FH (220310), WBR/E3C (220311), WBR/E3CH (220312), WBR/G2FH (220315), WBR/G2CH (220316), WBR/E2FH (220317), WBR/E2CH (220318)

ZANUSSI Fry top KRF/E2R (200202), KRF/E2RP (200225), QRF/E2R (210202), QRF/E2RP (210225), WRF/E2R (220202), WRF/E2RP (220225)

ZANUSSI Kitchen electric KC/E1 (200107), KC/E2 (200108), KCF/E2 (200109), KC/E1E5 (200110), KC/E2E5 (200111), KCF/E2E5 (200112), QC/E1 (210107), QC/E2 (210108), QCF/E2 (210109), QC/E1E5 (210110), QC/E2E5 (210111), QCF/E2E5 (210112), QC/E2M0 (210128), QC/E2M4 (210129), QCF/E2M0 (210130), QCF/E2M4 (210131), WC/E1 (220107), WC/E2 (220108), WCF/E2 (220109), WC/E1E5 (220110), WC/E2E5 (220111), WCF/E2E5 (220112)

ZANUSSI Kitchen gas KCF/M2 (200106), KCF/W2 (200144), KCF/M2G (200156), KCF/M2E5G (200163), QCF/M2 (210106), QCF/W2 (210144), WCF/M2 (220106)

