



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

## Rezistenta 1950W 230V CANDY 91201546 #HTR016CY

Fara TVA: 29,41 Lei

Pret cu TVA: 35,00Lei

Rezistenta 1950W 230V CANDY 91201546 #HTR016CY

Putere: 1950W

Voltaj: 230V

Lungime: 270x107mm

Compatibilitate:

CANDY 91201546

OMNIA HTR016CY

LF D355326

91211037 CANDY

91201546 EPMS

852193 EPMS

91201546 HOOVER

91211037 HOOVER

1R09490002 IRCA

91201546 KELVINATOR

91201546 MAYTAG

91211037 OTSEIN

91201546 PHILCO

91201546 ROSIERES

91211037 ROSIERES

91201546 ZEROWATT

91211037 ZEROWATT

CANDY Go108-37, VHD813Z-37, VHD814ZI-37

CANDY ALISECMD106ARG (31002230)

CANDY ALISECMD106S (31001104)

CANDY ALISECMD126S (31001103)

CANDY ALSI31300EVR01 (31800038)

CANDY BELWD12V (31800051)

CANDY BELWM13VI (31800052)

CANDY BWA5119 (31800026)

CANDY BWA5120 (31800025)

CANDY C1145184 (31002407)

CANDY C2145184 (31002406)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY C2510101S (31002433)  
CANDY C514801 (31001478)  
CANDY CBD1006504 (31000684)  
CANDY CBD10175SAU (31000736)  
CANDY CBD106037CO (31000669)  
CANDY CBD116137 (31000668)  
CANDY CBD116337S (31000670)  
CANDY CBD11637 (31000666)  
CANDY CBD11637SME (31000667)  
CANDY CBD13637 (31000672)  
CANDY CBD16684 (31000768)  
CANDY CBD856504S (31000685)  
CANDY CBD9637 (31000671)  
CANDY CBE165T80 (31000675)  
CANDY CIN100TUK (31800007)  
CANDY CIN126TL37S (31800024)  
CANDY CKDLADYCL833E (31000988)  
CANDY CKDLADYCL834 (31000242)  
CANDY CKDLADYCL834E (31001121)  
CANDY CL208785S (31001178)  
CANDY CL210701S (31001170)  
CANDY CL211701S (31001429)  
CANDY CL2117101S (31002138)  
CANDY CL2127136S (31001173)  
CANDY CL212736S (31001016)  
CANDY CL214701S (31001169)  
CANDY CLD135-86S  
CANDY CLD13501 (31000932)  
CANDY CLD13586S (31000955)  
CANDY CLD135AUS (31002430)  
CANDY CM0860D01 (31001679)  
CANDY CM0860D101 (31002227)  
CANDY CM106TXT01 (31000924)  
CANDY CM106TXT03S (31000990)  
CANDY CM112680 (31000940)  
CANDY CM114680 (31001357)  
CANDY CM1146S80 (31001376)  
CANDY CM1166180 (31001975)  
CANDY CM116680 (31001356)



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY CM1265ARG (31001077)  
CANDY CM126TXT01 (31000981)  
CANDY CM126TXT16S (31000962)  
CANDY CM146HTXT01 (31000927)  
CANDY CM146HTXT03 (31000993)  
CANDY CM146TXT14M (31000913)  
CANDY CM161280 (31001045)  
CANDY CM1612J80 (31001044)  
CANDY CM1663D80 (31002526)  
CANDY CM166HTXT36 (31001008)  
CANDY CM166TXT84S (31000864)  
CANDY CM166TXT86S (31000957)  
CANDY CM207618S (31001018)  
CANDY CM208601 (31000980)  
CANDY CM208618S (31001017)  
CANDY CM210601 (31000921)  
CANDY CM2106101 (31002225)  
CANDY CM210616S (31000960)  
CANDY CM2106504S (31001113)  
CANDY CM21065AR (31001078)  
CANDY CM2106S01S (31000934)  
CANDY CM21137S (31001015)  
CANDY CM2116147 (31001738)  
CANDY CM211637S (31001014)  
CANDY CM212603S (31000992)  
CANDY CM212614 (31000909)  
CANDY CM212647 (31001283)  
CANDY CM213614 (31000910)  
CANDY CM2136147 (31001469)  
CANDY CM213647 (31001415)  
CANDY CM213680 (31000941)  
CANDY CM214614 (31000911)  
CANDY CM2146186S (31002409)  
CANDY CM214647 (31000854)  
CANDY CM214647 (31001471)  
CANDY CM214680 (31000942)  
CANDY CM214686S (31000954)  
CANDY CM215647 (31000850)  
CANDY CM216614 (31000912)



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY CM2166186S (31001735)

CANDY CM216680 (31000943)

CANDY CM216684 (31000865)

CANDY CM216686S (31000956)

CANDY CM2610137 (31002280)

CANDY CM2611S37 (31000977)

CANDY CM46280 (31002598)

CANDY CM462S80 (31002603)

CANDY CM611TXT37 (31000979)

CANDY CM613TXT37 (31000978)

CANDY CM614TXT37 (31000976)

CANDY CM66280 (31002597)

CANDY CMD106-16S

CANDY CMD10616S (31002232)

CANDY CMD126-01

CANDY CMD126-50HZ

CANDY CMD12601 (31000933)

CANDY CMD126101 (31002229)

CANDY CMD126104S (31002231)

CANDY CMD12650HZ (31001375)

CANDY CMD12666 (31002242)

CANDY CMD126ARG (31002749)

CANDY CMD126S66 (31002243)

CANDY CMD136-80

CANDY CMD136180 (31001504)

CANDY CMD13680 (31000939)

CANDY CMD13686S (31001403)

CANDY CMD146-80

CANDY CMD14680 (31000938)

CANDY CMD14686S (31002108)

CANDY CMD146S80 (31001374)

CANDY CMD166-80

CANDY CMD16680 (31000937)

CANDY CMD166A39S (31001520)

CANDY CMF10601S (31002959)

CANDY CN126T80 (31000755)

CANDY CN136T80 (31000753)

CANDY CN146T80 (31000608)

CANDY CN166T40S (31000644)



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY CN166T80 (31000610)  
CANDY CNA127-80  
CANDY CNA12780 (31001207)  
CANDY CNA156-80  
CANDY CNA15680 (31000835)  
CANDY CNA16680 (31001059)  
CANDY CNE165T84 (31000767)  
CANDY CNE169TV83S (31000788)  
CANDY CNL13647S (31001219)  
CANDY CNV256-80  
CANDY CNV25680 (31000686)  
CANDY CNV25680 (31000792)  
CANDY CNW136T80 (31000609)  
CANDY CNW156T80 (31000607)  
CANDY CNWD13680 (31001215)  
CANDY CNWD14680  
CANDY CNWD14680 (31001214)  
CANDY CWD126-47  
CANDY CWD12647 (31000915)  
CANDY CWD146-47  
CANDY CWD14647 (31000914)  
CANDY CWD14847 (31002648)  
CANDY GEC12EHEW31  
CANDY GEC12EHEW31 (31002446)  
CANDY GO10601 (31001256)  
CANDY GO1060D01 (31001657)  
CANDY GO10637 (31001271)  
CANDY GO106TXT01 (31001258)  
CANDY GO10701 (31001261)  
CANDY GO10837 (31001661)  
CANDY GO1137S (31001276)  
CANDY GO116TXT37 (31001273)  
CANDY GO12614 (31001269)  
CANDY GO12637 (31001272)  
CANDY GO12680 (31001348)  
CANDY GO126S80 (31001384)  
CANDY GO126TXT01 (31001260)  
CANDY GO13614 (31001268)  
CANDY GO14614 (31001267)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY GO14680 (31001347)  
CANDY GO14684 (31001305)  
CANDY GO146HTXT01 (31001259)  
CANDY GO14701 (31001262)  
CANDY GO14714 (31001264)  
CANDY GO14780 (31001349)  
CANDY GO147HTXT01 (31001514)  
CANDY GO16614 (31001266)  
CANDY GO16684 (31001307)  
CANDY GO16780 (31001350)  
CANDY GO16784 (31001309)  
CANDY GO6100D16S (31001655)  
CANDY GO61037S (31001278)  
CANDY GO6105ARG (31001488)  
CANDY GO610S01S (31001257)  
CANDY GO610TXT07S (31001324)  
CANDY GO61137S (31001279)  
CANDY GO61237S (31001277)  
CANDY GO61247 (31001287)  
CANDY GO6125TXTARG (31001486)  
CANDY GO612TXT07S (31001323)  
CANDY GO612X37S (31001274)  
CANDY GO61347 (31001489)  
CANDY GO61447 (31001286)  
CANDY GO61486S (31001304)  
CANDY GO614HTXT16S (31001327)  
CANDY GO614TXT14S (31001265)  
CANDY GO61683S  
CANDY GO61683S (31001366)  
CANDY GO616TXT86S  
CANDY GO616TXT86S (31001303)  
CANDY GO6718S  
CANDY GO6718S (31001379)  
CANDY GO6818S  
CANDY GO6818S (31001377)  
CANDY GO71016S  
CANDY GO71016S (31001328)  
CANDY GO71237S  
CANDY GO71237S (31001270)



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY GO712HTXT07S  
CANDY GO712HTXT07S (31001346)  
CANDY GO71347  
CANDY GO71347 (31001284)  
CANDY GO71437S  
CANDY GO71437S (31001275)  
CANDY GO71447  
CANDY GO71447 (31001285)  
CANDY GO714HTXT07S  
CANDY GO714HTXT07S (31001345)  
CANDY GO812AUS  
CANDY GO812AUS (31001487)  
CANDY GO8601  
CANDY GO8601 (31001255)  
CANDY HJA8513  
CANDY HJA8513 (31800057)  
CANDY HJA8552  
CANDY HJA8552 (31800059)  
CANDY HJA8703  
CANDY HJA8703 (31800058)  
CANDY KITPAK606T  
CANDY KITPAK606T (31000235)  
CANDY LBAC130PFR  
CANDY LBAC130PFR (31000290)  
CANDY LBACS1006SY  
CANDY LBACS1006SY (31000395)  
CANDY LBACS100IT  
CANDY LBACS100IT (31105158)  
CANDY LBACS100SY  
CANDY LBACS100SY (31105273)  
CANDY LBACS101FR  
CANDY LBACS101FR (31105208)  
CANDY LBACS106ES  
CANDY LBACS106ES (31105216)  
CANDY LBACS120IT  
CANDY LBACS120IT (31105166)  
CANDY LBACS1306SY  
CANDY LBACS1306SY (31000396)  
CANDY LBACS130CESY



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBACS130CESY (31000016)  
CANDY LBACS130DE  
CANDY LBACS130DE (31000014)  
CANDY LBACS130PFI  
CANDY LBACS130PFI (31000342)  
CANDY LBACS130PSY  
CANDY LBACS130PSY (31105281)  
CANDY LBACS130UK  
CANDY LBACS130UK (37616968)  
CANDY LBACS132FR  
CANDY LBACS132FR (31105182)  
CANDY LBACS136ES  
CANDY LBACS136ES (31105224)  
CANDY LBACS160CESY  
CANDY LBACS160CESY (31000020)  
CANDY LBACS160DE  
CANDY LBACS160DE (31000019)  
CANDY LBACS160NL  
CANDY LBACS160NL (31000008)  
CANDY LBACS160PDE  
CANDY LBACS160PDE (31000364)  
CANDY LBACS160PFI  
CANDY LBACS160PFI (31000343)  
CANDY LBACS160PNL  
CANDY LBACS160PNL (31000366)  
CANDY LBACS160PSY  
CANDY LBACS160PSY (31000365)  
CANDY LBACS806SY  
CANDY LBACS806SY (31000394)  
CANDY LBACS80IT  
CANDY LBACS80IT (31105174)  
CANDY LBACS80SY  
CANDY LBACS80SY (31105265)  
CANDY LBACS86ES  
CANDY LBACS86ES (31105190)  
CANDY LBACTML10AIT  
CANDY LBACTML10AIT (31121015)  
CANDY LBACTML10DE  
CANDY LBACTML10DE (31121163)





magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBACTML10F  
CANDY LBACTML10F (31121171)  
CANDY LBACTML10FR  
CANDY LBACTML10FR (31121106)  
CANDY LBACTML10PL  
CANDY LBACTML10PL (31121197)  
CANDY LBACTML10RU  
CANDY LBACTML10RU (31121155)  
CANDY LBACTML10SY  
CANDY LBACTML10SY (31121130)  
CANDY LBACTML12FR  
CANDY LBACTML12FR (31124175)  
CANDY LBACTML12PL  
CANDY LBACTML12PL (31121205)  
CANDY LBACTML12SY  
CANDY LBACTML12SY (31124209)  
CANDY LBACTML13DE  
CANDY LBACTML13DE (31124233)  
CANDY LBACTML13SYM  
CANDY LBACTML13SYM (31124241)  
CANDY LBACTML7IT  
CANDY LBACTML7IT (31124183)  
CANDY LBACTML8AIT  
CANDY LBACTML8AIT (31121114)  
CANDY LBACTML8PL  
CANDY LBACTML8PL (31121189)  
CANDY LBACTML8RU  
CANDY LBACTML8RU (31121148)  
CANDY LBACTML8SY  
CANDY LBACTML8SY (31121122)  
CANDY LBACTML9FR  
CANDY LBACTML9FR (31124191)  
CANDY LBACTSM13DE  
CANDY LBACTSM13DE (31105141)  
CANDY LBACTSM13DIT  
CANDY LBACTSM13DIT (31105109)  
CANDY LBACTSM13FR  
CANDY LBACTSM13FR (31105018)  
CANDY LBACTSM13RU



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY LBACTSM13RU (31105133)

CANDY LBACTSM13UK

CANDY LBACTSM13UK (31105125)

CANDY LBACTSM13UK (37616422)

CANDY LBACTSM14DEN

CANDY LBACTSM14DEN (37616919)

CANDY LBACTSM15DEN

CANDY LBACTSM15DEN (37616893)

CANDY LBACTSM16DE

CANDY LBACTSM16DE (37616448)

CANDY LBACTSM16IT

CANDY LBACTSM16IT (37616455)

CANDY LBACTSM16NL

CANDY LBACTSM16NL (37616802)

CANDY LBACTSM16SY

CANDY LBACTSM16SY (37616463)

CANDY LBACTSM16UK

CANDY LBACTSM16UK (37616430)

CANDY LBAL12001

CANDY LBAL12001 (37615929)

CANDY LBAL12011

CANDY LBAL12011 (31136104)

CANDY LBAL12031

CANDY LBAL12031 (31136112)

CANDY LBAL120PL

CANDY LBAL120PL (31136393)

CANDY LBAL12611

CANDY LBAL12611 (31000217)

CANDY LBAL13001

CANDY LBAL13001 (37615960)

CANDY LBAL13011

CANDY LBAL13011 (31136260)

CANDY LBAL13031

CANDY LBAL13031 (31136245)

CANDY LBAL130PL

CANDY LBAL130PL (31136401)

CANDY LBAL13131

CANDY LBAL13131 (37616620)

CANDY LBAL13211



*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice**

CANDY LBAL13211 (31136278)  
CANDY LBAL14011  
CANDY LBAL14011 (37616034)  
CANDY LBAL14031  
CANDY LBAL14031 (37616067)  
CANDY LBAL15001  
CANDY LBAL15001 (37616547)  
CANDY LBAL8011  
CANDY LBAL8011 (31136179)  
CANDY LBAL80PL  
CANDY LBAL80PL (31136385)  
CANDY LBAL8611  
CANDY LBAL8611 (31000183)  
CANDY LBALSI21200  
CANDY LBALSI21200 (31800019)  
CANDY LBAMC12101  
CANDY LBAMC12101 (37616083)  
CANDY LBAQ1201TUK  
CANDY LBAQ1201TUK (31000476)  
CANDY LBAQ1301TUK  
CANDY LBAQ1301TUK (31000475)  
CANDY LBAUS130TRUK  
CANDY LBAUS130TRUK (31124225)  
CANDY LBCBD1006IT  
CANDY LBCBD1006IT (31000482)  
CANDY LBCBD110FR  
CANDY LBCBD110FR (31000259)  
CANDY LBCBD130FR  
CANDY LBCBD130FR (31000224)  
CANDY LBCBD13647  
CANDY LBCBD13647 (31000570)  
CANDY LBCBD150FR  
CANDY LBCBD150FR (31000276)  
CANDY LBCBD15647  
CANDY LBCBD15647 (31000590)  
CANDY LBCBD16614  
CANDY LBCBD16614 (31000579)  
CANDY LBCBD80PIT  
CANDY LBCBD80PIT (31000291)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBCBD85PIT  
CANDY LBCBD85PIT (31000352)  
CANDY LBCBD86SY  
CANDY LBCBD86SY (31000474)  
CANDY LBCBE75TRIT  
CANDY LBCBE75TRIT (31124258)  
CANDY LBCBL1006SY  
CANDY LBCBL1006SY (31000032)  
CANDY LBCBL100PL  
CANDY LBCBL100PL (31123797)  
CANDY LBCBL100SY  
CANDY LBCBL100SY (31123672)  
CANDY LBCBL106ES  
CANDY LBCBL106ES (31123912)  
CANDY LBCBL120FIN  
CANDY LBCBL120FIN (31123821)  
CANDY LBCBL120PL  
CANDY LBCBL120PL (31123839)  
CANDY LBCBL120SY  
CANDY LBCBL120SY (31123664)  
CANDY LBCBL130DE  
CANDY LBCBL130DE (31123805)  
CANDY LBCBL130NLEX  
CANDY LBCBL130NLEX (31123854)  
CANDY LBCBL130PDE  
CANDY LBCBL130PDE (31000355)  
CANDY LBCBL130PSY  
CANDY LBCBL130PSY (31000356)  
CANDY LBCBL130SY  
CANDY LBCBL130SY (31123813)  
CANDY LBCBL132FR  
CANDY LBCBL132FR (31123649)  
CANDY LBCBL140DE  
CANDY LBCBL140DE (37616810)  
CANDY LBCBL146UK  
CANDY LBCBL146UK (31000505)  
CANDY LBCBL160DE  
CANDY LBCBL160DE (37616828)  
CANDY LBCBL160NLEX



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBCBL160NLEX (37616877)

CANDY LBCBL160P14

CANDY LBCBL160P14 (31000581)

CANDY LBCBL160PDE

CANDY LBCBL160PDE (31000361)

CANDY LBCBL160PSY

CANDY LBCBL160PSY (31000362)

CANDY LBCBL160SY

CANDY LBCBL160SY (37616869)

CANDY LBCBL160UK

CANDY LBCBL160UK (31000270)

CANDY LBCBL16614

CANDY LBCBL16614 (31000580)

CANDY LBCBL166UK

CANDY LBCBL166UK (31000504)

CANDY LBCBL656SY

CANDY LBCBL656SY (31000033)

CANDY LBCBL756SY

CANDY LBCBL756SY (31000184)

CANDY LBCBL76ES

CANDY LBCBL76ES (31123896)

CANDY LBCBL856SY

CANDY LBCBL856SY (31000031)

CANDY LBCBL85PL

CANDY LBCBL85PL (31123789)

CANDY LBCBL85SY

CANDY LBCBL85SY (31123680)

CANDY LBCBL863ESSE

CANDY LBCBL863ESSE (31123888)

CANDY LBCBL864ESCO

CANDY LBCBL864ESCO (31123870)

CANDY LBCBL86ES

CANDY LBCBL86ES (31123904)

CANDY LBCBL96ESMR

CANDY LBCBL96ESMR (31123862)

CANDY LBCDN130TRUK

CANDY LBCDN130TRUK (37616638)

CANDY LBCDN140TRUK

CANDY LBCDN140TRUK (37616646)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBCHIA772ETR  
CANDY LBCHIA772ETR (31124290)  
CANDY LBCIN100T  
CANDY LBCIN100T (31800008)  
CANDY LBCIN60T  
CANDY LBCIN60T (31800020)  
CANDY LBCIN80T  
CANDY LBCIN80T (31800011)  
CANDY LBCL208785S  
CANDY LBCL208785S (31001378)  
CANDY LBCM146TXT1  
CANDY LBCM146TXT1 (31001101)  
CANDY LBCM161280  
CANDY LBCM161280 (31001118)  
CANDY LBCM214614  
CANDY LBCM214614 (31001095)  
CANDY LBCM214647  
CANDY LBCM214647 (31001094)  
CANDY LBCN116TUK  
CANDY LBCN116TUK (31000495)  
CANDY LBCN120TUK  
CANDY LBCN120TUK (31000376)  
CANDY LBCN126TUK  
CANDY LBCN126TUK (31000501)  
CANDY LBCN136TUK  
CANDY LBCN136TUK (31000503)  
CANDY LBCN150TUK  
CANDY LBCN150TUK (31000502)  
CANDY LBDBQ151  
CANDY LBDBQ151 (31000105)  
CANDY LBHC110MUK  
CANDY LBHC110MUK (31000330)  
CANDY LBHC120MUK  
CANDY LBHC120MUK (31000321)  
CANDY LBHC130MUK  
CANDY LBHC130MUK (31000322)  
CANDY LBHC145MUK  
CANDY LBHC145MUK (31000331)  
CANDY LBHC150MUK



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBHC150MUK (31000314)  
CANDY LBHC6120MUK  
CANDY LBHC6120MUK (31000437)  
CANDY LBHC6130MUK  
CANDY LBHC6130MUK (31000438)  
CANDY LBHC6145MUK  
CANDY LBHC6145MUK (31000439)  
CANDY LBHC6150MUK  
CANDY LBHC6150MUK (31000440)  
CANDY LBHC6160EUK  
CANDY LBHC6160EUK (31000441)  
CANDY LBHMC131UKC  
CANDY LBHMC131UKC (31000159)  
CANDY LBLLBC965EX  
CANDY LBLLBC965EX (31000053)  
CANDY LBMAF1200AAW  
CANDY LBMAF1200AAW (31000138)  
CANDY LBMAF1300AAW  
CANDY LBMAF1300AAW (31000156)  
CANDY LBSEL732ETR  
CANDY LBSEL732ETR (31124266)  
CANDY LBSCOM13  
CANDY LBSCOM13 (31105232)  
CANDY LBSCOM16  
CANDY LBSCOM16 (37616794)  
CANDY LBSCOMP13  
CANDY LBSCOMP13 (31000309)  
CANDY LBSCOMP16  
CANDY LBSCOMP16 (31000292)  
CANDY LBSCOMPS16  
CANDY LBSCOMPS16 (31000359)  
CANDY LBSPR100TRUK  
CANDY LBSPR100TRUK (31123334)  
CANDY LBSPR100TRUK (37616372)  
CANDY LBSPR101TRUK  
CANDY LBSPR101TRUK (31123441)  
CANDY LBSPR110TRUK  
CANDY LBSPR110TRUK (31123342)  
CANDY LBSPR110TRUK (37616380)



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

CANDY LBSPR120TRUK  
CANDY LBSPR120TRUK (31123458)  
CANDY LBSPR120TRUK (37616398)  
CANDY LBWDDQ150UK  
CANDY LBWDDQ150UK (37616554)  
CANDY MAF1060AAW  
CANDY MAF1060AAW (31001088)  
CANDY MAF1260AAW31  
CANDY MAF1260AAW31 (31000834)  
CANDY MAF1275AAW31  
CANDY MAF1275AAW31 (31000826)  
CANDY MAF1375AAW31  
CANDY MAF1375AAW31 (31000825)  
CANDY MAF1675AAW  
CANDY MAF1675AAW (31001089)  
CANDY NWW12V  
CANDY NWW12V (31800071)  
CANDY NWW10V  
CANDY NWW10V (31800053)  
CANDY TKL990931  
CANDY TKL990931 (31800056)  
CANDY WDALCBL1055  
CANDY WDALCBL1055 (31000494)  
CANDY WDALCL12647  
CANDY WDALCL12647 (31000621)  
CANDY WDAQW130UK  
CANDY WDAQW130UK (37616562)  
CANDY WDCIW100T  
CANDY WDCIW100T (31800010)  
CANDY WDCIW100TUK  
CANDY WDCIW100TUK (31800009)  
CANDY WDDQ130METU  
CANDY WDDQ130METU (31000271)  
RAMSONSPARES RS122910  
CANDY Kitchen A0002245 (OVENSECTION), A0002246 (OVENSECTION), A0002251 (OVENSECTION), A0002258 (OVENSECTION), A0002261 (OVENSECTION), A0002262 (OVENSECTION), A0002263 (OVENSECTION), A0002265 (OVENSECTION), A0002296 (OVENSECTION), A0002298 (OVENSECTION), A0002300 (OVENSECTION), A0002302 (OVENSECTION), A0002380 (OVENSECTION), A0002382 (OVENSECTION), A0002387 (OVENSECTION), A0002394 (OVENSECTION), A0002396 (OVENSECTION), A0002398



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(OVENSECTION), A0002400 (OVENSECTION), A0002402 (OVENSECTION), A0002404 (OVENSECTION), A0002406 (OVENSECTION), A0002408 (OVENSECTION), A0002999 (OVENSECTION), A0003003 (OVENSECTION), A0003006 (OVENSECTION), A0003009 (OVENSECTION), A0003012 (OVENSECTION), A0003015 (OVENSECTION)

CANDY Washing machine 31105117 (ACTSMART13), 31000641 (ALCB103TR), 31000721 (ALCB106TR-04), 31000828 (ALCB1355-86S), 31002230 (ALISECMD106-ARG), 31001103 (ALISECMD126-S), 31000684 (CBD100.65-04), 31000736 (CBD101.75SAU), 31000669 (CBD1060-37CO), 31000668 (CBD1161-37), 31000670 (CBD1163-37S), 31000666 (CBD116-37), 31000667 (CBD116-37SME), 31000672 (CBD136-37), 31000768 (CBD166-84), 31000685 (CBD85.65-04S), 31000671 (CBD96-37), 31000675 (CBE165T-80), 31800030 (CDB115-80), 31800064 (CDB126-80), 31800044 (CDB134-SY), 31800007 (CIN100TUK), 31800024 (CIN126TL-37S), 31001178 (CL2087-85S), 31001170 (CL2107-01S), 31001429 (CL2117-01S), 31002138 (CL2117-1-01S), 31001016 (CL2127-36S), 31001169 (CL2147-01S), 31000932 (CLD135-01), 31001679 (CM0860D-01), 31002227 (CM0860D-1-01), 31000924 (CM106TXT-01), 31000990 (CM106TXT-03S), 31000940 (CM1126-80), 31001357 (CM1146-80), 31001376 (CM1146S-80), 31001975 (CM1166-1-80), 31001356 (CM1166-80), 31001077 (CM126.5ARG), 31000927 (CM146HTXT-01), 31000993 (CM146HTXT-03), 31000913 (CM146TXT-14M), 31001045 (CM1612-80), 31001044 (CM1612J-80), 31002526 (CM1663D-80), 31001008 (CM166HTXT-36), 31000864 (CM166TXT-84S), 31000957 (CM166TXT-86S), 31001018 (CM2076-18S), 31000980 (CM2086-01), 31001017 (CM2086-18S), 31001078 (CM2106.5AR), 31000921 (CM2106-01), 31002225 (CM2106-1-01), 31001015 (CM211-37S), 31001738 (CM2116-1-47), 31001014 (CM2116-37S), 31000992 (CM2126-03S), 31000909 (CM2126-14), 31001283 (CM2126-47), 31000910 (CM2136-14), 31001469 (CM2136-1-47), 31001415 (CM2136-47), 31000941 (CM2136-80), 31000911 (CM2146-14), 31002409 (CM2146-1-86S), 31000854 (CM2146-47), 31001471 (CM2146-47), 31000942 (CM2146-80), 31000850 (CM2156-47), 31000912 (CM2166-14), 31001735 (CM2166-1-86S), 31000943 (CM2166-80), 31000865 (CM2166-84), 31000956 (CM2166-86S), 31002280 (CM2610-1-37), 31000974 (CM2610-37), 31002598 (CM462-80), 31002603 (CM462S-80), 31000979 (CM611TXT-37), 31000978 (CM613TXT-37), 31000976 (CM614TXT-37), 31002597 (CM662-80), 31002232 (CMD106-16S), 31000933 (CMD126-01), 31002229 (CMD126-1-01), 31002231 (CMD126-1-04S), 31001375 (CMD126-50HZ), 31002242 (CMD126-66), 31002749 (CMD126-ARG), 31002243 (CMD126S-66), 31001504 (CMD136-1-80), 31000939 (CMD136-80), 31001403 (CMD136-86S), 31000938 (CMD146-80), 31002108 (CMD146-86S), 31001374 (CMD146S-80), 31000937 (CMD166-80), 31001520 (CMD166A-39S), 31002959 (CMF106-01S), 31000755 (CN126T-80), 31000753 (CN136T-80), 31000608 (CN146T-80), 31000644 (CN166T-40S), 31000610 (CN166T-80), 31001207 (CNA127-80), 31000835 (CNA156-80), 31001059 (CNA166-80), 31000767 (CNE165T-84), 31001219 (CNL136-47S), 31000686 (CNV256-80), 31000792 (CNV256-80), 31000609 (CNW136T-80), 31000607 (CNW156T-80), 31001215 (CNWD136-80), 31001214 (CNWD146-80), 31800028 (CWB100-37S), 31800033 (CWB110-80), 31800029 (CWB120-37S), 31800065 (CWB120-80), 31800027 (CWB80-37S), 31000290 (LBACS130PFR), 31000395 (LBACS100.6SY), 31105158 (LBACS100IT), 31105273 (LBACS100SY), 31105208 (LBACS101FR), 31105216 (LBACS106ES), 31000396 (LBACS130.6SY), 31000016 (LBACS130CESY), 31000014 (LBACS130DE), 31000342 (LBACS130PFI), 31105281 (LBACS130PSY), 31105182 (LBACS132FR), 31105224 (LBACS136ES), 31000019 (LBACS160DE), 31000008 (LBACS160NL), 31000364 (LBACS160PDE), 31000343



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

(LBACS160PFI), 31000366 (LBACS160PNL), 31000365 (LBACS160PSY), 31105174 (LBACS80IT), 31105265 (LBACS80SY), 31105190 (LBACS86ES), 31086226 (LBACT108ACUN), 31121627 (LBACT1091ACD), 31121619 (LBACT109ACRF), 31121601 (LBACT109ACRS), 31085210 (LBACT128ACCE), 31121635 (LBACT1291ACD), 31124001 (LBACT129ACRS), 31124134 (LBACT79RI), 31124159 (LBACT79RSY), 31124118 (LBACT89ACRIT), 31124126 (LBACT89ACRS), 31124167 (LBACT99RFR), 31105000 (LBACTIVAS12), 31121015 (LBACTML10AIT), 31121163 (LBACTML10DE), 31121171 (LBACTML10-F), 31121106 (LBACTML10FR), 31121197 (LBACTML10PL), 31121155 (LBACTML10RU), 31121130 (LBACTML10SY), 31124175 (LBACTML12FR), 31121205 (LBACTML12PL), 31124209 (LBACTML12SY), 31124233 (LBACTML13DE), 31124241 (LBACTML13SYM), 31124183 (LBACTML7IT), 31121114 (LBACTML8AIT), 31121189 (LBACTML8PL), 31121148 (LBACTML8RU), 31121122 (LBACTML8SY), 31124191 (LBACTML9FR), 31105141 (LBACTSM13DE), 31105109 (LBACTSM13DIT), 31105018 (LBACTSM13FR), 31105133 (LBACTSM13RU), 31105125 (LBACTSM13UK), 37616422 (LBACTSM13UK), 37616919 (LBACTSM14DEN), 37616893 (LBACTSM15DEN), 37616448 (LBACTSM16DE), 37616455 (LBACTSM16IT), 37616802 (LBACTSM16NL), 37616430 (LBACTSM16UK), 31105612 (LBACTSMARTRU), 31072135 (LBALCB103TAR), 31072127 (LBALCB103TRD), 31072150 (LBALCB103TRF), 31072143 (LBALCB103TRS), 31072010 (LBALCB123TRF), 31072168 (LBALCB133TRS), 31072101 (LBALCB83TRIT), 31072119 (LBALCB83TRSY), 31123318 (LBCB1013TRRU), 31123516 (LBCB1023TRBL), 31123524 (LBCB1033TRYE), 31123300 (LBCB103TR), 31123532 (LBCB1043TRME), 31123581 (LBCB106TRES), 31123508 (LBCB106TRSY), 31123326 (LBCB1213TRE), 31123292 (LBCB123TR), 31000473 (LBCB60.6T), 31123573 (LBCB66TRES), 31123482 (LBCB66TRSY), 31127368 (LBCB74TRIT), 31123599 (LBCB86TRES), 31123490 (LBCB86TRSY), 31123656 (LBCB96TRSY), 31000482 (LBCBD100.6IT), 31000259 (LBCBD110FR), 31000224 (LBCBD130FR), 31000570 (LBCBD136-47), 31000276 (LBCBD150FR), 31000590 (LBCBD156-47), 31000579 (LBCBD166-14), 31000291 (LBCBD80PIT), 31000352 (LBCBD85PIT), 31000474 (LBCBD86SY), 31124258 (LBCBE75TRIT), 31000032 (LBCBL100.6SY), 31123797 (LBCBL100PL), 31123672 (LBCBL100SY), 31123912 (LBCBL106ES), 31123821 (LBCBL120FIN), 31123839 (LBCBL120PL), 31123664 (LBCBL120SY), 31123805 (LBCBL130DE), 31123854 (LBCBL130NLEX), 31000355 (LBCBL130PDE), 31000356 (LBCBL130PSY), 31123813 (LBCBL130SY), 31123649 (LBCBL132FR), 37616810 (LBCBL140DE), 31000505 (LBCBL146UK), 37616828 (LBCBL160DE), 37616877 (LBCBL160NLEX), 31000581 (LBCBL160P-14), 31000361 (LBCBL160PDE), 31000362 (LBCBL160PSY), 37616869 (LBCBL160SY), 31000270 (LBCBL160UK), 31000580 (LBCBL166-14), 31000504 (LBCBL166UK), 31000033 (LBCBL65.6SY), 31000184 (LBCBL75.6SY), 31123896 (LBCBL76ES), 31123789 (LBCBL85PL), 31123680 (LBCBL85SY), 31123888 (LBCBL863ESSE), 31123870 (LBCBL864ESCO), 31123904 (LBCBL86ES), 31123862 (LBCBL96ESMR), 37616646 (LBCDN140TRUK), 31124290 (LBCHIA772ETR), 31119001 (LBCI100A), 31123177 (LBCI100TB), 31123102 (LBCI100TR), 31123185 (LBCI100TR), 31123151 (LBCI100TY), 31123128 (LBCI1016TR), 31123227 (LBCI120EXP), 31123003 (LBCI120TR), 31123144 (LBCI656TR), 31123136 (LBCI816TR), 31123219 (LBCI827TRE), 31123110 (LBCI950TR), 31800008 (LBCIN100T), 31800020 (LBCIN60T), 31800011 (LBCIN80T), 31001378 (LBCL2087-85S), 31001118 (LBCM1612-80), 31001095 (LBCM2146-14), 31001094 (LBCM2146-47), 31000495 (LBCN116TUK), 31000376 (LBCN120TUK), 31000503 (LBCN136TUK), 31000502 (LBCN150TUK), 31105232 (LBSM.COM13), 37616794 (LBSM.COM16), 31000309 (LBSM.COMP13), 31000292 (LBSM.COMP16), 31000359 (LBSM.COMPS16), 31123334 (LBSPR100TRUK), 37616372 (LBSPR100TRUK), 31000622 (WDALCB115-47), 31000494 (WDALCBL1055), 31000621 (WDALCL126-47),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

31800010 (WDCIW100T), 31800009 (WDCIW100TUK)  
HOOVER Washing machine 31800040 (HDB 244-80), 31800031 (HDB 284-80), 31800048 (HDB 284-SY),  
31001004 (HI148-47), 31001005 (HI168-47), 31001006 (HIZ169-47), 31002437 (HN 6135-1-86S), 31002910  
(HN 6146-84), 31001263 (HN5125-84S), 31002408 (HN6135-1-84), 31001428 (HNF 6107-1-85S), 31001179  
(HNF 6107-85S), 31001177 (HNF 687-85S), 31001353 (HNF 7127-80), 31001385 (HNF 7127S-80), 31001501  
(HNF 7128-80), 31001515 (HNF 7138-80), 31001352 (HNF 7147-80), 31001533 (HNF 7148-80), 31001351 (HNF  
7167-80), 31002281 (HNF 71683D-80), 31001040 (HNF 9147 Z-14), 31001041 (HNF 9167 Z-14), 31001152  
(HNF 9167-03 S), 31000892 (HNF 9167Z-80), 31001147 (HNF6127PULSE-30), 31001022 (HNF9167ZS-80),  
31000759 (HNL 6106 -37S), 31001367 (HNL 6106 Z-30), 31001369 (HNL 6106.5-04S), 31002647 (HNL  
6126-31OS), 31001649 (HNL 6126-86S), 34001510 (HNL 6126-86S), 31001650 (HNL 6136-86S), 31000852  
(HNL 6136ZX-30), 31001099 (HNL 6146-83M), 31001092 (HNL 6146-84), 31001093 (HNL 6146-86S), 31000881  
(HNL 6166-80), 31000771 (HNL 6166-84), 31000846 (HNL 6166-86S), 31000801 (HNL 6166S-83M ), 31002595  
(HNL 642-80), 31002596 (HNL 662-80), 31001280 (HNL 686-30), 31000757 (HNL 686-37 S), 31001354 (HNL  
7126-80), 31001386 (HNL 7126S-80), 31001355 (HNL 7146-80), 31001973 (HNL 71663D-80), 31001976 (HNL  
7166-80), 31002073 (HNL 8146-80), 39338967 (HNL 8146-80), 31002669 (HNL 842-80), 31000811 (HNL  
9116-85S), 31000807 (HNL 9126-16S), 31000758 (HNL 9136 - 37S), 31001065 (HNL 9136 PULSE), 31001175  
(HNL 9136-03S), 31000982 (HNL 9166 Z - 84), 31000800 (HNL 9166-83M ), 31000816 (HNL 9166-86S ),  
31000984 (HNL 9166Z-83M), 31000605 (HNL2126 - 80), 31000598 (HNL2126S-80), 31000597 (HNL2136-80),  
31000640 (HNL2136S-80), 31000599 (HNL3146-80), 31000600 (HNL3146S-80), 31000722 (HNL3156-80),  
31000630 (HNL3166Z-80), 31002100 (HNL576-30), 31002224 (HNL6106-1-37), 31000776 (HNL6116Z-30),  
31000697 (HNL6116ZS-SILVER), 31000875 (HNL6126-80), 31000876 (HNL6126S-80), 31000878  
(HNL6136S-80), 31000879 (HNL6146-80), 31000798 (HNL6146-83M), 31000772 (HNL6146-84), 31000847  
(HNL6146-86S), 31000880 (HNL6156S-80), 31000699 (HNL6856Z-30), 31002226 (HNL686-1-30), 31002223  
(HNL686-1-37S), 31000829 (HNL9136-80), 31000891 (HNL9146Z-80), 31000899 (HNWF 6135-80), 31000900  
(HNWF 6135S-80), 31001181 (HNWF 6137E-30), 31000935 (HNWF 6165-88S), 31001085 (HNWF 6167-80),  
31001115 (HNWF 6167-84M), 31001363 (HNWF 7137-80), 31001512 (HNWF 7148-80), 31001513 (HNWF  
7168-80), 31000903 (HNWF 9167-80), 31000632 (HNWF3135-80), 31002233 (HNWL 6126E-1-30), 31001182  
(HNWL 6126E-30), 31001114 (HNWL 6136 - 84S), 31000897 (HNWL 6136-80), 31001020 (HNWL 6136S-80),  
31000898 (HNWL 6146-80), 31000893 (HNWL 6166-80), 31001505 (HNWL 7136-1-80), 31001358 (HNWL  
7136-80), 31001361 (HNWL 7136S-80), 31001732 (HNWL 7146 A-88S), 31001362 (HNWL 7146-80), 31001359  
(HNWL 7166-80), 31000639 (HNWL3126-80), 31000631 (HNWL3136-80), 31000723 (HNWL3136S-80),  
31000633 (HNWL3166-80), 31000809 (HNWL6136-85S), 31000770 (HNWL6146-84), 31001027 (HP 12J-80),  
31000872 (HP 13-80), 31001021 (HP 14-80), 31001026 (HP 14J-80), 31001025 (HP15J-80), 31001024  
(HP16J-80), 31001210 (HPA 146-80), 31001209 (HPA 166-80), 31001184 (HPE 236-80), 31001208 (HPF  
137-80), 31001212 (HPF 167-80), 31001476 (HPL 146-1-84), 37653623 (HPL 146-1-84), 31001321 (HPL  
146-84), 31002405 (HPL145-1-84), 31002228 (HPL146-1-84), 37616943 (HPL146-1-84), 31001216 (HPWD  
136-80), 31001213 (HPWD 166-80), 31000664 (HSE130M-80), 31000873 (HSP15-80), 31001060 (HSW 146-80  
SOFT), 31001063 (HSW 166S-80 SOFT), 31000663 (HSW2115M-80), 31000676 (HSW2125M-80), 31001082  
(HSWD 126-80), 31001083 (HSWD 146-80), 31001084 (HSWD 166-80), 31001062 (HSWF 147-80 SOFT),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

31001061 (HSWF 167-80 SOFT), 31800039 (HWB 240-80), 31800047 (HWB 280-30S), 31800032 (HWB 280-80), 31800060 (HWB280D-80S), 31001037 (HWD 120-80), 31001038 (HWD130J-80), 31000275 (HWF 5516 ECE), 31000896 (HWP12-80), 31001019 (KIT LB H66 T CKD), 37615531 (LB AA212011), 37615556 (LB AA231061), 37615796 (LB AA232 021), 37615564 (LB AA232011), 37615937 (LB AAA160 01), 37616018 (LB AAA160 11), 37616042 (LB AAA160 31), 37616158 (LB AAA160 61), 37616133 (LB AAA160 71), 37616885 (LB AAA160 PL), 37614120 (LB AB110011), 37614260 (LB AB110021), 37614138 (LB AB130011), 37614278 (LB AB130021), 37614112 (LB AB90011), 37614245 (LB AB90021), 37616679 (LB ACM 11 01), 31000269 (LB ACM 16 UK), 37614971 (LB AE 143071), 37614344 (LB AE110021), 37614203 (LB AE110031), 37614427 (LB AE112011), 37614419 (LB AE113071), 37614302 (LB AE130021), 37614211 (LB AE130031), 37614401 (LB AE131061), 37614229 (LB AE140031), 37614393 (LB AE142), 37616182 (LB AI 100 11), 37616166 (LB AI 120 61), 37615952 (LB AI130 01), 37616059 (LB AI140 31), 39987946 (LB AIS136 31), 31136450 (LB AIS136 PL), 31136104 (LB AL 120 11), 31136112 (LB AL 120 31), 31136393 (LB AL 120 PL), 31136260 (LB AL 130 11), 31136245 (LB AL 130 31), 31136401 (LB AL 130 PL), 37616620 (LB AL 131 31), 31136278 (LB AL 132 11), 31136179 (LB AL 80 11), 31136385 (LB AL 80 PL), 31000183 (LB AL 86 11), 37615929 (LB AL120 01), 37615960 (LB AL130 01), 37616034 (LB AL140 11), 37616067 (LB AL140 31), 37616547 (LB AL150 01), 37616091 (LB ALA122 01), 31136252 (LB AM 131 11), 37616927 (LB AM100 LEB), 37615911 (LB AM110 01), 31136138 (LB AM110 11), 37616901 (LB AM110 LEB), 37615978 (LB AM115 01), 31136120 (LB AM130 11), 37616109 (LB AMA122 07), 37616083 (LB AMC121 01), 37615614 (LB AR210031), 37615622 (LB AR213071), 37615630 (LB AR230031), 37615648 (LB AR233071), 37614286 (LB AS110021), 37614476 (LB AS111061), 37614484 (LB AS112011), 37614468 (LB AS113071), 37614294 (LB AS130021), 37614450 (LB AS131061), 37614443 (LB AS132), 37614435 (LB AS133071), 37614146 (LB AS90031), 37614492 (LB AS92), 37615671 (LB AV130011), 37615788 (LB AV210 021), 37615663 (LB AV210011), 37616844 (LB CA 231 03), 31000192 (LB CA 232 UK), 31000313 (LB CA 233 UK), 31136435 (LB H 110M DE), 37616992 (LB H 120 MUK), 31000228 (LB H 120E PL), 31136443 (LB H 130M DE), 31000227 (LB H 80 E PL), 31000427 (LB H100 E PL), 31000073 (LB H110 M CE), 37616984 (LB H110 M UK), 31000107 (LB H130 E CE), 31000102 (LB H130 E DE), 31000074 (LB H130 M CE), 31000268 (LB H140 E NE), 31000236 (LB H140 E PL), 31000082 (LB H160 E CE), 31000081 (LB H160 E DE), 31000267 (LB H160 I NE), 31000213 (LB H70 M6 SY), 31000330 (LB HC110 MUK), 31000321 (LB HC120 MUK), 31000322 (LB HC130 MUK), 31000331 (LB HC145 MUK), 31000314 (LB HC150 MUK), 31000565 (LB HP6 110 M), 31000497 (LB HP6 120M), 31000506 (LB HP6 130 M), 31000507 (LB HP6 150 M), 31000317 (LB HPM 110), 31000318 (LB HPM 120), 31000319 (LB HPM 130), 31000320 (LB HPM 150), 31000412 (LB HSE 120UK), 31000411 (LB HSE 140UK), 31000398 (LB HW5513MUK), 31000793 (LB PE 235), 31000106 (LB PE235), 31000512 (LB SE 160 E), 37615895 (LB SE130 011), 31103104 (LB W105 SX-1), 37614179 (LB WB 120011), 37614328 (LB WB120021), 37615994 (LB WDM120 01), 37616000 (LB WDM130 01), 31103112 (LB WDM130 11), 37616349 (LB WDM150 01), 37616364 (LB WDM150 11), 37616356 (LB WDM150 31), 37614187 (LB WE120031), 37614195 (LB WE140031), 37614351 (LB WE143), 37615903 (LB WSE130011), 31000154 (LBACM15UK), 31000065 (LB AIS136SYE), 31000274 (LBEL160UKCMT), 31000283 (LBH110 M6 SY), 31000006 (LBH130EUK), 31000272 (LBH130MNE), 37617008 (LBH130MUKCMT), 31000080 (LBH140 E DE), 31000012 (LBH160 I UK), 31000007 (LBH160EUK), 31000437 (LBHC6 120MUK), 31000438 (LBHC6 130MUK), 31000439 (LBHC6 145MUK), 31000440 (LBHC6 150MUK), 31000441 (LBHC6160EUK), 31000315 (LBHCP160 EUK),

magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

31000323 (LBHCP160 IUK), 31000185 (LBHLYS1059E), 31000159 (LBHMC131UKC), 31001080 (LBHNF6137P),  
31001081 (LBHNF6167P), 31001066 (LBHNL6106P), 31001067 (LBHNL6126P30), 31000567 (LBHP 13 ECE),  
31000577 (LBHP 13 EDE), 31000562 (LBHP 16 E CE), 31000561 (LBHP 16 E DE), 31000499 (LBHP 16 E NL),  
31000158 (LBHQ130UKCIH), 31000157 (LBHQ150UKCIH), 31000155 (LBHSW110M UK), 31000003  
(LBHW120MUK), 31000258 (LBHW120PROMO), 31000002 (LBHW130MUK), 31000257 (LBHW130PROMO),  
31000009 (LBHW160MUK), 31000325 (LBHWF 131MUK), 31000024 (LBHWF130MUK), 31800021  
(LBHWM120TS80), 31000844 (PFW135-80), 31000845 (PPA136-80), 31000837 (PPA136S-80), 31000838  
(PPA146-80), 31000842 (PPW126-80), 31000841 (PPW166-80), 31000831 (SE234-80), 31000830 (SE264-80),  
31001510 (VHD 106-16S), 31001442 (VHD 146-86S), 31001445 (VHD 166 I-86S), 31001462 (VHD 166 ZI-88S),  
31001444 (VHD 166-86S), 31001438 (VHD 610-30), 31001440 (VHD 611 P-30), 31001491 (VHD 612Z-14),  
31001528 (VHD 614-84), 31001529 (VHD 616-84), 31001437 (VHD 710-30), 31001527 (VHD 812-14),  
31001436 (VHD 812-30), A0000993 (VHD 812-30), 31001414 (VHD 812-47), 31001404 (VHD 812-80),  
31001408 (VHD 812S-80), 31001439 (VHD 814 P-30), 31001435 (VHD 814 Z-47), 31001412 (VHD 814-47),  
31001405 (VHD 814-80), 31001493 (VHD 814Z-14), 31001407 (VHD 816 I-80), 31001441 (VHD 816 PI-30),  
31001530 (VHD 816 ZI-84), 31001413 (VHD 816-47), 31001406 (VHD 816-80), 31001494 (VHD 816Z-14),  
31001434 (VHD816Z-47), 31001433 (VHD816ZI-47), 31001012 (WD HW 556-47), 31000549 (WDHSW150M80),  
31000478 (WDHW5213MUK), 31000193 (WDHW6313E CE), 31000479 (WDHW6313MUK), 31000480  
(WDHW6316MUK), 31800022 (WDHWD120TD80), 31000464 (WDHWF5513EF), 31002612 (WT 1408 E)  
KELVINATOR Washing machine 31001144 (CKD K 66 T), 31000386 (FAM 120 S), 31000387 (LB FAM 100 S),  
31000388 (LB FAM 80), 31097140 (LB K 62.6 T), 31000587 (LB K 66T-04S), 31000588 (LB K 86T- 4S),  
31104011 (LB KWD 835 T), 31000589 (LBKWD100604S)  
MAYTAG Washing machine 31000138 (LBMAF1200AAW), 31000156 (LBMAF1300AAW), 31001088 (MAF 1060  
AAW), 31000834 (MAF 1260AAW - 31), 31000826 (MAF 1275AAW - 31), 31000825 (MAF 1375AAW - 31),  
31001089 (MAF 1675 AAW)  
OTSEIN Washing machine 39987920 (LB ET906H), 39987797 (LB ETERNA906), 39987672 (LB ETRNA 900),  
39987771 (LB LBO 946 A), 39987789 (LB LBO1256 A)  
PHILCO Washing machine 31800054 (PAS 1053 EN), 31800023 (PAS1053E-04)  
ROSIERES Washing machine 39987037 (LB LH 700), 39987607 (LB LH 802), 39987623 (LB LWH 105),  
31800017 (LBRILS120H-C), 31800042 (RILL 140-47S), 31800070 (RILS 140-04OS), 31800043 (RILS 140-47)  
ZEROWATT Washing machine 31000988 (CKD LADYCL 833E), 31000242 (CKD LADYCL 834), 31002733 (CKD  
ZNL 686-1), 31002209 (CKDZNL686HC), 31000698 (HNL6106-30), 31000700 (HNL6856-30), 31000687  
(HNL9136Z-30), 31000702 (HNWL6106-30), 39987631 (LADYSTEEL 9S), 39987656 (LB CM 768 SS), 39987664  
(LB CM 797 SS), 39987649 (LB CM 968 SS), 31088156 (LB EMA 80 SS), 31088297 (LB EMH80 AS), 39987052  
(LB HM 6 S), 39987888 (LB HM 750E S), 39984927 (LB HM 756E), 39987854 (LB HM 758E S), 39987862 (LB HM  
958E S), 31000205 (LB HMP 5085E), 31000293 (LB HMP 756 E), 31000294 (LB HMP 856 E), 31000360 (LB HZ6  
11 I), 31000363 (LB HZ6 16 I), 37616521 (LB HZI110 51), 37616539 (LB HZI160 51), 39987045 (LB  
LADFAM6SS), 39987730 (LB MA 758 SS), 39987748 (LB MA 958 SS), 39987896 (LB SHM850E S), 39987870 (LB  
SHM959E S), 39987011 (LB SUPER5 AM), 31000432 (LB Z 86 E), 39987805 (LBEP7501MASS), 31000436  
(LBH100EUNI), 31000295 (LBHMP1058E S), 31000296 (LBHMP1059E S), 39987722 (LBMI7509MASS),



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

39987763 (LBSE8507MASS), 39987755 (LBSTEMA959SS), 39987813 (LBSTMA1059SS), 39987003 (LBSUPER5-800), 31001241 (ZL 100.6), 31001383 (ZL 100.7), 31001240 (ZL 120.6), 31001382 (ZL 120.7), 31002137 (ZL100.7-1), 31002139 (ZL120.7-1), 31002129 (ZLP 106-01), 31002130 (ZLP 126-01)  
CANDY, CYLINDA, FRIAC, General Electric, Hoover, Howden, Kelvinator, Maytag, Ostein, Philco, Rosieres, TEKA  
Hoover CANDY HVR 91201546  
CANDY Hoover Rosières Iberna Zerowatt ref. 91201546  
ACTSMART13 ALCB103TR ALCB1355-86S ALI31300E ALISECMD106-AR ALISECMD106-ARG  
ALISECMD106-S-S ALISECMD126 ALSI31300EVR01 BELWD12V BELWM13VI  
BWA5119 BWA5120 C1145 / C2145 1-84 / 1-84 C2510 / 1-01S CBD116-37SME  
CBD1163-37S CBD166-84 CDB134 -SY CKDK66T CKDLADYCL833E CKDLADYCL834  
CKDLADYCL834E CKDZNL686 / 1 CKDZNL686HC CL2087-85S CL2107-01S CL2117-01S  
CL2117 / 1-01S CL2127-36S CL2127 / 1-36S CL2147-01S CLD135-01 CLD135-86S  
CM0860D CM0860D-01 / 1-01 CM106TXT -01 CM106TXT CM126TXT-03S-01-16S CM126TXT  
CM146HTXT-01 CM146HTXT-03 CM146TXT-14M CM166TXT-84S CM2076-18S  
CM2086-01 CM2086-18S CM2106-01 CM2106-16S CM2106 / 1-01 CM2106S-01S  
CM2116 / CM2146 1-47 CM2126-03S CM2146-86S / 1-86S CM2166-14 CM2166-84  
CM2166-86S CM2166 / 1-86S CMD106-16S CMD126-01 CMD126 ARG CMD126 / 1-01  
CMD126 / 1-04S CMD136 -86S CMD146-86S CMD166A-39s-40S CMF106-01S CN166T  
CNE165T-84 CWB100-37S CWB120-37S CWB80-37S CWD126-47 FAM120S GEC12EHEW-31  
GO106-01 GO1060D-01 GO106TXT-01 GO107-01 GO126S-80 GO126TXT- 01  
GO146-84 GO146HTXT-01 GO147-01 GO147HTXT-01 GO166-84 GO167-84  
GO610-37S GO610.5ARG GO6100D GO610S-16S-01S-07s GO610TXT GO611-37S  
GO612-37S GO612.5TXTARG GO612TXT GO612X-07s-37S GO614 -86S GO614HTXT-16S  
GO614TXT-14S-86s GO616-83S GO616TXT GO68-18S GO710-16S GO712-37S  
GO714-37S GO714HTXT-07s GO812AUS GO86-01 HDB284-SY HJA8513 HJA8552  
HJA8703 HN6135 / 1-84 HN6135 / 1-86S HN6146-84 HNF6107-85S HNF6127PULSE-30  
HNF7127-80 HNF9167-03S HNL2126-80 HNL3166Z 80 HNL576-30 HNL6106-30  
HNL6106-37S HNL6106.5-04S HNL6106 / 1- 37 HNL6106Z-30 HNL6116Z-30  
HNL6116ZS-SILVER HNL6126-31OS HNL6126-80 HNL6126-86S HNL6136-86S  
HNL6136S-80 HNL6136ZX-30 HNL6146-83M HNL6146-84 HNL6146 / 1-84 HNL6166-80  
HNL6166-84 HNL6166-86S HNL6166S- 83M HNL6856-30 HNL6856Z-30 HNL686-30  
HNL686-37S HNL686 / 1-30 HNL686 / 1-37S HNL7126-80 HNL7126S 80 HNL7146-80  
HNL8146-80 HNL9126-16S HNL9136-03S HNL9136PULSE HNL9136Z-30 HNL9166-83M  
HNL9166Z- 83M-84 HNL9166Z HNW6135-80 HNW6137E-30 HNW6165-88S  
HNWF6167-84M HNWF7137-80 HNWF7148-80 HNWL6106-30 HNWL6126E-30  
HNWL6126E / 1-30 HNWL6136-84S HNWL6136-85S HNWL6146-84 HNWL7136-80  
HNWL7146-80 HPL145 / 1-84 HPL146-84 HPL146 / 1-84 HWB280-30S HWF5516ECE  
KITLBH66TCKD KITPAK606T LBAAA14001 LBAAA16011 LBAAA16031 LBACS100.6SY  
LBACS100IT LBACS100SY LBACS120IT LBACS130. 6SY LBACS130CESY LBACS130DE



magazin online HORECA

Piese schimb / Accesorii / Consumabile / Reparații  
Automatizări / Materiale Electrice

LBACS160CESY LBACS160DE LBACS160PDE LBACS160PSY LBACS80.6SY LBACS80IT  
LBACS80SY LBACTML10AIT LBACTML10DE LBACTML10RU LBACTML10SY LBACTML12SY  
LBACTML13DE LBACTML13SYM LBACTML7IT LBACTML8AIT LBACTML8RU LBACTML8SY  
LBACTSM13DE LBACTSM13DIT LBACTSM13RU LBACTSM16DE LBACTSM16IT LBACTSM16SY  
LBAI10011 LBAI13001 LBAI13041 LBAI14011 LBAI14031 LBAIS13631 LBAIS136SYE  
LBAL12001 LBAL12011 LBAL12031 LBAL12611 LBAL13011 LBAL13031 LBAL13211  
LBAL14011 LBAL14031 LBAL8011 LBAL8611 LBALCB103TRS LBALCB133TRS  
LBALCB83TRIT LBALCB83TRSY LBALI21200E LBALSI21200 LBAM100LEB LBAM11001  
LBAM11011 LBAM110LEB LBAM13011 LBACA106TR LBACA66TR LBACA861TRES  
LBACA86TR LBCB1013TRRU LBCB1023TRBL LBCB1033TRYE LBCB103TR LBCB1043TRME  
LBCB1213TRE LBCB123TR LBCB60.6T LBCB66TRSY LBCB74TRIT LBCB86TRSY  
LBCBD100.6IT LBCBD80PIT LBCBD85PIT LBCBE75TRIT LBCBL100.6SY LBCBL100SY  
LBCBL120SY LBCBL130DE LBCBL130PDE LBCBL130PSY LBCBL130SY LBCBL140DE  
LBCBL160DE LBCBL160PDE LBCBL160PSY LBCBL160SY LBCBL65.6SY LBCBL85.6SY  
LBCBL85SY LBCHIA772ETR LBCIN100T LBCIN60T LBCIN80T LBCL2087-85S  
LBCM146TXT-1 LBEMA80SS LBEMH80AS LBFAM100S LBFAM60 LBFAM80 LBH100EUNI  
LBH110M6SY LBH110MCE LBH110MDE LBH110MUK LBH120MUK LBH130ECE LBH130EDE  
LBH130EUK LBH130MCE LBH130MDE LBH130MNE LBH140EDE LBH160ECE LBH160EDE  
LBH160EUK LBH160IUK LBHC6120MUK LBHC6130MUK LBHC6150MUK LBHM750ES  
LBHM756E LBHM758ES LBHM856E LBHM958ES LBHMP1058ES LBHMP1059ES  
LBHMP5085E LBHMP756E LBHMP856E LBHNF6137P LBHNF6167P LBHNL6106P  
LBHNL6126P30 LBHP13ECE LBHP13EDE LBHP16ECE LBHP16EDE LBHP6110M  
LBHW120MUK LBHW130MUK LBHW5513MUK LBHWF131MUK LBHWM120TS80 LBHZ611I  
LBHZ616I LBHZI11051 LBHZI16051 LBK62.6T LBKWD835T LBL12800 LBLI21000  
LBLI21200E LBLLOH1256A LBLLOH906A LBLLOH946A LBMA758SS LBMAF1200AAW  
LBMAF1300AAW LBMAXIALISIT LBMBL1200FL LBRILL120 LBRILS120H / C LBSEL732ETR  
LBSHM850ES LBSHM959ES LBSLF2060 LBSM.COM13 LBSM.COM16 LBSM.COMP13  
LBSM.COMP16 LBSM.COMPS16 LBSTMA1059SS LBW105SX / 1 LBWDM13011 LBWDM15011  
LBWDM15031 LI31000E LI31300E LI3800E LI41000E LI41400E LI4800E  
LP21000 LP2800BR LP2800WH LSI21200 LSI31300EVR01 LSP21000 MAF1060AAW  
MAF1260AAW-31 MAF1275AAW-31 MAF1375AAW-31 MAF1675AAW NWW12V NWW10V  
PAS1053E-04 PAS1053EN RILL140-47S TKL9909-31 TKX10WD TKX113WD  
TKX13WD TKX13WD220 / 60 VHD106-16S VHD146-86S VHD148-86S VHD166-86S  
VHD166I-86s VHD168-86S VHD610-30 VHD611P-30 VHD614-84 VHD616-84  
VHD710-30 VHD812 -30 VHD812-80 VHD812S-80 VHD814P-30 VHD814-80  
VHD816-80 VHD816PI-30 VHD816ZI-84 WDALCBL1055 WDCIW100T WDHWD6313ECE  
WDHWD120TD80 WDI1000 ZL100.6 ZL100.7 ZL100.7 / 1 ZL120.6 ZL120.7  
ZL120.7 / 1 ZLP106-01 ZLP126-01



**Kalva Solutions SRL**  
PLOIESTI, str. Cuza Voda nr.9 D8B parter  
Tel.: 0737095202

*magazin online HORECA*

**Piese schimb / Accesorii / Consumabile / Reparații**  
**Automatizări / Materiale Electrice**

